

MXK-F Monitoring Guide

For software version 3.3

Aug, 2020

Document Part Number: 830-04155-06

DZS AMERICAS
Global Headquarters &
Regional Headquarters
Plano, TX, USA

info@dzsi.com
www.dzsi.com/contact-us/

DZS-KEYMILE EMEA
Regional Headquarters
Hanover,
Germany

info.emea@dzsi.com
[www.keymile.com/en/web/keymile/
contact_sales](http://www.keymile.com/en/web/keymile/contact_sales)

DZS KOREA-APAC
Regional Headquarters
Seongnam-si, Gyeonggi-do,
South Korea

info@dzsi.com
www.dzsi.com/contact-us/

COPYRIGHT C2000-2020 DZS and its licensors.

All rights reserved.

This publication is protected by copyright law. No part of this publication may be copied or distributed, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language in any form or by any means, electronic, mechanical, magnetic, manual or otherwise, or disclosed to third parties without the express written permission from DZS.

Bitstorm, DZS, DZS EVERY CONNECTION MATTERS, EtherXtend, FiberLAN, IMACS, MALC, MXK, ReachDSL, SLMS, vNOS, Z-Edge, Zhone, ZMS, zNID and the DZS and Zhone logos are trademarks of DZS.

DZS makes no representation or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability, non infringement, or fitness for a particular purpose.

Further, DZS reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation of DZS to notify any person of such revision or changes.

TABLE OF CONTENTS

About This Guide	7
Style and notation conventions	7
Alerting Messages	7
Typographical conventions	8
Related documentation	8
Acronyms & Definitions	9
Contacting DZS Quality & Service	10
Technical support	10
Hardware repair	10
Chapter 1 Monitoring Overview	13
1- 1. MXK-F Overview	13
1- 2. Monitoring and Troubleshooting Overview	13
Chapter 2 Basic Component & Port Status Monitoring	15
2- 1. Monitor the Chassis and Fan Tray	15
2- 1.1. Monitor the MXK-F14xx Chassis and Fan Tray	15
2- 1.2. Monitor the MXK-F219 Chassis and Fan Tray	16
2- 2. Monitor MXK-F Cards	18
2- 2.1. Viewing Cards Overview	18
2- 2.2. View Management Cards for the MXK-F14xx	18
2- 2.3. View Fabric Cards for the MXK-F14xx	19
2- 2.4. View Line Cards for the MXK-F14xx	20
2- 2.5. View Management Cards for the MXK-F219	21
2- 2.6. View Line Cards for the MXK-F219	22
2- 3. Monitor MXK-F14xx Ports	22
2- 3.1. port status and port show Command	23
2- 3.2. port testing Command	24
2- 4. Monitor MXK-F219 Ports	25
2- 4.1. port status and port show Command	25
2- 4.2. port testing Command	26
2- 5. Monitor SFPs and QSFPs	26
2- 5.1. View SFP Information	27

2- 5.2	View QSFP Information	31
2- 5.3	Active Ethernet and Uplink Port - SFP Monitoring	33
2- 5.3.1	Read DDM Info on Ethernet SFPs	33
2- 5.4	GPON Port - SFP Monitoring	35
2- 6	ONT Inventory and Status	37
2- 6.1	ONT Inventory Reports	37
2- 6.1.1	Additional GPON ONT Inventory Reports	38
2- 6.1.2	Additional Active Ethernet ONT Inventory Reports	39
2- 6.2	GPON ONT and ONT Port Status Monitoring	40
2- 6.2.1	GPON ONT Status	40
2- 6.2.2	GPON ONT Subscriber Facing Port - Status	43
Chapter 3	Logs for the MXK-F	45
3- 1	Logging on the Serial Port	45
3- 2	Monitor the System with Log Files	46
3- 2.1	Overview	46
3- 2.2	Default Log Store Level	46
3- 2.3	User Login Notification	47
3- 2.4	Enable/disable Logging	47
3- 2.5	Log Message Format	48
3- 2.6	Modify Logging Levels	49
3- 2.7	Non-persistent Log Messages	50
3- 2.8	Persistent Log Messages	52
3- 2.9	Example Log Messages	52
3- 2.10	Log Filter Command	52
3- 2.11	Send Messages to a Syslog Server	53
3- 2.12	Specify Different Log Formats for System and Syslog Messages	54
Chapter 4	Traps and Alarms on the MXK-F	59
4- 1	system 0 Default Traps and Alarms	59
4- 2	Alarm Manager	60
4- 3	Alarm Suppression	61
4- 4	Configurable High and Low Chassis Temperature Alarms	63
4- 5	Settable Alarms on Ethernet Ports	68
4- 6	GPON, XGPON1 and NG-PON2 Alarms and Traps	69
4- 6.1	GPON Alarms	69
4- 6.1.1	Retrieve Alarm Information From an ONU	70
4- 6.1.2	Monitor GPON Alarms	70
4- 6.1.3	GPON BIP Threshold Crossing Monitor Alarms	70
4- 6.1.4	GPON High and Low Receive Power Threshold Alarms	75
4- 6.1.5	Rogue ONU Detection and Rogue ONU Alarms	77
4- 6.1.5: 1	Periodical Background Process Detection Mode	80
4- 6.1.5: 2	Rogue RSSI Detection Mode	83
4- 6.1.5: 3	Auto Rogue RSSI Detection Mode	87

4- 6.1.6	ONU Dying Gasp Alarms	89
4- 6.1.7	ONU Manual Reboot Alarms	90
4- 6.2	GPON Traps	91
4- 6.2.1	View or Change Trap Reporting Status on an ONU	91
4- 6.2.2	Change Alarm Severity for LineStatusTraps	92
4- 7	Bridge Related	93
4- 7.1	Bridge Loop Prevention	93
4- 7.1.1	Bridge Loop Prevention Overview	93
4- 7.1.1: 1	Bridge Loop Prevention on Asymmetrical Bridges	94
4- 7.1.1: 2	Bridge Loop Prevention on TLS Bridges	94
4- 7.1.2	Configure Bridge Loop Prevention	95
4- 7.1.3	View Bridge Loop Detection Alarms	97
4- 7.1.4	View Bridge Loop Prevention on a Bridge Interface	98
4- 7.1.5	Unblock a Bridge Interface	99
4- 7.2	Bridge storm protection	100
4- 7.2.1	Bridge storm protection overview	100
4- 7.2.2	Default packet rule filters (bridgestormdetect)	101
4- 7.2.2: 1	Rules for default packet rule bridgestormdetect	101
4- 7.2.2: 2	Disable the bridgestormdetect packet rules	102
4- 7.2.3	Case 1: bridgestormdetect packet rule for discard	104
4- 7.2.4	Case 2: bridgestormdetect packet rule for discard + alarm	104
4- 7.2.5	Case 3: bridgestormdetect packet rule for discard + alarm + block	105
4- 7.2.6	Modify the default bridgestormdetect rules	107
4- 7.2.6: 1	Modify default bridgestormdetect pps and cs values	107
4- 7.2.6: 2	Default bridgestormdetect auto-enable-interval values	107
4- 7.2.7	View detected packets statistics	109
4- 7.2.8	View the packets	109
4- 7.2.9	Unblock a bridge	112
4- 8	Monitoring MXK-F Management Cards	112
4- 8.1	Redundancy Status Information	112
Chapter 5	Statistics on the MXK-F	115
5- 1	View Runtime Statistics on the MXK-F	115
5- 2	View Bridge Statistics	117
5- 2.1	Bridge Interface Statistics Overview	118
5- 2.2	Bridge Statistics Commands	118
5- 2.2.1	View Bridge Interface Statistics	118
5- 2.2.2	Use the bridge stats reset, clear, list, and rules Commands for Statistics	119
5- 2.3	Bridge Statistics Display	120
5- 3	Ethernet Port Statistics	121
5- 4	GPON OMCI (ONT) and PON Statistics	136
5- 4.1	OMCI (ONT) Statistics	136
5- 4.2	PON Statistics	141
5- 4.2.1	View OLT Statistics	141
5- 4.2.2	View ONU Statistics	148

Index.....151

ABOUT THIS GUIDE

This document provides information about one or more specific DZS products as identified on the document Cover page and in the chapters that follow. This Preface explains some of the conventions that are used in this document and explains how to contact DZS Quality and Service for support. Carefully read and follow the instructions included in this document.

Style and notation conventions

The following style and notation conventions are used in this document.

Alerting Messages

Special Alerting Messages, like the ones below, are used to alert users to information that is instructional, warns of potential damage to system equipment or data, and warns of potential injury or death. Carefully read and follow the instructions included in this document.



Note: A note provides important supplemental or amplified information.



Caution: A caution alerts users to conditions or actions that could damage equipment or data.



Tip: A tip provides additional information that enables users to more readily complete their tasks.



WARNING! A warning alerts users to conditions or actions that could lead to injury or death.



WARNING! A warning with this icon alerts users to conditions or actions that could lead to injury caused by a laser.

Typographical conventions

The following typographical styles are used in this guide to represent specific types of information.

Bold	Used for names of buttons, dialog boxes, icons, menus, profiles when placed in body text, and property pages (or sheets). Also used for commands, options, parameters in body text, and user input in body text.
<code>Fixed</code>	Used in code examples for computer output, file names, path names, and the contents of online files or directories.
Fixed Bold	Used in code examples for text typed by users.
<i>Italic</i>	Used for book titles, chapter titles, file path names, notes in body text requiring special attention, section titles, emphasized terms, and variables.
PLAIN UPPER CASE	Used for user configured/selected variables.

Related documentation

Refer to the following documents for additional information:

MXK-F Hardware and Installation Guide — contains information about the MXK-F chassis including environmental and power requirements, procedures on how to prepare, install, and maintain the MXK-F chassis, install and remove slot cards, and to add them to the system to make them available for configuration.

MXK-F Management Guide — explains how to access the MXK-F, manage user accounts, navigate the MXK-F file system, manage cards and ports, configure clocking options and the security available for the MXK-F.

MXK-F Configuration Guide — explains how to configure the MXK-F for passing data, providing rate limiting, fault tolerance, redundancy and link aggregation, and mass provisioning devices connected to the MXK-F.

SLMS GPON Troubleshooting Guide — explains how to troubleshoot faults/alarms that can occur in a GPON system and provides some background information about GPON technology.

Refer to the release notes for software installation information and for changes in features and functionality of the product (if any).

Acronyms & Definitions

The following acronyms and definitions are related to DZS products and may appear throughout this manual:

Table 1: Acronyms and Definitions

Acronym	Description
ARP	Address resolution protocol
MIB	Management Information Base
OLT	Optical Line Terminal. An electronic device/equipment at the beginning (core/network side) of the optical access network that connects to ONT/ONUs.
ONT	Optical Network Terminal (a type of ONU). An electronic device at the end (subscriber side) of the access optical network located on the subscriber side.
ONU	Optical Network Unit. An electronic device at the end of the access optical network located on the subscriber side.
SFP	Small Form factor Pluggable module
SLMS	Single Line Multi-Service
SNMP	Simple Network Management Protocol
TFTP	Trivial File Transfer Protocol
ZMS	DZS Management System

Contacting DZS Quality & Service

All new DZS equipment purchases include one year of HW Warranty and 90 days of Bronze-level Technical Support.

If your product is not within 90 days of the purchase date or you do not have a valid support contract, please contact your local sales representative to get a quote on a support contract.

Customers with a valid support contract or are eligible for 90 days technical support associated with a new product purchase can request technical support by opening a case at:

<https://dzsi.com/support/#TAC>

Customers with a valid support contract have access to technical product documentation, software downloads, knowledge base and consultation on the covered DZS product at the same support portal.

For repair services within the HW Warranty period or under an Extended Warranty support contract, a Return Material Authorization (RMA) must be obtained before sending the equipment for repair. RMA requests can be submitted at:

<https://dzsi.com/support/#RMA>

Technical support

The Technical Assistance Center (TAC) is available with experienced support engineers who can handle questions, assist with service requests, and help troubleshoot systems.

Hours of operation	Monday - Friday, 8 a.m. to 6 p.m, Eastern Time (excluding U.S. holidays)
Telephone (North America)	877-946-6320, prompt #3, #1
Telephone (International)	510-777-7133, prompt #3, #1
E-mail	support@dzsi.com
Web - available 24 x 7 to submit and track field issues/ problem reports	https://dzsi.com/support/#TAC Click DZS Problem Reporting System

If you purchased the product from an authorized dealer, distributor, Value Added Reseller (VAR), or third party, contact that supplier for technical assistance and warranty support.

Hardware repair

If the product malfunctions, all repairs must be authorized by DZS with a Return Merchandise Authorization (RMA) and performed by the manufacturer or a DZS-authorized agent. It is the responsibility of users

requiring service to report the need for repair to DZS Quality & Service as follows:

- Complete the RMA Request form (<https://dzsi.com/support/#RMA>) or contact DZS Quality & Service via phone or email:

Hours of operation: Monday - Friday, 8 a.m. to 6 p.m, Eastern Time (excluding U.S. holidays)

E-mail: support@dzsi.com (preferred)

Phone: 877-946-6320 or 510-777-7133, prompt #3, #2

- Provide the part numbers and serial numbers of the products to be repaired.
- All product lines ship with a minimum one year standard warranty (may vary by contract). DZS warrants all repairs for 90 days or the remainder of the standard warranty (whichever is greater).
- DZS will verify the warranty and provide the customer with a repair quote for anything that is not under warranty. DZS requires a purchase order or credit card for out of warranty fees.

1

CHAPTER 1 MONITORING OVERVIEW

This document explains how to monitor DZS's MXK-F multi-card chassis products which include the MXK-F1419, F1421 and F219. The MXK-F1419 and F1421 are referred to as MXK-F14xx. All three are referred to as MXK-F (MXK-F1419, F1421 and F219).

1-1 MXK-F OVERVIEW

The MXK-F14xx and MXK-F219 chassis support high-density 1G and 10G Active Ethernet, ITU-T G.984 GPON, ITU-T G.987 XG-PON1 and ITU-T G.989 NG-PON2 Line Cards. Each Line Card slot can support up to 200 Gbps of bandwidth that will enable even higher bandwidth services in the future.

The MXK-F, in conjunction with zNIDs, provides a complete end-to-end access solution for GPON and Active Ethernet fiber deployments that support triple-play services to subscribers. The MXK-F management architecture sets new standards for system availability, reliability and manageability and is based on the same SLMS code base as other DZS products ensuring seamless integration with other DZS solutions and management systems.



Note: The terms “ONU” and “ONT” have been used interchangeably throughout this document unless noted otherwise. The CLI command term “onu” is unique and cannot be substituted with “ont”.

1-2 MONITORING AND TROUBLESHOOTING OVERVIEW

This monitoring guide contains various CLI commands used to display monitoring information provided for different components of the MXK-F including the chassis, cards, ports, SFPs, and ONUs.

This guide provides the following information:

- [Chapter 2, Basic Component & Port Status Monitoring, on page 15](#)
This chapter covers the monitoring commands.
- [Chapter 3, Logs for the MXK-F, on page 45](#)
This chapter describes how to use logs and generate system messages.
- [Chapter 4, Traps and Alarms on the MXK-F, on page 59](#)

This chapter describes the alarms and how to configure them.

- [Chapter 5, Statistics on the MXK-F, on page 115](#)

This chapter describes runtime statistics.

2

CHAPTER 2 BASIC COMPONENT & PORT STATUS MONITORING

This chapter provides an overview of the basic component status monitoring.

- [Monitor the Chassis and Fan Tray, page 15](#)
- [Monitor MXK-F Cards, page 18](#)
- [Monitor MXK-F14xx Ports, page 22](#)
- [Monitor MXK-F219 Ports, page 25](#)
- [Monitor SFPs and QSFPs, page 26](#)
- [ONT Inventory and Status, page 37](#)

2-1 MONITOR THE CHASSIS AND FAN TRAY

This section describes how to monitor the MXK-F14xx and the MXK-F219:

- [Monitor the MXK-F14xx Chassis and Fan Tray, page 15](#)
- [Monitor the MXK-F219 Chassis and Fan Tray, page 16](#)

2- 1.1 Monitor the MXK-F14xx Chassis and Fan Tray

The MXK-F supports monitoring the chassis/fan tray through the CLI.

The fan trays for the MXK-F support enhanced monitoring capabilities:

- individual fan rotation
- ambient air temperature
- three-point exhaust air temperature
- battery and return voltage measurement

To view the chassis environmental status, use the **shelfctrl monitor** command:

```
zSH> shelfctrl monitor
Shelf                               Status
-----
Uptime                               3 hours, 55 minutes
Shelf start time                      1437502799
```

Basic Component & Port Status Monitoring

Upper Fan Tray:			
FPGA version	0.2		
Firmware version	0.0		
Lower Fan Tray:			
FPGA version	0.2		
Firmware version	0.0		
Management Card Glue version	0.15		
Chassis Temperatures	Celsius (C)	Fahrenheit (F)	

Ambient	56	132	
Outlet	62	143	
Temperature reading	normal		
Fan Power Supplies & Alarm	Status		

Upper Fan Tray:			
Fan Power 1	normal		
Fan Power 2	normal		
Fan alarm	ok		
Lower Fan Tray:			
Fan Power 1	normal		
Fan Power 2	normal		
Fan alarm	ok		
Power Supplies	Volts (V)	Status	

Battery A	-52.84V	normal	
Battery B	-52.82V	normal	
Battery A return	-0.49V		
Battery B return	-0.48V		
Device	Status		

System	Critical alarm set		
Card m1	Critical alarm set		
Card m2	Critical alarm set		
Card a	Critical alarm set		
Card b	Critical alarm set		

Alarm I/O Board			

CPLD version	0.0		
Present:	Yes		
Alarm input:	Ai1	Ai2	Ai3
Status (Energized/de-energized):	d	d	d
NormalOpen/NormalClosed/NotSpec:	NS	NS	NS
Alarm Active:	No	No	No

System and **Card <#>** will show **Critical alarm set** when an alarm has been triggered. Other parameters provide full descriptions such as **warning fans A, B, C, F are stopped** or **warning all fans are stopped** for the Fan alarm.

The Battery A and Battery B voltages are measured relative to battery return (+). The Battery return voltage measurement is relative to ground (i.e., the chassis).

2- 1.2 Monitor the MXK-F219 Chassis and Fan Tray

The MXK-F219 fan tray supports a subset of the monitoring features.

- individual fan rotation
- ambient air temperature
- three-point exhaust air temperature
- battery and return voltage measurement



Note: The MXK-F219 fan tray is controlled by the m1/m2 management cards. To prevent overheating if neither (m1/m2) card is installed the line cards power down through hardware.

To view the chassis environmental status, use the **shelfctrl monitor** command:

```
zSH> shelfctrl monitor
Shelf                               Status
-----
Uptime                               3 days, 2 hours, 5 minutes
FPGA version                          0.3
Firmware version                      0.0
Management Card Glue version          1.15

Chassis Temperatures                Celsius (C)           Fahrenheit (F)
-----
Ambient                              28                   82
Outlet                               30                   86
Temperature reading                   normal

Fan Power Supplies & Alarm           Status
-----
Fan Power 1                           normal
Fan Power 2                           normal
Fan alarm                              ok

Power Supplies                       Volts (V)            Status
-----
Battery A                             -53.57V              normal
Battery B                             -53.55V              normal
Battery A return                       -0.16V
Battery B return                       -0.18V

Device                               Status
-----
System                                Critical alarm set
Card m1                               Critical alarm set
Card m2                               Critical alarm set

Alarm I/O Board
-----
CPLD version                          0.3
Present:                               Yes
Alarm input:                          Ai1  Ai2  Ai3  Ai4  Ai5  Ai6  Ai7  Ai8
Status (Energized/de-energized):      d    d    d    d    d    d    d    d
NormalOpen/NormalClosed/NotSpec:      NS   NS   NS   NS   NS   NS   NS   NS
Alarm Active:                          No   No   No   No   No   No   No   No
```

2-2 MONITOR MXK-F CARDS

This section describes how to monitor MXK-F cards:

- [Viewing Cards Overview, page 18](#)
- [View Management Cards for the MXK-F14xx, page 18](#)
- [View Fabric Cards for the MXK-F14xx, page 19](#)
- [View Line Cards for the MXK-F14xx, page 20](#)
- [View Management Cards for the MXK-F219, page 21](#)

2- 2.1 Viewing Cards Overview

You can view information by entering the **slots slot_number** command to view card information including

- ROM Version
- Software Version
- Card-Profile ID

The **slots** command displays the cards currently provisioned in the MXK-F chassis and their state which can include: running, loading, not provisioned, booting, and configuring.

```
zSH> slots
MXK 1421

Management Cards
m1:*MXK-MC-TOP, 14U MGMT W/ TOP (RUNNING)
m2: MXK-MC-TOP, 14U MGMT W/ TOP (RUNNING)

Fabric Cards
a:*MXK-FC-AETG8, 14U FABRIC W/ 8x10G AE (RUNNING+TRAFFIC)
b: MXK-FC-AETG8, 14U FABRIC W/ 8x10G AE (RUNNING+TRAFFIC)

Line Cards
3: MXK-LC-GP16, LINE CARD W/ 16 GPON (RUNNING)
4: MXK-LC-GP16, LINE CARD W/ 16 GPON (RUNNING)
9: MXK-LC-AEG32, LINE CARD W/ 32x1G AE ANGL (RUNNING)
```

2- 2.2 View Management Cards for the MXK-F14xx

The asterisk next to the card type indicates the card is in a redundant configuration. Enter the **slots m1** or **slots m2** command to view management card information.

```
zSH> slots m1
MXK 1421
Type          : *MXK-MC-TOP, 14U MGMT W/ TOP
Card Version   : 800-03404-02-A
EEPROM Version : 1
```

```

Serial #       : 7986440
CLEI Code     : No CLEI
Card-Profile ID : 1/m1/20001
Shelf        : 1
Slot         : m1
ROM Version   : MXK 3.1.1.141
Software Version: MXK 3.1.1.219
State        : RUNNING
Mode         : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last : WED JUL 22 23:30:38 2015
Heartbeat resp : 8976
Heartbeat late : 0
Hbeat seq error : 0
Hbeat longest  : 19
Fault reset   : enabled
Power fault mon : supported
Uptime       : 2 hours, 29 minutes

```

```

zSH> slots m2
MXK 1421
Type       : MXK-MC-TOP, 14U MGMT W/ TOP
Card Version : 800-03404-02-A
EEPROM Version : 1
Serial #    : 7985260
CLEI Code   : No CLEI
Card-Profile ID : 1/m2/20001
Shelf      : 1
Slot       : m2
ROM Version : MXK 3.1.1.141
Software Version: MXK 3.1.1.219
State      : RUNNING
Mode       : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last : WED JUL 22 23:30:38 2015
Heartbeat resp : 9022
Heartbeat late : 0
Hbeat seq error : 0
Hbeat longest  : 7
Fault reset   : enabled
Power fault mon : supported
Uptime       : 2 hours, 30 minutes

```

2- 2.3 View Fabric Cards for the MXK-F14xx

Enter the **slots a** or the **slots b** command to view fabric card information.

```

zSH> slots a
MXK 1421
Type       : *MXK-FC-AETG8, 14U FABRIC W/ 8x10G AE
Card Version : 800-03383-01-A
EEPROM Version : 1
Serial #    : 8089780
CLEI Code   : No CLEI
Card-Profile ID : 1/a/20104
Shelf      : 1
Slot       : a
ROM Version : MXK 3.1.1.141

```

Basic Component & Port Status Monitoring

```
Software Version: MXK 3.1.1.219
State           : RUNNING
Mode           : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last  : WED JUL 22 23:30:38 2015
Heartbeat resp  : 9577
Heartbeat late  : 0
Hbeat seq error : 0
Hbeat longest  : 3
Fault reset    : enabled
Power fault mon : supported
Uptime         : 2 hours, 39 minutes
```

zSH> **slots b**

```
MXK 1421
Type           : MXK-FC-AETG8, 14U FABRIC W/ 8x10G AE
Card Version   : 800-03383-01-A
EEPROM Version : 1
Serial #       : 8088740
CLEI Code      : No CLEI
Card-Profile ID : 1/b/20104
Shelf         : 1
Slot          : b
ROM Version    : MXK 3.1.1.141
Software Version: MXK 3.1.1.219
State         : RUNNING
Mode         : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last  : WED JUL 22 23:30:38 2015
Heartbeat resp  : 9709
Heartbeat late  : 0
Hbeat seq error : 0
Hbeat longest  : 4
Fault reset    : enabled
Power fault mon : supported
Uptime         : 2 hours, 41 minutes
```

2- 2.4 View Line Cards for the MXK-F14xx

Enter the **slots slot_number** command to view line card information. In this case GPON.

zSH> **slots 3**

```
MXK 1421
Type           : MXK-LC-GP16, LINE CARD W/ 16 GPON
Card Version   : 800-03401-02-A
EEPROM Version : 1
Serial #       : 8088071
CLEI Code      : No CLEI
Card-Profile ID : 1/3/20201
Shelf         : 1
Slot          : 3
ROM Version    : MXK 3.1.1.121
Software Version: MXK 3.1.1.219
State         : RUNNING
Mode         : FUNCTIONAL
Heartbeat check : enabled
```

```

Heartbeat last : WED JUL 22 23:30:38 2015
Heartbeat resp : 9921
Heartbeat late : 0
Hbeat seq error : 0
Hbeat longest : 12
Fault reset : enabled
Power fault mon : supported
Uptime : 2 hours, 45 minutes

```

Enter the **slots slot_number** command to view line card information. In this case Ethernet.

```

zSH> slots 9
MXK 1421
Type : MXK-LC-AEG32, LINE CARD W/ 32x1G AE ANGL
Card Version : 800-03440-01-A
EEPROM Version : 1
Serial # : 10886240
CLEI Code : No CLEI
Card-Profile ID : 1/9/20222
Shelf : 1
Slot : 9
ROM Version : MXK 3.1.1.211
Software Version: MXK 3.1.1.219
State : RUNNING
Mode : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last : WED JUL 22 23:33:32 2015
Heartbeat resp : 28110
Heartbeat late : 0
Hbeat seq error : 0
Hbeat longest : 26
Fault reset : enabled
Power fault mon : supported
Uptime : 12 minutes

```

2- 2.5 View Management Cards for the MXK-F219

The asterisk next to the type of card indicates that this card is in a redundant configuration. Enter the **slots m1** or **slots m2** command to view management card information.

```

zSH> slots
MXK 219
Management Cards
m1:*MXK-MC-AETG2-TOP, 2U MGMT W/ 2x10G AE, W/ TOP (RUNNING)
m2: MXK-MC-AETG2-TOP, 2U MGMT W/ 2x10G AE, W/ TOP (RUNNING)
Line Cards
1:*MXK-LC-GP16, LINE CARD W/ 16 GPON (RUNNING)
2: MXK-LC-GP16, LINE CARD W/ 16 GPON (RUNNING)

```

```

zSH> slots m1
MXK 219
Type : *MXK-MC-AETG2-TOP, 2U MGMT W/ 2x10G AE, W/ TOP
Card Version : 800-03432-01-A
EEPROM Version : 1
Serial # : 13481460

```

```
CLEI Code       : No CLEI
Card-Profile ID : 1/m1/20002
Shelf           : 1
Slot            : m1
ROM Version     : MXK 3.1.1.248
Software Version: MXK 3.1.2.129
State           : RUNNING
Mode            : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last  : FRI NOV 04 15:09:48 2016
Heartbeat resp  : 233933
Heartbeat late  : 0
Hbeat seq error : 0
Hbeat longest   : 12
Fault reset     : enabled
Power fault mon : supported
Uptime          : 2 days, 16 hours, 58 minutes
Start time      : 1478038256
```

2- 2.6 View Line Cards for the MXK-F219

Enter the `slots slot_number` command to view line card information. In this case GPON.

```
zSH> slots 1
MXK 219
Type           : MXK-LC-GP16, LINE CARD W/ 16 GPON
Card Version   : 800-03401-04-AA
EEPROM Version : 1
Serial #       : 10082790
CLEI Code      : No CLEI
Card-Profile ID : 1/1/20201
Shelf          : 1
Slot           : 1
ROM Version    : MXK 3.1.2.101
Software Version: MXK 3.1.2.120
State          : RUNNING
Mode           : FUNCTIONAL
Heartbeat check : enabled
Heartbeat last  : WED SEP 21 23:04:00 2016
Heartbeat resp  : 13172
Heartbeat late  : 0
Hbeat seq error : 0
Hbeat longest   : 17
Fault reset     : enabled
Power fault mon : supported
Uptime          : 1 hour, 49 minutes
Traffic Ready   : yes
Database Ready  : yes
Bridge Count    : 2
```

2- 3 MONITOR MXK-F14XX PORTS

This section describes port monitoring:

- [port status and port show Command, page 23](#)

- [port testing Command, page 24](#)

2- 3.1 port status and port show Command

Use the **port status** command to view the operational status, speed, and duplex mode of an Ethernet port.



Note: The **port status** command is only valid for Ethernet ports.

```
zSH> port status 1-a-1-0/eth
Operational status : Up
Rate in Mbps      : 10000
Duplex            : Full
```

Use the **port show** command to view the administrative status of a port or interface.

```
zSH> port show 1-a-1-0/eth
Interface 1-a-1-0/eth
  Physical location:    1/a/1/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  DDM data:
    Temperature:      30c
    Voltage:          3.29v
    Tx bias current:  27mA
    Transmit power:   -2.3dBm
    Receive power:    0.2dBm
```

Use the **port show** command to view the status of an GPON OLT.

```
zSH> port show 1-3-1-0/gponolt
Interface 1-3-1-0/gponolt
  Physical location:    1/3/1/0/gponolt
  Administrative status: up
```

Use the **port show** command to view the status of a GPON ONU.

```
zSH> port show 1-1-1-1/gpononu
Interface 1-1-1-1/gpononu
  Administrative status: up
```

Use **port show** command to view the status of a line card Ethernet port.

```
zSH> port show 1-9-1-0/eth
Interface 1-9-1-0/eth
  Physical location:    1/9/1/0/eth

  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
```

```
Ingress rate: 0 Kbps burst size: 0 Kbits
Egress rate: 0 Kbps burst size: 0 Kbits
DDM data:
  Temperature:      0c
  Voltage:          0.00v
  Tx bias current:  0mA
  Transmit power:   0.0dBm
  Receive power:    0.0dBm
```

Use the **port show** command to view the status of a port with a configured bridge.

```
zSH> port show ethernet1-800/bridge
Interface ethernet1-800/bridge
  Administrative status: up
```

2- 3.2 port testing Command

Use the **port testing** command to set the administrative state to testing on an Ethernet port.

```
zSH> port testing 1-a-2-0/eth
1-a-2-0/eth set to admin state TESTING
```

Verify the state.

```
zSH> port show 1-a-2-0/eth
Interface 1-a-2-0/eth
  Physical location: 1/a/2/0/eth
  Administrative status: testing
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  DDM data:
    Temperature:      29c
    Voltage:          3.29v
    Tx bias current:  28mA
    Transmit power:   -2.4dBm
    Receive power:    -4.0dBm
```

Use the **port testing** command to set the administrative state to testing on an GPON ONU port.

```
zSH> port testing 1-1-1-1/gpononu
1-1-1-1/gpononu set to admin state TESTING
```

Verify the state.

```
zSH> port show 1-1-1-1/gpononu
Interface 1-1-1-1/gpononu
  Administrative status: testing
```

2-4 MONITOR MXK-F219 PORTS

This section describes port monitoring:

- [port status and port show Command, page 23](#)
- [port testing Command, page 24](#)

2- 4.1 port status and port show Command

Use the **port status** command to view the operational status, speed, and duplex mode of an Ethernet port.



Note: The **port status** command is only valid for Ethernet ports.

```
zSH> port status 1-1-101-0/eth
Operational status : Up
Rate in Mbps      : 10000
Duplex           : Full
```

Use the **port show** command to view the administrative status of a port or interface.

```
zSH> port show 1-1-101-0/eth
Interface 1-1-101-0/eth
  Physical location: 1/1/101/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  DDM not supported
```

```
zSH> port show 1-m1-1-0/eth
Interface 1-m1-1-0/eth
  Physical location: 1/m1/1/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  No DDM data available from ethernet port
```

Use the **port show** command to view the status of an GPON OLT.

```
zSH> port show 1-1-1-0/gponolt
Interface 1-1-1-0/gponolt
  Physical location: 1/1/1/0/gponolt
  Administrative status: up
```

Use the **port show** command to view the status of a GPON ONU.

```
zSH> port show 1-1-1-1/gpononu
Interface 1-1-1-1/gpononu
```

```
Administrative status: up
```

Use the **port show** command to view the status of a port with a configured bridge.

```
zSH> port show ethernet1-800/bridge
Interface ethernet1-800/bridge
Administrative status: up
```

2- 4.2 port testing Command

Use the **port testing** command to set the administrative state to testing on an Ethernet port.

```
zSH> port testing 1-1-102-0/eth
1-1-102-0/eth set to admin state TESTING
```

Verify the state.

```
zSH> port show 1-1-102-0/eth
Interface 1-1-102-0/eth
Physical location:    1/1/102/0/eth

Administrative status: testing
Port type specific information:
  Frame size: 0 bytes
  Ingress rate: 0 Kbps burst size: 0 Kbits
  Egress rate: 0 Kbps burst size: 0 Kbits
DDM not supported
```

Use the **port testing** command to set the administrative state to testing on an GPON ONU port.

```
zSH> port testing 1-1-1-1/gpononu
1-1-1-1/gpononu set to admin state TESTING
```

Verify the state.

```
zSH> port show 1-1-1-1/gpononu
Interface 1-1-1-1/gpononu
Administrative status: testing
```

2- 5 MONITOR SFPS AND QSFPS

- [View SFP Information, page 27](#)
- [View QSFP Information, page 31](#)
- [Active Ethernet and Uplink Port - SFP Monitoring, page 33](#)

2- 5.1 View SFP Information

To view the presence of SFPs on the MXK-F, enter the **sfp show all** command:

```
zSH> sfp show all
SFP Data for interface 1-a-1-0/eth
vendorName                Ligent Photonics
vendorOui                 00-01-47
vendorPartNumber          LTF8502-BH
vendorRevisionLevel       1
serialNumber              LIGL7641000350
manufacturingDateCode     140126
complianceCode            unknown value (0x0000)
connectorType             lc (7)
transceiverType           sfp (3)
extendedIdentifier        4
encodingAlgorithm         unknownOrUnspecified (6)
channelLinkLength         unknown value (0x0000)
channelTransmitterTechnology unknown value (0x0000)
channelTransmitterMedia   unknown value (0x0000)
channelSpeed              unknown value (0x0000)
nineTo125mmFiberLinkLengthKm 0
nineTo125mmFiberLinkLength100m 0
fiftyTo125mmFiberLinkLength10m 8
sixtyTwoDot5To125mmFiberLinkLength10m 3
nominalBitRate            103
upperBitRateMarginPercentage 20
lowerBitRateMarginPercentage 20
copperLinkLength          0

SFP Data for interface 1-a-2-0/eth
vendorName                Titan Photonics
vendorOui                 00-01-47
vendorPartNumber          MXK-10GE-SFP+-SR
vendorRevisionLevel       A
serialNumber              TITD140909009
manufacturingDateCode     140909
complianceCode            unknown value (0x0000)
connectorType             lc (7)
transceiverType           sfp (3)
extendedIdentifier        4
encodingAlgorithm         unknownOrUnspecified (6)
channelLinkLength         intermediate-distance (0x0020)
channelTransmitterTechnology shortwavelaser-without-ofc (0x2040)
channelTransmitterMedia   multimode-50m | multimode-62dot5m (0x000c)
channelSpeed              unknown value (0x0080)
nineTo125mmFiberLinkLengthKm 0
nineTo125mmFiberLinkLength100m 0
fiftyTo125mmFiberLinkLength10m 8
sixtyTwoDot5To125mmFiberLinkLength10m 3
nominalBitRate            103
upperBitRateMarginPercentage 0
lowerBitRateMarginPercentage 0
copperLinkLength          0

SFP Data for interface 1-a-3-0/eth
```

Basic Component & Port Status Monitoring

** No SFP present **

SFP Data for interface 1-a-4-0/eth

vendorName	FINISAR CORP.
vendorOui	00-90-65
vendorPartNumber	FCLF-8521-3
vendorRevisionLevel	A
serialNumber	PDK1YWE
manufacturingDateCode	080506
complianceCode	base1000T (0x0008)
connectorType	unknownOrUnspecified (0)
transceiverType	sfp (3)
extendedIdentifier	4
encodingAlgorithm	eightb10b (1)
channelLinkLength	unknown value (0x0000)
channelTransmitterTechnology	unknown value (0x0000)
channelTransmitterMedia	unknown value (0x0000)
channelSpeed	unknown value (0x0000)
nineTo125mmFiberLinkLengthKm	0
nineTo125mmFiberLinkLength100m	0
fiftyTo125mmFiberLinkLength10m	0
sixtyTwoDot5To125mmFiberLinkLength10m	0
nominalBitRate	12
upperBitRateMarginPercentage	0
lowerBitRateMarginPercentage	0
copperLinkLength	100

SFP Data for interface 1-a-5-0/eth

vendorName	FINISAR CORP.
vendorOui	00-90-65
vendorPartNumber	FCLF-8521-3
vendorRevisionLevel	A
serialNumber	PD53726
manufacturingDateCode	080131
complianceCode	base1000T (0x0008)
connectorType	unknownOrUnspecified (0)
transceiverType	sfp (3)
extendedIdentifier	4
encodingAlgorithm	eightb10b (1)
channelLinkLength	unknown value (0x0000)
channelTransmitterTechnology	unknown value (0x0000)
channelTransmitterMedia	unknown value (0x0000)
channelSpeed	unknown value (0x0000)
nineTo125mmFiberLinkLengthKm	0
nineTo125mmFiberLinkLength100m	0
fiftyTo125mmFiberLinkLength10m	0
sixtyTwoDot5To125mmFiberLinkLength10m	0
nominalBitRate	12
upperBitRateMarginPercentage	0
lowerBitRateMarginPercentage	0
copperLinkLength	100

SFP Data for interface 1-a-6-0/eth

** No SFP present **

SFP Data for interface 1-a-7-0/eth

** No SFP present **

SFP Data for interface 1-a-8-0/eth

** No SFP present **

SFP Data for interface 1-b-1-0/eth

vendorName	Ligent Photonics
vendorOui	00-01-47
vendorPartNumber	LTF8502-BH
vendorRevisionLevel	1
serialNumber	LIGL7641000359
manufacturingDateCode	140126
complianceCode	unknown value (0x0000)
connectorType	lc (7)
transceiverType	sfp (3)
extendedIdentifier	4
encodingAlgorithm	unknownOrUnspecified (6)
channelLinkLength	unknown value (0x0000)
channelTransmitterTechnology	unknown value (0x0000)
channelTransmitterMedia	unknown value (0x0000)
channelSpeed	unknown value (0x0000)
nineTo125mmFiberLinkLengthKm	0
nineTo125mmFiberLinkLength100m	0
fiftyTo125mmFiberLinkLength10m	8
sixtyTwoDot5To125mmFiberLinkLength10m	3
nominalBitRate	103
upperBitRateMarginPercentage	20
lowerBitRateMarginPercentage	20
copperLinkLength	0

SFP Data for interface 1-3-1-0/gponolt

vendorName	Ligent
vendorOui	00-01-47
vendorPartNumber	LTE3680M-BH
vendorRevisionLevel	1.0
serialNumber	LIGJ0348000622
manufacturingDateCode	140804
complianceCode	unknown value (0x0000)
connectorType	sc (1)
transceiverType	sfp (3)
extendedIdentifier	4
encodingAlgorithm	nrz (3)
channelLinkLength	unknown value (0x0000)
channelTransmitterTechnology	unknown value (0x0000)
channelTransmitterMedia	unknown value (0x0000)
channelSpeed	unknown value (0x0000)
nineTo125mmFiberLinkLengthKm	20
nineTo125mmFiberLinkLength100m	200
fiftyTo125mmFiberLinkLength10m	0
sixtyTwoDot5To125mmFiberLinkLength10m	0
nominalBitRate	25
upperBitRateMarginPercentage	20
lowerBitRateMarginPercentage	20
copperLinkLength	0

SFP Data for interface 1-3-2-0/gponolt

** No SFP present **

SFP Data for interface 1-3-3-0/gponolt

** No SFP present **

SFP Data for interface 1-3-4-0/gponolt

Basic Component & Port Status Monitoring

** No SFP present **

SFP Data for interface 1-3-5-0/gponolt

** No SFP present **

SFP Data for interface 1-3-6-0/gponolt

** No SFP present **

SFP Data for interface 1-3-7-0/gponolt

** No SFP present **

SFP Data for interface 1-3-8-0/gponolt

** No SFP present **

SFP Data for interface 1-3-9-0/gponolt

** No SFP present **

SFP Data for interface 1-3-10-0/gponolt

** No SFP present **

SFP Data for interface 1-3-11-0/gponolt

** No SFP present **

SFP Data for interface 1-3-12-0/gponolt

** No SFP present **

SFP Data for interface 1-3-13-0/gponolt

** No SFP present **

SFP Data for interface 1-3-14-0/gponolt

** No SFP present **

SFP Data for interface 1-3-15-0/gponolt

** No SFP present **

SFP Data for interface 1-3-16-0/gponolt

** No SFP present **

SFP Data for interface 1-4-1-0/gponolt

vendorName	Ligent
vendorOui	00-01-47
vendorPartNumber	LTE3680M-BH
vendorRevisionLevel	1.0
serialNumber	LIGJ0348000314
manufacturingDateCode	140804
complianceCode	unknown value (0x0000)
connectorType	sc (1)
transceiverType	sfp (3)
extendedIdentifier	4
encodingAlgorithm	nrz (3)
channelLinkLength	unknown value (0x0000)
channelTransmitterTechnology	unknown value (0x0000)
channelTransmitterMedia	unknown value (0x0000)
channelSpeed	unknown value (0x0000)
nineTo125mmFiberLinkLengthKm	20
nineTo125mmFiberLinkLength100m	200
fiftyTo125mmFiberLinkLength10m	0
sixtyTwoDot5To125mmFiberLinkLength10m	0
nominalBitRate	25

```

upperBitRateMarginPercentage      20
lowerBitRateMarginPercentage      20
copperLinkLength                  0

```

```

SFP Data for interface 1-4-2-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-3-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-4-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-5-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-6-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-7-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-8-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-9-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-10-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-11-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-12-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-13-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-14-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-15-0/gponolt
** No SFP present **

```

```

SFP Data for interface 1-4-16-0/gponolt

```

2- 5.2 View QSFP Information

To view the presence of QSFPs on the MXK-F, enter the **qsfp show all** command:

```

zSH> qsfp show all
QSFP Data for interface 1-a-1-0/eth
vendorName                               WTD

```

Basic Component & Port Status Monitoring

```

vendorOui                00-1c-ad
vendorPartNumber         RTX320-400
vendorRevisionLevel      A
serialNumber             RD155103000010
manufacturingDateCode    151217
complianceCode1040GbEthernet 40GbEthernet-lr4 (0x40000000)
complianceCodeSonet      unknown value (0x0000)
complianceCodeSas        unknown value (0x0000)
connectorType            lc (7)
transceiverType          qsfp-plus (13)
extendedIdentifier        192
encodingSupport           sixtyfourB-per-66B (5)
deviceTechnology         64
fiberLinkLength1Km       10
extendedFiberLinkLength  0
mm62Dot5umFiberLinkLengthlm 0
mm50umFiberLinkLengthlm 0
bitRate                  103
bitRateExtended          0
enhancedOptions          0

```

QSFP Data for interface 1-a-2-0/eth

```

vendorName               WTD
vendorOui                00-1c-ad
vendorPartNumber         RTX320-551
vendorRevisionLevel      10
serialNumber             RD143710100001
manufacturingDateCode    140904
complianceCode1040GbEthernet 40GbEthernet-sr4 (0x20000000)
complianceCodeSonet      unknown value (0x0000)
complianceCodeSas        unknown value (0x0000)
connectorType            mpo (12)
transceiverType          qsfp-plus (13)
extendedIdentifier        0
encodingSupport           sixtyfourB-per-66B (5)
deviceTechnology         0
fiberLinkLength1Km       0
extendedFiberLinkLength  50
mm62Dot5umFiberLinkLengthlm 0
mm50umFiberLinkLengthlm 0
bitRate                  105
bitRateExtended          0
enhancedOptions          0

```

QSFP Data for interface 1-b-1-0/eth

```

vendorName               Ligent Photonics
vendorOui                00-00-00
vendorPartNumber         LTA8511-PC
vendorRevisionLevel      1
serialNumber             E335B000137
manufacturingDateCode    151110
complianceCode1040GbEthernet 40GbEthernet-sr4 (0x20000000)
complianceCodeSonet      unknown value (0x0000)
complianceCodeSas        unknown value (0x0000)
connectorType            mpo (12)
transceiverType          qsfp-plus (13)
extendedIdentifier        0
encodingSupport           nrz (3)
deviceTechnology         0

```

```

fiberLinkLength1Km          0
extendedFiberLinkLength    50
mm62Dot5umFiberLinkLength1m 0
mm50umFiberLinkLength1m   0
bitRate                     103
bitRateExtended             0
enhancedOptions              0

```

2- 5.3 Active Ethernet and Uplink Port - SFP Monitoring

The MXK-F uplink and Active Ethernet card ports use Ethernet SFPs. Some Ethernet SFPs support Digital Diagnostic Monitoring (DDM) that provides the temperature, supply voltage, transmit bias current, transmit power, and receive power of the SFP.

The **port show interface/type** command is used to display DDM data on Ethernet ports that have DDM-capable SFPs. [Table 2](#). describes the DDM displayed data fields.

Table 2: port show Command Output Fields for DDM data on Ethernet Ports

Field	Description
Temperature	Internally measured Transceiver Temperature in degrees celsius.
Voltage	Internally measured Transceiver Supply Voltage in hundredths of volts.
Tx Bias Current	Measured Tx Bias current in milliamperes.
Transmit Power	Measured Tx Output power in tenths of dB.
Receive Power	Measured Rx power in tenths of dB.

2- 5.3.1 Read DDM Info on Ethernet SFPs

The examples that follow are for the MXK-F14xx Fabric/uplink ports.

The same procedures can be used for MXK-F219 (m1/m2) uplink ports and for Active Ethernet Line Card ports by using the appropriate interface names (e.g. replace the F14xx interface = 1-a-1-0/eth with the F219 interface name = 1-1-101-0 or the Active Ethernet Line Card name = 1-7-4-0/eth).

Read the DDM info of an Ethernet SFP on an MXK-F14xx fabric card.

```

zSH> port show 1-a-1-0/eth
Interface 1-a-1-0/eth
  Physical location:    1/a/1/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  DDM data:

```

Basic Component & Port Status Monitoring

```
Temperature:      29c
Voltage:          3.29v
Tx bias current:  5mA
Transmit power:   -2.1dBm
Receive power:    -4.0dBm
```

Ethernet port on fabric card with QSFP that supports DDM data.

```
zSH> port show 1-a-1-0/eth
Interface 1-a-1-0/eth
  Physical location:    1/a/1/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  DDM data:
    Temperature:      0c
    Voltage:          0.00v
    Tx bias current:  0mA
    Transmit power:   -40.0dBm
    Receive power:    -4.0dBm
```

Ethernet port on fabric card without SFP.

```
zSH> port show 1-a-3-0/eth
Interface 1-a-3-0/eth
  Physical location:    1/a/3/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  SFP not present
```

Ethernet port on fabric card with SFP that does not support DDM data.

```
zSH> port show 1-a-5-0/eth
Interface 1-a-5-0/eth
  Physical location:    1/a/5/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  DDM not supported
```

Ethernet management port that does not use an SFP.

```
zSH> port show 1-m1-1-0/eth
Interface 1-m1-1-0/eth
  Physical location:    1/m1/1/0/eth
  Administrative status: up
  Port type specific information:
    Frame size: 0 bytes
    Ingress rate: 0 Kbps burst size: 0 Kbits
    Egress rate: 0 Kbps burst size: 0 Kbits
  No DDM data available from ethernet port
```

2- 5.4 GPON Port - SFP Monitoring

DDM and Received Signal Strength Indication (RSSI) are types of info that are provided by some GPON SFPs. DDM provides basic info like SFP temperature (the MXK-F GPON DDM info is slightly different from the AE/uplink DDM info; compare [Table 2](#) with [Table 3](#)). GPON RSSI provides more detailed information about the OLT/ONT connections.

Procedure:

Read DDM Info on a GPON SFP

The **gponolt show port** command reads the SFP DDM info for GPON ports.

Table 3: gponolt show port Command Output Fields for DDM data from GPON Line Card SFPs

Field	Description
Temperature	Internally measured Transceiver Temperature of the OLT in Celsius.
Voltage	Internally measured Transceiver Supply Voltage of the OLT in Volts.
Tx Bias Current	Measured Tx Bias current per OLT in Milli Amperes.
Tx Power	Measured Tx Output Power of the OLT in dBm. The OLT SFP measures its own TX Power output level. The level should be in the range +5 dBm to +1.5 dBm (for B+ optical level SFPs). If the output level is not in this range, one or more ONTs may have downstream data errors or may be lost. If the output is higher than +5 dBm, the optical transceiver of one or more ONTs may die prematurely (cause a shorter end of life time period)
End of Life Status	<p>When the End Of Life (EOL) Alarm bit is set an alarm will be raised.</p> <p>SFP automatically maintains a laser output optical power by adjusting the laser current. Alarm is raised when the SFP reaches the end of life which is about 150% of original current. Alarm will be cleared when the SFP is connected. The alarm severity level is Major.</p> <p>Values:</p> <p>ok No alarm conditions are raised</p> <p>warning Warning is set when EOL is at about 130% original current.</p> <p>alarm Alarm conditions are raised</p> <p>SFP not present SFP is not detected</p>

Read the DDM parameters on a GPON OLT card with the **gponolt show port [slot [/olt]]** command.

```
zSH> gponolt show port
SLOT/OLT Temperature Voltage Tx Bias Current Tx Power End Of Life Status
=====
```

1/1	43c	3.3v	13mA	3.7dBm	Ok
1/2	48c	3.3v	13mA	3.7dBm	Ok
1/3	48c	3.3v	14mA	3.8dBm	Ok
1/4	43c	3.3v	12mA	3.7dBm	Ok
1/5	47c	3.3v	13mA	3.8dBm	Ok
1/6	48c	3.3v	13mA	3.7dBm	Ok
1/7	43c	3.3v	14mA	3.7dBm	Ok
1/8	47c	3.3v	15mA	3.8dBm	Ok

Basic Component & Port Status Monitoring

1/9	46c	3.3v	14mA	3.9dBm	Ok
1/10	43c	3.3v	15mA	3.7dBm	Ok
1/11	42c	3.3v	14mA	3.7dBm	Ok
1/12	39c	3.3v	14mA	3.8dBm	Ok
1/13	42c	3.3v	13mA	3.9dBm	Ok
1/14	42c	3.3v	12mA	3.6dBm	Ok
1/15	37c	3.3v	12mA	3.9dBm	Ok
1/16	39c	3.3v	12mA	3.8dBm	Ok

SLOT/OLT	Temperature	Voltage	Tx Bias Current	Tx Power	End Of Life Status
2/1	50c	3.3v	15mA	3.7dBm	Ok
2/2	46c	3.3v	14mA	3.5dBm	Ok
2/3	52c	3.3v	15mA	3.7dBm	Ok
2/4	50c	3.3v	15mA	3.7dBm	Ok
2/5	43c	3.3v	18mA	3.7dBm	Ok
2/6	45c	3.3v	15mA	3.9dBm	Ok
2/7	48c	3.3v	15mA	3.8dBm	Ok
2/8	43c	3.3v	16mA	3.7dBm	Ok
2/9	48c	3.3v	14mA	3.8dBm	Ok
2/10	44c	3.3v	16mA	3.9dBm	Ok
2/11	44c	3.3v	14mA	3.9dBm	Ok
2/12	45c	3.3v	14mA	3.8dBm	Ok
2/13	45c	3.3v	14mA	4.2dBm	Ok
2/14	44c	3.3v	14mA	3.8dBm	Ok
2/15	38c	3.3v	11mA	3.8dBm	Ok
2/16	37c	3.3v	9mA	3.7dBm	Ok
.....					

Procedure:

Read RSSI Info on a GPON SFP

The GPON technology allows more than one ONT on a single GPON OLT port, which leads to the need for more information than is provided by DDM. RSSI provides info to determine which ONT connections are working properly and which are not. ONT and OLT RX power levels aid in diagnosing the cause of ONT/OLT faults.

RSSI also provides the distance to each ONT, which can be useful to diagnose problems, but is primarily needed for the (hidden) GPON inter-workings that enable multiple ONTs to more efficiently use a single GPON optical fiber without colliding (without one ONT transmitting on top of other ONTs' data).

The user can view the upstream optical power level received at the OLT, and the downstream optical power level received at the ONT.

The downstream optical power received at an ONT should be -28 or above for SFP-B+ (i.e. RSSI ONT Rx Power = ONT Receive Power). Otherwise the ONT connection may fail, be intermittent or have data errors.

By default, if the upstream optical power of an ONT received at the OLT is outside the range of -10 dBm to -30 dBm, the MXK will trigger a local alarm, and send a trap to ZMS (i.e. RSSI OLT Rx Power = OLT Receive Power; RX signal too high or too low). Although the OLT may continue to forward ONT data when the OLT RX Power is out of range, this fault should be corrected. A signal that is too high or low may cause intermittent or constant downstream

data errors or loss of an ONT. A signal that is too high can cause an OLT optical transceiver to die prematurely (e.g. -7 dBm; shorter end of life).

If an OLT RX Power level is reported for an ONT, the ONT is still functioning (but perhaps with data errors). Properly functioning ONTs do not transmit to the OLT unless they properly receive a downstream signal from the OLT.

The following example shows that the ONT and OLT RX power for the four ONTs on GPON card slot 3, port 1 are within the normal ranges.

```
zSH> gpononu power show 3/1
Processing list of 32
This command may take several minutes to complete.
Do you want to continue? (yes or no) [no] yes
```

Interface	OLT Receive Power	ONT Receive Power
1-3-1-1	-14.1 dBm	-13.9 dBm
1-3-1-2	-13.2 dBm	-14.5 dBm
1-3-1-3	-13.9 dBm	-14.6 dBm
1-3-1-4	-14.2 dBm	-14.7 dBm

Total ONUs = 4

If there is no SFP inserted in the OLT, or the OLT/ ONU admin status is set to down, then the ONT's Receive Power fields display "NA".

If the Receive Power field displays the value "error", it means the measurement failed. Users can run the **gpononu power show** command again.

The OLT RX Power and ONT RX Power info can also be read using other commands. See [ONT Inventory Reports on page 37](#) and [GPON ONT Status on page 40](#)

2-6 ONT INVENTORY AND STATUS

- [ONT Inventory Reports, page 37](#)
- [GPON ONT Status, page 40](#)
- [GPON ONT Subscriber Facing Port - Status, page 43](#)

2-6.1 ONT Inventory Reports

The **onu inventory** command generates a list of all Active Ethernet and GPON ONTs connected to an MXK-F. There are some small differences between the lists generated for Active Ethernet as compared to GPON ONTs.

A per-system list of Active Ethernet and GPON ONTs can be generated using the **onu inventory** command without a slot/port ID. The information provided for the GPON and Active Ethernet ONTs is similar, but with some differences that are primarily due to the differences between Ethernet and GPON SFPs.

The Active Ethernet and GPON ONTs can easily be distinguished from each other in these lists by their sub-port IDs. Active Ethernet ONT subport IDs are always “0” (e.g. “0” in the interface = 1-7-4-0) while GPON ONT subport IDs are always “non-zero” numbers (e.g. “4” in the interface = 1-3-1-4).

```
zSH> onu inventory
Processing list of 994
This command may take several minutes to complete.
Do you want to continue? (yes or no) [no] yes
```

ID	Interface	Serial Number	Vendor ID	Model ID	ONT Version	SW Version	ONT Rx Pwr	OLT Rx Pwr	Distance (KM)
1	1-3-1-1	032AFD56	ZNTS	2426	S2.5.037	S2.5.037	-13.9 dBm	-14.1 dBm	0.0000
2	1-3-1-2	A4907360	ZNTS	2520	00144-00011-27	R3.4.2.270sbn	-14.5 dBm	-13.4 dBm	0.0000
3	1-3-1-3	93425012	ZNTS	5114	00124-00044-01	R3.4.2.272c	-14.6 dBm	-14.3 dBm	0.0000
4	1-3-1-4	032AECB8	ZNTS	2427	S3.1.209	S3.1.209	-14.7 dBm	-14.2 dBm	0.0000

```
Total ONUs = 4
...
```

```
Slot 7
```

Interface	Serial Number	Vendor ID	Model ID	Act S/W Version	Stby S/W Version	Operational Status
1-7-1-0	00485890	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-2-0	00486310	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-3-0	15862810	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-4-0	00485650	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-15-0 +	-	-	-	-	-	Down
1-7-17-0 +	-	-	-	-	-	Down
1-7-19-0 +	-	-	-	-	-	Down
1-7-21-0 +	-	-	-	-	-	Up

```
Total CPEs = 8
* against interface name indicates CPE is not configured
+ against interface name indicates CPE is misconfigured
```

```
Slot 9
```

Interface	Serial Number	Vendor ID	Model ID	Act S/W Version	Stby S/W Version	Operational Status
1-9-1-0	306484238	ZNTS	2804D	S3.1.266	S3.1.268	Up
1-9-2-0	306484212	ZNTS	2804D	S3.1.266	S3.1.268	Up
1-9-3-0	306484194	ZNTS	2804D	S3.1.266	S3.1.268	Up
1-9-4-0	306484164	ZNTS	2804D	S3.1.266	S3.1.268	Up

```
Total CPEs = 4
+ against interface name indicates CPE is misconfigured
* against interface name indicates CPE is not configured
```

2- 6.1.1 Additional GPON ONT Inventory Reports

GPON ONTs can also be listed per GPON card, per GPON OLT port, or per an individual ONT.

The following generates a report for all ONTs on the GPON card in slot 3:

```
zSH> onu inventory 3
Processing list of 994
```

This command may take several minutes to complete.

Do you want to continue? (yes or no) [no] **yes**

ID	Interface	Serial Number	Vendor ID	Model ID	ONT Version	SW Version	ONT Rx Pwr	OLT Rx Pwr	Distance (KM)
1	1-3-1-1	032AFD56	ZNTS	2426	S2.5.037	S2.5.037	-13.9 dBm	-14.1 dBm	0.0000
2	1-3-1-2	A4907360	ZNTS	2520	00144-00011-27	R3.4.2.270sbn	-14.5 dBm	-13.4 dBm	0.0000
3	1-3-1-3	93425012	ZNTS	5114	00124-00044-01	R3.4.2.272c	-14.6 dBm	-14.3 dBm	0.0000
4	1-3-1-4	032AECB8	ZNTS	2427	S3.1.209	S3.1.209	-14.7 dBm	-14.2 dBm	0.0000

Total ONUs = 4
...

The following generates a report for all ONTs on GPON OLT port 3/1:

zSH> **onu inventory 3/1**

Processing list of 32

This command may take several minutes to complete.

Do you want to continue? (yes or no) [no] **yes**

ID	Interface	Serial Number	Vendor ID	Model ID	ONT Version	SW Version	ONT Rx Pwr	OLT Rx Pwr	Distance (KM)
1	1-3-1-1	032AFD56	ZNTS	2426	S2.5.037	S2.5.037	-13.9 dBm	-14.1 dBm	0.0000
2	1-3-1-2	A4907360	ZNTS	2520	00144-00011-27	R3.4.2.270sbn	-14.5 dBm	-13.3 dBm	0.0000
3	1-3-1-3	93425012	ZNTS	5114	00124-00044-01	R3.4.2.272c	-14.6 dBm	-14.3 dBm	0.0000
4	1-3-1-4	032AECB8	ZNTS	2427	S3.1.209	S3.1.209	-14.7 dBm	-14.2 dBm	0.0000

Total ONUs = 4
...

The following example generates a report for GPON ONT 3/1/1:

zSH> **onu inventory 3/1/1**

ID	Interface	Serial Number	Vendor ID	Model ID	ONT Version	SW Version	ONT Rx Pwr	OLT Rx Pwr	Distance (KM)
1	1-3-1-1	032AFD56	ZNTS	2426	S2.5.037	S2.5.037	-13.9 dBm	-14.6 dBm	0.0000

2- 6.1.2 Additional Active Ethernet ONT Inventory Reports

Active Ethernet ONTs can also be listed per Active Ethernet card or per Active Ethernet card port. Each Active Ethernet card port can only support one ONT, so a “per Active Ethernet ONT” request is not useful.

The following lists the ONTs on the Active Ethernet card in slot 7:

zSH> **onu inventory 7**

Processing list of 32

This command may take several minutes to complete.

Do you want to continue? (yes or no) [no] **yes**

Slot 7

Interface	Serial Number	Vendor ID	Model ID	Act S/W Version	Stby S/W Version	Operational Status
1-7-1-0	00485890	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-2-0	00486310	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-3-0	15862810	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-4-0	00485650	ZNTS	2608T	S3.1.266	S3.0.711	Up
1-7-15-0 +	-	-	-	-	-	Down
1-7-17-0 +	-	-	-	-	-	Down

```

1-7-19-0 +           -           -           -           -           -           Down
1-7-21-0 +           -           -           -           -           -           Up
Total CPEs = 8
* against interface name indicates CPE is not configured
+ against interface name indicates CPE is misconfigured
    
```

When a slot and port ID of an Active Ethernet card are included with the **onu inventory** command, the ONT on that port is listed (per Active Ethernet port).

The following lists the ONT on port 4 of the Active Ethernet card in slot 7:

```

zSH> onu inventory 7/4
      Interface      Serial      Vendor      Model      Act S/W      Stby S/W      Operational
                   Number      ID          ID          Version      Version      Status
-----
1-7-4-0             00485650   ZNTS       2608T     S3.1.266     S3.0.711     Up
    
```

2- 6.2 GPON ONT and ONT Port Status Monitoring

2- 6.2.1 GPON ONT Status

There are GPON ONT status commands that have no equivalent Active Ethernet ONT commands. The additional info provided by these commands are part of the GPON standards to provide information for maintaining and diagnosing GPON networks.

View status and alarms generated on an ONT with the **gpononu status** command.

[Table 4](#) provides the output fields description for this command.

Table 4: gpononu status Command Output Field Explanations

Field	Description
ID	The ONU ID. In the range of 1 to 64.
Onu	The ONU interface name. By default in the format of shelf ID-Slot ID-OLT ID-ONU ID
OperStatus	The operational status of the ONU. Values: Up Down

Table 4: gpononu status Command Output Field Explanations (Continued)

Field	Description
ConfigState	<p>The OMCI configuration states on the ONU. It is detected by the OLT side with respect to the ONU.</p> <p>Values:</p> <p>None This will probably only show during a bootup. Not yet queued for configuration.</p> <p>Queue Waiting to be configured.</p> <p>Configuring Being configured.</p> <p>Active configuration was successful.</p> <p>Inactive The ONU is down.</p> <p>Non-OMCI not provisioned for OMCI or SNMP.</p> <p>RgComError (for RG-enabled ONTs) SNMP cannot communicate with the ONT.</p> <p>RgServiceSetupErr (for RG-enabled ONTs) One or more SNMP commands failed.</p> <p>OmcErr an error occurred during the OMCI configuration.</p> <p>OmcErr+RgComErr both an OMCI error and SNMP communications failure.</p> <p>OmcErr+RgServErr both an OMCI error and failure of one or more SNMP commands.</p>
GponOnuStatus	<p>The standard GPON MAC alarms of the ONU detected on the OLT.</p> <p>Values:</p> <p>Active ONU is active, no alarm</p> <p>Inactive ONU is inactive, cannot get alarm</p> <p>LOS Lost of Signal</p> <p>LOF Lost of Frame</p> <p>DOW Drift of Window</p> <p>DG Dying Gasp</p> <p>SF Signal Fail</p> <p>SD Signal Degrade</p> <p>LCDG Lost of GEM Channel Delinquency</p> <p>RD Remote Defect</p> <p>RXPWRDSA Received Power of Range, and ONU is disabled</p> <p>TF Transmitter Failure</p> <p>SUF Start Up Failure</p> <p>LOA Lost of Ack</p> <p>MEM Message error</p> <p>PEE Physical equipment error</p> <p>OAML Lost of OAM</p>

Table 4: gpononu status Command Output Field Explanations (Continued)

Field	Description
DownloadState	ONT software image download states. Values: — this ONU is not configured with OMCI None Queued NoUpgrade Downloading Complete Error Aborted
OLT Rx Power	Upstream optical power level received at the OLT.
ONT Rx Power	Downstream optical power level received at the ONU.
Distance (KM)	Calculated distance of an ONU from the OLT.

This example shows the output of a gpononu status command. This command displays considerable output and can take up to several minutes. The syntax for this command can be gpononu status or onu status.



Note: The “gpononu” argument can be replaced in many of the cli commands with the abbreviated “onu” (as in **onu status**).

```
zSH> onu status
Processing list of 3908 GPON ONTs and 0 ActiveE CPEs
```

This command may take several minutes to complete.
Do you want to continue? (yes or no) [no] **yes**
Slot 1 olt 1

ID	Onu	OperStatus	ConfigState	Download State	OLT Rx Power	ONT Rx Power	Distance (KM)	Gpon OnuStatus	AutoConfig State
1	1-1-1-1	Up	Active	NoUpgrade	-25.2dBm	-19.5dBm	0.0391	Active	Init
2	1-1-1-2	Up	Active	NoUpgrade	-25.6dBm	-19.8dBm	0.0382	Active	Init
3	1-1-1-3	Up	Active	NoUpgrade	-25.2dBm	-19.1dBm	0.0385	Active	Init
4	1-1-1-4	Down	Inactive	None	error	error	error	Inactive+LOS+LOF+SUFL+OAML	Init
5	1-1-1-5	Up	Active	NoUpgrade	-24.2dBm	-20.0dBm	0.0394	Active	Init
6	1-1-1-6	Up	Active	NoUpgrade	-27.9dBm	-20.9dBm	0.0391	Active	Init
7	1-1-1-7	Up	Active	NoUpgrade	-25.8dBm	-19.8dBm	0.0394	Active	Init
8	1-1-1-8	Up	Active	NoUpgrade	-24.9dBm	-19.2dBm	0.0388	Active	Init
9	1-1-1-9	Up	Active	NoUpgrade	-23.8dBm	-19.8dBm	0.0386	Active	Init
10	1-1-1-10	Up	Active	NoUpgrade	-24.4dBm	-19.3dBm	0.0386	Active	Init
11	1-1-1-11	Up	Active	NoUpgrade	-24.0dBm	-18.7dBm	0.0381	Active	Init
12	1-1-1-12	Up	Active	NoUpgrade	-24.2dBm	-18.6dBm	0.0382	Active	Init
13	1-1-1-13	Up	Active	NoUpgrade	-24.3dBm	-18.8dBm	0.0386	Active	Init
14	1-1-1-14	Up	Active	NoUpgrade	-24.3dBm	-19.9dBm	0.0379	Active	Init

Slot 2 olt 1

ID	Onu	OperStatus	ConfigState	Download State	OLT Rx Power	ONT Rx Power	Distance (KM)	Gpon OnuStatus	AutoConfig State
1	1-1-1-1	Up	Active	NoUpgrade	-25.0 dBm	-19.5 dBm	0.0391	Active	Init
2	1-1-1-2	Up	Active	NoUpgrade	-25.6 dBm	-19.9 dBm	0.0382	Active	Init
3	1-1-1-3	Up	Active	NoUpgrade	-25.2 dBm	-19.1 dBm	0.0385	Active	Init
4	1-1-1-4	Down	Inactive	None	error	error	error	Inactive+LOS+LOF +SUF+OAML	Init
5	1-1-1-5	Up	Active	NoUpgrade	-24.3 dBm	-20.0 dBm	0.0394	Active	Init
6	1-1-1-6	Up	Active	NoUpgrade	-27.9 dBm	-21.0 dBm	0.0391	Active	Init
7	1-1-1-7	Up	Active	NoUpgrade	-25.8 dBm	-19.8 dBm	0.0394	Active	Init
8	1-1-1-8	Up	Active	NoUpgrade	-25.0 dBm	-19.2 dBm	0.0388	Active	Init
9	1-1-1-9	Up	Active	NoUpgrade	-23.7 dBm	-19.8 dBm	0.0386	Active	Init
10	1-1-1-10	Up	Active	NoUpgrade	-24.5 dBm	-19.3 dBm	0.0386	Active	Init
11	1-1-1-11	Up	Active	NoUpgrade	-24.0 dBm	-18.7 dBm	0.0381	Active	Init
12	1-1-1-12	Up	Active	NoUpgrade	-24.2 dBm	-18.6 dBm	0.0382	Active	Init
13	1-1-1-13	Up	Active	NoUpgrade	-24.2 dBm	-18.8 dBm	0.0386	Active	Init
14	1-1-1-14	Up	Active	NoUpgrade	-24.4 dBm	-19.9 dBm	0.0379	Active	Init

This example shows an operational ONT that completes OMCI provisioning.

```
zSH> onu status 1/7/5
```

ID	Onu	OperStatus	ConfigState	Download State	OLT Rx Power	ONT Rx Power	Distance (KM)	Gpon OnuStatus	AutoConfig State
5	1-1-7-5	Up	Active	NoUpgrade	-13.3dBm	-14.2dBm	0.0260	Active	Init

This example shows an operational ONT that gave a “dying gasp” message before going down. The OnuStatus message is stored for diagnostics.

```
zSH> onu status 1/7/5
```

ID	Onu	OperStatus	ConfigState	Download State	OLT Rx Power	ONT Rx Power	Distance (KM)	Gpon OnuStatus	AutoConfig State
5	1-1-7-5	Down	Inactive	None	error	error	error	Inactive+LOS+LOF +DG+OAML	Init

2- 6.2.2 GPON ONT Subscriber Facing Port - Status

When the port argument is used with the **gpononu status** command, the command displays the status of ports on the ONT using OMCI.

```
gpononu status [<<slot>[/olt[/onu>>]] | <ifname>] [port <all |<portType>  
<portNumber>] >]
```

The administrative state and operational state of the subscriber facing port on ONU is also displayed.

The *portType* is based on what is supported by the ONU model. The possible port types could be *eth* (Ethernet port), *pots* (POTS port), *rf* (RF port), and *ces* (T1/E1 port).

This example shows the status of an Ethernet port on ONU:

```
zSH> gpononu status 3/1/1 port eth 1
3/1/1 ONU Port Status
Ethernet Port Status - Port 1
```

Basic Component & Port Status Monitoring

Configured Auto-Detection	auto
Administrative State	up
Operational State	active
Connection Type	100BaseT full duplex

3

CHAPTER 3 LOGS FOR THE MXK-F

This chapter provides an overview of logging on the MXK-F.

- [Logging on the Serial Port, page 45](#)
- [Monitor the System with Log Files, page 46](#)

3-1 LOGGING ON THE SERIAL PORT

Procedure:

```
zSH> log serial off
Serial port logging disabled.
```

```
zSH> log serial on
Serial port logging enabled.
```

```
zSH> log session on
Logging enabled.
```

```
zSH> log session off
Logging disabled.
```

Enabling and Disabling logging

By default, log messages are enabled on the serial craft port. Use the **log serial** command and the **log session** command to enable/disable logging:

The **log serial** command enables/disables logging messages for the session on the serial craft port. This command can be used in both Telnet connections and serial port connections to turn on and off the serial craft port logs.

This command setting persists across system reboots and serial logging is *on* by default.

To enable/disable logging for the serial craft port enter:

The **log session** command enables/disables logging messages for that session only when connected to the device through a Telnet session. If the user logs out, the logging setting returns to the default.

This command setting does not persist across system reboots and is *off* by default.

To enable/disable logging for the current Telnet session only enter:

3-2 MONITOR THE SYSTEM WITH LOG FILES

This section provides the following information on how logs work on the MXK-F

- [Overview, page 46](#)
- [Default Log Store Level, page 46](#)
- [User Login Notification, page 47](#)
- [Enable/disable Logging, page 47](#)
- [Log Message Format, page 48](#)
- [Modify Logging Levels, page 49](#)
- [Non-persistent Log Messages, page 50](#)
- [Persistent Log Messages, page 52](#)
- [Example Log Messages, page 52](#)
- [Log Filter Command, page 52](#)
- [Send Messages to a Syslog Server, page 53](#)
- [Specify Different Log Formats for System and Syslog Messages, page 54](#)

3- 2.1 Overview

Logging enables administrators to monitor system events by generating system messages. It sends these messages to:

- A temporary management session (either on the serial craft port or over a Telnet session)
- Log modules to create permanent log files
- A syslog server (optional)

The type of information sent in these messages can be configured using the **log** command. By default, the system sends the same type of information to all log message destinations. If you want to send different types of messages to the syslog daemon, use the **syslog** command.

3- 2.2 Default Log Store Level

The default log store level is now set to emergency so by default the **log display** command displays only emergency level messages. Use the **log cache** command to display all messages that have been logged to console.

Use the **cd log** and **dir** commands to view the log file history. The log files in this directory record console activity on the MXK-F for the running image, and preserve a copy of the last two reboots. The files *consolelog1.txt* and *consolelog2.txt* hold 10000 lines of console output each. Once the file reaches

10000 lines, the filename is changed to *.old* and a new *.txt* file is used. After a reboot, the *.txt* files are also saved as *.old* files. Use the **consolelog display <filename>** command to view the contents for a consolelog file. These files are used for troubleshooting and system activity monitoring.

3- 2.3 User Login Notification

Notifications of user login are sent to the console log.

```
APR 09 11:06:01: notice : 1/ml/12 : shelfctrl: Slot m1, max temp 66C(150F) is back to normal operational
condition
APR 09 11:06:01: alert : 1/ml/1025: alarm_mgr: 01:m1:00 Minor Slot m1, max temp 66C(150F) is normal
APR 09 11:53:59: critical: 1/ml/1027: rebootserver:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 9
APR 09 11:54:01: critical: 1/ml/1027: rebootserver:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 11
APR 09 11:54:04: critical: 1/ml/1027: rebootserver:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 13
APR 09 11:54:08: critical: 1/ml/1027: rebootserver:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 15
```

3- 2.4 Enable/disable Logging

By default, log messages are enabled on the serial craft port. Use the **log session** command and the **log serial** command to enable/disable logging:

The **log session** command enables/disables logging messages for that session only. If the user logs out, the logging setting returns to the default. To enable logging for the only the current session:

```
zSH> log session on
Logging enabled.
```

To disable logging for the session:

```
zSH> log session off
Logging disabled.
```

The **log serial** command enables/disables logging messages for all sessions on the serial craft port. This setting persists across system reboots. To enable/disable logging for the serial craft port:

```
zSH> log serial on
Serial port logging enabled.
```

To disable logging for the serial port:

```
zSH> log serial off
Serial port logging disabled.
```

3- 2.5 Log Message Format

Log messages contain the following information

Table 5: Default Log Message Fields

Option	Description
Date	Date stamp of log message. Enabled by default.
Time	Time stamp of log message. Enabled by default.
Ticks	Current tick count. When the tick option is used, the date and time fields are not displayed.
Level	Logging level of the message. Enabled by default.
Address	The shelf and slot and application identifier causing the alarm.
Logtest	Log handle.
Taskname	Name of task that generated the log message. This is generally useful only for DZS development engineers. Enabled by default.
Function	Function that generated the log message.
Line	Line in code that generated the log message. This is generally useful only for DZS support staff.
Port	Port related to the log message.
Category	Category of the log message.
System	System related to the log message.
All	Controls all log message options.
Default	Controls the default log message options.
Message text	A description of the error that caused the alarm.

To change the information displayed in the log messages, use the **log option** command. First, display the available options:

```
zSH> log option
Usage: log option < time          | 1 > < on | off >
      < date          | 2 > < on | off >
      < level         | 3 > < on | off >
      < taskname      | 4 > < on | off >
      < taskid       | 5 > < on | off >
      < file          | 6 > < on | off >
      < function      | 7 > < on | off >
      < line          | 8 > < on | off >
      < port          | 9 > < on | off >
      < category      | 10 > < on | off >
      < system        | 11 > < on | off >
      < ticks         | 12 > < on | off >
      < stack         | 13 > < on | off >
      < globalticks   | 14 > < on | off >
      < all           | 14 > < on | off >
```

```

    < default      | 15 > < on | off >
options 'time' & 'date' supercede option 'ticks'
time: date: level: address: log: port: category: system: (0x707)

```

Then, turn the option **on** or **off**. For example, the following command will turn the task ID on or off in log messages:

```

zSH> log option taskid on
time: date: level: address: log: taskid: port: category: system: (0x717)

```

```

zSH> log option taskid off
time: date: level: address: log: port: category: system: (0x707)

```

The following commands will turn on or off the tick count display in log messages:

```

zSH> log option ticks on
time: date: level: address: log: port: category: system: ticks: (0xf07)

```

```

zSH> log option ticks off
time: date: level: address: log: port: category: system: (0x707)

```

The following command will turn all options on in log messages:

```

zSH> log option all on
time: date: level: address: log: taskname: taskid: file: function: line: port: category: system: ticks:
stack: globalticks: (0x3fff)

```

3- 2.6 Modify Logging Levels

To modify logging, use the **log** command. To modify syslog messages, use the **syslog** command.



Caution: Changing the log level may generate enough output to disrupt service.

To display the current levels for all logging modules, use the **log show** command:

```

zSH> log show
MODULE                LEVEL                STATUS
alarm_mgr             error                enabled
alarmconfigmibhdlr   error                enabled
assert                error                enabled
attproxy              error                enabled
atttree               error                enabled
autocfg               error                enabled
bds                   error                enabled
bds_client            error                enabled
bridgemib             error                enabled
bulkstats             error                enabled
bulkstatshdlr        error                enabled
cam                   error                enabled
card                  error                enabled

```

card_resource	error	enabled
carddeletehdlr	info	enabled
cardred	error	enabled
cardsvchdlr	error	enabled
cli	error	enabled
clkmgr	warning	enabled
cpecfg	error	enabled
cpemgr	error	enabled
...		

Logging levels determine the number of messages that are displayed on the console. The higher the log level, the more messages are displayed. The MXK-F supports the following log levels:

- 1: emergency
- 2: alert
- 3: critical
- 4: error
- 5: warning
- 6: notice
- 7: information
- 8: debug

To change the log level, use the **log module level** command. For example, the following command changes the card module logging level to emergency:



Caution: Changing the log level may generate enough output to disrupt service.

```
zSH> log level card emergency
Module: card at level: emergency
```

To enable or disable log levels for a module, use the log enable or log disable commands. For example:

```
zSH> log disable card
Module: card is now disabled
```

3- 2.7 Non-persistent Log Messages

The **log cache** command displays the non-persistent log cache messages:

```
zSH> log cache
[1]: FEB 06 22:30:07: notice : 1/ml/12 : shelfctrl: Resetting card 4.
[2]: FEB 06 22:30:07: notice : 1/ml/12 : shelfctrl: Resetting card m2.
[3]: FEB 06 22:30:07: notice : 1/ml/12 : shelfctrl: Resetting card a.
[4]: FEB 06 22:30:07: notice : 1/ml/12 : shelfctrl: Resetting card b.
[5]: FEB 06 22:30:08: alert : 1/ml/1025: alarm_mgr: 01:ml:01 Minor ETHERNET Up - Ethernet line up
```

```
[6]: FEB 06 22:30:10: alert : 1/ml/12 : shelfctrl: Card in slot m2 in the fault state. cause=0x8
POST=0x0.
[7]: FEB 06 22:30:10: notice : 1/ml/12 : shelfctrl: Resetting card m2.
[8]: FEB 06 22:30:10: notice : 1/ml/12 : shelfctrl: Upper and lower fan trays detected.
[9]: FEB 06 22:30:10: alert : 1/ml/1025: alarm_mgr: 01:m2:00 Major Card running
```

The **log cache max length** command sets the maximum number of log messages to store. The maximum log cache size is 2147483647, depending in the amount of memory available.

log cache max length

To change the current configured log cache size:

```
zSH> log cache max 200
Maximum number of log messages that can be saved: 200
```

The **log cache grep pattern** command searches through the log cache for the specified regular expression.

log cache grep pattern

The following example searches through the log cache for the string “Critical”:

```
zSH> log cache grep Major
Searching for: "Major"
[1]: JAN 01 00:02:00: alert : 1/ml/1025: alarm_mgr: 01:m2:00 Major Card running
[2]: JAN 01 04:11:53: alert : 1/ml/1025: alarm_mgr: 01:m2:00 Major Card running
```

The **log cache clear** command clears the log cache.

log cache clear

The **log cache size** command sets the maximum amount of memory for the log cache. Without options, displays the current log size.

```
zSH> log cache size
Number of log messages in the cache: 20
Total bytes used by the cache: 2052
```

The **log cache help** command displays the help information for the **log cache** command:

```
zSH> log cache help
Usage: log cache < max > < length >
      < grep > < pattern >
      < clear >
      < size >
      < help >
```

With no arguments the 'log cache' command prints out all the log messages currently in the cache.

The 'max' command is used to view/set the maximum number of log messages that can be cached at one time. If the cache is full then the oldest log is discarded and the new log is inserted. If no value is given then the current setting is displayed

The 'size' command is used to display the amount of memory

currently being used by the log cache.
The 'clear' command is used to erase the log cache.
The 'grep' command is used for searching the log cache for a specific pattern. Extended regular expressions are supported.

3- 2.8 Persistent Log Messages

Use the **log cache** command to view the persistent logs which only stores emergency level logs. For example:

```
zSH> log display
JAN 01 04:27:02: emergency: 1/m1/12 : shelfctrl: Critical alarm set!
JAN 01 04:27:02: emergency: 1/m1/12 : shelfctrl: Critical alarm set!
```

3- 2.9 Example Log Messages

This section provides examples of how to interpret log messages.

The following message appears when a card in the MXK chassis comes up or goes down.

The most important parts of the message are the date and time the event occurred, the shelf/slot of the event, and the message text. The remainder of the information is only useful for DZS development engineers.

For example:

```
[5]: JAN 01 04:27:02: emergency: 1/m1/12 : shelfctrl: Critical alarm set!
[97]: JAN 02 02:17:29: alert : 1/a/1025: alarm_mgr: 01: a:01 Critical ETHERNET Down - Ethernet uplink
down
```

3- 2.10 Log Filter Command

The **log filter** command is available as part of the log command functionality. This command enables users to show, set and delete log filters. Log filters limit the scope of log messages to a specific entity for troubleshooting and diagnostics. When a log filter is set, the filter is assigned an index number and only messages relate the specified entity are displayed. Filters can be set for a specific ifindex, slot/port or subscriber.

log filter

Restrict the display of log messages to only the log messages for a specified entity.

Syntax: `log filter show | set (ifindex|port slotport|vcl ifindex vpi vci|subscriber endpoint) | delete`

```
zSH> log filter set ifindex 12
New filter saved.
```

```
zSH> log filter set port 5 24
```

New filter saved.

```
zSH> log filter set subscriber 22
```

New filter saved.

```
zSH> log filter show
```

```

Index   Type           Filter Parameters
-----
1       Port           slot=1, port=1
2       Port           slot=1, port=4
3       IfIndex        IfIndex=12
4       Port           slot=5, port=24
6       IfIndex        IfIndex=100
7       IfIndex        IfIndex=104
8       IfIndex        IfIndex=109
9       IfIndex        IfIndex=103
10      IfIndex        IfIndex=107

```

```
zSH> log filter delete 10
```

Log filter 10 deleted

3- 2.11 Send Messages to a Syslog Server

[Table 6](#) describes the parameters in the **syslog-destination** profile you can modify to send messages to a syslog server.

Table 6: syslog-destination Profile Parameters

Parameter	Description
address	The IP address of the machine hosting the syslog server. Default: 0.0.0.0
port	The UDP port to which the syslog messages will be sent. Default: 514

Table 6: syslog-destination Profile Parameters (Continued)

Parameter	Description
facility	<p>The syslog facility to which the syslog messages will be sent.</p> <p>Values:</p> <ul style="list-style-type: none"> local0 local1 local2 local3 local4 local5 local6 local7 no-map <p>Default: local0</p>
severity	<p>The severity level used to filter messages being set to the syslog server.</p> <p>Values:</p> <ul style="list-style-type: none"> emergency alert critical error warning notice info debug <p>Default: debug</p>

```

zSH> new syslog-destination 1
Please provide the following: [q]uit.
address: --> {0.0.0.0}: 192.200.42.5 IP address of the syslog server
port: -----> {514}: leave at default
facility: -> {local0}:
severity: -> {debug}:
.....
Save new record? [s]ave, [c]hange or [q]uit: s
New record saved.
    
```

3- 2.12 Specify Different Log Formats for System and Syslog Messages

[Table 7](#) describes the **log-module** profile that supports the configuration of persistent log messages, syslog messages, and persistent storage levels by module. Modify this profile when you need to send different messages to admin sessions, the persistent logs, and the syslog server.

Table 7: log-module Profile Parameters

Parameter	Description
name	The name of the module whose logging is controlled by this profile. Default: logtest
display	Controls the display of messages on the system. Messages logged at this level and above will be displayed. Values: emergency alert critical error warning notice info debug Default: error

Table 7: log-module Profile Parameters (Continued)

Parameter	Description
syslog	<p>Controls the format of messages sent to the syslog server described in the syslog-destination profile. This field is similar to the display field, except for the trackdisplay value.</p> <p>Values:</p> <ul style="list-style-type: none"> emergency alert critical error warning notice info debug <p>trackdisplay Messages logged at, and above, the level set in the display parameter will also be recorded in the syslog server.</p> <p>Default: trackdisplay</p>
store	<p>Controls the persistent storage of messages. This field is similar to the display field, except for the trackdisplay value.</p> <p>Values:</p> <ul style="list-style-type: none"> emergency alert critical error warning notice info debug <p>trackdisplay Messages logged at, and above, the level set in the display parameter will also be recorded in the syslog server.</p> <p>Default: trackdisplay</p>

```

zSH> new log-module 1
Please provide the following: [q]uit.
name: ----> {logtest}: test1
display: -> {error}: warning
syslog: --> {trackdisplay}:
store: ---> {trackdisplay}:
.....
Save new record? [s]ave, [c]hange or [q]uit: s
New record saved.
    
```

In this case, the **log-module 1** will display to the screen, all messages at and above *warning*. The variable *trackdisplay* means that the same messages as defined in display are also sent to the syslog and storage. If different level of

messages are needed for the different destinations, the variables for **display**, **syslog**, and **store** can be set at different levels.

4

CHAPTER 4 TRAPS AND ALARMS ON THE MXK-F

This chapter describes MXK-F traps and alarms:

- [Alarm Manager, page 60](#)
- [Alarm Suppression, page 61](#)
- [Configurable High and Low Chassis Temperature Alarms, page 63](#)

4-1 SYSTEM 0 DEFAULT TRAPS AND ALARMS

A default **system 0** profile exists with the following configuration:

- Authentication traps are not enabled
- ZMS communication is not configured
- Alarm notification and output are enabled for all severity levels

```
zSH> get system 0
system 0
syscontact: -----> {}
sysname: -----> {}
syslocation: -----> {}
enableauthtraps: -----> {disabled}
setserialno: -----> {0}
zmsexists: -----> {false}
zmsconnectionstatus: --> {inactive}
zmsipaddress: -----> {0.0.0.0}
configsyncexists: -----> {false}
configsyncoverflow: ---> {false}
configsyncpriority: ---> {high}
configsyncaction: -----> {noaction}
configsyncfilename: ---> {172.16.160.49_4_1392921484267}
configsyncstatus: -----> {synccomplete}
configsyncuser: -----> {zmsftp}
configsyncpasswd: -----> ** private **
numshelves: -----> {1}
shelvesarray: -----> {}
numcards: -----> {3}
ipaddress: -----> {172.16.160.49}
alternateipaddress: ---> {0.0.0.0}
countryregion: -----> {us}
primaryclocksource: ---> {0/0/0/0/0}
ringsource: -----> {internalringsourceLabel}
```

```

revertiveLocksource: -> {true}
voicebandwidthcheck: --> {false}
alarm-levels-enabled: -> {critical+major+minor+warning}
userauthmode: -----> {local}
radiusauthindex: -----> {0}
secure: -----> {disabled}
webinterface: -----> {enabled}
options: -----> {disdefpktrules}
reservedVlanIdStart: --> {0}
reservedVlanIdCount: --> {0}
snmpVersion: -----> {snmpv2}
persistentLogging: ----> {disabled}
outletTemperatureHighThreshold: -> {65}
outletTemperatureLowThreshold: --> {-12}

```

4-2 ALARM MANAGER



Note: For GPON ONU alarms, refer to the MXK-F Configuration Guide. The **alarm show** command does not display GPON ONU alarms.

The MXK-F central alarm manager includes the ability to view the active alarms on the system (using the **alarm show** command) and the ability to store active alarms on the device. ZMS can use the alarms stored on the device to recreate the state of the alarms if it becomes disconnected.

The alarm command uses the following syntax:

alarm show [summary]

For example, the following command displays the number of current active alarms, the total number of alarms, the number of cleared alarms, as well as each active alarm and its severity:

```

zSH> alarm show
*****      Central Alarm Manager      *****
ActiveAlarmCurrentCount      :9
AlarmTotalCount              :21
ClearAlarmTotalCount         :12
OverflowAlarmTableCount      :0

ResourceId                    AlarmType                    AlarmSeverity
-----
1-3-1-0/gponolt              linkDown                      critical
1-4-1-0/gponolt              linkDown                      critical
1-b-3-0/eth                   linkDown                      critical
1-b-4-0/eth                   linkDown                      critical
1-b-6-0/eth                   linkDown                      critical
1-b-7-0/eth                   linkDown                      critical
1-b-8-0/eth                   linkDown                      critical

```

The **summary** option displays the number of current active alarms, the total number of alarms, the number of system cleared alarms:

zSH> **alarm show summary**

```

*****      Central Alarm Manager      *****
ActiveAlarmCurrentCount      :9
AlarmTotalCount              :21
ClearAlarmTotalCount         :12
OverflowAlarmTableCount      :0

```

The **alarm clear** command clears a transient alarm the system was unable to clear.



Caution: Alarms cleared with the **alarm clear** command will not be redisplayed if condition reoccurs. The alarm will redisplay only if the condition reoccurs, goes away, and then reoccurs.

```

zSH> alarm clear
Num  ResourceId      AlarmType      AlarmSeverity
-----
 1  1-3-1-0/gponolt  linkDown      critical
 2  1-4-1-0/gponolt  linkDown      critical
 3  1-b-3-0/eth      linkDown      critical
 4  1-b-4-0/eth      linkDown      critical
 5  1-b-6-0/eth      linkDown      critical
 6  1-b-7-0/eth      linkDown      critical
 7  1-b-8-0/eth      linkDown      critical

```

Caution: use this option with discretion.

Alarm will not be redisplayed if condition reoccurs. Alarm will redisplay only if condition reoccurs, goes away, and then reoccurs.

Enter alarm number from list, or 'q' to quit:

The **alarm clear** command only clears alarms one at a time by the alarm number displayed in the *Num* column.

4-3 ALARM SUPPRESSION

The alarm suppression feature allows alarm/LED notification and output to be disabled based on alarm severity level for existing and future alarms. When an alarm level is disabled, all existing alarms of that type are cleared from the system. Future alarms of that type do not set LEDs or alarm relays and are not displayed in alarm output.

Alarm suppression is also supported in ZMS.

[Table 8](#) lists the alarm suppression options and the resulting behaviors. By default, alarms for all severity levels are enabled.

Table 8: Alarm Suppression Options

Alarm Levels Enabled Setting	Alarm Behavior
critical+major+minor+warning	Enables all alarm levels. The default setting.
critical+major+minor	Disables all warning alarms.

Table 8: Alarm Suppression Options (Continued)

Alarm Levels Enabled Setting	Alarm Behavior
critical+major	Disables all minor, and warning alarms.
critical+major+warning	Disables all minor alarms.
critical+minor+warning	Disables all major alarms.
critical+minor	Disables all major and warning alarms.
critical+warning	Disables all major and warning alarms.
critical	Disables all major, minor, and warning alarms.
major	Disables all critical, minor, and warning alarms.
major+minor+warning	Disables all critical alarms.
major+minor	Disables all critical and warning alarms.
major+warning	Disables all critical and minor alarms.
minor	Disables all critical, major, and warning alarms.
minor+warning	Disables all critical and major alarms.
(no levels)	Disables all alarm levels.

This example disables alarm/LED notification and output for all current and future alarms with the severity levels minor and warning.

```

zSH> update system 0
system 0
Please provide the following: [q]uit.
syscontact: -----> {}:
sysname: -----> {}:
syslocation: -----> {}:
enableauthtraps: -----> {disabled}:
setserialno: -----> {0}:
zmsexists: -----> {false}:
zmsconnectionstatus: --> {inactive}:
zmsipaddress: -----> {0.0.0.0}:
configsyncexists: -----> {false}:
configsyncoverflow: ---> {false}:
configsyncpriority: ---> {high}:
configsyncaction: -----> {noaction}:
configsyncfilename: ---> {}:
configsyncstatus: -----> {syncinitializing}:
configsyncuser: -----> {}:
configsyncpasswd: -----> ** private **
numshelves: -----> {1}:
shelvesarray: -----> {}:
numcards: -----> {3}:
ipaddress: -----> {0.0.0.0}:
alternateipaddress: ---> {0.0.0.0}:
countryregion: -----> {us}:
primaryclocksource: ---> {0/0/0/0/0}:
ringsource: -----> {internalringsourcelabel}:
revertiveclocksource: -> {true}:

```

```

voicebandwidthcheck: --> {false}:
alarm-levels-enabled: -> {critical+major+minor+warning}: critical+major
userauthmode: -----> {local}:
radiusauthindex: -----> {0}:
secure: -----> {disabled}:
webinterface: -----> {enabled}:
options: -----> {NONE(0)}:
reservedVlanIdStart: --> {0}:
reservedVlanIdCount: --> {0}:
snmpVersion: -----> {snmpv2}:
persistentLogging: ----> {disabled}
outletTemperatureHighThreshold: -> {65}
outletTemperatureLowThreshold: --> {-12}
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.

```

4-4 CONFIGURABLE HIGH AND LOW CHASSIS TEMPERATURE ALARMS

High and low temperature threshold parameters were added to the **system** profile:

```

zSH> show system
...
outletTemperatureHighThreshold:-> {35 - 65}
outletTemperatureLowThreshold:--> {-40 - 0}

```

Parameter defaults are:

```

zSH> get system 0
...
outletTemperatureHighThreshold: -> {65}
outletTemperatureLowThreshold: --> {-12}

```

A minor alarm is raised when the outlet temperature is at the **outletTemperatureHighThreshold**. Major alarm is raised when the outlet temperature is **outletTemperatureHighThreshold+5**. Critical alarm is raised when the outlet temperature is **outletTemperatureHighThreshold+10**. For example, if the **outletTemperatureHighThreshold** is configured as 35, alarms will be in the order of 35, 40, 45 for Minor, Major, and Critical. If the **outletTemperatureHighThreshold** is configured as 65, alarms will be in the order of 65, 70, 75 for Minor, Major, and Critical.

When the **outletTemperatureLowThreshold** is set and the outlet sensor reaches the configured temperature, a Minor alarm is raised.

Procedure:

Configuring high and low chassis temperature alarms

- 1 Configure the **outletTemperatureHighThreshold** and the **outletTemperatureLowThreshold** parameter in the **system 0** profile.

```

zSH> update system 0
system 0

```

```

Please provide the following: [q]uit.
syscontact: -----> {}:
sysname: -----> {}:
syslocation: -----> {}:
enableauthtraps: -----> {disabled}:
setserialno: -----> {0}:
zmsexists: -----> {true}:
zmsconnectionstatus: -----> {inactive}:
zmsipaddress: -----> {10.51.1.241}:
configsyncexists: -----> {false}:
configsyncoverflow: -----> {false}:
configsyncpriority: -----> {high}:
configsyncaction: -----> {noaction}:
configsyncfilename: -----> {10.51.1.118_4_1405380127627}:
configsyncstatus: -----> {synccomplete}:
configsyncuser: -----> {zmsftp}:
configsyncpasswd: -----> {** private **}: ** read-only **
numshelves: -----> {1}:
shelvesarray: -----> {}:
numcards: -----> {3}:
ipaddress: -----> {10.51.1.118}:
alternateipaddress: -----> {0.0.0.0}:
countryregion: -----> {us}:
primaryclocksource: -----> {0/0/0/0/0}:
ringsource: -----> {internalringsource}:
revertiveclocksource: -----> {true}:
voicebandwidthcheck: -----> {false}:
alarm-levels-enabled: -----> {critical+major+minor+warning}:
userauthmode: -----> {local}:
radiusauthindex: -----> {0}:
secure: -----> {disabled}:
webinterface: -----> {enabled}:
options: -----> {NONE(0)}:
reservedVlanIdStart: -----> {0}:
reservedVlanIdCount: -----> {0}:
snmpVersion: -----> {snmpv2}:
persistentLogging: -----> {disabled}:
outletTemperatureHighThreshold: -> {65}: 55
outletTemperatureLowThreshold: --> {-12}: 0
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.

```

2 Verify the changes.

```

zSH> get system 0
system 0
syscontact: -----> {}
sysname: -----> {}
syslocation: -----> {}
enableauthtraps: -----> {disabled}
setserialno: -----> {0}
zmsexists: -----> {true}
zmsconnectionstatus: -----> {inactive}
zmsipaddress: -----> {10.51.1.241}
configsyncexists: -----> {false}
configsyncoverflow: -----> {false}
configsyncpriority: -----> {high}
configsyncaction: -----> {noaction}

```

```

configsyncfilename: -----> {10.51.1.118_4_1405380127627}
configsyncstatus: -----> {synccomplete}
configsyncuser: -----> {zmsftp}
configsyncpasswd: -----> ** private **
numshelves: -----> {1}
shelvesarray: -----> {}
numcards: -----> {3}
ipaddress: -----> {10.51.1.118}
alternateipaddress: -----> {0.0.0.0}
countryregion: -----> {us}
primaryclocksource: -----> {0/0/0/0/0}
ringsource: -----> {internalringsourcelabel}
revertiveclocksource: -----> {true}
voicebandwidthcheck: -----> {false}
alarm-levels-enabled: -----> {critical+major+minor+warning}
userauthmode: -----> {local}
radiusauthindex: -----> {0}
secure: -----> {disabled}
webinterface: -----> {enabled}
options: -----> {NONE(0)}
reservedVlanIdStart: -----> {0}
reservedVlanIdCount: -----> {0}
snmpVersion: -----> {snmpv2}
persistentLogging: -----> {disabled}
outletTemperatureHighThreshold: -> {55}
outletTemperatureLowThreshold: --> {0}

```

- 3 View the alarms sent in the console window when thresholds are met or exceeded or use the **alarm show** command.

Alarm output will display in the console with **log ses on**.

```
zSH> log ses on
```

```
Logging is already enabled for this session.
```

```

JUN 18 09:59:58: alert : 1/ml/12 : shelfctrl: Chassis Outlet temperature 55 degrees C (131 F)
zSH> JUN 18 09:59:58: alert : 1/ml/12 : shelfctrl: Warning: Chassis temperature is above 55 degrees C
(131 F) threshold
JUN 18 10:05:02: alert : 1/ml/1025: alarm_mgr: 01:ml:00 Minor Updating Chassis Temperature alarm
severity
JUN 18 09:59:58: alert : 1/ml/1025: alarm_mgr: 01:ml:00 Minor Chassis Temperature above 55 degrees C
(131 F) threshold

JUN 18 10:05:02: alert : 1/ml/12 : shelfctrl: Chassis Outlet temperature 60 degrees C (140 F)
JUN 18 10:05:02: alert : 1/ml/12 : shelfctrl: Warning: Chassis temperature is above 60 degrees C (140
F) threshold.
JUN 18 10:05:02: alert : 1/ml/1025: alarm_mgr: 01:ml:00 Major Updating Chassis Temperature alarm
severity
JUN 18 10:05:02: alert : 1/ml/1025: alarm_mgr: 01:ml:00 Major Chassis temperature above 60 degrees C
(140 F) threshold

JUN 18 10:10:08: alert : 1/ml/12 : shelfctrl: Chassis Outlet temperature 65 degrees C (149 F)
JUN 18 10:10:08: alert : 1/ml/12 : shelfctrl: Warning: Chassis temperature is above 65 degrees C (149
F) threshold.
JUN 18 10:10:08: alert : 1/ml/1025: alarm_mgr: 01:ml:00 Critical Updating Chassis Temperature alarm
severity
JUN 18 10:10:08: alert : 1/ml/1025: alarm_mgr: 01:ml:00 Critical Chassis temperature above 65 degrees
C (149 F) threshold

```

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount :21
AlarmTotalCount :100
ClearAlarmTotalCount :79
OverflowAlarmTableCount :0
ResourceId AlarmType AlarmSeverity
-----
...
system temp_over_limit minor
...
```

View the alarm when the outlet temperature exceeds the configured temperature high threshold by +5.

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount :21
AlarmTotalCount :101
ClearAlarmTotalCount :80
OverflowAlarmTableCount :0
ResourceId AlarmType AlarmSeverity
-----
...
system temp_over_limit major
...
```

View the alarm when the outlet temperature exceeds the configured temperature high threshold by +10.

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount :21
AlarmTotalCount :102
ClearAlarmTotalCount :81
OverflowAlarmTableCount :0
ResourceId AlarmType AlarmSeverity
-----
...
system temp_over_limit critical
...
```

View the alarm when the outlet temperature reaches the configured temperature low threshold.

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount :21
AlarmTotalCount :112
ClearAlarmTotalCount :91
OverflowAlarmTableCount :0
ResourceId AlarmType AlarmSeverity
-----
...
system temp_under_limit minor
...
```

The temperature of the chassis can also be viewed with the **shelfctrl monitor** command.

```

zSH> shelfctrl monitor
Shelf                               Status
-----
Uptime                               6 hours, 10 minutes
Upper Fan Tray:
  FPGA version                       0.1
  Firmware version                   0.0
Lower Fan Tray:
  FPGA version                       0.1
  Firmware version                   0.0
Management Card Glue version        0.15

Chassis Temperatures                Celsius (C)          Fahrenheit (F)
-----
Ambient                             74                  165
Outlet                              93                  199
Temperature reading                  failure - Over 75 C / 167 F

Fan Power Supplies & Alarm           Status
-----
Upper Fan Tray:
  Fan Power 1                       normal
  Fan Power 2                       normal
  Fan alarm                          ok
Lower Fan Tray:
  Fan Power 1                       normal
  Fan Power 2                       normal
  Fan alarm                          ok

Power Supplies                      Volts (V)          Status
-----
Battery A                           -0.44V            failure
Battery B                           -51.74V           normal
Battery A return                    ----
Battery B return                    -0.51V

Device                               Status
-----
System                              Critical alarm set
Card m1                              Critical alarm set
Card m2                              Critical alarm set
Card a                               Critical alarm set
Card b                               Critical alarm set

Alarm I/O Board
-----
CPLD version                        0.0
Present:                            Yes
Alarm input:                        Ai1  Ai2  Ai3  Ai4  Ai5  Ai6  Ai7  Ai8
Status (Energized/de-energized):    d    d    d    d    d    d    d    d
NormalOpen/NormalClosed/NotSpec:    NS   NS   NS   NS   NS   NS   NS   NS
Alarm Active:                        No   No   No   No   No   No   No   No

```

4-5 SETTABLE ALARMS ON ETHERNET PORTS

The alarm severity for Ethernet ports can be set to the following levels: *critical*, *major*, *minor*, or *warning*.

Procedure:

Viewing Alarms on Ethernet Ports

- 1 View the current alarm setting on a single Ethernet port.

```
zSH> port show alarm 1-m1-1-0/eth
```

Interface	Alarm severity	Status trap
1-m1-1-0/eth	CRITICAL	ENABLED

- 2 View the current alarms on multiple Ethernet fabric card ports with wildcard.

```
zSH> port show alarm 1-a-**-*/eth
```

Interface	Alarm severity	Status trap
1-a-1-0/eth		
1-a-8-0/eth	CRITICAL	ENABLED
1-a-7-0/eth	CRITICAL	ENABLED
1-a-6-0/eth	CRITICAL	ENABLED
1-a-5-0/eth	CRITICAL	ENABLED
1-a-4-0/eth	CRITICAL	ENABLED
1-a-3-0/eth	CRITICAL	ENABLED
1-a-2-0/eth	CRITICAL	ENABLED

Procedure:

Changing the alarm severity level for one Ethernet port

Use the **port config alarm interfaceName/type severity <severity level>** command to set the severity level on an Ethernet port.

Configure a different alarm setting on an Ethernet port.

```
zSH> port config alarm 1-9-1-0/eth severity major
Alarm severity level set for 1-9-1-0/eth is major
```

Procedure:

Changing the alarm severity level for multiple Ethernet ports

Use the **port config alarm interfaceName/type severity <severity level>** command to set the severity level on multiple Ethernet ports.

Change the alarm setting of all Ethernet ports on the line card.

```
zSH> port config alarm 1-9-**-*/eth severity critical
Alarm severity level set for 1/9/32/0/eth is critical
Alarm severity level set for 1/9/31/0/eth is critical
Alarm severity level set for 1/9/30/0/eth is critical
Alarm severity level set for 1/9/29/0/eth is critical
Alarm severity level set for 1/9/28/0/eth is critical
Alarm severity level set for 1/9/27/0/eth is critical
```

Alarm severity level set for 1/9/26/0/eth is critical
 Alarm severity level set for 1/9/25/0/eth is critical
 Alarm severity level set for 1/9/24/0/eth is critical
 Alarm severity level set for 1/9/23/0/eth is critical
 Alarm severity level set for 1/9/22/0/eth is critical
 Alarm severity level set for 1/9/21/0/eth is critical
 Alarm severity level set for 1/9/20/0/eth is critical
 Alarm severity level set for 1/9/19/0/eth is critical
 Alarm severity level set for 1/9/18/0/eth is critical
 Alarm severity level set for 1/9/17/0/eth is critical
 Alarm severity level set for 1/9/16/0/eth is critical
 Alarm severity level set for 1/9/15/0/eth is critical
 Alarm severity level set for 1/9/14/0/eth is critical
 Alarm severity level set for 1/9/13/0/eth is critical
 Alarm severity level set for 1/9/12/0/eth is critical
 Alarm severity level set for 1/9/11/0/eth is critical
 Alarm severity level set for 1/9/10/0/eth is critical
 Alarm severity level set for 1/9/9/0/eth is critical
 Alarm severity level set for 1/9/8/0/eth is critical
 Alarm severity level set for 1/9/7/0/eth is critical
 Alarm severity level set for 1/9/6/0/eth is critical
 Alarm severity level set for 1/9/5/0/eth is critical
 Alarm severity level set for 1/9/4/0/eth is critical
 Alarm severity level set for 1/9/3/0/eth is critical
 Alarm severity level set for 1/9/2/0/eth is critical
 Alarm severity level set for 1/9/1/0/eth is critical

4- 6 GPON, XGPON1 AND NG-PON2 ALARMS AND TRAPS

The GPON, XGPON1 and NG-PON2 alarms and traps are the same, and identified as “GPON” alarms and traps unless otherwise noted. This sections describes the following topics:

- [GPON Alarms, page 69](#)
- [GPON Traps, page 91](#)

4- 6.1 GPON Alarms

- [Monitor GPON Alarms, page 70](#)
- [GPON BIP Threshold Crossing Monitor Alarms, page 70](#)
- [GPON High and Low Receive Power Threshold Alarms, page 75](#)
- [Rogue ONU Detection and Rogue ONU Alarms, page 77](#)
- [ONU Dying Gasp Alarms, page 89](#)
- [ONU Manual Reboot Alarms, page 90](#)

4- 6.1.1 Retrieve Alarm Information From an ONU

View alarms that are internal to the ONU and ONU LAN facing port with the **gpononu alarms** command.

```
zSH> gpononu alarms 1/7/1
1/7/1 ONU Active Alarms
  MINOR      PptpEthUni 0x0504 LanLo
```

4- 6.1.2 Monitor GPON Alarms

Users can monitor GPON alarms in different levels:

- If users want to view the standard GPON MAC alarms that generated on the ONU and detected on the OLT, use the **gpononu status** command. For example: LOS (Lost Of Signal) alarm or DG (Dying Gasp) alarm of an ONU.
- If users want to view the internal alarms that generated on the ONU UNI ports (also called LAN facing ports or subscriber facing ports) and detected on the ONU, use the **gpononu alarms** command. For example: LanLos alarm of an Ethernet UNI port.
- If users want to view the ONU and OLT alarms that generated on the MXK system, use the **alarm show** command. For example: GPON BIP threshold crossing monitor alarms, GPON high and low receive power threshold alarms, or rogue ONU detection and rogue ONU alarms.

The GPON alarms reported with the **alarm show** command are described in the following section.

4- 6.1.3 GPON BIP Threshold Crossing Monitor Alarms

Users can monitor BIP threshold crossing alarms, set the threshold for BIP errors on GPON, and also configure whether or not to auto-disable the ONU if the threshold has been exceeded. BIP is a counter representing bit errors on the PON link to a specific ONU. This is configured on a per-OLT basis, but is monitored per ONU. To configure the GPON BIP threshold on all ONUs under an OLT, use the **update gpon-olt-config** command.

ONU raises a “bip threshold exceeded” alarm if bip-error-monitoring-mode in the gpon-olt-config profile is set to either monitorOnly or blockOnError and the alarm condition exists. When the alarm is set, the MXK will periodically restart the BIP error measurement. If the condition that cause the alarm is improved, a deactivated ONU is reactivated, and the alarm is cleared. The default interval for the periodic measurement is 5 minutes.

```
zSH> update gpon-olt-config 1-1-1-0/gponolt
gpon-olt-config 1-1-1-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: ----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eqd: -----> {0}:
los-alpha: -----> {4}:
```

```

lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:
dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: ----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: -> {48}:
protection-switchover-timer: -> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ---> {0x0b}:
preamble-type-3-post-range: --> {0x08}:
preamble-type-3-pattern: ----> {0xaa}:
bip-error-monitoring-mode: ---> {monitorOnly}:
errors-per-sample-threshold: -> {100}:
errored-samples-threshold: ---> {10}:
bip-max-sample-gap: -----> {10}:
rogue-onu-detection: -----> {disabled}:
rogue-onu-detect-frequency: ----> {10}:
rogue-onu-rx-power-threshold: --> {-30}:
.....
Save changes? [s]ave, [c]hange or [q]uit:q

```

Table 9: BIP Error Threshold Attributes in gpon-olt-config Profile

Attribute	Description
bip-error-monitoring-mode	<p>Disable or enable the BIP error monitoring.</p> <p>Values:</p> <p>disabled The BIP error monitoring feature is disabled.</p> <p>monitorOnly Monitor BIP errors. When the ONU crosses the BIP error threshold, trigger a local alarm and send a trap to ZMS.</p> <p>blockOnError Monitor BIP errors. When the ONU crosses the BIP error threshold, trigger a local alarm, send a trap to ZMS, disable ONU ranging and set ONU line status to DSA (i.e. disabled).</p> <p>Default: monitorOnly</p>
errors-per-sample-threshold	<p>If the number of BIP errors per sample exceeds this threshold, it is counted as an errored sample.</p> <p>Default: 100</p>
errored-samples-threshold	<p>If the number of errored samples exceed this sample threshold, report and disable the onu if in blockOnError mode, otherwise simply report the threshold as being exceeded.</p> <p>Default: 10</p>
bip-max-sample-gap	<p>If two adjacent errored samples were taken farther apart than this threshold, do not count the earlier sample as an errored sample. This value is in the unit of seconds.</p> <p>Default: 10</p>

Procedure:

Configuring GPON BIP Error Threshold Crossing Monitor Alarms

- 1 View the ONU status.

zSH> **onu status 1/1/2**

ID	Onu	OperStatus	Onci ConfigState	Gpon OnuStatus	Download State	OLT Rx Power	ONT Rx Power	Distance (KM)
2	1-1-1-2	Up	Active	Active	NoUpgrade	-23.8 dBm	-23.0 dBm	18

- 2 Configure the BIP error monitoring mode and thresholds as desired. This example changes the monitoring mode to **blockonerror**, and changes the BIP error threshold values.

zSH> **update gpon-olt-config 1-1-1-0/gponolt**

```

gpon-olt-config 1-1-1-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: ----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eqd: -----> {0}:
los-alpha: -----> {4}:
lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:

```

```

dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: ----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: -> {48}:
protection-switchover-timer: -> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ---> {0x0b}:
preamble-type-3-post-range: --> {0x08}:
preamble-type-3-pattern: -----> {0xaa}:
bip-error-monitoring-mode: ---> {monitorOnly}:blockonerror
errors-per-sample-threshold: -> {100}: 99
errored-samples-threshold: ---> {10}:9
bip-max-sample-gap: -----> {10}:9
rogue-onu-detection: -----> {disabled}:
rogue-onu-detect-frequency: ----> {10}:
rogue-onu-rx-power-threshold: --> {-30}:
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.

```

- 3 View the ONU status. This example assumes the BIP error on this ONU exceeded the threshold values. With the **blockonerror** mode, the ONU will raise an alarm and be auto-disabled. The **GponOnuStatus** in this example shows a brief description about this ONU is inactive and EXCBIPDSA (i.e. exceeded BIP threshold, and ONU is disabled.).

```

zSH> onu status 1/1/2

```

ID	Onu	OperStatus	Onci ConfigState	Gpon OnuStatus	Download State	OLT Rx Pwr	ONT Rx Pwr (KM)	Dist.
2	1-1-1-2	Down	Inactive	Inactive+EXCBIPDSA	None	error	error	0.0

GponOnuStatus acronym definitions:

- “Active” - ONU is Active
- “Inactive” - ONU is Inactive
- “LOS” - Loss of Signal
- “LOF” - Loss of Frame

- “SD” - Drift Of Window
- “SF” - Signal Fail
- “SD” - Signal Degrade
- “LCDG” - Loss of GEM channel delineation
- “RD” - Remote defect
- “TF” - Transmitter Failure
- “SUF” - Start-up Failure
- “LOA” - Loss of Acknowledge
- “DG” - Receive Dying-gasp
- “OAML” - PLOAM Cell Loss
- “MEM” - Message Error Message
- “PEE” - Physical Equipment Error
- “EXCBIPDSA” - Disable Onu, excessive BIP errors
- “EXCBIP” - Excessive BIP errors. ONU is not disabled
- “RXPWRDSA” - Upstream Rx Power out of range. ONU is disabled.
- “RXPWRNOTDSA” - Upstream Rx Power out of range. ONU is not disabled.

4 View the raised alarms on this ONU at the system level.

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount      :8
AlarmTotalCount              :15
ClearAlarmTotalCount         :7
OverflowAlarmTableCount      :0
ResourceId                   AlarmType                               AlarmSeverity
-----
1-a-3-0/eth                  linkDown                                critical
1-1-1-0/gponolt              linkDown                                critical
1-1-2-0/gponolt              linkDown                                critical
1-1-3-0/gponolt              linkDown                                critical
1-1-4-0/gponolt              linkDown                                critical
1-1-1-2/gpononu             linkDown                                minor
1-1-1-2/gpononu             inactive,bip threshold exceeded,dsa      minor
```



Note: If more than one error condition is present (example: Excessive BIP errors and Optical Rx Power too high), the local alarm text may be too long to fit within the display output. In this case, AlarmType shows “issue 'onu status' command 0x300002” in order to prompt user to enter the **onu status** command for more details. The “0x300002” value is the actual alarm status word and will vary.

```
zSH> alarm show
***** Central Alarm Manager *****
```

```

ActiveAlarmCurrentCount      :8
AlarmTotalCount              :32
ClearAlarmTotalCount         :24
OverflowAlarmTableCount      :0
ResourceId                   AlarmType                               AlarmSeverity
-----
1-1-1-2/gpononu             issue 'onu status' command 0x300002          minor

```

4- 6.1.4 GPON High and Low Receive Power Threshold Alarms

By default, the MXK will trigger a local alarm, and send a trap to ZMS when the GPON high/low receive power thresholds are crossed for the ONU received power on the upstream. The default value of the High threshold is -10 dbm. The default value of the Low threshold is -30 dbm. Users can change the default threshold values, and choose the upstream received power monitoring mode as desired.

ONU raises a “rx power out of range” alarm if `us-rx-power-monitoring-mode` in `gpon-olt-onu-config` profile is set to either `monitorOnly` or `blockOnError` and the alarm condition exists. When the alarm is set, the MXK will periodically restart the power level measurement. If the condition that cause the alarm is improved, a deactivated ONU is reactivated, and the alarm is cleared. The default interval for the periodic measurement is 5 minutes.

The GPON high/low receive power threshold values and monitoring modes are configured on a per-ONU basis with the `update gpon-olt-onu-config` command.

```

zSH> update gpon-olt-onu-config 1-1-1-2/gpononu
gpon-olt-onu-config 1-1-1-2/gpononu
Please provide the following: [q]uit.
serial-no-vendor-id: -----> {ZNTS): ** read-only **
serial-no-vendor-specific: -----> {2216690777): ** read-only **
password: -----> {}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
onu-added: -----> {true}:
omci-file-name: -----> {}:
ONU-Managed-Entity-Profile-name: -----> {znid-gpon-2510-omci-4port-me}:
ONU-Generic-Assignments-Profile-name: -> {znid-gpon-2510-omci-4port-gen}:
physical-traps: -----> {disabled}:
ont-traps: -----> {disabled}:
line-status-traps: -----> {disabled}:
auto-upgrade: -----> {enabled}:
serial-no-vendor-specific-fsan: -----> {84200459): ** read-only **
use-reg-id: -----> {disabled}:
us-rx-power-monitoring-mode: -----> {monitorOnly}:
us-rx-power-high-threshold: -----> {-10}:
us-rx-power-low-threshold: -----> {-30}:
dba-status-reporting: -----> {disabled}
.....
Save changes? [s]ave, [c]hange or [q]uit:q

```

Table 10: Received Power Threshold Attributes in gpon-olt-onu-config Profile

Attribute	Description
us-rx-power-monitoring-mode	<p>Disable or enable the received power threshold alarm.</p> <p>Values: disabled This feature is disabled. monitorOnly Monitor ONU Receive Power Level. When ONU Receive Power Level crosses either the High or Low thresholds, trigger a local alarm, and send trap to ZMS. blockOnError Monitor ONU Receive Power Level. When ONU Receive Power Level crosses either the High or Low thresholds, trigger a local alarm, send trap to ZMS, disable ONT ranging and set ONT line status to DSA. Default: monitorOnly</p>
us-rx-power-high-threshold	<p>Upstream Receive Power High Threshold value, in the unit of dbm.</p> <p>Default: -10</p>
us-rx-power-low-threshold	<p>Upstream Receive Power Low Threshold value, in the unit of dbm.</p> <p>Default: -30</p>

Procedure:

Configuring GPON High and Low Received Power Threshold Alarms

- 1 View the ONU status. In this example, the upstream ONU received power under the OLT Rx Power column is -13.7 dBm, which is within the default value range of the GPON high and low received power threshold (-10 to -30).

```
zSH> onu status 1/1/2
```

AutoConfig ID	Onu ID	OperStatus	ConfigState	OLT State	ONT Rx Power	Distance	Gpon Rx Power (KM)
2	1-1-1-2	Up	Active	NoUpgrade	-13.7 dBm	-15.4 dBm	0.0240

- 2 Configure the upstream ONU received power monitoring mode and thresholds as desired.

This example changes the low-threshold to -20 from the default value -30, and changes the monitoring mode to **blockonerror**. If the current OLT RX power has crossed the low threshold, a received power threshold alarm will be triggered, and the ONU will be disabled.

```
zSH> update gpon-olt-onu-config 1-1-1-2/gpononu
gpon-olt-onu-config 1-1-1-2/gpononu
Please provide the following: [q]uit.
serial-no-vendor-id: -----> {ZNTS}: ** read-only **
serial-no-vendor-specific: -----> {2216690777}: ** read-only **
password: -----> {}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
us-ber-interval: -----> {5000}:
```

```

ds-ber-interval: -----> {5000}:
onu-added: -----> {true}:
omci-file-name: -----> {}:
ONU-Managed-Entity-Profile-name: -----> {znid-gpon-2510-omci-4port-me}:
ONU-Generic-Assignments-Profile-name: -> {znid-gpon-2510-omci-4port-gen}:
physical-traps: -----> {disabled}:
ont-traps: -----> {disabled}:
line-status-traps: -----> {disabled}:
auto-upgrade: -----> {enabled}:
serial-no-vendor-specific-fsan: -----> {84200459}: ** read-only **
use-reg-id: -----> {disabled}:
us-rx-power-monitoring-mode: -----> {monitorOnly}:blockonerror
us-rx-power-high-threshold: -----> {-10}:
us-rx-power-low-threshold: -----> {-30}:-20
dba-status-reporting: -----> {disabled}
.....
Save changes? [s]ave, [c]hange or [q]uit:s

```

3 View the ONU status.

This example shows GponOnuStatus is inactive and RXPWRDSA (i.e. received power out of range, and ONU is disabled.) Refer to the **alarm show** command for the explanation of the cryptic acronyms.

```
zSH> onu status 1/1/2
```

ID	Onu	OperStatus	Omci ConfigState	Gpon OnuStatus	Download State	OLT Rx Power	ONT Rx Power	Distance (KM)
2	1-1-1-2	Down	Inactive	Inactive+RXPWRDSA	None	error	error	0.0

4 View the alarms on this ONU at the system level.

Two alarms are raised, link down and Rx power threshold alarms.

```
zSH> alarm show
```

```

***** Central Alarm Manager *****
ActiveAlarmCurrentCount      :8
AlarmTotalCount              :32
ClearAlarmTotalCount         :24
OverflowAlarmTableCount      :0

ResourceId      AlarmType      AlarmSeverity
-----
1-a-3-0/eth     linkDown      critical
1-1-1-0/gponolt linkDown      critical
1-1-2-0/gponolt linkDown      critical
1-1-3-0/gponolt linkDown      critical
1-1-4-0/gponolt linkDown      critical
1-1-1-2/gpononu linkDown      minor
1-1-1-2/gpononu inactive,rx power out of range,dsa minor

```

4- 6.1.5 Rogue ONU Detection and Rogue ONU Alarms

A rogue ONU is an ONU that transmits outside of its allocated bandwidth map. It can cause disruption to multiple subscribers or to all subscribers on a PON. DZS provides versatile ways to detect a rogue ONU that is present on

the PON and/or shut it down. That saves the other subscribers from experiencing any service issues.

To detect and/or shutdown a rogue ONU, use the following detection modes per OLT basis:

1. Periodical background process detection mode

Periodical background process detection mode can detect certain cases of rogue ONUs, but will not disable rogue ONUs. If a rogue ONU has been detected on the OLT, an OLT-level alarm

“**gpon_olt_rogue_onu_detected**” is raised.

Refer to [Periodical Background Process Detection Mode on page 80](#) for the details.

2. Rogue RSSI detection mode

Rogue RSSI detection mode can detect and disable rogue ONUs by using the RSSI measurement on ONUs. If a rogue ONU has been detected on an OLT, an OLT-level alarm “**gpon_olt-rssi_rogue_onu_detected**” is raised. And then this rogue ONU will be identified, isolated, and disabled. An ONU-level alarm “**inactive, rogue ONU**” will be raised too.

Refer to [Rogue RSSI Detection Mode on page 83](#) for the details.

3. Auto rogue RSSI detection mode

Auto rogue RSSI detection mode normally functions as disabled, it will be switched to the rogue RSSI detection mode only under certain circumstances.

Refer to [Auto Rogue RSSI Detection Mode on page 87](#) for the details.

All three kinds of rogue ONU alarms have severity levels as minor.



Note: As a rule users only want to use either **disabled** or **autorssi** mode under normal conditions, although users might want to set either **roguerssi** or **backgroundprocess** if users suspect a rogue ONU for some reasons that is not detected or not isolated by **autorssi** mode.

Users can configure the ONU detection modes in the gpon-olt-config profile. This profile contains three rogue ONU detection related attributes:

```
zSH> show gpon-olt-config
max-rt-propagation-delay:-----> {0 - 0}
max-onu-response-time:-----> {0 - 0}
preassigned-eqd:-----> {0 - 0}
los-alpha:-----> {0 - 0}
lof-alpha:-----> {0 - 0}
loam-alpha:-----> {0 - 0}
scrambler:-----> enabled disabled
fec-mode:-----> enabled disabled
auto-learn:-----> enabled disabled
power-level:-----> {0 - 0}
guard-bit-count:-----> {0 - 0}
dba-mode:-----> predictive piggyback wholereport
```

```

gem-block-size:-----> {0 - 0}
us-ber-interval:-----> {0 - 0}
ds-ber-interval:-----> {0 - 0}
ber-sf-threshold:-----> {3 - 8}
ber-sd-threshold:-----> {4 - 9}
fec-request:-----> enabled disabled
key-exchange:-----> enabled disabled
min-rt-propagation-delay:-----> {0 - 0}
min-onu-response-time:-----> {0 - 0}
eqd-measure-cycles:-----> {0 - 0}
drift-ctrl-interval:-----> {0 - 0}
drift-ctrl-limit:-----> {0 - 0}
alloc-cycle-length:-----> {1 - 10}
min-us-alloc:-----> {0 - 0}
ack-timeout:-----> {0 - 0}
pls-max-alloc-size:-----> {0 - 0}
dba-cycle:-----> {2 - 10}
sr-dba-reporting-block-size:--> {0 - 0}
protection-switchover-timer:--> {0 - 0}
preamble-override:-----> enabled disabled
preamble-type-0:-----> {8}
preamble-type-1:-----> {8}
preamble-type-3-pre-range:----> {8}
preamble-type-3-post-range:---> {8}
preamble-type-3-pattern:-----> {8}
bip-error-monitoring-mode:----> disabled monitoronly blockonerror
errors-per-sample-threshold:--> {0 - 0}
errored-samples-threshold:----> {0 - 0}
bip-max-sample-gap:-----> {0 - 0}
rogue-onu-detection:-----> disabled roguerssi backgroundprocess autorssi
rogue-onu-detect-frequency:---> {1 - 60}
rogue-onu-rx-power-threshold:--> {0 - 0}

```

Table 11: rogue ONU Detection Attributes in gpon-olt-config Profile

Attribute	Description
rogue-onu-detection	<p>Disable or enable the rogue ONU detection modes.</p> <p>Values:</p> <p>disabled Disable all the rogue ONU detection mode.</p> <p>roguerssi Enable rogue RSSI detection. When a rogue ONU RSSI measurement crosses the rogue-onu-rx-power-threshold, an attempt is made to isolate the rogue ONU. If successful, disable the rogue ONU. Trigger a local alarm and send a trap to ZMS.</p> <p>backgroundprocess Enable background process detection. When a rogue transmission is detected, trigger a local alarm and send a trap to ZMS.</p> <p>autorssi Enable auto RSSI detection. In this mode, it normally stays as disabled, it will switch to the rogue RSSI detection mode 1) if more than half the active ONUs go down within a brief interval, 2) or if BIP errors exceed threshold on any ONU. Note that the second case is a detect only measurement, no attempt to disable the rogue ONU will be automatically performed.</p> <p>Default: disabled</p>
rogue-onu-detect-frequency	<p>How often to run a detection after enabling the detection.</p> <p>Default: 10 seconds</p>

Table 11: rogue ONU Detection Attributes in gpon-olt-config Profile

Attribute	Description
rogue-onu-rx-power-threshold	<p>Upstream Receive Power High Threshold value for detecting rogue ONU, in the unit of dbm.</p> <p>RSSI upstream received power is measured on an unused ONU, which should measure zero, if the measurement exceeds the threshold, an alarm is reported and isolation is attempted. This is ignored in background process mode.</p> <p>Default: -30</p>

4- 6.1.5: 1

Periodical Background Process Detection Mode

Certain rogue behaviors can only be detected by running the periodical background process detection mode on an OLT. This mode can only be used to detect the condition, rather than disable it.

The periodical background process opens a special allocation window and monitors for potential rogue transmission. The special window is opened with an unused Alloc_ID, for which no response is expected unless there is a rogue ONU. The window is opened so that it may detect a transmission either within the PON distance or further.

When a rogue ONU transmission is detected in the special window, “**gpon_olt_rogue_onu_detected**” alarm is raised on the OLT port. It shows there is a rogue ONU has been detected on this OLT. The alarm severity level is minor.

Procedure:

Running the Periodical Background Process Detection and Viewing OLT-level Rogue ONU Alarms

- 1 Set the rogue ONU detection mode to the periodical background process.

This example uses the default settings 10 seconds in the rogue-onu-detect-frequency field. After enabling the periodical background process, the process will run every 10 seconds.

```
zSH> update gpon-olt-config 1-1-1-0/gponolt
gpon-olt-config 1-1-1-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: -----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eqd: -----> {0}:
los-alpha: -----> {4}:
lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:
dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
```

```

ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: -----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: --> {48}:
protection-switchover-timer: --> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ----> {0x0b}:
preamble-type-3-post-range: ---> {0x08}:
preamble-type-3-pattern: -----> {0xaa}:
bip-error-monitoring-mode: ----> {monitoronly}:
errors-per-sample-threshold: --> {100}:
errored-samples-threshold: ----> {10}:
bip-max-sample-gap: -----> {10}:
rogue-onu-detection: -----> {disabled}:backgroundprocess
rogue-onu-detect-frequency: ---> {10}:
rogue-onu-rx-power-threshold: -> {-30}:
.....

```

Save changes? [s]ave, [c]hange or [q]uit:s

- 2 If there are any rogue ONUs under this OLT port have been detected by running the periodical background process, the rogue ONU alarm will be raised on the OLT port.

Use the **alarm show** command to check the rogue ONU alarms:

```

zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount      :8
AlarmTotalCount              :15
ClearAlarmTotalCount         :7
OverflowAlarmTableCount      :0

ResourceId      AlarmType      AlarmSeverity
-----
1-a-3-0/eth     linkDown      critical
1-1-1-0/gponolt gpon_olt_rogue_onu_detected  minor
...

```

Procedure:

Clearing OLT-level Rogue ONU Alarms

To clear the OLT level rogue ONU alarm “gpon_olt_rogue_onu_detected”, ONTs must be manually disabled one by one until the condition is no longer detected, at which time the alarm will go away.

If the rogue ONU detection mode is switched back to normal states, the alarm will clear, but condition still stay.

Procedure:

Switching the Rogue ONU Detection Mode Back to Normal States from the Periodical Background Process Mode

After finished the periodical background process, follow the rule to set the rogue ONU detection mode back to the normal states. Normal states could be disabled or auto RSSI mode.

```
zSH> update gpon-olt-config 1-1-1-0/gponolt
gpon-olt-config 1-1-1-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: ----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eqd: -----> {0}:
los-alpha: -----> {4}:
lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:
dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: ----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: --> {48}:
protection-switchover-timer: --> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ----> {0x0b}:
preamble-type-3-post-range: ---> {0x08}:
preamble-type-3-pattern: -----> {0xaa}:
bip-error-monitoring-mode: ----> {monitoronly}:
errors-per-sample-threshold: --> {100}:
errored-samples-threshold: ----> {10}:
bip-max-sample-gap: -----> {10}:
rogue-onu-detection: -----> {backgroundprocess}:disabled or autorssi
rogue-onu-detect-frequency: --> {10}:
rogue-onu-rx-power-threshold: -> {-30}:
.....
```

Save changes? [s]ave, [c]hange or [q]uit:s

4- 6.1.5: 2

Rogue RSSI Detection Mode



Caution: The rogue RSSI measurement is a semi-invasive mode. During the activation of the RSSI measurement on an OLT port it is not allowed to provision Alloc_IDs or to activate ONUs under that OLT port.

The rogue RSSI detection not only can detect the rogue ONU, and also can disable it. Note that after the rogue ONU had been disabled, this disabled ONU must be cleared and physically removed.

If the periodical background process detection cannot find the rogue ONU, users can run the rogue RSSI detection.

If users want to provision Alloc_IDs (by creating bridges/interfaces on ONU Gemports), and activate ONUs (by assigning serial numbers to ONUs ports), users must change the rogue-onu-detection mode from rogue RSSI to auto RSSI mode or disabled, after clearing any disabled ONUs.

A rogue RSSI detection performs the following two parts:

1. **1st part:** Detect rogue ONUs and get OLT-level alarms

The rogue RSSI detection uses the rogue RSSI measurement to identify a rogue ONU by measuring transmission power on an unused ONU.

The RSSI measurement is a stand-alone utility for testing rogue transmission when no upstream burst is expected. The intention is to identify when a rogue ONU injects a constant energy on the link, and does not respond to OLT allocations.

If the rogue ONU RSSI measurement is higher than the rogue-onu-rx-power-threshold defined in the **gpon-olt-config** profile, an OLT-level alarm “**gpon_olt_rssi_rogue_onu_detected**” and trap will be sent. This rogue ONU alarm shows there is a rogue ONU has been detected with the RSSI measurement on the OLT.

2. **2nd part:** Isolate and shutdown rogue ONUs, and get ONU-level alarms

Once the rogue RSSI detection is determined that a rogue ONU does exist on an OLT, it will start the process to determine which one is the rogue ONU and disable it. The process disables ONTs one at a time, each time it will perform a rogue RSSI measurement, until get a good reading, at which time it declare the last ONU disabled as rogue, and enable all the other “good” ONUs. An ONU error will be raised on the isolated ONU, and this ONU shows as disabled in the showline.

When this rogue ONU is disabled, an ONU-level alarm “**inactive, rogue onu**” and trap will be sent.

Note that the **2nd part** may fail, in which case the OLT-level alarm continues to be displayed. Reasons for failing to isolate rogue ONUs could be:

- Certain models of ONT do not disable transmission

- If a rogue ONU is connected with OLT on the fiber but not activated (by associating an ONU port ID with its serial number with the **onu set** command), it will not be isolated
- If the ONT is too “bad” to respond to a disable request.

Procedure:Running the RSSI Rogue ONT Detection and Viewing OLT-Level and ONU-Level RSSI Rogue Alarms

- 1 To enable the RSSI rogue ONT detection mode, change the rogue-onu-detection field of the gpon-olt-config profile to **roguerssi**.

This example uses the default values set in the rogue-onu-detect-frequency field and rogue-onu-rx-power-threshold field. That means the RSSI rogue ONT detection will run every 10 seconds, and if the RSSI measurement exceeds -30 dbm, an alarm is reported and isolation is attempted.

```
zSH> update gpon-olt-config 1-1-4-0/gponolt
gpon-olt-config 1-1-4-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: -----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eqd: -----> {0}:
los-alpha: -----> {4}:
lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:
dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: -----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: --> {48}:
protection-switchover-timer: --> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ----> {0x0b}:
preamble-type-3-post-range: ---> {0x08}:
```

```
preamble-type-3-pattern: -----> {0xaa}:
bip-error-monitoring-mode: ----> {monitoronly}:
errors-per-sample-threshold: --> {100}:
errored-samples-threshold: ----> {10}:
bip-max-sample-gap: -----> {10}:
rogue-ONU-detection: -----> {disabled}:roguerssi
rogue-ONU-detect-frequency: ---> {10}:
rogue-ONU-rx-power-threshold: -> {-30}:
.....
```

Save changes? [s]ave, [c]hange or [q]uit:s

2 If a rogue ONU is detected, users will see a rogue ONU alarm on the OLT port.

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount      :8
AlarmTotalCount              :15
ClearAlarmTotalCount         :7
OverflowAlarmTableCount      :0

ResourceId      AlarmType      AlarmSeverity
-----
1-a-3-0/eth     linkDown          critical
1-1-4-0/gponolt gpon_olt_rssi_rogue_onu_detected  minor
...
```

3 If a rogue ONU is isolated and disabled, users will see a rogue ONU alarm on the ONU port. This alarm will clear the OLT-level alarm listed in the previous step, unless there are more rogue ONUs under this OLT port, or failed to isolate and shutdown the detected rogue ONUs.

```
zSH> alarm show
***** Central Alarm Manager *****
ActiveAlarmCurrentCount      :8
AlarmTotalCount              :15
ClearAlarmTotalCount         :7
OverflowAlarmTableCount      :0

ResourceId      AlarmType      AlarmSeverity
-----
1-a-3-0/eth     linkDown          critical
1-1-4-1/gpononu inactive,rogue onu          minor
...
```

Procedure:

Clearing OLT-Level and ONU-Level RSSI Rogue Alarms

To clear the ONU level RSSI rogue alarm “inactive, rogue onu”, the ONT must be physically removed from the network before using the **gpononu clear** command.

To clear the OLT-level RSSI rogue alarms, “gpon_olt_rssi_rogue_onu_detected”, use the same method shown in [Clearing OLT-level Rogue ONU Alarms, page 81](#).

Note that alarms can be cleared by changing detect mode or threshold, but this will not clear the condition.

Procedure:***Switching the Rogue ONU Detection Back to Normal States from the Rogue RSSI Mode***

After users detected a rogue ONU on an OLT by running the rogue RSSI detection mode, the OLT port is in a restricted mode keeps users from activating any ONUs connected to it. To go back to the normal states, perform the following steps:

- 1** Physically unplug the rogue ONU.
- 2** Clear the rogue ONU. This step will clear the onu-level “inactive, rogue onu” alarm too.

```
zSH> gpononu clear 1/4/1
```

- 3** Set the rogue ONU detection mode back to the normal states (disabled or auto RSSI mode).

```
zSH> update gpon-olt-config 1-1-4-0/gponolt
gpon-olt-config 1-1-4-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: -----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eqd: -----> {0}:
los-alpha: -----> {4}:
lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:
dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: -----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: --> {48}:
protection-switchover-timer: --> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ----> {0x0b}:
preamble-type-3-post-range: ---> {0x08}:
preamble-type-3-pattern: -----> {0xaa}:
```

```

bip-error-monitoring-mode: ----> {monitoronly}:
errors-per-sample-threshold: --> {100}:
errored-samples-threshold: ----> {10}:
bip-max-sample-gap: -----> {10}:
rogue-onu-detection: -----> {roguerssi}:disabled or autorssi
rogue-onu-detect-frequency: ---> {10}:
rogue-onu-rx-power-threshold: -> {-30}:
.....

```

Save changes? [s]ave, [c]hange or [q]uit:s

4- 6.1.5: 3 Auto Rogue RSSI Detection Mode

The auto rogue ONU RSSI detection mode normally functions as disabled, it will be switched to the rogue RSSI detection mode only if one of the following two cases happened:

1. Case 1: If more than half the active ONUs on the OLT go down within a brief interval (currently 1 minute), then the disabled mode will be switched to the rogue RSSI detection mode for one measurement cycle.

In case 1, there are three possible outcomes:

No.1 The process did not detect presence of a rogue ONU. Then the detection mode will be switched back to the disabled mode, with a “no rogue ONU was detected” message shown on the console.

No.2 A rogue ONU was detected and isolated. In this case, the rogue RSSI mode is retained, so that the ONU stays disabled until it is cleared, or until the rogue detection mode is changed.

An ONU-level alarm “**inactive, rogue onu**” and trap will be sent.

No.3 Presence of rogue ONU is detected, but unable to isolate the ONU. In this case, the detection mode will be switched back to disabled.

An OLT-level alarm “**gpon_olt_rssi_rogue_onu_detected**” and trap will be sent.

2. Case 2: If BIP errors exceed threshold on any ONU, the disabled mode will be switched to rogue RSSI detection mode. But in this case, it is a “detect only” measurement. No attempt at isolation will be automatically performed, only **No.1** and **No.3** of the above outcomes are possible.

Procedure:

Running the Auto RSSI Rogue ONT Detection and Viewing RSSI Rogue ONU Alarm on an ONU

- 1 To enable the auto RSSI rogue ONT detection mode, change the rogue-onu-detection field of the gpon-olt-config profile to **autorssi**.

```

zSH> update gpon-olt-config 1-1-4-0/gponolt
gpon-olt-config 1-1-4-0/gponolt
Please provide the following: [q]uit.
max-rt-propagation-delay: -----> {200}:
max-onu-response-time: -----> {50}:
preassigned-eq: -----> {0}:
los-alpha: -----> {4}:

```

```

lof-alpha: -----> {4}:
loam-alpha: -----> {3}:
scrambler: -----> {enabled}:
fec-mode: -----> {disabled}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
guard-bit-count: -----> {32}:
dba-mode: -----> {predictive}:
gem-block-size: -----> {16}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
ber-sf-threshold: -----> {3}:
ber-sd-threshold: -----> {5}:
fec-request: -----> {disabled}:
key-exchange: -----> {disabled}:
min-rt-propagation-delay: -----> {0}:
min-onu-response-time: -----> {10}:
eqd-measure-cycles: -----> {5}:
drift-ctrl-interval: -----> {1000}:
drift-ctrl-limit: -----> {3}:
alloc-cycle-length: -----> {2}:
min-us-alloc: -----> {16}:
ack-timeout: -----> {2000}:
pls-max-alloc-size: -----> {120}:
dba-cycle: -----> {2}:
sr-dba-reporting-block-size: --> {48}:
protection-switchover-timer: --> {500}:
preamble-override: -----> {disabled}:
preamble-type-0: -----> {0x00}:
preamble-type-1: -----> {0x00}:
preamble-type-3-pre-range: ----> {0x0b}:
preamble-type-3-post-range: ---> {0x08}:
preamble-type-3-pattern: -----> {0xaa}:
bip-error-monitoring-mode: ----> {monitoronly}:
errors-per-sample-threshold: --> {100}:
errored-samples-threshold: ----> {10}:
bip-max-sample-gap: -----> {10}:
rogue-onu-detection: -----> {disabled}:autorssi
rogue-onu-detect-frequency: ---> {10}:
rogue-onu-rx-power-threshold: -> {-30}:
.....

```

Save changes? [s]ave, [c]hange or [q]uit:**s**

2 If a rogue ONU is detected, users will see a rogue ONU alarm on the OLT port.

```

zSH> alarm show
*****      Central Alarm Manager      *****
ActiveAlarmCurrentCount      :8
AlarmTotalCount              :15
ClearAlarmTotalCount         :7
OverflowAlarmTableCount      :0
ResourceId      AlarmType      AlarmSeverity
-----
1-a-3-0/eth      linkDown      critical
1-1-4-0/gponolt gpon_olt_rssi_rogue_onu_detected      minor
...

```

- If a rogue ONU is isolated and disabled, users will see a rogue ONU alarm on the ONU port. This alarm will clear the OLT-level alarm listed in the previous step, unless there are more rogue ONUs under this OLT port, or failed to isolate and shutdown the detected rogue ONUs.

```
zSH> alarm show
*****      Central Alarm Manager      *****
      ActiveAlarmCurrentCount           :8
      AlarmTotalCount                   :15
      ClearAlarmTotalCount               :7
      OverflowAlarmTableCount            :0
ResourceId      AlarmType      AlarmSeverity
-----
1-a-3-0/eth     linkDown      critical
1-1-4-1/gpononu inactive,rogue onu  minor
...
```

4- 6.1.6 ONU Dying Gasp Alarms

When an ONU is power down, and the line-status-traps field in the gpon-olt-onu-config profile has been set to enabled or auto, then the lineStatusChange trap will be sent and the Dying Gasp Alarm will be raised.

Dying gasp alarm provides ONU information to the service provider when this ONU is about to power down. The dying gasp event is followed by an ONU down event.

If there is a link down alarm prior to receiving the dying gasp alarm, link down alarm will be cleared and dying gasp alarm will be created.

Procedure:

Viewing ONU Dying Gasp Alarm on an ONU

- To enable the ONU dying gasp alarm, change the line-status-traps field of the gpon-olt-onu-config profile to **auto or enabled**.

This example sets enabled for line-status-traps field:

```
zSH> update gpon-olt-onu-config line-status-traps=enabled 1-7-1-1/gpononu
gpon-olt-onu-config 1-7-1-1/gpononu
Record updated.
```

- Create trap-destination profile to define a trap recipient the MXK-F will send traps to.

```
zSH> new trap-destination 1
trap-destination 1
Please provide the following: [q]uit.
trapdestination: -----> {0.0.0.0}: 172.16.80.39      the IP address of the SNMP trap server
communityname: -----> {}:
resendseqno: -----> {0}:
ackedseqno: -----> {0}:
traplevel: -----> {low}:
trapttype: -----> {0}:
trapadminstatus: -----> {enabled}:
gatewaytrapserveraddr: -> {none}:
.....
Save new record? [s]ave, [c]hange or [q]uit: s
```

New record saved.

- 3 Power down this ONU.
- 4 User will see Dying Gasp in the alarm or trap description:
 - a Send lineStatusChange trap with trap value as inactive | dyinggasp.
You can check the trap values in the trap recipient console in MIB browser.
 - b Raise alarm string as Dying Gasp received.

```
OCT 23 11:46:13: alert : 1/7/1025: alarm_mgr: _laMgrLogMsg(): l=295 : tLineAlarm: 01: 7:01:01 Minor ONU
Down
Line 1/7/1/1/gpononu CAUSE: Dying Gasp received
```

- c Get the onuStatus as Inactive+DG:

```
zSH> onu status 7/1/1
```

ID	Onu	OperStatus	ConfigState	Download State	OLT Rx Pwr	ONT Rx Pwr	Distance (KM)	Gpon OnuStatus	AutoConfig State
1	1-7-1-1	Down	Inactive	None	error	error	error	Inactive+DG	Init

4- 6.1.7 ONU Manual Reboot Alarms

When an ONU is rebooted manually from ZMS or MXK, and the line-status-traps in the gpon-olt-onu-config profile has been set to enabled or auto, then the lineStatusChange trap will be sent and the ONU manual reboot alarm will be raised.R

Procedure:

Viewing ONU Manual Rebooted Alarm on an ONU

- 1 To enable the ONU manual rebooted alarm, change the line-status-traps field of the gpon-olt-onu-config profile to **auto or enabled**.

This example sets enabled for line-status-traps field:

```
zSH> update gpon-olt-onu-config line-status-traps=enabled 1-7-1-1/gpononu
gpon-olt-onu-config 1-7-1-1/gpononu
Record updated.
```

- 2 Create trap-destination profile to define a trap recipient the MXK-F will send traps to.

```
zSH> new trap-destination 1
trap-destination 1
Please provide the following: [q]uit.
trapdestination: -----> {0.0.0.0}: 172.16.80.39    the IP address of the SNMP trap server
communityname: -----> {}:
resendseqno: -----> {0}:
ackedseqno: -----> {0}:
traplevel: -----> {low}:
trapttype: -----> {0}:
trapadminstatus: -----> {enabled}:
gatewaytrapserveraddr: -> {none}:
.....
```

Save new record? [s]ave, [c]hange or [q]uit: s
New record saved.

3 Reboot this ONU:

```
zSH> onu reboot 7/1/1
```

4 User will see ONU reboot in the alarm or trap description:

- a Send lineStatusChange trap with trap value as inactive | onu rebooted. You can check the trap values in the trap recipient console in MIB browser.
- b Raise alarm string as onu rebooted.

```
OCT 23 09:52:32: alert : 1/7/1025: alarm_mgr: _laMgrLogMsg(): l=295 : tLineAlarm: 01: 7:01:01 Minor ONU
Down
Line 1/7/1/1/gpononu CAUSE: ONU rebooted
```

c Get the onuStatus as Inactive+onuRebooted:

```
zSH> onu status 7/1/1
```

ID	Onu	OperStatus	ConfigState	Download State	OLT Rx Pwr	ONT Rx Pwr	Distance (KM)	Gpon OnuStatus	AutoConfig State
1	1-7-1-1	Down	Inactive	None	error	error	error	Inactive+onuRebooted	Init

4- 6.2 GPON Traps

- [View or Change Trap Reporting Status on an ONU, page 91](#)
- [Change Alarm Severity for LineStatusTraps, page 92](#)

4- 6.2.1 View or Change Trap Reporting Status on an ONU

The conditions that cause asynchronous reporting traps can be controlled from the OLT through SNMP. The purpose of these controls is to reduce trap traffic between the MXK and ZMS to allow more information about critical or failing ONUs.

These three trap types are reported on an ONU:

- phy (PhysicalTraps): Includes the power status, battery status, and physical intrusion conditions as reported from the ONU through OMCI.

The options for the PhysicalTraps are:

- enable: The PhysicalTraps are sent.
- disable: The PhysicalTraps are not sent. Default value.

- ont (OntTraps): The status of LAN facing ports on the ONU (e.g. ethernet port LanLos).

The options for the OntTraps are:

- enable: The OntTraps are sent.

- disable: The OntTraps are not sent. Default value.
- line (LineStatusTraps): It is originated on the MXK, and reports the ONU line going up or down.

The options for the LineStatusTraps are:

- enable: The linkUp, linkDown, and lineStatusChange traps are sent.
- disable: The lineStatusTraps are not sent. Default value.
- auto: In this setting, the linkUp or linkDown traps are not sent, only the lineStatusChange trap is sent if the line is going down with dying gasp (presumably powered down), if there is a manual ONU reboot; or if the line is coming up.
- linkonly: Sends traps to set and clear ONU linkDown alarm only. Dying Gasp alarm is suppressed in this mode.

View the current reporting status of traps on ONU(s) with the **gpononu traps show [slot/olt/onu]** command.

```
zSH> gpononu traps show 1/4/2
Slot 1 olt 4
ONU      Name      PhysicalTraps  OntTraps  LineStatusTraps
-----
2        1-1-4-2    enabled       disabled  auto
```

Change the current reporting status of traps on ONU 1/4/2 with the **gpononu traps enable|disable|auto|linkonly slot/olt/onu phy|ont|line** command.

Note that only LineStatusTraps (i.e. line) has auto and linkonly options.

```
zSH> gpononu traps disable 1/4/2 phy
zSH> gpononu traps linkonly 1/4/2 line
```

Verify the settings in the show command:

```
zSH> gpononu traps show 1/4/2
Slot 1 olt 4
ONU      Name      PhysicalTraps  OntTraps  LineStatusTraps
-----
2        1-1-4-2    disabled      disabled  linkonly
```

4- 6.2.2 Change Alarm Severity for LineStatusTraps

Users can change the alarm severity for an ONT when the LineStatusTraps are sent. The LineStatusTraps includes linkUp, linkDown, and lineStatusChange traps.

To change the alarm severity of LineStatusTraps, use the “link-status-alarm-severity” field in the **gpon-olt-onu-config** profile. By default, the alarm severity is minor, it could be changed to major or critical.

The following example sets **LineStatusTraps** to *auto*, and sets the alarm severity level of **LineStatusTraps** to *major*:

```
zSH> update gpon-olt-onu-config 1-1-1-1
gpon-olt-onu-config 1-1-1-1/gpononu
```

```

Please provide the following: [q]uit.
serial-no-vendor-id: -----> {ZNTS}: ** read-only **
serial-no-vendor-specific: -----> {51974624}: ** read-only **
password: -----> {}:
auto-learn: -----> {enabled}:
power-level: -----> {0}:
us-ber-interval: -----> {5000}:
ds-ber-interval: -----> {5000}:
onu-added: -----> {true}:
omci-file-name: -----> {}:
ONU-Managed-Entity-Profile-name: -----> {zhone-2425}:
ONU-Generic-Assignments-Profile-name: -> {}:
physical-traps: -----> {disabled}:
ont-traps: -----> {disabled}:
line-status-traps: -----> {disabled}: auto
auto-upgrade: -----> {enabled}:
serial-no-vendor-specific-fsan: -----> {031911E0}: ** read-only **
use-reg-id: -----> {disabled}:
us-rx-power-monitoring-mode: -----> {monitoronly}:
us-rx-power-high-threshold: -----> {-10}:
us-rx-power-low-threshold: -----> {-30}:
dba-status-reporting: -----> {disabled}:
auto-config-state: -----> {init}: ** read-only **
link-status-alam-severity: -----> {minor}: major
.....
Save changes? [s]ave, [c]hange or [q]uit: s

```

4-7 BRIDGE RELATED

4-7.1 Bridge Loop Prevention

This section covers:

- [Bridge Loop Prevention Overview, page 93](#)
- [Configure Bridge Loop Prevention, page 95](#)
- [View Bridge Loop Detection Alarms, page 97](#)
- [View Bridge Loop Prevention on a Bridge Interface, page 98](#)
- [Unblock a Bridge Interface, page 99](#)

4-7.1.1 Bridge Loop Prevention Overview

This section covers:

- [Bridge Loop Prevention on Asymmetrical Bridges, page 94](#)
- [Bridge Loop Prevention on TLS Bridges, page 94](#)

Bridge loop prevention can be configured on either asymmetrical or TLS bridges to resolve certain incorrect MAC address behaviors.

4- 7.1.1: 1

Bridge Loop Prevention on Asymmetrical Bridges

Bridge loop prevention can be configured on the bridge path of the bridge interface when a MAC address on asymmetrical bridges is seen as coming in on both the uplink and the downlink.

When bridge loop behavior occurs and *block blockAsym* is configured on the uplink bridge interface with VLAN ID the system blocks the downlink after detecting this incorrect MAC address behavior.

After the blocked bridge receives an offending MAC address, the system sends a MAJOR alarm that indicates a bridge was blocked to prevent a loop. This alarm displays the bridge interface and the offending MAC address.

In this case, the blocked bridge interface must be unblocked with the **bridge unblock interface/type** command.

When bridge loop behavior occurs and *block blockAsymAuto* is configured on the uplink bridge interface with VLAN ID, the system initiates a series of three cyclic monitoring checks to see if the bridge loop condition is resolved. If the bridge loop condition is resolved, the bridge interface is automatically unblocked and a bridge loop clear alarm is sent.

If the condition is not resolved, the MAJOR alarm is cleared and a CRITICAL alarm is sent. In this case, the blocked bridge interface must be unblocked with the **bridge unblock interface/type** command.

4- 7.1.1: 2

Bridge Loop Prevention on TLS Bridges

Bridge loop prevention can be configured on the bridge path of a TLS bridge when a MAC address is seen as coming in on one TLS bridge and then as coming in on another TLS bridge.

When configuring the TLS network facing bridge, the bridge type *tls-gw must* be used. That way, when this behavior occurs, the network facing TLS bridge remains up and passing traffic. The subscriber facing bridge will be the one to be blocked.

When this behavior occurs and *block blockall* is configured on the VLAN ID of the TLS bridges, the system blocks the subscriber facing TLS bridge and then sends a MAJOR alarm describing that a second TLS bridge that saw the MAC address. The subscriber facing bridge is then blocked to prevent a loop.

When this occurs, the blocked bridge interface must be unblocked with the **bridge unblock interface/type** command.

When bridge loop behavior occurs and *block blockAsymAuto* is configured on the TLS bridge interface with VLAN ID, the system initiates a series of three cyclic monitoring checks to see if the bridge loop condition is resolved. If the bridge loop condition is resolved, the bridge interface is automatically unblocked and a bridge loop clear alarm is sent.

If the condition is not resolved, the MAJOR alarm is cleared and a CRITICAL alarm is sent. In this case, the blocked bridge interface must be unblocked with the **bridge unblock interface/type** command.

4- 7.1.2 Configure Bridge Loop Prevention

Procedure:

Configuring bridge loop prevention on asymmetric bridges with *blockAsym*

- 1 Create the asymmetrical bridging configuration.

Create an uplink bridge.

```
zSH> bridge add 1-a-4-0/eth uplink vlan 100
Adding bridge on 1-a-4-0/eth
Created bridge-interface-record ethernet4-100/bridge
Bridge-path added successfully
```

- 2 Modify the bridge path to enable asymmetrical bridge blocking using **bridge-path modify interface/type vlan default block blockAsym**.

```
zSH> bridge-path modify ethernet4-100/bridge vlan 100 default block blockAsym
Bridge-path ethernet4-100/bridge/3/100/0/0/0/0/0/0/0 has been modified
```



Note: Enter exactly the same command syntax to enable blocking on an existing bridge path. The existing bridge path will be overwritten, and blocking will be enabled.

View the bridge path.

```
zSH> bridge-path show
VLAN/SLAN  Bridge                               Address
-----
100 ethernet4-100/bridge                Default, Age: 3600, MCAST Age: 250, IGMP Query Interval: 0,
IGMP DSCP: 0, Flap Mode: Default, Block: Asym
```

- 3 Create a downlink bridge.

```
zSH> bridge add 1-6-1-501/gponport gtp 1 downlink-data vlan 100 tagged
Adding bridge on 1-6-1-501/gponport
Created bridge-interface-record 1-6-1-501-gponport-100/bridge
```

View the bridges.

```
zSH> bridge show
Type      Orig
VLAN/SLAN  VLAN/SLAN  Physical      Bridge          St  Table Data
-----
dwn-dat   Tagged 100   1/6/1/1/gpononu  1-6-1-501-gponport-100/bridge  DWN
upl       Tagged 100   1/a/4/0/eth     ethernet4-100/bridge          DWN S VLAN 100 default
2 Bridge Interfaces displayed
```

Procedure:

Configuring Bridge Loop Prevention on Asymmetric Bridges with *blockAsymAuto*

- 1 Create the asymmetrical bridging configuration.

Create an uplink bridge.

```
zSH> bridge add 1-a-2-0/eth uplink vlan 200 tagged
Adding bridge on 1-a-2-0/eth
Created bridge-interface-record ethernet2-200/bridge
```

Bridge-path added successfully

- 2 Modify the bridge path to enable asymmetrical bridge auto unblocking using **bridge-path modify interface/type vlan default block blockAsymAuto**.

```
zSH> bridge-path modify ethernet2-200/bridge vlan 200 default block blockAsymAuto
Bridge-path ethernet2-200/bridge/3/200/0/0/0/0/0/0/0 has been modified
```

View the bridge bath:

```
zSH> bridge-path show
VLAN/SLAN Bridge Address
-----
200 ethernet2-200/bridge Default, Age: 3600, MCAST Age: 250, IGMP Query Interval: 0,
IGMP DSCP: 0, Flap Mode: Default, Block: Asym/Auto
```

- 3 Create a downlink bridge on the same VLAN ID.

```
zSH> bridge add 1-1-6-0/eth downlink-data vlan 200 tagged
Adding bridge on 1-1-6-0/eth
Created bridge-interface-record 1-1-6-0-eth-200/bridge
```

- 4 View the bridges:

```
zSH> bridge show
Orig
Type VLAN/SLAN VLAN/SLAN Physical Bridge St Table Data
-----
dwn-dat Tagged 200 1/1/6/0/eth 1-1-6-0-eth-200/bridge DWN
upl Tagged 200 1/a/2/0/eth ethernet2-200/bridge UP S VLAN 200 default
2 Bridge Interfaces displayed
```

Procedure:

Configuring Bridge Loop Prevention on TLS Bridges with blockAll

- 1 Create the network facing TLS bridge with the bridge type *tls-gw*.

```
zSH> bridge add 1-a-4-0/eth tls-gw vlan 999
Adding bridge on 1-a-4-0/eth
Created bridge-interface-record ethernet4/bridge
Bridge-path added successfully
```

- 2 Modify the bridge path on the VLAN ID to enable TLS bridge blocking using **bridge-path modify interface/type vlan <vlanid> block blockasym**.

```
zSH> bridge-path modify vlan 999 block blockAll
Bridge-path /14/999/0/0/0/0/0/0/0/0 has been modified
```

- 3 View the bridge-path.

```
zSH> bridge-path show
VLAN/SLAN Bridge Address
-----
999 N/A VLAN, Age: 3600, MCAST Age: 250, IGMP Query Interval: 0,
IGMP DSCP: 0, Flap Mode: Fast, Block: All
```

- 4 Create the subscriber facing TLS bridges.

```
zSH> bridge add 1-6-12-0/eth tls vlan 999
Adding bridge on 1-6-12-0/eth
Created bridge-interface-record 1-6-12-0-eth/bridge
```

```
zSH> bridge add 1-6-13-0/eth tls vlan 999
Adding bridge on 1-6-13-0/eth
Created bridge-interface-record 1-6-13-0-eth/bridge
```

Procedure:

Configuring Bridge Loop Prevention on TLS Bridges with blockAllAuto

- 1 Create the network facing TLS bridge with the *tls-gw* bridge type.

The network facing TLS bridge must be configured with the *tls-gw* bridge type.

```
zSH> bridge add 1-a-3-0/eth tls-gw vlan 700
Adding bridge on 1-a-3-0/eth
Created bridge-interface-record ethernet3/bridge
Bridge-path added successfully
```

- 2 Modify the bridge path on the VLAN ID to enable TLS bridge blocking using **bridge-path modify interface/type vlan <vlanid> block blockasym**.

```
zSH> bridge-path modify vlan 700 block blockAllAuto
Bridge-path /14/700/0/0/0/0/0/0/0/0 has been modified
```

- 3 View the bridge-path.

```
zSH> bridge-path show
VLAN/SLAN Bridge
```

VLAN/SLAN Bridge	Address
700 N/A	VLAN, Age: 3600, MCAST Age: 250, IGMP Query Interval: 0, IGMP DSCP: 0, Flap Mode: Fast, Block: All/Auto

- 4 Create the subscriber facing TLS bridges.

```
zSH> bridge add 1-6-1-0/eth tls vlan 700
Adding bridge on 1-6-1-0/eth
Created bridge-interface-record 1-6-1-0-eth/bridge
```

```
zSH> bridge add 1-6-2-0/eth tls vlan 700
Adding bridge on 1-6-2-0/eth
Created bridge-interface-record 1-6-2-0-eth/bridge
```

4- 7.1.3

View Bridge Loop Detection Alarms

Procedure:

Viewing Loop Detected Alarms

- 1 On the console, the following alarm appears when a loop is detected.

```
zSH> JUN 22 02:12:40: alert : 1/a/1093: bridge: BridgeTrapSend(): l=1223: tBridgeMain: Bridge Loop detected on 1-10-1-501-gponport-100: (0/100/00:15:C5:3A:A3:B8) .
```

- 2 Enter **alarm show** to display the loop detection alarm at the system level.

```
zSH> alarm show
```

```

***** Central Alarm Manager *****
  ActiveAlarmCurrentCount :13
  AlarmTotalCount :16
  ClearAlarmTotalCount :3
  OverflowAlarmTableCount :0
ResourceId AlarmType AlarmSeverity
-----
1-a-2-0/eth linkDown critical
1-a-3-0/eth linkDown critical
1-a-6-0/eth linkDown critical
1-a-7-0/eth linkDown critical
1-a-8-0/eth linkDown critical
1-a-9-0/eth linkDown critical
1-a-10-0/eth linkDown critical
1-a-11-0/eth linkDown critical
1-10-2-0/gponolt linkDown critical
1-10-3-0/gponolt linkDown critical
1-10-4-0/gponolt linkDown critical
system not_in_redundant_mode major
1-10-1-501-gponport-100 bridgeLoopDetect 0/100/00:15:C5:3A:A3:B8 major

```

4- 7.1.4 View Bridge Loop Prevention on a Bridge Interface

All bridges that are blocked by bridge loop protection, RSTP, or EAPS are displayed with the **bridge show blk** command.



Note: The **bridge show blk** command displays bridges that are normally blocked in EAPS or RSTP configurations.

Bridges configured with the *block blockassym* variable for bridge loop prevention will display the MAC address as well as the bridge interface name. Bridges blocked as a normal part of RSTP or EAPS configurations do not display MAC addresses and should remain blocked. Do not unblock the RSTP and EAPS interfaces.

Procedure:

```

zSH> bridge show blk
No Bridge Interfaces found.

```

Finding Bridges That Were Blocked By Bridge Loop Protection

Enter the **bridge show blk** command to view blocked bridges.

This example confirms that there are no existing blocked bridges.

This example confirms that a blocked bridge exists.

A bridge loop alarm appears in the console window.

```

zSH> AUG 05 19:38:38: alert : 1/b/1062: bridge: BridgeTrapSend():
l=1233: tBridgeMain: Bridge Loop detected on
1-9-4-0-eth-100:(0/100/00:00:00:00:04) .
AUG 05 19:38:42: alert : 1/a/1093: bridge: BridgeTrapSend(): l=1233:
tBridgeMain: Bridge Loop detected on
1-9-4-0-eth-100:(0/100/00:00:00:00:04) .

```

The **bridge show blk** command displays a blocked bridge.

```
zSH> bridge show blk
      Orig
Type  VLAN/SLAN  VLAN/SLAN  Physical          Bridge          St  Table Data
-----
dwn           Tagged 100  1/9/4/0/eth      1-9-4-0-eth-100/bridge  BLK  A 00:00:00:00:00:04
1 Bridge Interfaces displayed
```

4- 7.1.5 Unblock a Bridge Interface

The syntax for unblocking a blocked bridge interface is:

```
bridge unblock <interface>/<type> |
  [slot <slotNum>]
  [vlan <vlanId>]
  [slan <slanId>]
  [vlan-count <value>]
  [mvr [<mvrVlan>]]
  [secure]
  [uplink | downlink | intralink | tls | rlink | pppoa | wire |
  mvr | user | downlink-video | downlink-data | downlink-pppoe |
  downlink-p2p | downlink-voice | downlink-upmcast | ipob-tls |
  ipob-uplink | ipob-downlink]
  [verbose]
```

Unblocks bridge interfaces which have been blocked due to bridge storm detection (BSD) and due to bridge loop detection.

Where:

<interface>/<type>

The interface can be a bridge, GPON OLT, Ethernet Port, etc.

Wildcard formats are supported. The interface must come immediately after "bridge unblock".

slot <slotNum>

Process all bridge interfaces for ports in the specified slot. <slotNum> may be a single number, a bracketed list containing comma-separated numbers or a dash-separated number range or a combination of both.

vlan <vlanId>

Process all bridge interfaces for the specified VLAN. <vlanId> may be a single number, a bracketed list containing comma-separated numbers or a dash-separated number range or a combination of both.

vlan-count <count>

Process bridges that have VLAN ID values in the range <vlan> to <vlan+count>

slan <slanId>

Process all bridge interfaces for the specified SLAN. <slanId> may be a single number, a bracketed list containing comma-separated numbers or a dash-separated number range or a combination of both.

secure

Process secure bridges.

mvr [<mvrVlan>]

Process all bridge interfaces associated with the given MVR vlan. <mvrVlan> may be a single number, a bracketed list containing comma-separated numbers or a dash-separated number range or a combination of both. If no MVR vlan or 0 is entered, all MVR related bridges are processed.

uplink | downlink | intralink | tls | rlink | pppoa | wire |
mvr | user | downlink-video | downlink-data | downlink-pppoe |

```
downlink-p2p | downlink-voice | downlink-upmcast | ipob-tls |  
ipob-uplink | ipob-downlink]  
    Process bridges of the specified bridge-type.  Multiple bridge  
    types can be specified.  
verbose  
    display "unblock" operation status
```

Procedure:

Unblocking the Bridge Interface

For example, to unblock a bridge that is blocked because of loop prevention using the bridge interface enter.

```
zSH> bridge unblock 1-10-1-501-gponport/bridge
```

The following type of information is displayed in the console window.

```
zSH> JUN 22 02:14:15: alert : 1/a/1027: bridge: BridgeTrapSend(): l=1233: tCliInit0: Bridge Loop Alarm  
for 1-10-1-501-gponport-100 cleared.
```

To unblock a bridge using the slot number and VLAN ID enter:

```
zSH> bridge unblock slot 5 vlan 100
```

To unblock a bridge using the VLAN ID enter:

```
zSH> bridge unblock vlan 100
```

4- 7.2 Bridge storm protection

This section describes the packet rule for bridge storm protection:

- [Bridge storm protection overview, page 100](#)
- [Default packet rule filters \(bridgestormdetect\), page 101](#)
- [Case 1: bridgestormdetect packet rule for discard, page 104](#)
- [Case 2: bridgestormdetect packet rule for discard + alarm, page 104](#)
- [Case 3: bridgestormdetect packet rule for discard + alarm + block, page 105](#)
- [Modify the default bridgestormdetect rules, page 107](#)
- [View detected packets statistics, page 109](#)
- [Unblock a bridge, page 112](#)

4- 7.2.1 Bridge storm protection overview

The **bridgestormdetect** filter provides a way to analyze packets by capturing discarded packets when a certain threshold is reached and is configured only on the ingress of a bridge interface.

This packet rule will capture the first N packets after the target packets-per-second threshold is reached. Since all discarded packets are not captured, and there may be multiple interfaces with a bridge storm, some

packets on the first interface with a bridge storm are captured, then some packets on the next interface with a bridge storm are captured, and so on.

The rule **add bridgestormdetect** command syntax is:

```
rule add bridgestormdetect <group/member> <discard | discardandalarm | discardandalarmandblock>
<packets-per-second> [<consecutive-seconds>]
```

If the rule **add bridgestormdetect** command is configured with *discard*, only the *packets-per-seconds* is set.

If the rule **add bridgestormdetect** command is configured with *discardandalarm* or *discardandalarmandblock*, both the *packets-per-seconds* and the *consecutive-seconds* fields must be set.

If the card reboots, the captured packets are lost.

4- 7.2.2

Default packet rule filters (bridgestormdetect)

Currently, default packet rules are created only for the **bridgestormdetect** filter.

The default **bridgestormdetect** rule is configured for *discard+alarm+block* with defined auto-enable intervals.

4- 7.2.2: 1

Rules for default packet rule bridgestormdetect

The rules for the default **bridgestormdetect** packet rule filters are:

- A default packet rule filter for **bridgestormdetect** is automatically defined and applied to *downlink*, *tls*, and *wire* bridge interfaces when a **bridgestormdetect** packet rule is not currently applied.
- If an eligible bridge type is configured with packet rules other than **bridgestormdetect**, the default **bridgestormdetect** rule is applied.
- The default packet rules are configured in group *0*.
- The group/member *0/1* **bridgestormdetect** rule is automatically applied to *downlink* bridge interfaces and rule *0/2* is automatically applied to *tls* and *wire* bridge interfaces.
- The default **bridgestormdetect** rule is not applied to other bridge types.

The default rules are always displayed with the **rule show** command:

```
zSH> rule show
-----
Group/Member                                     Type Value(s)
-----
Default dwn (0/1)                               bridgestormdetect discard+alarm+block pps 30 cs 30
                                                auto-enable-interval (def) 300 600 1200
Default tls/wire (0/2)                          bridgestormdetect discard+alarm+block pps 100 cs 30
                                                auto-enable-interval (def) 300 600 1200
2 record(s) found
```

The **rule showuser default** command displays bridges with the default packet rule **bridgestormdetect**.

```
zSH> rule showuser default
      Group/Member                                Type           IfIndex  IfAddr
-----
(ingress)  Default dwn (0/1)                             bridgestormdetect  1359  1-4-1-303-gponport-100/bridge
(ingress)  Default dwn (0/1)                             bridgestormdetect  1362  1-4-1-501-gponport/bridge
2 record(s) found
```

4- 7.2.2: 2 Disable the bridgestormdetect packet rules

The default **bridgestormdetect** rules can be disabled by entering the *disdefpktrules* keyword to the **options** parameter in **system 0**. Both default packet rules are disabled.

The default rules *0/1* and *0/2* cannot be deleted with the **rule delete** command.

```
zSH> rule delete 0/1
Not allowed to delete from default group index 0
```

Procedure:

Disabling the default bridgestormdetect packet rules

Update the **system 0** file.

```
zSH> update system 0
system 0
Please provide the following: [q]uit.
syscontact: -----> {}:
sysname: -----> {}:
syslocation: -----> {}:
enableauthtraps: -----> {disabled}:
setserialno: -----> {0}:
zmsexists: -----> {false}:
zmsconnectionstatus: --> {inactive}:
zmsipaddress: -----> {0.0.0.0}:
configsyncexists: -----> {false}:
configsyncoverflow: ---> {false}:
configsyncpriority: ---> {high}:
configsyncaction: -----> {noaction}:
configsyncfilename: ---> {}:
configsyncstatus: -----> {syncinitializing}:
configsyncuser: -----> {}:
configsyncpasswd: -----> {** private **}: ** read-only **
numshelves: -----> {1}:
shelvesarray: -----> {}:
numcards: -----> {3}:
ipaddress: -----> {0.0.0.0}:
alternateipaddress: ---> {0.0.0.0}:
countryregion: -----> {us}:
primaryclocksource: ---> {0/0/0/0/0}:
ringsource: -----> {internalringsourcelabel}:
revertiveclocksource: -> {true}:
voicebandwidthcheck: --> {false}:
alarm-levels-enabled: -> {critical+major+minor+warning}:
userauthmode: -----> {local}:
radiusauthindex: -----> {0}:
secure: -----> {disabled}:
webinterface: -----> {enabled}:
```

```

options: -----> {NONE(0)}: disdefpktrules <-----
reservedVlanIdStart: --> {0}:
reservedVlanIdCount: --> {0}:
snmpVersion: -----> {snmpv2}
persistentLogging: ----> {disabled}
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.

```

Procedure:**Re-enabling the default bridgestormdetect packet rule**

Update **system 0** by entering the *none 0* keyword to the **options** parameter.

```

zSH> update system 0
system 0
Please provide the following: [q]uit.
syscontact: -----> {}:
sysname: -----> {}:
syslocation: -----> {}:
enableauthtraps: -----> {disabled}:
setserialno: -----> {0}:
zmsexists: -----> {false}:
zmsconnectionstatus: --> {inactive}:
zmsipaddress: -----> {0.0.0.0}:
configsyncexists: ----> {false}:
configsyncoverflow: ---> {false}:
configsyncpriority: ---> {high}:
configsyncaction: ----> {noaction}:
configsyncfilename: ---> {}:
configsyncstatus: ----> {syncinitializing}:
configsyncuser: -----> {}:
configsyncpasswd: -----> {** private **}: ** read-only **
numshelves: -----> {1}:
shelvesarray: -----> {}:
numcards: -----> {3}:
ipaddress: -----> {0.0.0.0}:
alternateipaddress: ---> {0.0.0.0}:
countryregion: -----> {us}:
primaryclocksource: ---> {0/0/0/0/0}:
ringsource: -----> {internalringsourcecelabel}:
revertiveclocksource: -> {true}:
voicebandwidthcheck: --> {false}:
alarm-levels-enabled: -> {critical+major+minor+warning}:
userauthmode: -----> {local}:
radiusauthindex: -----> {0}:
secure: -----> {disabled}:
webinterface: -----> {enabled}:
options: -----> {disdefpktrules}: none 0 <-----
reservedVlanIdStart: --> {0}:
reservedVlanIdCount: --> {0}:
snmpVersion: -----> {snmpv2}
persistentLogging: ----> {disabled}
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.

```

4- 7.2.3

Case 1: bridgestormdetect packet rule for discard

Procedure:

Configuring a bridge discard

Configuring the *bridgestormdetect* packet rule for *discard*, means that when the packets exceed the packets-per-second threshold, the overall traffic on the bridge will be limited.

- 1 Enter the **rule add** command to create the *bridgestormdetect* packet rule for *discard* and set the packets-per-second threshold.

```
zSH> rule add bridgestormdetect 1/1 discard pps 20
Created packet-rule-record 1/1 (bridgestormdetect)
```

Verify the rule.

```
zSH> rule show
```

Group/Member	Type	Value(s)
Default dwn (0/1)	bridgestormdetect	discard+alarm+block pps 30 cs 30 auto-enable-interval (def) 300 600 1200
Default tls/wire (0/2)	bridgestormdetect	discard+alarm+block pps 100 cs 30 auto-enable-interval (def) 300 600 1200
1/1	bridgestormdetect	discard pps 20

3 record(s) found

- 2 Apply the rule to a bridge interface.

```
zSH> bridge add 1-6-1-0/eth downlink vlan 100 tagged ipktrule 1
Adding bridge on 1-6-1-0/eth
Created bridge-interface-record 1-6-1-0-eth-100/bridge
```

Verify the bridge.

```
zSH> bridge show
```

Orig	Type	VLAN/SLAN	VLAN/SLAN	Physical	Bridge	St	Table	Data
dwn		Tagged 100	1/6/1/0/eth	1-6-1-0/eth	1-6-1-0-eth-100/bridge	UP	D	00:01:47:31:dc:1a

1 Bridge Interfaces displayed

Verify the rule *1/1* is applied to the bridge.

```
zSH> rule showuser
```

Group/Member	Type	IfIndex	IfAddr
1/1	bridgestormdetect	1354	1-6-1-0-eth-100/bridge (ingress)

1 record(s) found

4- 7.2.4

Case 2: bridgestormdetect packet rule for discard + alarm

Procedure:

Configuring a rule for discard + alarm

Configuring the *bridgestormdetect* packet rule for *discard + alarm*, means that when the packets exceeds the packets-per-second threshold over a

configured number of seconds, the overall traffic on the bridge will be limited and a bridge storm alarm will be sent. When the bridge storm is cleared, a clearing alarm is sent.

- 1 Enter the **rule add** command to create the *bridgestormdetect* packet rule for *discard + alarm*.

```
zSH> rule add bridgestormdetect 2/1 discardandalarm pps 20 cs 10
Created packet-rule-record 2/1 (bridgestormdetect)
```

Verify the rule.

```
zSH> rule show
```

Group/Member	Type	Value(s)
Default dwn (0/1)	bridgestormdetect	discard+alarm+block pps 30 cs 30 auto-enable-interval (def) 300 600 1200
Default tls/wire (0/2)	bridgestormdetect	discard+alarm+block pps 100 cs 30 auto-enable-interval (def) 300 600 1200
1/1	bridgestormdetect	discard pps 20
2/1	bridgestormdetect	discard+alarm pps 20 cs 10

4 record(s) found

- 2 Apply the rule to a bridge interface.

```
zSH> bridge add 1-6-2-0/eth downlink vlan 400 tagged ipktrule 2
Adding bridge on 1-6-2-0/eth
Created bridge-interface-record 1-6-2-0-eth-400/bridge
```

Verify the bridge.

```
zSH> bridge show
```

Type	Orig	VLAN/SLAN	Physical	Bridge	St	Table Data
dwn	Tagged 100	1/6/1/0/eth	1-6-1-0-eth-100/bridge	UP	D 00:01:47:31:dc:1a	
dwn	Tagged 400	1/6/2/0/eth	1-6-2-0-eth-400/bridge	UP		

2 Bridge Interfaces displayed

Verify the rule 2/1 is applied to the bridge.

```
zSH> rule showuser
```

Group/Member	Type	IfIndex	IfAddr
1/1	bridgestormdetect	1354	1-6-1-0-eth-100/bridge (ingress)
2/1	bridgestormdetect	1356	1-6-2-0-eth-400/bridge (ingress)

2 record(s) found

4- 7.2.5

Case 3: bridgestormdetect packet rule for discard + alarm + block

Configuring the *bridgestormdetect* packet rule for *discard + alarm + block*, means that when the packets exceeds the packets-per-second threshold over a configured number of seconds, the overall traffic on the bridge will be completely blocked and a bridge storm alarm will be sent. When the bridge storm is cleared, a clearing alarm is sent.

The *bridgestormdetect* packet rule for *discard + alarm + block* automatically creates an **auto-enable-interval** parameter configured for 300 seconds, 600 seconds, and 1200 seconds. The first value indicates that the bridge will automatically unblock after 300 seconds (five minutes). The second value indicates that when the next bridge storm occurs, the bridge will unblock after 600 seconds (ten minutes), and after the third bridge storm detection, the bridge will unblock after 1200 seconds (20 minutes). After the third time, if the storm continues, the bridge remains blocked and must be unblocked through the CLI. See [Unblock a bridge, page 112](#).

Procedure:

Configuring a rule for discard + alarm + block

- 1 Enter the **rule add** command to create the *bridgestormdetect* packet rule for *discard + alarm + block*.

```
zSH> rule add bridgestormdetect 3/1 discardandalarmandblock pps 20 cs 10
Created packet-rule-record 3/1 (bridgestormdetect)
```

Verify the rule.

```
zSH> rule show
```

Group/Member	Type	Value(s)
Default dwn (0/1)	bridgestormdetect	discard+alarm+block pps 30 cs 30 auto-enable-interval (def) 300 600 1200
Default tls/wire (0/2)	bridgestormdetect	discard+alarm+block pps 100 cs 30 auto-enable-interval (def) 300 600 1200
1/1	bridgestormdetect	discard pps 20
2/1	bridgestormdetect	discard+alarm pps 20 cs 10
3/1	bridgestormdetect	discard+alarm+block pps 20 cs 10 auto-enable-interval (def) 300 600 1200

5 record(s) found

- 2 Apply the rule to a bridge interface.

```
zSH> bridge add 1-6-3-0/eth downlink vlan 500 tagged ipktrule 3
Adding bridge on 1-6-3-0/eth
Created bridge-interface-record 1-6-3-0-eth-500/bridge
```

Verify the bridge.

```
zSH> bridge show
```

Type	Orig	VLAN/SLAN	VLAN/SLAN	Physical	Bridge	St	Table	Data
dwn	Tagged	100	1/6/1/0/eth	1-6-1-0-eth-100/bridge	UP	D	00:01:47:31:dc:1a	
dwn	Tagged	400	1/6/2/0/eth	1-6-2-0-eth-400/bridge	DWN			
dwn	Tagged	500	1/6/3/0/eth	1-6-3-0-eth-500/bridge	DWN			

3 Bridge Interfaces displayed

Verify the rule 3/1 is applied to the bridge.

```
zSH> rule showuser
```

Group/Member	Type	IfIndex	IfAddr
1/1	bridgestormdetect	1354	1-6-1-0-eth-100/bridge (ingress)
2/1	bridgestormdetect	1356	1-6-2-0-eth-400/bridge (ingress)

3 record(s) found 3/1 bridgestormdetect 1357 1-6-3-0-eth-500/bridge (ingress)

4- 7.2.6 **Modify the default bridgestormdetect rules**

The default parameters in the **bridgestormdetect** rule can be modified by the user.

The syntax for the **rule modify bridgestormdetect** is:

```
rule modify bridgestormdetect <group/member>
  [<discard | discardandalarm | discardandalarmandblock >]
  [pps <packets-per-second>] [cs <consecutive-seconds>]
  [auto-enable-interval <param0> [<param1> [<param2>]]]
```

The **rule modify** command allows you to disable or change the *auto-enable-interval* values as well as the threshold *pps* and *cs*.

4- 7.2.6: 1 **Modify default bridgestormdetect pps and cs values**

The **bridgestormdetect** *discardandalarmandblock* packet rule blocks the bridge interface when packets exceed a level configured by the *pps* over time set by the *cs* value.

The default values for *pps* and *cs* in default *0/1* and *0/2* differ due to higher normal traffic on *tls* and *wire* bridges.

The range for consecutive alarm seconds values is 5 to 30 seconds.

Procedure:

Modifying default pps and cs values

- 1 Enter the **rule modify bridgestormdetect** command to change the default values.

```
zSH> rule modify bridgestormdetect 0/1 discardandalarmandblock pps 25 cs 25
Modified packet-rule-record 0/1 (bridgestormdetect)
```

- 2 Verify the changes.

```
zSH> rule show
-----
Group/Member                                Type Value(s)
-----
Default dwn (0/1)                            bridgestormdetect discard+alarm+block pps 25 cs 25
auto-enable-interval (def) 300 600 1200
Default tls/wire (0/2)                        bridgestormdetect discard+alarm+block pps 100 cs 30
auto-enable-interval (def) 300 600 1200
```

2 record(s) found

4- 7.2.6: 2 **Default bridgestormdetect auto-enable-interval values**

The default *auto-disable-interval* parameter sets the time in seconds when the bridge is unblocked and allowed to pass traffic at *300*, *600*, and *1200* seconds.

When a bridge interface is blocked the first time, it is unblocked after 300 seconds. The second time, if the storm continues, the interface is unblocked

after 600 seconds. The third time, if the storm continues, the bridge interface is unblocked at 1200 seconds. After the third time, if the storm continues, the bridge remains blocked and must be unblocked through the CLI. See [Unblock a bridge, page 112](#).

The *auto-enable-interval* times in seconds can be modified or disabled.

Procedure:

Modifying the auto-enable-interval values

- 1 Enter the **rule modify bridgestormdetect** command to change the default values for *auto-enable-interval*.

```
zSH> rule modify bridgestormdetect 0/1 discardandalarmandblock pps 25 cs 25
auto-enable-interval 60 300 600
Modified packet-rule-record 0/1 (bridgestormdetect)
```

- 2 Verify the changes.

```
zSH> rule show
      Group/Member                                     Type Value(s)
-----
      Default dwn (0/1)                               bridgestormdetect discard+alarm+block pps 25 cs 25
                                                         auto-enable-interval 60 300 600
      Default tls/wire (0/2)                           bridgestormdetect discard+alarm+block pps 100 cs 30
                                                         auto-enable-interval (def) 300 600 1200
2 record(s) found
```

Procedure:

Disabling the default auto-enable-interval

Entering the value *0* to the first field of the **auto-enable-interval** parameter disables the re-enable traffic feature of **bridgestormdetect**.

- 1 Enter the **rule modify bridgestormdetect** command to disable the *auto-enable-interval*.

```
zSH> rule modify bridgestormdetect 0/2 discardandalarmandblock pps 100 cs 30
auto-enable-interval 0
Modified packet-rule-record 0/2 (bridgestormdetect)
```

The bridge interface will be blocked and must be unblocked through CLI. See [Unblock a bridge on page 112](#)

- 2 Verify the change.

```
zSH> rule show
      Group/Member                                     Type Value(s)
-----
      Default dwn (0/1)                               bridgestormdetect discard+alarm+block pps 25 cs 25
                                                         auto-enable-interval 60 300 600
      Default tls/wire (0/2)                           bridgestormdetect discard+alarm+block pps 100 cs 30
                                                         auto-enable-interval 0
2 record(s) found
```

4- 7.2.7 View detected packets statistics

Procedure:

Viewing detected packets statistics

The **bridge stats interface/type** command sorts and displays the detected packets into unicast, multicast, or broadcast and displays the number of alarms sent.

```
zSH> bridge stats 1/9/1/4/gpononu
Interface                               Received Packets      Transmitted Packets      Storm Detect
Packets      Byte Counters
Name
Alarm  Received  Transmitted
1-9-1-304-gponport-1001/bridge          0      0      0          0      0      0      0      0      0      0
0      0      0
1-9-1-904-gponport-998/bridge          0      0      49         227     529     3883     0      0      0      0
0      360     169k
```

4- 7.2.8 View the packets

Use the **bridge capture show** command to view which interfaces had a bridge storm and how many packets were captured.

The Packet column shows the number of packets captured, and the Count column displays the number of packets allowed to be captured.

Each interface having a bridge storm will capture fewer packets. The first interface that has a bridge storm can capture eight packets, the next interface that has a bridge storm can capture six packets, and so on.

Procedure:

Viewing the packets

You must connect to the line card before using the **bridge capture show** command.

- 1 Connect to the line card by entering **connect** and the slot number of the line card.

```
zSH> connect 9
Connecting to shelf: 1, slot: 3 .....
Connection established.
```

- 2 Enter the **bridge capture show** command to view which interfaces had a bridge storm and how many packets were captured.

```
1/9-qzSH> bridge capture show
Interface Name      Packet Count
-----
1-9-1-304-gponport-1001      8/ 8
<Queue Empty>              0/ 6
<Queue Empty>              0/ 4
<Queue Empty>              0/ 2
```

- 3 Enter the **bridge capture dump interface/type** command to view the captured packets.

Traps and Alarms on the MXK-F

```
1/9-zSH> bridge capture dump 1-9-1-304-gponport-1001 # 1-9-1-304-gponport-1001, IfIndex = 1111 # tick =
0x00000034822d3bf4
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 "..`....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ".'......W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 58 c0 09 32 58 c0 ">.....X..2X."
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x00000034822d52cf
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 "..`....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ".'......W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 9e 78 03 e6 9e 78 ">.....x...x"
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x00000034822d6800
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 "..`....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ".'......W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 74 79 70 65 20 3d ">.....type ="
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x00000034822d9677
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 "..`....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ".'......W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 64 64 72 36 20 3d ">.....ddr6 ="
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x00000034822e9b03
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 "..`....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ".'......W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 63 61 64 64 72 33 ">.....caddr3"
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x00000034822f55b7
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 "..`....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
```

```

00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ". '.....W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 00 00 00 00 00 00 ">....."
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x000000348bb7e71e
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 ". `....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ". '.....W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 00 00 00 00 00 00 ">....."
# 1-9-1-304-gponport-1001, IfIndex = 1111
# tick = 0x000000348bb89f5d
00000000: 33 33 00 01 00 02 00 00 00 00 01 81 00 03 e9 "33....."
00000010: 86 dd 60 00 00 00 00 40 11 01 fe 80 00 00 00 00 ". `....@....."
00000020: 00 00 02 15 c5 ff fe 57 b6 3e ff 02 00 00 00 00 ".....W.>....."
00000030: 00 00 00 00 00 00 01 00 02 02 22 02 23 00 40 ".....".#.@"
00000040: 14 5d 01 d1 4b 90 00 01 00 0e 00 01 00 01 1c ed ".].K....."
00000050: e7 34 00 15 c5 57 b6 3e 00 06 00 08 00 17 00 18 ".4...W.>....."
00000060: 00 27 00 1f 00 08 00 02 ff ff 00 03 00 0c c5 57 ". '.....W"
00000070: b6 3e 00 00 0e 10 00 00 15 18 15 d0 0a 5d 15 d0 ">.....].."

```



Note: For customers who want to view output in a packet capture tool such as Wireshark, copy the output into a notepad file, then run the `text2pcap` application. The output should then be in a viewable state.

- 4 Enter the **bridge capture clear -all** command to clear all the interfaces with bridge storms, then verify the output with the **bridge capture show** command.

You can also enter the bridge capture clear *interface/type* command to clear individual bridge interfaces.

```
1/9-zSH> bridge capture clear -all
```

```
1/9-zSH> bridge capture show
```

Interface Name	Packet Count
<Queue Empty>	0/ 8
<Queue Empty>	0/ 6
<Queue Empty>	0/ 4
<Queue Empty>	0/ 2

- 5 Close the connection to the line card by entering the **exit** command.

```
zSH> exit
Connection closed.
```

4- 7.2.9 Unblock a bridge

Procedure:

Unblocking a bridge

Use the **bridge unblock interface/type** command to unblock a blocked bridge interface configured with the **bridgestormdetect** packet rule *discard + alarm + block*.

Enter the **bridge unblock** command.

```
zSH> bridge unblock 1-6-1-0-eth-100/bridge
```

4- 8 MONITORING MXK-F MANAGEMENT CARDS

The MXK-F14xx and MXK-F219 chassis each provide two slots, *m1* and *m2*, for redundant management cards that provide the controller and database functions for the chassis.

4- 8.1 Redundancy Status Information

To display summary redundancy status, enter the **showredundancy** command:

```
zSH> showredundancy
Redundancy status for card 01:m1 - Safe, all services have redundant peers
01:m1 is active storage
01:m2 is standby storage
```

To display detailed redundancy status, enter the **showredundancy -d** command.

```
zSH> showredundancy -d
Redundancy status for card 01:m1 -
```

Taskname	Active Addr	Standby Addr	Stdby Ready?
InfoServer	01:m1:02	01:m2:02	Yes
RdsServer	01:m1:03	01:m2:03	Yes
tNumSrv	01:m1:1043	01:m2:1032	Yes
tShelfRR	01:m1:1044	01:m2:1033	Yes
tMAXTask	01:m1:1045	01:m2:1034	Yes
zCardRed	01:m1:26	01:m2:26	Yes
trapSrv	01:m1:25	01:m2:25	Yes
tFTD	01:m1:67	01:m2:67	Yes
TadSrvTask	01:m1:1047	01:m2:1036	Yes
ifcftask	01:m1:78	01:m2:78	Yes
L-RR-1/m1	01:m1:79	01:m2:79	Yes
_RedSpawnSvrTask	01:m1:1051	01:m2:1040	Yes
LogServer	01:m1:08	01:m2:08	Yes
gponOltMibHdlr	01:m1:1078	01:m2:1055	Yes
DhcpServerTask	01:m1:90	01:m2:90	Yes
RlyAlmHdlr	01:m1:1084	01:m2:1042	Yes
tIPSIM	01:m1:75	01:m2:75	Yes
tEtherOamRp	01:m1:83	01:m2:83	Yes

bridgeMibHdlr	01:m1:1087	01:m2:1062	Yes
tDS1RP	01:m1:1086	01:m2:1061	Yes

Safe, all services have redundant peers

01:m1 is active storage

01:m2 is standby storage

5

CHAPTER 5 STATISTICS ON THE MXK-F

This chapter provides statistics commands for the MXK-F:

- [View Runtime Statistics on the MXK-F, page 115](#)
- [View Bridge Statistics, page 117](#)
- [GPON OMCI \(ONT\) and PON Statistics, page 136](#)

5-1 VIEW RUNTIME STATISTICS ON THE MXK-F

The **card stats** command displays runtime statistics for the MXK-F14xx device.

```
zSH> card stats
----- cpu % utilization ----- memory (KB)----- Card Mem  uptime
slot idle usage high serv frmwrk low % Used Tot Peak Avail Status ddd:hh:mm:ss s/w version
=====
m1* 97 3 0 1 0 1 21.25 966358 209937 761003 1-OK 0:21:07:01 MXK 3.1.1.215
```

The **card stats all** command displays information for all the cards.

```
zSH> card stats all
----- cpu % utilization ----- memory (KB)----- Card Mem  uptime
slot idle usage high serv frmwrk low %Used Tot Peak Avail Status ddd:hh:mm:ss s/w version
=====
1 92 8 3 4 0 5 22.58 939295 212078 727226 1 - OK 0:20:56:58 MXK 3.1.1.215
2 91 9 3 4 0 5 22.54 939295 211819 727577 1 - OK 0:20:56:29 MXK 3.1.1.215
3 92 8 3 4 0 5 22.49 939296 211257 728049 1 - OK 0:20:56:21 MXK 3.1.1.215
4 92 8 3 4 0 5 22.52 939295 211505 727800 1 - OK 0:20:56:30 MXK 3.1.1.215
5 92 8 3 4 0 5 22.63 939294 212588 726716 1 - OK 0:20:47:42 MXK 3.1.1.215
6 92 8 3 4 0 5 22.66 939293 212854 726448 1 - OK 0:20:47:07 MXK 3.1.1.215
7 92 8 3 4 0 5 22.67 939293 212936 726367 1 - OK 0:20:47:18 MXK 3.1.1.215
8 92 8 3 4 0 5 22.67 939294 213069 726318 1 - OK 0:20:47:34 MXK 3.1.1.215
9 92 8 3 4 0 6 22.64 939292 212670 726631 1 - OK 0:20:35:27 MXK 3.1.1.215
10 92 8 3 4 0 6 22.66 939294 212878 726425 1 - OK 0:20:35:26 MXK 3.1.1.215
11 92 8 3 4 0 6 22.68 939293 212999 726303 1 - OK 0:20:35:40 MXK 3.1.1.215
12 92 8 3 4 0 6 22.68 939291 213023 726278 1 - OK 0:20:34:56 MXK 3.1.1.215
13 92 8 3 4 0 5 22.70 939292 217150 726053 1 - OK 0:20:07:41 MXK 3.1.1.215
14 92 8 3 4 0 6 22.70 939292 216083 726068 1 - OK 0:20:07:19 MXK 3.1.1.215
m1* 97 3 0 1 0 1 21.25 966358 209937 761003 1 - OK 0:21:07:08 MXK 3.1.1.215
m2 98 2 0 0 0 1 12.97 966359 125372 841037 1 - OK 0:21:04:34 MXK 3.1.1.215
a 88 12 2 8 0 0 18.77 944282 177269 767022 1 - OK 0:21:05:00 MXK 3.1.1.215
b 89 11 2 7 0 0 18.77 944282 177250 767052 1 - OK 0:21:04:36 MXK 3.1.1.215
```

The **card stats** command displays runtime statistics for the MXK-F219 device.

```
zSH> card stats
----- cpu % utilization ----- memory (KB)----- Card Mem  uptime
slot idle usage high serv fmwrk low %Used Tot Peak Avail Status ddd:hh:mm:ss s/w version
=====
m1* 97 3 0 1 0 1 5.24 203905 106923 193213 1 - OK 0:14:47:11 MXK 3.1.2.110
```

The **card stats all** command displays information for all the cards.

```
zSH> card stats all
----- cpu % utilization ----- memory (KB)----- Card Mem  uptime
slot idle usage high serv fmwrk low %Used Tot Peak Avail Status ddd:hh:mm:ss s/w version
=====
1 92 8 2 5 0 2 21.96 948744 209313 740394 1 - OK 0:14:42:55 MXK 3.1.2.110
2 91 9 3 5 0 2 22.30 948745 211654 737148 1 - OK 0:14:40:21 MXK 3.1.2.110
m1* 97 3 0 1 0 1 5.24 203905 106925 193213 1 - OK 0:14:47:19 MXK 3.1.2.110
m2 98 2 0 0 0 1 4.65 203905 94827 194432 1 - OK 0:14:44:23 MXK 3.1.2.110
```

Table 12: card stats Command Fields

Section	Field
CPU% utilization	slot Textual description of the unit/card or access device type.
	idle Percentage of time the CPU has spent executing tasks with priority of 200 or less. Tasks with priority of 200 or less (the higher the number, the lower the priority) are considered idle tasks.
	usage Percentage of time the CPU has spent executing tasks with priority of 199 or higher
	high High priority tasks are primarily related to packet processing and critical system monitoring. Percentage of time the CPU has spent executing tasks with priority of 001 to 099. High priority tasks are primarily related to packet processing and critical system monitoring.
	services Services are primarily line monitoring tasks for line state and alarms. Percentage of time the CPU has spent executing tasks with priority of 100 to 179. Services tasks are primarily line monitoring tasks for line state and alarms.

Table 12: card stats Command Fields (Continued)

Section	Field
	<p>framework</p> <p>Framework tasks are primarily database and network management system related activities such as config synch and backup.</p> <p>Percentage of time the CPU has spent executing tasks with priority of 180 to 199. Framework tasks are primarily database and network management system related activities such as config synch and backup.</p>
	<p>low</p> <p>Percentage of time the CPU has spent executing tasks with priority of 200 to 250</p>
memory (KB)	<p>Used</p> <p>Percentage of time the CPU has spent executing tasks with priority of 199 or higher.</p>
	<p>Total</p> <p>The amount of physical memory contained by the device/card.</p>
	<p>Peak</p> <p>The maximum physical memory that has been allocated at any time by the device/card.</p>
	<p>Avail</p> <p>The amount of physical memory that is unallocated and not in use by the device/card.</p>
Card Memory Status	<p>Memory status of the card sent with memory trap. A trap is sent when each condition occurs.</p> <p>1 - ramMemOK less then 90% of ram is used</p> <p>2 - ramMemLow more then 90% of ram is used</p> <p>3 - flashMemOK enough flash for maximum database</p> <p>4- flashMemLow not enough flash for maximum database</p> <p>5 - flashMemOut no more flash memory, data no longer persistent</p>
uptime ddd:hh:mm:ss	Uptime is calculated as sysUpTime - ifLastChange (assuming the device/card is running).
s/w version	Software version.

5-2 VIEW BRIDGE STATISTICS

This section describes:

- [Bridge Interface Statistics Overview, page 118](#)
- [Bridge Statistics Commands, page 118](#)
- [Bridge Statistics Display, page 120](#)

5- 2.1 Bridge Interface Statistics Overview

There are two commands for viewing statistics on bridge interfaces. The first command, **bridge stats**, displays all of the packet counters that have passed through the interface. The second command, **bridge rates**, displays all of the packets that pass through the bridge interface in rate-per-second.

The **bridge stats** command can display statistics for all bridge interfaces that display statistics, for a specified bridge interface, or for bridges on a specified VLAN ID.

The default counters for the **bridge stats** command are packet counters. Counters in bytes are also displayed in the Byte Counters columns.

5- 2.2 Bridge Statistics Commands

- [View Bridge Interface Statistics on page 118](#)
- [Use the bridge stats reset, clear, list, and rules Commands for Statistics on page 119](#)

5- 2.2.1 View Bridge Interface Statistics

- [Viewing Bridge Statistics on page 118](#)
- [Viewing Bridge Statistics By VLAN ID on page 119](#)

Procedure:

Viewing Bridge Statistics

Enter the **bridge stats** *interfaceName/bridge* command to view statistics on a bridge interface.

In this case, the bridge interface is *GPON*.

```
zSH> bridge stats 1-3-1-704-gponport-3003/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name           UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
1-3-1-704-gponport-3003/bridge 3    0    0  1577  0    0    0    0    0    0    0    668 119k
```

Enter the **bridge rates** *interfaceName/bridge* command to view statistics in rate-per-second.

```
zSH> bridge rates 1-3-1-704-gponport-3003/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name           UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
1-3-1-704-gponport-3003/bridge 1    0    0    1    0    0    0    0    0    0    0    1 39
```

Enter the **bridge stats** *interfaceName/bridge* command to view statistics on a bridge interface.

In this case, the bridge interface is Active Ethernet.

```
zSH> bridge stats 1-9-21-0-eth/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name           UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
```

```
1-9-21-0-eth/bridge      1  4923  302  988k  803  383  0  0  0  0  0  0  0  159M
```

Enter the **bridge rates** *interfaceName/bridge* command to view statistics in rate-per-second.

```
zSH> bridge rates 1-9-21-0-eth/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name          UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
1-9-21-0-eth/bridge  1    1    1   11    1    1    0  0  0    0  0  0  0 1651
```

Procedure:

Viewing Bridge Statistics By VLAN ID

Enter the **bridge stats** *vlanid* command to view bridge statistics by VLAN ID.

```
zSH> bridge stats vlan 3003
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name          UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
ethernet2-3003/bridge 1680  0  0    3    0  0  0  0  0    0  0  0 121k 656
1-3-1-704-gponport-3003/bridge  3  0  0  1680  0  0  0  0  0    0  0  0  668 127k
1-9-1-0-eth-3003/bridge    0  0  0    0  0  0  0  0  0    0  0  0    0  0
```

5- 2.2.2

Use the bridge stats reset, clear, list, and rules Commands for Statistics

Procedure:

Using the Bridge Statistics Reset Command

Use the **bridge statistics reset** *interfaceName/bridge* command to display and clear statistics and rates on bridge interfaces.

- 1 Enter the **bridge stats reset** *interfaceName/bridge* command to display and reset statistical counters to 0, and resume counting.

Bridge interface with statistics-on-demand enabled.

```
zSH> bridge stats reset ethernet1-840/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name          UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
ethernet1-840/bridge  971M  0   244 2600M  0  2695  0  0  0  0  0  8004G 193G
```

- 2 Enter the **bridge stats** *interfaceName/bridge* command immediately following the **bridge stats reset** *interfaceName/bridge* command to display counters reset.

```
zSH> bridge stats reset ethernet1-840/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name          UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
ethernet1-840/bridge  430k  0    0  2066k  0    0  0  0  0  0  0  6529M 1537M
```

- 3 Enter the **bridge stats** *interfaceName/bridge* command after an interval to display the reset packet counter information.

```
zSH> bridge stats ethernet1-840/bridge
Interface      ----Rcvd Pkts---- -----Xmt Pkts----- --Storm Detect Pkts-  Byte Count
Name          UCast MCast BCast UCast MCast Bcast Err  UCast MCast Bcast Alm Rcvd Xmt
ethernet1-840/bridge  645M  0   244  224M  0  2695  0  0  0  0  0  751G 182G
```

Procedure:

Entering the bridge stats clear Command

Enter the **bridge stats clear** *interfaceName/bridge* command to clear statistics and rates without displaying them.

```
zSH> bridge stats clear ethernet5-3605/bridge
Bridge statistics cleared
```

5- 2.3 Bridge Statistics Display

[Table 13](#) defines the columns the **bridge stats** and **bridge stats rules** commands display.

Table 13: bridge stats Display Columns

Column	Description
enabled	The on-demand stats collection for this bridge interface will be enabled and packets will be counted.
enabled, bytes	The on-demand stats collection for this bridge interface will be enabled and bytes will be counted.
ucastRx	Unicast packets received.
mcastRx	Multicast packets received.
bcastRx	Broadcast packets received.
ucastTx	Unicast packets sent.
mcastTx	Multicast packets sent.
errorTx	Error packets sent.
RulesSupported	The number of supported ingress statistics available for a line card.
RulesRemaining	The number of remaining ingress statistics available for a line card.
UcastPktBlocked	The number of unicast packets dropped due to bridge packet storm detection threshold exceeded.
McastPktBlocked	Number of multicast packets dropped due to bridge packet storm detection threshold exceeded.
BcastPktBlocked	Number of broadcast packets dropped due to bridge packet storm detection threshold exceeded.
AlarmCnt	This counter reflects the number of times this interface has transitioned to the alarm state due to the bridge packet storm detection threshold being exceeded for a pre-defined number of seconds.
bytesRcvd	This is a count of the number of bytes received. On-demand stats must be enabled for byte counters otherwise this counter is zero.
bytesSent	This is a count of the number of bytes transmitted. On-demand stats must be enabled for byte counters otherwise this counter is zero.

5-3 ETHERNET PORT STATISTICS

Use **port stats** command to display or clear various statistical information.

port stats <ifName/Type> <intf|rmon|eth|all|clear>

The **port stats interface/type intf** command displays mib2 interface statistics.

See [Table 14 on page 124](#) for parameter definitions.

```
zSH> port stats 1-1-19-0/eth intf
Interface Name                1-1-19-0
Operational Status           Up
Received Bytes                660624000
Received Packets              436317
Received Multicast Packets    3830
Received Broadcast Packets    269
Transmitted Bytes             673299000
Transmitted Unicast Packets   448250
Transmitted Multicast Packets 307
Transmitted Broadcast Packets 309
Received Discards             1110
Received Errors               0
Received Unknown Protocols    0
Transmitted Discards          0
Transmitted Errors            0
Speed Bits per Second         *** n/a ***
Speed Megabits per Second     100
```

The **port stats interface/type rmon** command displays Ethernet remote monitoring statistics.

```
zSH> port stats 1-1-19-0/eth rmon
Total Dropped Events          0
Total Dropped Frames          0
Total Bytes                    2115147000
Total Packets                  1410098
Transmitted Packets            709274
Received Packets               700824
Transmitted Multicast Bytes    0
Received Multicast Bytes       5745000
Received Multicast Dropped Bytes 0
Transmitted Average Throughput 72672000
Received Average Throughput    72672000
Transmitted Bandwidth Occupancy 72
Received Bandwidth Occupancy   72
Total Broadcast Packets        578
Total Multicast Packets        4137
CRC Align Errors               0
Undersize Packets              0
Oversize Packets               0
Transmitted Oversize Packets   0
Received Oversize Packets      0
Fragments                      0
Jabbers                        0
Collisions                     0
Transmitted No Errors          709274
Received No Errors             700824
IPMC Bridged Packets           3830
```

Statistics on the MXK-F

IPMC Routed Packets	0
Transmitted IPMC Dropped Packets	0
Received IPMC Dropped Packets	0
Total Packets 0 to 64 Bytes	0
Total Packets 65 to 127 Bytes	0
Total Packets 128 to 255 Bytes	0
Total Packets 256 to 511 Bytes	0
Total Packets 512 to 1023 Bytes	0
Total Packets 1024 to 1518 Bytes	1410098
Total Packets 1519 to 2047 Bytes	0
Total Packets 2048 to 4095 Bytes	0
Total Packets 4095 to 9216 Bytes	0
Received Packets 0 to 64 Bytes	0
Received Packets 65 to 127 Bytes	0
Received Packets 128 to 255 Bytes	0
Received Packets 256 to 511 Bytes	0
Received Packets 512 to 1023 Bytes	0
Received Packets 1024 to 1518 Bytes	700824
Received Packets 1519 to 2047 Bytes	0
Received Packets 2048 to 4095 Bytes	0
Received Packets 4095 to 9216 Bytes	0
Transmitted Packets 0 to 64 Bytes	0
Transmitted Packets 65 to 127 Bytes	0
Transmitted Packets 128 to 255 Bytes	0
Transmitted Packets 256 to 511 Bytes	0
Transmitted Packets 512 to 1023 Bytes	0
Transmitted Packets 1024 to 1518 Bytes	709274
Transmitted Packets 1519 to 2047 Bytes	0
Transmitted Packets 2048 to 4095 Bytes	0
Transmitted Packets 4095 to 9216 Bytes	0

The **port stats interface/type eth** command displays the Ethernet dot3 statistics.

```
zSH> port stats 1-1-19-0/eth eth
Alignment Errors          0
FCS Errors                0
Single Collision Frames   0
Multiple Collision Frames 0
SQE Test Errors          0
Deferred Transmissions    0
Late Collisions           0
Excessive Collisions      0
Internal Mac Transmit Errors 0
Carrier Sense Errors      0
FrameTooLongs            0
InternalMacReceiveErrors  0
SymbolErrors              0
DuplexStatus              Full
```

The **port stats interface/type all** commands displays all of the Ethernet statistics.

```
zSH> port stats 1-1-19-0/eth all
***** eth *****
Alignment Errors          0
FCS Errors                0
Single Collision Frames   0
```

Multiple Collision Frames	0
SQE Test Errors	0
Deferred Transmissions	0
Late Collisions	0
Excessive Collisions	0
Internal Mac Transmit Errors	0
Carrier Sense Errors	0
FrameTooLongs	0
InternalMacReceiveErrors	0
SymbolErrors	0
DuplexStatus	Full
***** mmon *****	
Total Dropped Events	0
Total Dropped Frames	0
Total Bytes	3405022500
Total Packets	2270015
Transmitted Packets	1139233
Received Packets	1130782
Transmitted Multicast Bytes	0
Received Multicast Bytes	5745000
Received Multicast Dropped Bytes	0
Transmitted Average Throughput	71659832
Received Average Throughput	71659664
Transmitted Bandwidth Occupancy	71
Received Bandwidth Occupancy	71
Total Broadcast Packets	578
Total Multicast Packets	4137
CRC Align Errors	0
Undersize Packets	0
Oversize Packets	0
Transmitted Oversize Packets	0
Received Oversize Packets	0
Fragments	0
Jabbers	0
Collisions	0
Transmitted No Errors	1139233
Received No Errors	1130782
IPMC Bridged Packets	3830
IPMC Routed Packets	0
Transmitted IPMC Dropped Packets	0
Received IPMC Dropped Packets	0
Total Packets 0 to 64 Bytes	0
Total Packets 65 to 127 Bytes	0
Total Packets 128 to 255 Bytes	0
Total Packets 256 to 511 Bytes	0
Total Packets 512 to 1023 Bytes	0
Total Packets 1024 to 1518 Bytes	2270015
Total Packets 1519 to 2047 Bytes	0
Total Packets 2048 to 4095 Bytes	0
Total Packets 4095 to 9216 Bytes	0
Received Packets 0 to 64 Bytes	0
Received Packets 65 to 127 Bytes	0
Received Packets 128 to 255 Bytes	0
Received Packets 256 to 511 Bytes	0
Received Packets 512 to 1023 Bytes	0
Received Packets 1024 to 1518 Bytes	1130782
Received Packets 1519 to 2047 Bytes	0
Received Packets 2048 to 4095 Bytes	0
Received Packets 4095 to 9216 Bytes	0

Statistics on the MXK-F

```

Transmitted Packets 0 to 64 Bytes          0
Transmitted Packets 65 to 127 Bytes       0
Transmitted Packets 128 to 255 Bytes      0
Transmitted Packets 256 to 511 Bytes     0
Transmitted Packets 512 to 1023 Bytes    0
Transmitted Packets 1024 to 1518 Bytes   1139233
Transmitted Packets 1519 to 2047 Bytes   0
Transmitted Packets 2048 to 4095 Bytes   0
Transmitted Packets 4095 to 9216 Bytes   0
***** intf *****
Interface Name                            1-1-19-0
Operational Status                        Up
Received Bytes                            1696173000
Received Packets                          1126682
Received Multicast Packets                3830
Received Broadcast Packets                269
Transmitted Bytes                         1708849500
Transmitted Unicast Packets               1138617
Transmitted Multicast Packets              307
Transmitted Broadcast Packets              309
Received Discards                         1110
Received Errors                           0
Received Unknown Protocols                 0
Transmitted Discards                       0
Transmitted Errors                         0
Speed Bits per Second                     *** n/a ***
Speed Megabits per Second                  100

```

The **port stats clear** *interface/type* command clears all port stats counters.

```

zSH> port stats clear 1-1-19-0/eth
INTF Stats cleared

```

Table 14 defines the parameters for all of the Ethernet statistics.

Table 14: MXK-F Enhanced Ethernet port statistics

Parameter	Description
eth	
Alignment Errors	<p>A count of frames received on a particular interface that are not an integral number of octets in length and do not pass the FCS check. The count represented by an instance of this object is incremented when the alignment Error status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtain are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC. This counter does not increment for 8-bit wide group encoding schemes.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of <code>ifCounterDiscontinuityTime</code>.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
FCS Errors	<p>A count of frames received on a particular interface that are an integral number of octets in length but do not pass the FCS check. This count does not include frames received with frame-too-long or frame-too-short error.</p> <p>The count represented by an instance of this object is incremented when the frameCheckError status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtain are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p> <p>Note: Coding errors detected by the physical layer for speeds above 10 Mb/s will cause the frame to fail the FCS check. Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Single Collision Frames	<p>A count of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.</p> <p>A frame that is counted by an instance of this object is also counted by the corresponding instance of either the ifOutUcastPkts, ifOutMulticastPkts, or ifOutBroadcastPkts, and is not counted by the corresponding instance of the dot3StatsMultipleCollisionFrames object.</p> <p>This counter does not increment when the interface is operating in full-duplex mode.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Multiple Collision Frames	<p>A count of successfully transmitted frames on a particular interface for which transmission is inhibited by more than one collision.</p> <p>A frame that is counted by an instance of this object is also counted by the corresponding instance of either the ifOutUcastPkts, ifOutMulticastPkts, or ifOutBroadcastPkts, and is not counted by the corresponding instance of the dot3StatsSingleCollisionFrames object. This counter does not increment when the interface is operating in full-duplex mode.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
SQE Test Errors	<p>A count of times that the SQE TEST ERROR message is generated by the PLS sublayer for a particular interface. The SQE TEST ERROR is set in accordance with the rules for verification of the SQE detection mechanism in the PLS Carrier Sense Function as described in IEEE Std. 802.3, 1998 Edition, section 7.2.4.6.</p> <p>This counter does not increment on interfaces operating at speeds greater than 10 Mb/s, or on interfaces operating in full-duplex mode.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
<p>Deferred Transmissions</p>	<p>A count of frames for which the first transmission attempt on a particular interface is delayed because the medium is busy. The count represented by an instance of this object does not include frames involved in collisions.</p> <p>This counter does not increment when the interface is operating in full-duplex mode. Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of <code>ifCounterDiscontinuityTime</code>.</p>
<p>Late Collisions</p>	<p>The number of times that a collision is detected on a particular interface later than one <code>slotTime</code> into the transmission of a packet.</p> <p>A (late) collision included in a count represented by an instance of this object is also considered as a (generic) collision for purposes of other collision-related statistics.</p> <p>This counter does not increment when the interface is operating in full-duplex mode. Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of <code>ifCounterDiscontinuityTime</code>.</p>
<p>Excessive Collisions</p>	<p>A count of frames for which transmission on a particular interface fails due to excessive collisions. This counter does not increment when the interface is operating in full-duplex mode.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of <code>ifCounterDiscontinuityTime</code>.</p>
<p>Internal Mac Transmit Errors</p>	<p>A count of frames for which transmission on a particular interface fails due to an internal MAC sublayer transmit error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the <code>dot3StatsLateCollisions</code> object, the <code>dot3StatsExcessiveCollisions</code> object, or the <code>dot3StatsCarrierSenseErrors</code> object.</p> <p>The precise meaning of the count represented by an instance of this object is implementation- specific. In particular, an instance of this object may represent a count of transmission errors on a particular interface that are not otherwise counted.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of <code>ifCounterDiscontinuityTime</code>.</p>
<p>Carrier Sense Errors</p>	<p>The number of times that the carrier sense condition was lost or never asserted when attempting to transmit a frame on a particular interface.</p> <p>The count represented by an instance of this object is incremented at most once per transmission attempt, even if the carrier sense condition fluctuates during a transmission attempt.</p> <p>This counter does not increment when the interface is operating in full-duplex mode. Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of <code>ifCounterDiscontinuityTime</code>.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
FrameTooLongs	<p>A count of frames received on a particular interface that exceed the maximum permitted frame size.</p> <p>The count represented by an instance of this object is incremented when the frameTooLong status is returned by the MAC service to the LLC (or other MAC user). Received frames for which multiple error conditions obtain are, according to the conventions of IEEE 802.3 Layer Management, counted exclusively according to the error status presented to the LLC.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
InternalMacReceive Errors	<p>A count of frames for which reception on a particular interface fails due to an internal MAC sublayer receive error. A frame is only counted by an instance of this object if it is not counted by the corresponding instance of either the dot3StatsFrameTooLongs object, the dot3StatsAlignmentErrors object, or the dot3StatsFCSErrors object.</p> <p>The precise meaning of the count represented by an instance of this object is implementation- specific. In particular, an instance of this object may represent a count of receive errors on a particular interface that are not otherwise counted.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime</p>
SymbolErrors	<p>For an interface operating at 100 Mb/s, the number of times there was an invalid data symbol when a valid carrier was present.</p> <p>For an interface operating in half-duplex mode at 1000 Mb/s, the number of times the receiving media is non-idle (a carrier event) for a period of time equal to or greater than slotTime, and during which there was at least one occurrence of an event that causes the PHY to indicate 'Data reception error' or 'carrier extend error' on the GMII.</p> <p>For an interface operating in full-duplex mode at 1000 Mb/s, the number of times the receiving media is non-idle (a carrier event) for a period of time equal to or greater than minFrameSize, and during which there was at least one occurrence of an event that causes the PHY to indicate 'Data reception error' on the GMII.</p> <p>The count represented by an instance of this object is incremented at most once per carrier event, even if multiple symbol errors occur during the carrier event. This count does not increment if a collision is present.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
DuplexStatus	<p>The current mode of operation of the MAC entity. 'unknown' indicates that the current duplex mode could not be determined. Management control of the duplex mode is accomplished through the MAU MIB. When an interface does not support autonegotiation, or when autonegotiation is not enabled, the duplex mode is controlled using ifMauDefaultType. When autonegotiation is supported and enabled, duplex mode is controlled using ifMauAutoNegAdvertisedBits. In either case, the currently operating duplex mode is reflected both in this object and in ifMauType.</p> <p>Note that this object provides redundant information with ifMauType. Normally, redundant objects are discouraged. However, in this instance, it allows a management application to determine the duplex status of an interface without having to know every possible value of ifMauType. This was felt to be sufficiently valuable to justify the redundancy.</p> <p>Values:</p> <p>unknown</p> <p>halfDuplex</p> <p>fullDuplex</p>
rmon	Remote Network Monitoring
Total Dropped Events	<p>The total number of events in which packets were dropped by the probe due to lack of resources.</p> <p>Note that this number is not necessarily the number of packets dropped; it is just the number of times this condition has been detected.</p>
Total Dropped Frames	<p>The total number of frames that were received by the probe and therefore not accounted for in the zhoneEtherStatsDropEvents, but that the probe chose not to count for this entry for whatever reason. Most often, this event occurs when the probe is out of some resources and decides to shed load from this collection.</p> <p>This count does not include packets that were not counted because they had MAC-layer errors.</p> <p>Note that, unlike the dropEvents counter, this number is the exact number of frames dropped.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Total Bytes	<p>The total number of octets of data (including those in bad packets) transmitted and received on the network (excluding framing bits but including FCS octets).</p> <p>This object can be used as a reasonable estimate of 10-Megabit ethernet utilization. If greater precision is desired, the <code>zhoneEtherStatsPkts</code> and <code>zhoneEtherStatsOctets</code> objects should be sampled before and after a common interval. The differences in the sampled values are <code>Pkts</code> and <code>Octets</code>, respectively, and the number of seconds in the interval is <code>Interval</code>. These values are used to calculate the Utilization as follows:</p> $\text{Pkts} * (9.6 + 6.4) + (\text{Octets} * .8)$ $\text{Utilization} = \frac{\text{Interval} * 10,000}{\text{Interval} * 10,000}$ <p>The result of this equation is the value <code>Utilization</code> which is the percent utilization of the ethernet segment on a scale of 0 to 100 percent.</p>
Total Packets	The total number of packets (including bad packets, broadcast packets, and multicast packets) transmitted and received.
Transmitted Packets	The total number of packets (including bad packets, broadcast packets, and multicast packets) transmitted.
Received Packets	The total number of packets (including bad packets, broadcast packets, and multicast packets) received.
Transmitted Multicast Bytes	Transmitted multicast bytes.
Received Multicast Bytes	Received multicast bytes.
Received Multicast Dropped Bytes	Dropped multicast bytes.
Transmitted Average Throughput	Average transmit throughput in bits per second since last query. For accuracy purposes, it is recommended that this object be queried in intervals of five (5) seconds or greater.
Received Average Throughput	Average receive throughput in bits per second since last query. For accuracy purposes, it is recommended that this object be queried in intervals of five (5) seconds or greater.
Transmitted Bandwidth Occupancy	Percentage of bandwidth currently being utilized for transmitting traffic. This rate is calculated based on the delta between prior and current query of this object. For accuracy purposes, it is recommended that this object be queried in intervals of five (5) seconds or greater.
Received Bandwidth Occupancy	Percentage of bandwidth currently being utilized for receiving traffic. This rate is calculated based on the delta between prior and current query of this object. For accuracy purposes, it is recommended that this object be queried in intervals of five (5) seconds or greater.
Total Broadcast Packets	<p>The total number of good packets transmitted and received that were directed to the broadcast address.</p> <p>Note that this does not include multicast packets.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Total Multicast Packets	The total number of good packets transmitted and received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.
CRC Align Errors	The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Undersize Packets	The total number of packets received that were less than 64 octets long (excluding framing bits, but including FCS octets) and were otherwise well formed.
Oversize Packets	The total number of packets transmitted and received that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.
Transmitted Oversize Packets	The total number of packets transmitted that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.
Received Oversize Packets	The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.
Fragments	<p>The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).</p> <p>Note that it is entirely normal for <code>zhoneEtherStatsFragments</code> to increment. This is because it counts both runts (which are normal occurrences due to collisions) and noise hits.</p>
Jabbers	<p>The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).</p> <p>Note that this definition of jabber is different than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These documents define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Collisions	<p>The best estimate of the total number of collisions on this Ethernet segment. The value returned will depend on the location of the RMON probe. Section 8.2.1.3 (10BASE-5) and section 10.3.1.3 (10BASE-2) of IEEE standard 802.3 states that a station must detect a collision, in the receive mode, if three or more stations are transmitting simultaneously. A repeater port must detect a collision when two or more stations are transmitting simultaneously. Thus a probe placed on a repeater port could record more collisions than a probe connected to a station on the same segment would. Probe location plays a much smaller role when considering 10BASE-T. 14.2.1.4 (10BASE-T) of IEEE standard 802.3 defines a collision as the simultaneous presence of signals on the DO and RD circuits (transmitting and receiving at the same time). A 10BASE-T station can only detect collisions when it is transmitting. Thus probes placed on a station and a repeater, should report the same number of collisions.</p> <p>Note also that an RMON probe inside a repeater should ideally report collisions between the repeater and one or more other hosts (transmit collisions as defined by IEEE 802.3k) plus receiver collisions observed on any coax segments to which the repeater is connected.</p>
Transmitted No Errors	The total number of TX packets transmitted without error.
Received No Errors	The total number of RX packets received without error.
IPMC Bridged Packets	Broadcom IPMC Bridged Packet count.
IPMC Routed Packets	Broadcom IPMC Routed Packet count.
Transmitted IPMC Dropped Packets	Broadcom IPMC Tx Dropped Packet count.
Received IPMC Dropped Packets	Broadcom IPMC Rx Dropped Packet count.
Total Packets 0 to 64 Bytes	The total number of packets (including bad packets) transmitted and received that were 64 octets in length (excluding framing bits but including FCS octets).
Total Packets 65 to 127 Bytes	The total number of packets (including bad packets) transmitted and received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
Total Packets 128 to 255 Bytes	The total number of packets (including bad packets) transmitted and received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
Total Packets 256 to 511 Bytes	The total number of packets (including bad packets) transmitted and received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
Total Packets 512 to 1023 Bytes	The total number of packets (including bad packets) transmitted and received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Total Packets 1024 to 1518 Bytes	The total number of packets (including bad packets) transmitted and received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).
Total Packets 1519 to 2047 Bytes	The total number of packets (including bad packets) transmitted and received that were between 1519 and 2047 octets in length inclusive (excluding framing bits but including FCS octets).
Total Packets 2048 to 4095 Bytes	The total number of packets (including bad packets) transmitted and received that were between 2048 and 4095 octets in length inclusive (excluding framing bits but including FCS octets).
Total Packets 4095 to 9216 Bytes	The total number of packets (including bad packets) transmitted and received that were between 4095 and 9216 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 0 to 64 Bytes	The total number of packets (including bad packets) received that were between 0 and 64 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 65 to 127 Bytes	The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 128 to 255 Bytes	The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 256 to 511 Bytes	The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 512 to 1023 Bytes	The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 1024 to 1518 Bytes	The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 1519 to 2047 Bytes	The total number of packets (including bad packets) received that were between 1519 and 2047 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 2048 to 4095 Bytes	The total number of packets (including bad packets) received that were between 2048 and 4095 octets in length inclusive (excluding framing bits but including FCS octets).
Received Packets 4095 to 9216 Bytes	The total number of packets (including bad packets) received that were between 4095 and 9216 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 0 to 64 Bytes	The total number of packets (including bad packets) transmitted that were between 0 and 64 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 65 to 127 Bytes	The total number of packets (including bad packets) transmitted that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 128 to 255 Bytes	The total number of packets (including bad packets) transmitted that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Transmitted Packets 256 to 511 Bytes	The total number of packets (including bad packets) transmitted that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 512 to 1023 Bytes	The total number of packets (including bad packets) transmitted that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 1024 to 1518 Bytes	The total number of packets (including bad packets) transmitted that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 1519 to 2047 Bytes	The total number of packets (including bad packets) transmitted that were between 1519 and 2047 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 2048 to 4095 Bytes	The total number of packets (including bad packets) transmitted that were between 2048 and 4095 octets in length inclusive (excluding framing bits but including FCS octets).
Transmitted Packets 4095 to 9216 Bytes	The total number of packets (including bad packets) transmitted that were between 4095 and 9216 octets in length inclusive (excluding framing bits but including FCS octets).
intf	Interface statistics
Interface Name	<p>The textual name of the interface. The value of this object should be the name of the interface as assigned by the local device and should be suitable for use in commands entered at the device's `console`. This might be a text name, such as `le0` or a simple port number, such as `1`, depending on the interface naming syntax of the device. If several entries in the ifTable together represent a single interface as named by the device, then each will have the same value of ifName. Note that for an agent which responds to SNMP queries concerning an interface on some other (proxied) device, then the value of ifName for such an interface is the proxied device's local name for it.</p> <p>If there is no local name, or this object is otherwise not applicable, then this object contains a zero-length string.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
<p>Operational Status</p>	<p>The current operational state of the interface.</p> <p>The testing(3) state indicates that no operational packets can be passed. If ifAdminStatus is down(2) then ifOperStatus should be down(2). If ifAdminStatus is changed to up(1) then ifOperStatus should change to up(1) if the interface is ready to transmit and receive network traffic; it should change to dormant(5) if the interface is waiting for external actions (such as a serial line waiting for an incoming connection); it should remain in the down(2) state if and only if there is a fault that prevents it from going to the up(1) state; it should remain in the notPresent(6) state if the interface has missing (typically, hardware) components.</p> <p>Values:</p> <p>up</p> <p>down</p> <p>testing</p> <p>unknown</p> <p>dormant</p> <p>notPresent</p> <p>lowerLayerDown</p>
<p>Received Bytes</p>	<p>The total number of octets received on the interface, including framing characters. This object is a 64-bit version of ifInOctets.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
<p>Received Multicast Packets</p>	<p>The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a multicast address at this sub-layer. For a MAC layer protocol, this includes both Group and Functional addresses. This object is a 64-bit version of ifInMulticastPkts.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
<p>Received Broadcast Packets</p>	<p>The number of packets, delivered by this sub-layer to a higher (sub-)layer, which were addressed to a broadcast address at this sub-layer. This object is a 64-bit version of ifInBroadcastPkts.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
<p>Transmitted Bytes</p>	<p>The total number of octets transmitted out of the interface, including framing characters. This object is a 64-bit version of ifOutOctets.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Transmitted Unicast Packets	<p>The total number of packets that higher-level protocols requested be transmitted, and which were not addressed to a multicast or broadcast address at this sub-layer, including those that were discarded or not sent. This object is a 64-bit version of ifOutUcastPkts.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Transmitted Multicast Packets	<p>The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a multicast address at this sub-layer, including those that were discarded or not sent. For a MAC layer protocol, this includes both Group and Functional addresses.</p> <p>This object is a 64-bit version of ifOutBroadcastPkts.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Transmitted Broadcast Packets	<p>The total number of packets that higher-level protocols requested be transmitted, and which were addressed to a broadcast address at this sub-layer, including those that were discarded or not sent.</p> <p>This object is a 64-bit version of ifOutBroadcastPkts.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Received Discards	<p>The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. One possible reason for discarding such a packet could be to free up buffer space.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Received Errors	<p>For packet-oriented interfaces, the number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol. For character-oriented or fixed-length interfaces, the number of inbound transmission units that contained errors preventing them from being deliverable to a higher-layer protocol.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Received Unknown Protocols	<p>For packet-oriented interfaces, the number of packets received via the interface which were discarded because of an unknown or unsupported protocol. For character-oriented or fixed-length interfaces that support protocol multiplexing the number of transmission units received via the interface which were discarded because of an unknown or unsupported protocol. For any interface that does not support protocol multiplexing, this counter will always be 0.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>

Table 14: MXK-F Enhanced Ethernet port statistics (Continued)

Parameter	Description
Transmitted Discards	<p>The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being transmitted. One possible reason for discarding such a packet could be to free up buffer space.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Transmitted Errors	<p>For packet-oriented interfaces, the number of outbound packets that could not be transmitted because of errors. For character-oriented or fixed-length interfaces, the number of outbound transmission units that could not be transmitted because of errors.</p> <p>Discontinuities in the value of this counter can occur at re-initialization of the management system, and at other times as indicated by the value of ifCounterDiscontinuityTime.</p>
Speed Bits per Second	<p>An estimate of the interface's current bandwidth in bits per second. For interfaces which do not vary in bandwidth or for those where no accurate estimation can be made, this object should contain the nominal bandwidth. If the bandwidth of the interface is greater than the maximum value reportable by this object then this object should report its maximum value (4,294,967,295) and ifHighSpeed must be used to report the interface's speed. For a sub-layer which has no concept of bandwidth, this object should be zero.</p>
Speed Megabits per Second	<p>An estimate of the interface's current bandwidth in units of 1,000,000 bits per second. If this object reports a value of 'n' then the speed of the interface is somewhere in the range of 'n-500,000' to 'n+499,999'. For interfaces which do not vary in bandwidth or for those where no accurate estimation can be made, this object should contain the nominal bandwidth. For a sub-layer which has no concept of bandwidth, this object should be zero.</p>

5-4 GPON OMCI (ONT) AND PON STATISTICS

This section includes:

- [OMCI \(ONT\) Statistics, page 136](#)
- [PON Statistics, page 141](#)

5-4.1 OMCI (ONT) Statistics

The MXK obtains ONU statistics from the ONU using the ITU standardized OMCI protocol. The MXK sends standards based OMCI commands to retrieve statistics information. The statistics are maintained on the ONU in 15-minute intervals. There are 2 intervals of statistics that is stored in the ONU, current and previous. When an ONU is activated, the ONU starts storing statistics. These statistics are stored under the current category of statistics. After a 15 minute time period, the statistics value are reset. The statistics tracked during the past 15 minute period are stored as the previous interval. A new set of the current interval statistics is tracked. After every 15-minute period the current interval is saved as previous and a new current category is created with zeroed out values.

Display OMCI statistics for selected ONU(s) with the **gpononu statistics** command.

Syntax:

```
gpononu statistics [previous] [slot[/olt[/onu]|ifName]
```

previous

The system retrieves the statistics collected during the previous 15 minutes interval. Without **previous**, the system retrieves the statistics collected in current 15 minutes interval.

slot[/olt[/onu]|ifName

The ONU(s) users want to collect statistics on.

Example:

```
zSH> gpononu statistics previous 4/1/1
4/1/1 ONU Statistics (previous)
  Ethernet Performance Monitoring History Data - Port 1
    32 Interval Time
      0 Threshold Data Pointer
      0 FCS Errors
      0 Excessive Collision Counter
      0 Late Collision Counter
      0 Frame Too Long
      0 Buffer Overflows on Receive
      0 Buffer Overflows on Transmit
      0 Single Collision Frame Counter
      0 Multiple Collisions Frame Counter
      0 SQE Counter
      0 Deferred Transmission Counter
      0 Internal MAC Transmit Error Counter
      0 Carrier Sense Error Counter
      0 Alignment Error Counter
      0 Internal MAC Receive Error Counter
  Ethernet Performance Monitoring History Data - Port 2
    32 Interval Time
      0 Threshold Data Pointer
      0 FCS Errors
      0 Excessive Collision Counter
      0 Late Collision Counter
      0 Frame Too Long
      0 Buffer Overflows on Receive
      0 Buffer Overflows on Transmit
      0 Single Collision Frame Counter
      0 Multiple Collisions Frame Counter
      0 SQE Counter
      0 Deferred Transmission Counter
      0 Internal MAC Transmit Error Counter
      0 Carrier Sense Error Counter
      0 Alignment Error Counter
      0 Internal MAC Receive Error Counter
  Ethernet Performance Monitoring History Data - Port 3
    32 Interval Time
      0 Threshold Data Pointer
      0 FCS Errors
```

Statistics on the MXK-F

```
0 Excessive Collision Counter
0 Late Collision Counter
0 Frame Too Long
0 Buffer Overflows on Receive
0 Buffer Overflows on Transmit
0 Single Collision Frame Counter
0 Multiple Collisions Frame Counter
0 SQE Counter
0 Deferred Transmission Counter
0 Internal MAC Transmit Error Counter
0 Carrier Sense Error Counter
0 Alignment Error Counter
0 Internal MAC Receive Error Counter
Ethernet Performance Monitoring History Data - Port 4
32 Interval Time
0 Threshold Data Pointer
0 FCS Errors
0 Excessive Collision Counter
0 Late Collision Counter
0 Frame Too Long
0 Buffer Overflows on Receive
0 Buffer Overflows on Transmit
0 Single Collision Frame Counter
0 Multiple Collisions Frame Counter
0 SQE Counter
0 Deferred Transmission Counter
0 Internal MAC Transmit Error Counter
0 Carrier Sense Error Counter
0 Alignment Error Counter
0 Internal MAC Receive Error Counter
Ethernet Performance Monitoring History Data 2 - Port 1
32 Interval Time
0 Threshold Data Pointer
0 PPPoE Filtered Frame Counter
Ethernet Performance Monitoring History Data 2 - Port 2
32 Interval Time
0 Threshold Data Pointer
0 PPPoE Filtered Frame Counter
Ethernet Performance Monitoring History Data 2 - Port 3
32 Interval Time
0 Threshold Data Pointer
0 PPPoE Filtered Frame Counter
Ethernet Performance Monitoring History Data 2 - Port 4
32 Interval Time
0 Threshold Data Pointer
0 PPPoE Filtered Frame Counter
GEM Port Protocol Monitoring History Data - Port 501
no data available
GEM Port Protocol Monitoring History Data - Port 701
no data available
GEM Port Protocol Monitoring History Data - Port 901
no data available
GEM Port Protocol Monitoring History Data - Port 1101
no data available
GEM Port Protocol Monitoring History Data - Port 1301
no data available
GEM Port Protocol Monitoring History Data - IPTV Port 4095
no data available
Ethernet Performance Monitoring History Data 3 - Port 1
```

32 Interval Time
0 Threshold Data 1/2 id
0 Drop Events
0 Octets
0 Packets
0 Broadcast Packets
0 Multicast Packets
0 Undersize Packets
0 Fragments
0 Jabbers
0 Packets 64 Octets
0 Packets 65 to 127 Octets
0 Packets 128 to 255 Octets
0 Packets 256 to 511 Octets
0 Packets 512 to 1023 Octets
0 Packets 1024 to 1518 Octets

Ethernet Performance Monitoring History Data 3 - Port 2

32 Interval Time
0 Threshold Data 1/2 id
0 Drop Events
0 Octets
0 Packets
0 Broadcast Packets
0 Multicast Packets
0 Undersize Packets
0 Fragments
0 Jabbers
0 Packets 64 Octets
0 Packets 65 to 127 Octets
0 Packets 128 to 255 Octets
0 Packets 256 to 511 Octets
0 Packets 512 to 1023 Octets
0 Packets 1024 to 1518 Octets

Ethernet Performance Monitoring History Data 3 - Port 3

32 Interval Time
0 Threshold Data 1/2 id
0 Drop Events
0 Octets
0 Packets
0 Broadcast Packets
0 Multicast Packets
0 Undersize Packets
0 Fragments
0 Jabbers
0 Packets 64 Octets
0 Packets 65 to 127 Octets
0 Packets 128 to 255 Octets
0 Packets 256 to 511 Octets
0 Packets 512 to 1023 Octets
0 Packets 1024 to 1518 Octets

Ethernet Performance Monitoring History Data 3 - Port 4

32 Interval Time
0 Threshold Data 1/2 id
0 Drop Events
0 Octets
0 Packets
0 Broadcast Packets
0 Multicast Packets
0 Undersize Packets

0 Fragments
 0 Jabbers
 0 Packets 64 Octets
 0 Packets 65 to 127 Octets
 0 Packets 128 to 255 Octets
 0 Packets 256 to 511 Octets
 0 Packets 512 to 1023 Octets
 0 Packets 1024 to 1518 Octets

Table 15 defines the OMCI statistics displayed in the **gpononu statistics** command.

Table 15: OMCI Statistics Attributes

Attribute	Description
Interval end time	This attribute identifies the most recently finished 15-minute interval.
Threshold data pointer	This attribute points to an instance of the threshold data 1 and 2 managed entities that contains Performance Monitoring threshold values.
FCS errors	This attribute counts frames received on a particular interface that were an integral number of octets in length but failed the frame check sequence (FCS) check. The count is incremented when the MAC service returns the frameCheckError status to the link layer control (LLC) or other MAC user. Received frames for which multiple error conditions are obtained are counted according to the error status presented to the LLC.
Excessive collision counter	This attribute counts frames whose transmission failed due to excessive collisions.
Late collision counter	This attribute counts the number of times that a collision was detected later than 512 bit times into the transmission of a packet.
Frames too long	This attribute counts received frames that exceeded the maximum permitted frame size. The count is incremented when the MAC service returns the frameTooLong status to the LLC.
Buffer overflows on receive	This attribute counts the number of times that the receive buffer overflowed.
Buffer overflows on transmit	This attribute counts the number of times that the transmit buffer overflowed.
Single collision frame counter	This attribute counts successfully transmitted frames whose transmission was delayed by exactly one collision.
Multiple collisions frame counter	This attribute counts successfully transmitted frames whose transmission was delayed by more than one collision.
SQE counter	This attribute counts the number of times that the SQE test error message was generated by the PLS sublayer.
Deferred transmission counter	This attribute counts frames whose first transmission attempt was delayed because the medium was busy. The count does not include frames involved in collisions.

Table 15: OMCI Statistics Attributes

Attribute	Description
Internal MAC transmit error counter	This attribute counts frames whose transmission failed due to an internal MAC sublayer transmit error.

5- 4.2 PON Statistics

This section includes the following topics:

- [View OLT Statistics, page 141](#)
- [View ONU Statistics, page 148](#)

PON statistics are the OLT or ONU statistics collected and reported by the MXK-F OLT.

The Downstream stats are the stats that were sent from the MXK to the ONU, and the upstream stats was sent from the ONU to the MXK.

5- 4.2.1 View OLT Statistics

The MXK-F OLT can report these stats types for an OLT interface: GPON physical layer stats for OLT (i.e. *gpon*), Ethernet layer stats (i.e. *rmon*), and interface layer stats (i.e. *intf*). The GPON physical layer stats are only available on OLT interfaces.

The MXK-F OLT can report these stats types for an ONU interface: ONU physical layer stats for ONU (i.e. *onu*) and interface layer stats (i.e. *intf*). The ONU physical layer stats are only available on ONU interfaces.

Collects and display OLT and ONU statistics with the **port statistics** command when specifying an OLT or ONU interface in the *interface name/type*.

Syntax:

port stats *interface name/type stats options*

interface name

interface name, in the format of *shelfID-SlotID-OLTID-ONU*

Type

interface type. e.g. *gponolt*, *gpononu*, *eth*, *linegroup*, etc.

To display stats for the OLT or ONU interface, users must use either *gponolt* or *gpononu* as the *type*.

StatsType

statistics type. The possible stats types are:

- **intf**

refers to mib2 interface statistics. intf is the default value, if there is no stats type specified, system shows intf stats. It is valid for all interface type.

- **rmon**

refers to ethernet remote monitoring statistics. It is valid for ethernet or gponolt interfaces.

- **eth**

refers to ethernet dot3 statistics.

- **olt**

refers to GPON OLT traffic management statistics. It is valid for **gponolt** interfaces only.

- **onu**

refers to GPON ONU error statistics as reported by the MXK OLT. It is valid for **gpononu** interfaces only.

- **all**

refers to all statistics relevant to the interface type.

Procedure:

Viewing OLT Statistics

- 1 When specifying **all** as the stats type, the rmon, OLT and interface stats are displayed for this OLT interface.

```
zSH> port stats 1-3-1-0/gponolt all
***** rmon *****
```

Total Dropped Events	0
Total Dropped Frames	0
Total Bytes	866284
Total Packets	10426
Transmitted Packets	7942
Received Packets	2484
Transmitted Multicast Bytes	0
Received Multicast Bytes	0
Received Multicast Dropped Bytes	0
Transmitted Average Throughput	456
Received Average Throughput	160
Transmitted Bandwidth Occupancy	0
Received Bandwidth Occupancy	0
Total Broadcast Packets	38
Total Multicast Packets	5494
CRC Align Errors	0
Undersize Packets	0
Oversize Packets	0
Transmitted Oversize Packets	0
Received Oversize Packets	0
Fragments	0
Jabbers	0
Collisions	0
Transmitted No Errors	7942
Received No Errors	2484

IPMC Bridged Packets	0
IPMC Routed Packets	0
Transmitted IPMC Dropped Packets	0
Received IPMC Dropped Packets	0
Total Packets 0 to 64 Bytes	0
Total Packets 65 to 127 Bytes	10403
Total Packets 128 to 255 Bytes	0
Total Packets 256 to 511 Bytes	23
Total Packets 512 to 1023 Bytes	0
Total Packets 1024 to 1518 Bytes	0
Total Packets 1519 to 2047 Bytes	0
Total Packets 2048 to 4095 Bytes	0
Total Packets 4095 to 9216 Bytes	0
Received Packets 0 to 64 Bytes	0
Received Packets 65 to 127 Bytes	2473
Received Packets 128 to 255 Bytes	0
Received Packets 256 to 511 Bytes	11
Received Packets 512 to 1023 Bytes	0
Received Packets 1024 to 1518 Bytes	0
Received Packets 1519 to 2047 Bytes	0
Received Packets 2048 to 4095 Bytes	0
Received Packets 4095 to 9216 Bytes	0
Transmitted Packets 0 to 64 Bytes	0
Transmitted Packets 65 to 127 Bytes	7930
Transmitted Packets 128 to 255 Bytes	0
Transmitted Packets 256 to 511 Bytes	12
Transmitted Packets 512 to 1023 Bytes	0
Transmitted Packets 1024 to 1518 Bytes	0
Transmitted Packets 1519 to 2047 Bytes	0
Transmitted Packets 2048 to 4095 Bytes	0
Transmitted Packets 4095 to 9216 Bytes	0
***** olt *****	
Upstream Valid Gem Frames	2484
Upstream Discarded Frames	0
Upstream Gem Frames	2484
Upstream OmcI Frames	2446
Upstream Ploam Frames	11009722
Upstream Idle Ploam Frames	11005260
Downstream Valid Gem Frames	7943
Downstream Discarded Frames	3
Downstream Gem Frames	7946
Downstream OmcI Frames	2410
Downstream Ploam Frames	7836
Downstream Idle Ploam Frames	0
Downstream Pon Valid Ethernet Packtes	5530
Downstream Pon Cpu Packets	2409
Downstream Transmitted Bytes	517230
Upstream Pon Valid Packets	38
Upstream Pon Valid Not Idle Ploams	4462
Upstream Pon Error Ploams	0
Upstream Pon Invalid Packets	0
Upstream Dropped Packets	0
Upstream Dropped Ploams Fifo Full	0
Downstream TM Valid Packets	7943
Downstream TM Crc Packets	0
Downstream TM Dropped Cpu Packets	0
Downstream TM MAC Lookup Miss	0

Statistics on the MXK-F

Downstream TM Packets Forwarded From Hm To Pon	5530
Downstream TM Packets Dropped Gem Pid Not Enabled	3
Downstream TM Q0 Valid Packets	5533
Downstream TM Q0 Dropped Packets	0
Downstream TM Q1 Valid Packets	0
Downstream TM Q1 Dropped Packets	0
Downstream TM Q2 Valid Packets	0
Downstream TM Q2 Dropped Packets	0
Downstream TM Q3 Valid Packets	0
Downstream TM Q3 Dropped Packets	0
Downstream TM Q4 Valid Packets	0
Downstream TM Q4 Dropped Packets	0
Downstream TM Q5 Valid Packets	0
Downstream TM Q5 Dropped Packets	0
Downstream TM Q6 Valid Packets	0
Downstream TM Q6 Dropped Packets	0
Downstream TM Q7 Valid Packets	0
Downstream TM Q7 Dropped Packets	0
Upstream TM Dropped Cpu Packets	0
Upstream TM Dropped Packets Crc Error	0
Upstream TM Dropped Packets Security	0
Upstream TM Learn Failures	0
Upstream TM Q0 Valid Packets	38
Upstream TM Q0 Dropped Packets	0
Upstream TM Q1 Valid Packets	0
Upstream TM Q1 Dropped Packets	0
Upstream TM Q2 Valid Packets	0
Upstream TM Q2 Dropped Packets	0
Upstream TM Q3 Valid Packets	0
Upstream TM Q3 Dropped Packets	0
Upstream TM Q4 Valid Packets	0
Upstream TM Q4 Dropped Packets	0
Upstream TM Q5 Valid Packets	0
Upstream TM Q5 Dropped Packets	0
Upstream TM Q6 Valid Packets	0
Upstream TM Q6 Dropped Packets	0
Upstream TM Q7 Valid Packets	0
Upstream TM Q7 Dropped Packets	0

***** intf *****

Interface Name	1-3-1-0
Operational Status	Up
Received Bytes	225530
Received Packets	2467
Received Multicast Packets	0
Received Broadcast Packets	17
Transmitted Bytes	640830
Transmitted Unicast Packets	2427
Transmitted Multicast Packets	5495
Transmitted Broadcast Packets	21
Received Discards	2472
Received Errors	0
Received Unknown Protocols	0
Transmitted Discards	5504
Transmitted Errors	0
Speed Bits per Second	*** n/a ***
Speed Megabits per Second	2400

2 When specifying **olt** as the stats type, only the GPON OLT physical layer statistics are displayed for this OLT interface.

```

zSH> port stats 1-3-1-0/gponolt olt
Upstream Valid Gem Frames          8591
Upstream Discarded Frames          0
Upstream Gem Frames                 8591
Upstream OmcI Frames               4645
Upstream Ploam Frames              34031574
Upstream Idle Ploam Frames         34017856
Downstream Valid Gem Frames        14400
Downstream Discarded Frames        3
Downstream Gem Frames              14403
Downstream OmcI Frames             4588
Downstream Ploam Frames            12045
Downstream Idle Ploam Frames        0
Downstream Pon Valid Ethernet Packtes 9809
Downstream Pon Cpu Packets         4585
Downstream Transmitted Bytes       920581
Upstream Pon Valid Packets         3946
Upstream Pon Valid Not Idle Ploams 13718
Upstream Pon Error Ploams          0
Upstream Pon Invalid Packets       0
Upstream Dropped Packets           0
Upstream Dropped Ploams Fifo Full  0
Downstream TM Valid Packets        14400
Downstream TM Crc Packets          0
Downstream TM Dropped Cpu Packets  0
Downstream TM MAC Lookup Miss      0
Downstream TM Packets Forwarded From Hm To Pon 9809
Downstream TM Packets Dropped Gem Pid Not Enabled 3
Downstream TM Q0 Valid Packets     9812
Downstream TM Q0 Dropped Packets   0
Downstream TM Q1 Valid Packets     0
Downstream TM Q1 Dropped Packets   0
Downstream TM Q2 Valid Packets     0
Downstream TM Q2 Dropped Packets   0
Downstream TM Q3 Valid Packets     0
Downstream TM Q3 Dropped Packets   0
Downstream TM Q4 Valid Packets     0
Downstream TM Q4 Dropped Packets   0
Downstream TM Q5 Valid Packets     0
Downstream TM Q5 Dropped Packets   0
Downstream TM Q6 Valid Packets     0
Downstream TM Q6 Dropped Packets   0
Downstream TM Q7 Valid Packets     0
Downstream TM Q7 Dropped Packets   0
Upstream TM Dropped Cpu Packets    0
Upstream TM Dropped Packets Crc Error 0
Upstream TM Dropped Packets Security 0
Upstream TM Learn Failures         0
Upstream TM Q0 Valid Packets       3946
Upstream TM Q0 Dropped Packets     0
Upstream TM Q1 Valid Packets       0
Upstream TM Q1 Dropped Packets     0
Upstream TM Q2 Valid Packets       0

```

Upstream TM Q2 Dropped Packets	0
Upstream TM Q3 Valid Packets	0
Upstream TM Q3 Dropped Packets	0
Upstream TM Q4 Valid Packets	0
Upstream TM Q4 Dropped Packets	0
Upstream TM Q5 Valid Packets	0
Upstream TM Q5 Dropped Packets	0
Upstream TM Q6 Valid Packets	0
Upstream TM Q6 Dropped Packets	0
Upstream TM Q7 Valid Packets	0
Upstream TM Q7 Dropped Packets	0

Table 16 defines the GPON OLT physical layer statistics displayed in the **port stats ifName/gponolt** command.

Note that the Downstream stats are the stats that were sent from MXK to ONU, and the upstream stats was sent from ONU to MXK.

Table 16: GPON OLT Physical Layer Statistics Attributes

Attribute	Description
Upstream Valid Gem Frames	The number of valid GEM frames sent in upstream direction.
Upstream Discarded Frames	Total number of discarded GEM frames sent in upstream direction.
Upstream Gem Frames	The number of GEM frames sent in the upstream direction.
Upstream Omci Framers	The number of OMCI frames sent in the upstream direction.
Upstream Ploam Frames	Total number of Physical Layer Operations, Administration and Maintenance (PLOAM) frames sent in the upstream direction. This includes: <ul style="list-style-type: none"> • Total number of PLOAM messages, including idle PLOAMs. • Total number of valid PLOAM messages (not including idle PLOAMs) • Total number of PLOAM messages dropped due to Cyclic Redundancy Check (CRC) errors.
Upstream Idle Ploam Frames	Total number of idle PLOAM frames sent in upstream direction.
Downstream Valid Gem Frames	Total number of valid GEM frames sent in downstream direction.
Downstream Discarded Frames	The number of downstream packets discarded due to CRC errors, MAC lookup miss, congestion, etc.
Downstream Gem Frames	Total number of GEM frames sent in downstream direction.
Downstream Omci Frames	Total number of OMCI frames sent in downstream direction.

Table 16: GPON OLT Physical Layer Statistics Attributes (Continued)

Attribute	Description
Downstream Ploam Frames	Total number of PLOAM frames sent in downstream direction.
Downstream Idle Ploam Frames	Total number of idle PLOAM frames sent in downstream direction.
Downstream PON Valid Ethernet Packets	Total number of valid Ethernet packets sent in downstream direction.
Downstream PON CPU Packets	The number of downstream packets generated by the CPU (MIPS).
Downstream Transmitted Bytes	Total number of bytes transmitted sent in downstream direction.
Upstream PON Valid Packets	Total number of valid PON packets sent in upstream direction.
Upstream PON Valid Not Idle Ploams	Total number of valid non-idle PLOAM messages sent in upstream direction.
Upstream PON Error Ploams	Total number of PON error PLOAM messages sent in upstream direction.
Upstream PON Invalid Packets	The number of upstream errored packets.
Upstream Dropped Packets Inactive Ports	Total number of upstream packets that were dropped because the GEM port ID was not configured.
Upstream Dropped Ploams Fifo Full	Total number of upstream PLOAMs that were dropped because the FIFO buffer was full.
Downstream TM Valid Packets	Total number of valid packets that were sent in downstream direction.
Downstream TM Crc Packets	The number of dropped downstream packets due to CRC errors.
Downstream TM Dropped Cpu Packets	The number of dropped downstream packets originated by the CPU (MIPS).
Downstream TM MAC Lookup Miss	The number of downstream MAC lookup miss events.
Downstream TM Packets Forwarded From Hm To PON	The number of downstream packets forwarded from the header modification stage to the PON.

Table 16: GPON OLT Physical Layer Statistics Attributes (Continued)

Attribute	Description
Downstream TM Packets Dropped Gem Pid Not Enabled	The number of downstream packets dropped because the GEM port ID was not configured correctly.
Downstream TM QN Valid Packets (N=0 to 7)	The number of downstream packets forwarded by egress priority queue [0 to 7] to the PON. Queue 0 is the highest priority; queue 7 is the lowest priority. Packets in the lowest priority queues are dropped first. When the PON link is not active, this counter will not increment.
Downstream TM QN Dropped Packets (N=0 to 7)	The number of downstream packets dropped by egress priority queue [0 to 7] due to congestion. Queue 0 is the highest priority; queue 7 is the lowest priority. Packets in the lowest priority queues are dropped first. When the PON link is not active, this counter will not increment.
Upstream TM Dropped Cpu Packets	The number of upstream packets dropped by the CPU(MIPS), not sent to SGMI interface.
Upstream TM Dropped Packets Crc Error	The number of upstream packets that were dropped because of CRC errors.
Upstream TM Dropped Packets Security	Total number of upstream packets that were dropped because they didn't pass the security rules.
Upstream TM Learn Failures	MAC address learning failures from traffic sent in upstream direction that were due to a full FIFO buffer.
Upstream TM QN Valid Packets (N=0 to 7)	Number of upstream packets forwarded by egress priority queue [0 to 7] to the MXK. Queue 0 is the highest priority; queue 7 is the lowest priority. Packets in the lowest priority queues are dropped first. When the PON link is not active, this counter will not increment.
Upstream TM QN Dropped Packets (N=0 to 7)	Number of upstream packets dropped by egress priority queue [0 to 7] due to congestion. Queue 0 is the highest priority; queue 7 is the lowest priority. Packets in the lowest priority queues are dropped first. When the PON link is not active, this counter will not increment.

5- 4.2.2 View ONU Statistics

Procedure:

Viewing ONU Statistics

- 1 When specifying **onu** as the stats type, the ONU physical layer statistics are displayed for this ONU interface.

```
zSH> port stats 1-3-1-1/gpononu onu
Upstream BIP8 Errors 0
Upstream FEC Corrected Bytes 0
Upstream FEC Corrected Code-words 0
Upstream FEC Uncorrectable Code-words 0
```

```

Upstream Received Code-words          0
Upstream Unreceived Bursts            0
Downstream Remote BIP8 Errors         0
Upstream Remote BIP8 Errors           0
Drift Of Window Indications           0
Message Error Message                 0

```

- 2 When specifying **all** as the stats type, only ONU stats type is displayed for the ONU interface.

```

zSH> port stats 1-3-1-1/gpononu all
Upstream BIP8 Errors                    0
Upstream FEC Corrected Bytes            0
Upstream FEC Corrected Code-words      0
Upstream FEC Uncorrectable Code-words  0
Upstream Received Code-words           0
Upstream Unreceived Bursts             0
Downstream Remote BIP8 Errors          0
Upstream Remote BIP8 Errors             0
Drift Of Window Indications            0
Message Error Message                  0

```

Table 17 defines the GPON ONU physical layer statistics displayed in the `port stats interface/gpononu` command.

Table 17: GPON ONU Physical Layer Statistics Attributes

Attribute	Description
Upstream BIP8 Errors	Total number of upstream Bit-Interleaved Parity with eight bit (BIP8) errors per ONU-ID.
Upstream FEC Corrected Bytes	Total number of upstream FEC corrected bytes per ONU-ID.
Upstream FEC Corrected Code-words	Total number of upstream FEC corrected code words per ONU-ID.
Upstream FEC Uncorrectable Code-words	Total number of upstream FEC uncorrected code words per ONU-ID.
Upstream Received Code-words	Total number of upstream code words transmitted per ONU-ID.
Upstream Unreceived Bursts	Total number of upstream un-received bursts per ONU-ID.
Downstream Remote BIP8 Errors	Total number of downstream remote BIP8 errors per ONU-ID.

Table 17: GPON ONU Physical Layer Statistics Attributes

Attribute	Description
Upstream Remote BIP8 Errors	Total number of upstream remote BIP8 errors per ONU-ID.
Drift Of Window Indications	The number of times the average drift for the ONU exceeds the drift threshold.
Message Error Message	The number of error messages sent from the ONU.

INDEX

A

Acronyms.....	9
Alarms	
Alarm Manager	60
Alarm Suppression	61
bridge loop detection alarm.....	97
Ethernet Port Alarms.....	68
GPON/XGPON1/NG-PON2 Alarms	69
High/Low Chassis Temp Alarms	63
system 0 Default Alarms	59
ARP.....	9

B

Bridge	
bridge loop detection alarm.....	97
bridge statistics.....	117
bridging loop prevention	93
broadcast storm protection.....	100

C

Card	
information.....	18
Monitoring (slots command).....	18
Chassis	
High/Low Chassis Temp Alarms	63

E

Ethernet Port	
Alarms	68

F

fan tray monitoring	15
---------------------------	----

G

GPON	
GPON/XGPON1/NG-PON2 Alarms	69
GPON/XGPON1/NG-PON2 Traps.....	91
Monitoring.....	136

Statistics.....	136
-----------------	-----

H

High/Low Chassis Temp Alarms	63
------------------------------------	----

L

Logs	
log messages	45
log serial command.....	45
log session command.....	45
logging	46
logging message format.....	48
logging messages for the system	46

M

Monitor	
Cards	18
Chassis	15
Fan Tray.....	15
ONT Inventory and Status	37
Ports - MXK-F14xx.....	22
Ports - MXK-F219.....	25
SFPs and QSFPs	26

O

OLT acronym definition	9
ONT	
acronym definition.....	9
Inventory and Status	37
ONU acronym definition.....	9

P

packet-rule-record	
broadcast storm protection.....	100

Q

QSFP	
QSFP Monitoring	26

R

runtime statistics 115

S

SFP

acronym definition 9

SFP Monitoring 26

shelfctrl monitor command 15

SLMS acronym definition 9

SNMP acronym definition 9

Statistics

bridge statistics 117

Ethernet port enhanced statistics 121

GPON Statistics 136

runtime statistics 115

System administration

log messages 45

log serial command 45

log session command 45

System Monitor

ONT Inventory and Status 37

System Monitoring

Cards 18

Chassis 15

Fan Tray 15

logging 46

logging message format 48

Ports - MXK-F14xx 22

Ports - MXK-F219 25

SFPs and QSFPs 26

shelfctrl monitor command 15, 17

system logging messages 46

T

TFTP acronym definition 9

Traps

GPON/XGPON1/NG-PON2 Traps 91

system 0 Default Traps 59

Z

ZMS 9