

Zhone CLI Reference Guide

For software version 1.13.2

April 2007

Document Part Number: 830-00506-19



Z H O N E TM

Zhone Technologies
@Zhone Way
7001 Oakport Street
Oakland, CA 94621
USA
510.777.7000
www.zhone.com
info@zhone.com

COPYRIGHT ©2000-2007 Zhone Technologies, Inc. All rights reserved.

This publication is protected by copyright law. No part of this publication may be copied, distributed, displayed, modified, transmitted, stored in a retrieval system, or translated without express written permission from Zhone Technologies, Inc.

Acculink, ADSL/R, Bitstorm, Comsphere, DSL the Easy Way, Etherloop, FrameSaver, GigMux, GranDSLAM, GrandVIEW, Hotwire, the Hotwire logo, iMarc, JetFusion, Jetstream, JetVision, MALC, NextEDGE, Net to Net Technologies, Paradyne, the Paradyne logo, Quick Channel, Raptor, ReachDSL, SLMS, StormPort, TruePut, Z-Edge, Zhone, ZMS, and the Zhone logo are trademarks owned by Zhone Technologies, Inc., which may be registered in some jurisdictions.

Zhone Technologies makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability, noninfringement, or fitness for a particular purpose. Further, Zhone Technologies reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation of Zhone Technologies to notify any person of such revision or changes.

CONTENTS

About This Guide	7
Style and notation conventions	7
Typographical conventions.....	7
Acronyms	8
Related documents	9
Contacting Global Service and Support	9
Technical support.....	9
Service requirements.....	10
Chapter 1 Introduction to the CLI	11
Terminology	11
Logging in	12
Profile indexes	13
Virtual.....	13
Automatically provisioned if-translate records.....	13
Physical interfaces.....	13
Virtual interfaces.....	13
Basic commands	13
Viewing profiles	15
Viewing records	16
Viewing commands	16
Getting help on a command.....	17
Finding a command.....	17
Modifying records	18
new command.....	18
Displaying parameter values.....	19
update command.....	20
delete command.....	21
ifTypes	21
CLI shortcuts	22
Command completion.....	22
Command shortcuts.....	23
Basic control commands.....	23

	Movement and search commands	24
	Insert and change commands	25
	Delete commands	25
	Put and undo commands.....	26
Chapter 2	Commands	27
	A	27
	B	32
	C	45
	D	62
	E	75
	F.....	77
	G.....	91
	H.....	95
	I.....	100
	L.....	117
	M.....	127
	N.....	130
	P.....	131
	R.....	134
	S.....	145
	T.....	184
	U.....	187
	V.....	190
	W.....	207
	Z.....	208
	Alphabetic List of Parameters.....	209
Chapter 3	Parameters	217
	ADSL	217
	ATM	229
	Bridging.....	247
	Card	251
	Channel Emulation Service (CES)	259
	Clocking.....	261
	DHCP	264

DNS	277
DS1	279
DS3	287
DSL	293
ELCP	299
Ethernet	302
FXS/FXO	307
GR303	313
IfIndex	319
IMA	322
IP	327
ISDN	335
MTAC/Ring	337
Network Time Protocol	338
PON	341
PPPoA	342
RIP	355
RS232	359
SHDSL	362
Sechtor 100A environmental	367
SNMP	368
SONET	370
Subscriber	376
System	378
V5.2	381
VDSL	394
Voice	395
User	404
VOIP	406
ZMS	414
Index	417



ABOUT THIS GUIDE

This guide is intended for use by system users or administrators.



Note: This document describes all the parameters and commands in the Zhone CLI. The parameters and commands that appear on a particular system depend on the system software running and the hardware configuration of the device.

Style and notation conventions

The following conventions are used in this document to alert users to information that is instructional, warns of potential damage to system equipment or data, and warns of potential injury or death. Carefully read and follow the instructions included in this document.



Caution: A caution alerts users to conditions or actions that could damage equipment or data.



Note: A note provides important supplemental or amplified information.



Tip: A tip provides additional information that enables users to more readily complete their tasks.



WARNING! A warning alerts users to conditions or actions that could lead to injury or death.



WARNING! A warning with this icon alerts users to conditions or actions that could lead to injury caused by a laser.

Typographical conventions

The following typographical styles are used in this guide to represent specific types of information.

Bold	Used for names of buttons, dialog boxes, icons, menus, profiles when placed in body text, and property pages (or sheets). Also used for commands, options, parameters in body text, and user input in body text.
Fixed	Used in code examples for computer output, file names, path names, and the contents of online files or directories.
Fixed Bold	Used in code examples for text typed by users.
<i>Fixed Bold Italic</i>	Used in code examples for variable text typed by users.
<i>Italic</i>	Used for book titles, chapter titles, file path names, notes in body text requiring special attention, section titles, emphasized terms, and variables.
PLAIN UPPER CASE	Used for environment variables.
Command Syntax	Brackets [] indicate optional syntax. Vertical bar indicates the OR symbol.

Acronyms

The following acronyms appear throughout this manual:

Table 1: Acronyms and their descriptions

Acronym	Description
ARP	Address Resolution Protocol
ATM	Asynchronous Transfer Mode
BAN	Broadband Access Node
DSL	Digital Subscriber Line
GSS	Global Service and Support
HDSL2	High-bit-rate Digital Subscriber Line
IAD	Integrated Access Device
MALC	Multi-Access Line Concentrator
MIB	Management Information Base
PBX	Private Branch Exchange
RIP	Routing Information Protocol
SDSL	Symmetric Digital Subscriber Line
SLMS	Single Line Multi-Service

Table 1: Acronyms and their descriptions

Acronym	Description
SNMP	Simple Network Management Protocol
TFTP	Trivial File Transfer Protocol
VCI	Virtual Channel Identifier
VCL	Virtual Channel Link
VPI	Virtual Path Identifier
ZMS	Zhone Management System

Related documents

Refer to the documentation that came with your Zhone device for information about configuring the device.

Contacting Global Service and Support

Contact Global Service and Support (GSS) if you have any questions about this or other Zhone products. Before contacting GSS, make sure you have the following information:

- Zhone product you are using
- System configuration
- Software version running on the system
- Description of the issue

Technical support

If you require assistance with the installation or operation of your product, or if you want to return a product for repair under warranty, contact GSS. The contact information is as follows:

E-mail	support@zhone.com
Telephone (North America)	877-ZHONE20
Telephone (International)	510-777-7133
Internet	www.zhone.com/support

If you purchased the product from an authorized dealer, distributor, Value Added Reseller (VAR), or third party, contact that supplier for technical assistance and warranty support.

Service requirements

If the product malfunctions, all repairs must be performed by the manufacturer or a Zhone-authorized agent. It is the responsibility of users requiring service to report the need for service to GSS.

1

INTRODUCTION TO THE CLI

This chapter describes how to use the Zhone command line interface (CLI). It contains the following sections:

- [Terminology, page 11](#)
- [Logging in, page 12](#)
- [Basic commands, page 13](#)
- [Viewing profiles, page 15](#)
- [Viewing records, page 16](#)
- [Viewing commands, page 16](#)
- [Modifying records, page 18](#)
- [ifTypes, page 21](#)
- [CLI shortcuts, page 22](#)

Terminology

The following terms are used throughout this document:

Term	Description
Access levels	The privilege level assigned to each user. Access levels determine the commands the user can execute.
Address	Every physical interface in the system has an address. Addressing on Zhone systems is of the form: <i>shelf/slot/port/subport</i> , where subport is a logical interface associated with a physical interface, such as Ethernet interface. Profiles not associated with physical interfaces, such as subscriber profiles, have profile indexes.
CLI	The command line interface. Used to configure the Zhone system.

Term	Description
Command	Commands are used to view, add, delete and configure system profiles. Commands also allow administrators to perform system administrative tasks such as loading new software, adding users, and viewing system status.
Parameter	An item within a profile that you set in order to configure the Zhone system. For example, each Subscriber profile has a Name parameter that contains the name of the subscriber.
Profile	A profile is a template that is used to create records. For example, IP interfaces and SDSL lines have profiles, which are configured by administrative users and associated with a particular address.
Profile index	An index for a profile. Profiles not associated with physical interfaces, such as subscriber profiles, have profile indexes. Profiles associated with physical interfaces, such as SDSL lines, have addresses.
Record	A record is an instance of a profile associated with a particular subscriber, service, or interface. Records store configuration information.
Subscriber	Subscribers are remote users to which the Zhone system provides services.
User	A user is an administrator of the Zhone system. Users log into the unit to configure or manage it.

Logging in

You can access the CLI through a local serial craft connection or through a telnet session.

To access the serial port, configure your terminal interface software with the following settings:

- 9600bps
- 8 data bits
- No parity
- 1 stop bit
- No flow control

Connect a serial crossover cable to the DE-9 port on the unit labeled Serial Craft. At the prompt, enter default username (**admin**) and password (**zhone**):

```
login: admin
password: *****
zSH>
```

Profile indexes

This section describes profile indexes.

Virtual

All non-physical (virtual) **if-translate** records have their shelf, slot, port, subport fields set to zero. These interfaces are accessible by name only. Physical interfaces have both names and *shelf-slot-port-subport* values. Examples of a physical interface types include **hdlsl2**, **adsl**, **sonet**, **atmima**, and **ethernetcmacd**. Examples of virtual interfaces types include **atm**, **aal5**, **rfc1483** and **ip**.

Automatically provisioned if-translate records

The system automatically provisions certain **if-translate** records. These include physical interfaces (for example **hdlsl2** and **adsl**), line group interfaces (**other**), and ATM interfaces (for example **atm**, **aal5**, **rfc1483**). The addressing of these profiles

Physical interfaces

For physical interfaces the name is a dash (-) separated string of shelf, slot, port, subport (*shelf-slot-port-subport*). For example: 1-2-1-0.

Virtual interfaces

For virtual interfaces, the profile address is the same with the addition of the name of the physical interface type on the end (*shelf-slot-port-subport/physicaltype*).

For example, for a virtual interface stacked on an **hdlsl2** interface, the index would be 1-2-1-0-hdsl2.

Basic commands

The CLI contains profiles, which are templates for configuring the system; records, which are specific instances of profiles; and commands, which manipulate records or perform system functions (such as displaying line status).

The following table describes the most important CLI commands.

Command	Description
delete	<p>Deletes a record.</p> <p>Syntax:</p> <p>delete <i>profile-type</i> [<i>index</i> *]</p> <p>where <i>profile-type</i> is the type of profile and * is a wildcard character.</p>
get	<p>Displays the contents of a record.</p> <p>Syntax:</p> <p>get <i>profile-type</i> <i>index</i></p> <p>where <i>profile-type</i> is the type of profile and <i>index</i> is the index of the profile (for example, <i>shelf-slot-port-subport/type</i>).</p>
help	<p>Displays the available commands or help on a particular command.</p> <p>Syntax:</p> <p>help [<i>command</i>]</p>
list	<p>Lists available profiles or displays the contents of a specified profile.</p> <p>Syntax:</p> <p>list [<i>profile-type</i> *]</p> <p>where <i>profile-type</i> is the type of profile and * is a wildcard character.</p> <p>Without options, the list command displays all the profiles on the system.</p>
new	<p>Creates a new record.</p> <p>Syntax:</p> <p>new <i>profile-type</i> <i>index</i></p> <p>where <i>profile-type</i> is the type of profile and <i>index</i> is the index of the profile (for example, <i>shelf-slot-port-subport/type</i>).</p>

Command	Description
show	Displays the content of the specified profile along with the possible values of the parameters. Syntax: show <i>profile-type</i> where <i>profile-type</i> is the type of profile.
update	Updates the contents of an existing record. Syntax: update <i>profile-type index</i> where <i>profile-type</i> is the type of profile and <i>index</i> is the index of the profile (for example, <i>shelf-slot-port-subport/type</i>).

Viewing profiles

To view the profiles on the system, use the **list** command. After each profile is the format of the address or profile index for the profile. For example, the card-profile requires a *shelf/slot/port* address:

```
card-profile: shelf/slot/type/
```

Where *shelf* and *slot* are the physical location of the device and *type* is the type of the card.

 **Note:** The profiles on your system may vary, depending on the configuration of your unit.

For example:

```
zSH> list
aal2-audio-profile: audioProfileIdentifier/apIndex
aal2-cid-profile: ifIndex/vpi/vci/cid
aal2-vcl-profile: ifIndex/vpi/vci
adsl-co-profile: shelf/slot/port
adsl-cpe-profile: shelf/slot/port
adsl-profile: shelf/slot/port
atm-cc: atmVcCrossConnectIndex
atm-if: ifIndex
atm-if-stats: ifIndex
atm-traf-descr: index
atm-traf-descr-idx-next: index
atm-traf-descr-stats: index
atm-vcl: ifIndex/vpi/vci
atm-vcl-param: index
atm-vcl-stats: ifIndex/vpi/vci
atm-vpi: ifIndex/vpi
atm-vpl: ifIndex/vpi
bulk-statistic: index
```

```
bulk-statistics-config: index<SPACE> for next page, <CR>
for next line, A for all, Q to quit
```

Viewing records

To view the configured records of a particular type, enter **list** command then the name of the profile. For example:

```
zSH> list atm-vcl
atm-vcl 1-6-1-0-sonet/atm/0/35
atm-vcl 1-6-1-0-sonet/atm/0/36
atm-vcl 1-6-1-0-sonet/atm/0/37
atm-vcl 1-6-2-0-sonet/atm/0/35
atm-vcl 1-6-2-0-sonet/atm/0/36
atm-vcl 1-6-2-0-sonet/atm/0/37
```

To view all configured records on the system, use the list command with the wildcard character (*):

```
zSH> list *
aal2-audio-profile 7/1
aal2-audio-profile 7/2
aal2-audio-profile 7/3
aal2-audio-profile 8/1
aal2-audio-profile 8/2
aal2-audio-profile 9/1
aal2-audio-profile 10/1
aal2-audio-profile 10/2
aal2-audio-profile 11/1
aal2-audio-profile 11/2
aal2-audio-profile 12/1
aal2-audio-profile 12/2
aal2-audio-profile 12/3
atm-cc 14
atm-cc 5
atm-cc 6
atm-cc 7
atm-cc 8
atm-cc 1
<SPACE> for next page, <CR> for next line, A for all, Q to
quit
```

Viewing commands

To see a list of all the commands available, along with a short description of their use, enter the **help** command without arguments:

```
zSH> help
 1 help [commands]
 2 adduser
 3 ata - initialize/show ATA flash partitions.
```

```

4 bootstate - <slot> display the boot state of a given
slot card
5 cd - change current directory.
6 changepass
7 commit <profile-type> <profile-storage-key>
8 copy - copy a file.
9 create <profile-type> <profile-storage-key>
10 del - Delete a file.
11 delete <profile-type> <profile-storage-key>
Wildcards may be used in the profile-storage-key.
12 deleteuser <userName>
13 dir - list directory contents.
14 dump <[console] | [file filename] | [network host
filename]>
15 eeset elementID elementValue <epromID> <slot>
16 eeshow eepromName <slot>
17 featurebitdisplay <featurenum>
18 featurebitset offset mask value hashCode
19 fhrameping shelf/slot</port>
20 file - download/upload files.
21 filter command [arguments]
Type A<CR> to print all, <CR> to continue, Q<CR> to stop:

```

Getting help on a command

To get help on a particular command, enter the **help** command with the name of the command. For example:

```

zSH> help get
Usage: get <profile-type> <profile-storage-key>
This command retrieves an existing profile record and
displays its contents.
EX: zSH> get a-profile <profile-storage-key>
zSH> show a-profile
aField: ----->[0 - 1]
bField: ----->[0 - 2]
cField: ----->[0 - 5]
dField: ----->[0 - 7]
Note: A message is displayed if there is no record
matching the profile storage key

```

Finding a command

The **find** command allows you to search through the available commands. The command uses the following syntax:

```
find [-s(ubSearch) | -d(etailed)] stringToSearch
```

-s

Search the previous search results for the specified string.

-d

Search the online help for each command for the specified string.

-ds or -sd

Search the online help of the commands in the previous search for the specified string.

substring

The string to search for.

For example, the following command finds all commands containing the string “show”:

```
zSH> find show
eeshow                msgtrafficshow
show                  showdatetime
showlinestatus       showlogo
showresolver         showuser
showzhonecpe
```

Modifying records

The **new**, **update**, and **delete** commands are the primary commands to modify records.

new command

The **new** command creates new profiles. Some profiles, such as those associated with physical devices, can only be created if the device is installed in the system.

The following example creates a new **ip-interface-record**. Press Enter to accept the default value:

```
zSH> new ip-interface-record 1-1-1-0/ip
Please provide the following: [q]uit.
vpi: -----> {0}:
vci: -----> {0}:
rdindex: -----> {1}:
dhcp: -----> {none}: ** read-only **
addr: -----> {0.0.0.0}: 192.168.8.21
netmask: -----> {0.0.0.0}: 255.255.255.0
bcastaddr: -----> {0.0.0.0}: 192.168.8.255
destaddr: -----> {0.0.0.0}:
farendaddr: -----> {0.0.0.0}:
mru: -----> {1500}:
reasmmaxsize: -----> {0}:
ingressfiltername: -> {}:
egressfiltername: --> {}:
pointtopoint: -----> {no}:
mcastenabled: -----> {yes}:
ipfwdenabled: -----> {yes}:
mcastfwdenabled: ----> {yes}:
natenabled: -----> {no}:
bcastenabled: -----> {yes}:
ingressfilterid: ----> {0}:
```

```

egressfilterid: ----> {0}:
ipaddrdynamic: -----> {static}:
dhcpserverenable: --> {false}:
.....
Save new record? [s]ave, [c]hange or [q]uit: s
Record created.

```

After entering the values the system displays the values you've entered and prompts you to save the record. If you want to save the changes, press **s**. If you want to make changes, press **c** to re-enter values. Press **q** at any time to quit without saving changes.



Note: The CLI accepts abbreviated or complete input to modify records: You can enter **s** or **save** to save changes, enter **c** or **change** to make more changes, enter **q** or **quit** to stop without saving changes.

Displaying parameter values

There are two ways to display valid values for a parameter, with the **show** command or inline while you are updating the record.

To use the **show** command:

```

zSH> show ip-interface-record
vpi:-----> {0 - 4095}
vci:-----> {0 - 65535}
rdindex:-----> {0 - 2147483647}
dhcp:-----> none client server both
addr:-----> {0 - -1}
netmask:-----> {0 - -1}
bcastaddr:-----> {0 - -1}
destaddr:-----> {0 - -1}
farendaddr:-----> {0 - -1}
mru:-----> {0 - 2147483647}
reasmmmaxsize:-----> {0 - 65535}
ingressfiltername:--> {33}
egressfiltername:--> {33}
pointtopoint:-----> no yes
mcastenabled:-----> no yes
ipfwdenabled:-----> no yes
mcastfwdenabled:----> no yes
natenabled:-----> no yes
bcastenabled:-----> no yes
ingressfilterid:----> {0 - 2147483647}
egressfilterid:----> {0 - 2147483647}
ipaddrdynamic:-----> static ppp dhcpclient
dhcpserverenable:--> true false

```

NOTE: Supported VPI/VCI ranges vary based on card type. See documentation for the exact range of supported VPI/VCI values

To use view the valid enumerated values while updating the record, enter a question mark (?) when prompted for a value:

```
zSH> update ip-interface-record 1-2-1-0/ip
Please provide the following: [q]uit.
vpi: -----> {0}: ?
Invalid entry: vpi range: [0 to 4095]
vpi: -----> {0}:
vci: -----> {0}:
rdindex: -----> {1}:
dhcp: -----> {none}: ** read-only **
addr: -----> {192.168.80.190}: ?
Invalid IP address format. Try "n.n.n.n", where n is 0 to
255
addr: -----> {192.168.80.190}:
netmask: -----> {255.255.252.0}:
bcastaddr: -----> {192.168.83.255}:
destaddr: -----> {0.0.0.0}:
farendaddr: -----> {0.0.0.0}:
mru: -----> {1500}:
reasmmaxsize: -----> {0}:
ingressfiltername: -> {}:
egressfiltername: --> {}:
pointtopoint: -----> {no}:
mcastenabled: -----> {yes}:
ipfwdenabled: -----> {yes}:
mcastfwdenabled: ---> {yes}:
natenabled: -----> {no}:
bcastenabled: -----> {yes}:
ingressfilterid: ---> {0}:
egressfilterid: ----> {0}:
ipaddrdynamic: -----> {static}:
dhcpserverenable: --> {false}:
```

update command

The **update** command changes an existing record. The command uses the following syntax:

The following example updates an **ip-interface-record**:

```
zSH> update ip-interface-record 1-1-1-0/ip
Please provide the following: [q]uit.
vpi: -----> {0}:
vci: -----> {0}:
rdindex: -----> {1}:
dhcp: -----> {none}: ** read-only **
addr: -----> {192.168.8.21}: 192.168.8.23
netmask: -----> {255.255.255.0}:
bcastaddr: -----> {192.168.8.255}:
destaddr: -----> {0.0.0.0}:
farendaddr: -----> {0.0.0.0}:
mru: -----> {1500}:
reasmmaxsize: -----> {0}:
```

```

ingressfiltername: -> {}:
egressfiltername: --> {}:
pointtopoint: -----> {no}:
mcastenabled: -----> {yes}:
ipfwdenabled: -----> {yes}:
mcastfwdenabled: ----> {yes}:
natenabled: -----> {no}:
bcastenabled: -----> {yes}:
ingressfilterid: ----> {0}:
egressfilterid: ----> {0}:
ipaddrdynamic: -----> {static}:
dhcserverenable: --> {false}:
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.

```

delete command

The **delete** command deletes an existing record. You can delete a single record by specifying the address or the index, or multiple records by using a wildcard (*).

Some records, such as **card-profiles**, delete all associated records when you delete them.

ifTypes

[Table 2](#) lists the ifTypes used in Zhone devices.



Tip: When entering an record address, you can specify either the ifType name or its number.

Table 2: ifTypes

ifType	Number	Description
EthernetCsmacd	6	Ethernet
dsl	18	DS1 or E1
basicISDN	20	ISDN BRI
primaryISDN	21	ISDN PRI
ppp	23	Point-to-point protocol
DS3	30	DS3
rs232	33	RS-232
atm	37	ATM cells
sonet	39	SONET or SDH

Table 2: ifTypes (Continued)

ifType	Number	Description
V35	45	V.35
AAL5	49	ATM Adaptation Layer 5
ISDN	63	ISDN or X.25
Async	84	Asynchronous protocols
ADSL	94	Asymmetric Digital Subscriber Loop (ADSL)
radsl	95	Rate-adaptive Digital Subscriber Loop
voiceEM	100	Voice receive and transmit
voiceFXO	101	Foreign Exchange Office
voiceFXS	102	Foreign Exchange Station
voiceEncap	103	Voice encapsulation
voiceOverIp	104	Voice over IP encapsulation
atmima	107	Inverse multiplexing over ATM
IP	126	Internet Protocol
voiceOverATM	152	Voice over ATM
rfc1483	159	Multiprotocol over ATM AAL5
hdsl2	168	High Bit-Rate DSL, 2nd generation or SDSL
shdsl	169	Multirate HDSL2

CLI shortcuts

This section describes the following CLI shortcuts:

- [Command completion, page 22](#)
- [Command shortcuts, page 23](#)

Command completion

Command completion provides a shortcut to entering commands and profile names at the CLI. If you type part of a command or profile name and then press the TAB key, the CLI will present you with either the remaining portion of the command/profile name or a list of possible completions.

If there is one option to complete the line, the CLI will provide the complete command or profile name (as in the following command and profile examples).

```
zSH> sw <TAB>
zSH> swversion
```

If there is more than one option to complete the line, the CLI will display a list of options that could complete command or profile (as in the following command and profile examples).

```
zSH> show <TAB>
show
showdatetime
showhost
showinetstat
showipstat
showlinestatus
showmem
showresolver
showuser
showzhonecpe
zSH> show
```

```
zSH> list atm <TAB>
atm-if
atm-if-stats
atm-traf-descr
atm-traf-descr-idx-next
atm-traf-descr-stats
atm-vcl
atm-vcl-stats
zSH> list atm-
```

Command shortcuts

The Zhone CLI supports vi-like commands. This section describes the CLI command shortcuts.

Basic control commands

[Table 3](#) describes the basic commands to edit, delete, and enter commands into the system.

Table 3: Basic control commands

Command	Description
ESC	Switch the line editing mode from regular input mode.
ENTER	Enter line and leave edit mode.
CTRL + H	Delete a character (backspace).

Table 3: Basic control commands

Command	Description
CTRL + U	Delete and entire line (in edit mode).
CTRL + L	Redraw a line (in edit mode).
CTRL + S	Suspend output.
CTRL + Q	Resume output.

Movement and search commands

Table 4 describes the movement and search commands.

Table 4: Movement and search commands

Command	Description
nG	Go to command n.
/string	Search for the specified string backward in the history buffer.
?string	Search for the specified string forward in the history buffer.
n	Repeats the last search.
nk or n-	Execute the nth previous shell command.
nj or n+	Execute the nth next shell command.
nh	Move the cursor n characters to the left.
nl or SPACE.	Move the cursor n characters to the right.
nw	Move the cursor n words forward. (Words are separated by blanks or punctuation.)
nW	Move the cursor n large words forward. (Large words are separated by blanks only.)
ne	Move the cursor to the end of the next nth word. (Words are separated by blanks or punctuation.)
nE	Move the cursor to the end of the next nth large word. (Large words are separated by blanks only.)
nb	Move the cursor back n words. (Words are separated by blanks or punctuation.)
nB	Move the cursor back n large words. (Large words are separated by blanks only.)
\$	Move cursor to end of the current line.
0	Move cursor to the beginning of the line.

Table 4: Movement and search commands (Continued)

Command	Description
^	Move cursor to the first non-blank character.
fc	Search forward for the character c.
Fc	Search backward for the character c.

Insert and change commands

[Table 5](#) describes the insert and change commands.

Table 5: Insert and change commands

Command	Description
a	Append text.
A	Append text at the end of line.
i	Insert text.
I	Insert text at the end of the line.
ns	Change n characters.
nc SPACE	Change n characters.
cw	Change word.
cc or S	Change the entire line.
c\$ or C	Change from cursor to end of line.
c0	Change from the cursor to the beginning of the line.
R	Type over characters.
nrc	Replace following n characters with c.
~	Toggle case, lower to upper, or upper to lower.

Delete commands

[Table 6](#) describes the delete commands.

Table 6: Delete commands

Command	Description
nx	Delete n characters, beginning at the cursor.
nX	Delete n characters to the left of the cursor.
dw	Delete word.
dd	Delete entire line.

Table 6: Delete commands

Command	Description
d\$ or D	Delete text from the cursor to the end of the line.
d0	Delete text from the cursor to the beginning of the line.

Put and undo commands

[Table 7](#) describes the put and undo commands.

Table 7: Put and undo commands

Command	Description
p	Put last deletion after the cursor.
P	Put last deletion before the cursor.
u	Undo last command.

2 COMMANDS

This chapter describes each of the CLI commands.

A

adduser

Creates a new user account and adds it to the database. The command also generates a random password which the user can change with the **changepass** command.

Syntax `adduser`

Follow the system prompts.

Example `zSH> adduser`
Please provide the following: [q]uit.
User Name: **jjsmith**
User Prompt[zSH>]:
Please select user access levels.
admin: -----> {no}: **yes**
zhonedebug: --> {no}:
voice: -----> {no}:
data: -----> {no}:
manuf: -----> {no}:
database: -----> {no}:
systems: -----> {no}:
tool: -----> {no}:
useradmin: ---> {no}:
.....
User name:(jjsmith) User prompt:(zSH>)
Access Levels:
(admin)
Save new account? [slave, [c]hange or [q]uit: **s**
User record saved.
TEMPORARY PASSWORD: sqgUr2J7

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `changepass`, `deleteuser`

alarm

Displays all active alarms since the last system reboot.

Syntax `alarm show [summary]`

Options `show`

Displays the alarm totals and lists alarm details, such as resource ID and alarm type and alarm severity.

summary

Displays only alarm totals.

Example `zSH> alarm show`

`zSH> alarm show`

```
*****          Central Alarm Manager          *****
ActiveAlarmCurrentCount          :8
ActiveAlarmTotalCount            :9
ClearAlarmTotalCount             :1
OverflowAlarmTableCount          :0
```

ResourceId	AlarmType	AlarmSeverity
1-1-1-0/sonet	linkDown	critical
1-3-1-0/adsl	linkDown	minor
1-3-4-0/adsl	linkDown	minor
1-3-5-0/adsl	linkDown	minor
1-3-6-0/adsl	linkDown	minor
1-3-12-0/adsl	linkDown	minor
1-3-13-0/adsl	linkDown	minor
1-1-1-0/sonet	sonetSectionStatusChange	major

Access Level admin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `powermon`

ata

Initializes, formats, or displays the contents of the system flash cards.



Caution: Formatting or initializing a PC card destroys all existing data on the card.

Syntax `ata [show | format | init] slot`

Options `show`

Displays the flash partition table in the specified PC card.

format

Formats the specified PC card.

init

Initializes the specified PC card by creating partitions and a file system. This destroys all existing data on the card.

slot

The slot that contains the PC card.

Access Level admin

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

atmping

Sends an ATM OAM F4 and F5 loopback cell to a VCL.



Note: You must turn on logging before issuing the **atmping** command.

Syntax `atmping [ifindex/vpi/vci] | [name/type/vpi/vci] | [shelf/slot/port/subport/type/vpi/vci] [segmentF4/F5 | endtoendF4/F5]`

Options **ifindex**

The ifindex of the interface Use the **lineGroup** command to find the ifindex.

vpi

The virtual path identifier of the ATM interface.

vci

The virtual path identifier of the ATM interface.

name

The name of the interface (for example, **uplink1**, or a user-defined name configured in the **if-translate** profile for the interface).

shelf/slot/port/subport

The physical location of the interface. For the Sector 100A and the Z-Edge, shelf and slot are always 1.

type

IANA type for the interface. For example, **adsl**, **ds1**, **ds3**, **hdl2**, **sonet**.

segmentF4/F5

Sends the ping to the next ATM interface using either F4 (VP) or F5 (VC) loopback cells. This option is currently unsupported.

endtoendF4/F5

Sends the ping to the far-end ATM interface.

Example Enable logging before issuing a **atmping** command.

```
zSH> log serial on
Serial port logging enabled.
```

If you are connected to the device over a network:

```
zSH> log session on
Logging enabled.
```

Find the VCL which you want to ping:

```
zSH> list atm-vcl
atm-vcl 1-1-1-0-hdsl2/atm/0/35
atm-vcl 1-1-1-0-hdsl2/atm/0/36
atm-vcl 1-1-16-0-hdsl2/atm/0/37
```

For example, to manually send segment and end-to-end OAM F4 loopbacks and segment OAM F5 loopbacks, issue the following commands:

```
zSH> atmping uplink1/atm/0/37 segmentf4
zSH> Received OAM ping response for uplink1, vpi 0 ,vci 37
APR 06 20:31:22: info : 1/1/16 : atmmgr: atmMgrDrv.c:
AtmMgrOamPingRspProcess(): l=4492: atmmgr: Received OAM
ping response for uplink1, vpi 0, vci 37
```

```
zSH> atmping uplink1/atm/0/37 endtoendf4
zSH> Received OAM ping response for uplink1, vpi 0 ,vci 37
APR 06 21:00:18: info : 1/1/16 : atmmgr: atmMgrDrv.c:
AtmMgrOamPingRspProcess(): l=4492: atmmgr: Received OAM
ping response for uplink1, vpi 0, vci 37
```

```
zSH> atmping uplink1/atm/0/37 segmentf5
zSH> Received OAM ping response for uplink1, vpi 0 ,vci 37
APR 06 20:32:11: info : 1/1/16 : atmmgr: atmMgrDrv.c:
AtmMgrOamPingRspProcess(): l=4492: atmmgr: Received OAM
ping response for uplink1, vpi 0, vci 37
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge

atmvclshow

The **atmvclshow** command provides the administrative user with the ability to view Virtual Channel Link (VCL) status information, as well as audit members in a traffic descriptor group.

Syntax **atmvclshow** [**port** [**vpi vci**]]

Options **(no option)**

Displays global information of all ATM VCL records on the system.

port

Displays all ATM VCL records on the specified port.

port vpi vci

Displays the ATM VCL record on a singular occurrence of a VCL.

Example 1 This first example displays a global ATM VCL record which includes the task state, message count, error rate, and shelf/slot/port/VPI/VCI information. In this instance, the ATM VCL record displays information on shelf 1, slot 1, port 8.

```
zSH> atmvclshow
ATMMGR task state = READY
```

```

ATMMGR rx msg cnt = 1778
ATMMGR rx errors = 0
shelf = 1 slot = 1
VC Switched vpi = 4 vci = 202 ifIndex = 0xc (12) port = 1
    rxTdIndex = 1 txTdIndex = 1
    MPHY bank = 0 Priority Queue = 0
    vclState = active adminStatus = up, AALType = aal2(6)
    connId=263 intVpi = 0 intVci = 36

VC Switched vpi = 4 vci = 203 ifIndex = 0xc (12) port = 1
    rxTdIndex = 1 txTdIndex = 1
    MPHY bank = 0 Priority Queue = 0
    vclState = active adminStatus = up, AALType = aal2(6)
    connId=262 intVpi = 0 intVci = 35

VC Switched vpi = 4 vci = 208 ifIndex = 0xc (12) port = 1
    rxTdIndex = 1 txTdIndex = 1
    MPHY bank = 0 Priority Queue = 0
    vclState = active adminStatus = up, AALType = aal2(6)
    connId=261 intVpi = 0 intVci = 34
<SPACE> for next page, <CR> for next line, A for all, Q to quit

```

Example 2 This second example shows all of the ATM VCL records. In this instance, the ATM VCL record displays status information of all VCLs on port 1.

```

zSH> atmvc1show 1
ATMMGR task state = READY
ATMMGR rx msg cnt = 1779
ATMMGR rx errors = 0
shelf = 1 slot = 1

VC Switched vpi = 4 vci = 202 ifIndex = 0xc (12) port = 1
    rxTdIndex = 1 txTdIndex = 1
    MPHY bank = 0 Priority Queue = 0
    vclState = active adminStatus = up, AALType = aal2(6)
    connId=263 intVpi = 0 intVci = 36

VC Switched vpi = 4 vci = 203 ifIndex = 0xc (12) port = 1
    rxTdIndex = 1 txTdIndex = 1
    MPHY bank = 0 Priority Queue = 0
    vclState = active adminStatus = up, AALType = aal2(6)
    connId=262 intVpi = 0 intVci = 35

VC Switched vpi = 4 vci = 208 ifIndex = 0xc (12) port = 1
    rxTdIndex = 1 txTdIndex = 1
    MPHY bank = 0 Priority Queue = 0
    vclState = active adminStatus = up, AALType = aal2(6)
    connId=261 intVpi = 0 intVci = 34
<SPACE> for next page, <CR> for next line, A for all, Q to quit

```

Example 3 This third example shows the ATM VCL record on a specific VCL as defined by the port, VCI, and VPI. In this instance, the ATM VCL record displays port 1, VPI of 4, and VCI of 202.

```
zSH> atmvc1show 1 4 202
ATMMGR task state = READY
ATMMGR rx msg cnt = 1779
ATMMGR rx errors = 0
shelf = 1 slot = 1

VC Switched vpi = 4 vci = 202 ifIndex = 0xc (12) port = 1
  rxTdIndex = 1 txTdIndex = 1
  MPHY bank = 0 Priority Queue = 0
  vclState = active adminStatus = up, AALType = aal2(6)
  connId=263 intVpi = 0 intVci = 36
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A

B

bond show

Display the configured bond groups by link interface, bond group, slot number, or a bond groups on a device.

Syntax `bond show all | slot slotNum | group groupName | link interface`

Options all

Displays all bond groups on a device.

slot slotnum

Displays all bond groups for the specified slot.

group groupname

Displays all bond groups for the specified bond group, for example 1-2-103-0/n2nbond.

link interface

Displays all bond groups and group members for the specified interface and type, for example 1-2-1-0/ds1.

Example 1 zSH> bond show all

Bond Groups					
Slot	GrpId	Name	Type	State	
8	207	1-8-207-0	n2nbond	ACT	
8	201	1-8-201-0	n2nbond	OOS	
8	203	1-8-203-0	n2nbond	ACT	

Example 2 zSH> bond show slot 8

Bond Groups					
Slot	GrpId	Name	Type	State	
8	207	1-8-207-0	n2nbond	ACT	
8	201	1-8-201-0	n2nbond	OOS	

```
8      203      1-8-203-0      n2nbond      ACT
```

Example 3 zSH> **bond show group 1-8-203-0/n2nbond**

```

Bond Groups
Slot  GrpId  Name          Type          State
8     203     1-8-203-0    n2nbond       ACT
```

```

Group Members
Slot  Port    Name          Type          State
8     3       1-8-3-0      ds1           ACT
8     4       1-8-4-0      ds1           ACT
8     5       1-8-5-0      ds1           ACT
```

Example 4 zSH> **bond show group 112**

```

Bond Groups
Slot  GrpId  Name          Type          State
8     207     1-8-207-0    n2nbond       ACT
```

```

Group Members
Slot  Port    Name          Type          State
8     7       1-8-7-0      ds1           ACT
8     8       1-8-8-0      ds1           ACT
```

bootstate

Displays the boot state of a card in the system.

Syntax **bootstate slotcard**

Options **slotcard**

Number of the slot card.

Example 1 The following example shows the slot card in slot 8 in the middle of loading its image.

```
zSH> bootstate 8
Boot State: Loading Image over backplane
```

Example 2 The following example shows the output of the **bootstate** command if there is no slot card in the slot:

```
zSH> bootstate 6
POST Result Register Value = 255
```

Example 3 The following example shows the output of the **bootstate** command for a slot card that has successfully booted:

```
zSH> bootstate 3
Boot State: BootMgr: Booting Completed Successfully
```

Access Level user

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also **slotreboot**

bridge

The **bridge** command can add, delete, or show bridges. A flush option is also available to purge bridge filters of learned MAC entries, either separately or for a specified interface. The MALC supports a maximum of 1024 bridges.



Note: Only learned bridge entries are purged with this command. Static bridge entries are not removed with this command.

Syntax `bridge add interface/type`

```
[vc vpi/vci] [tc tcvalue] [td tdvalue | txt d txt dvalue |
rxt d rxt dvalue] other | llc [uplink | downlink |
intralink | tpid tpid value| vlan vlan_id | slan slan
value | tagged | untagged] [cos cosvalue] [outcosall
outcos value] scos scos value | soutcosall soutcos value
| video mcastctrl/maxvideostreams | config
confgiGroupIndex | pppoa | name ifname
```

add

Add a bridge interface on the specified physical interface.

*interface**type*

Name and type of the physical interface.



Note: In the bridge add command, <slot> and <port> may be replaced with brackets containing numbers in series and/or (dash-separated) ranges; <port> may be replaced with wildcard '*' for all ports on the card.

Examples:

```
zSH> bridge add 1-3-*-0/adsl vc 0/37 td 3661
downlink vlan 500
```

```
zSH> bridge add 1-[10-13]-[1,3-5,21]-0/ds3 vc 0/37
td 3661 downlink vlan 500
```

vc vpi/vci

Used to specify the VPI and VCI values for ATM circuits. For example: **0/23**. This is a mandatory field if you are creating a bridge on an ATM logical interface. This field is not required if you are creating a bridge on an Ethernet interface.

tc tcvalue

Traffic container information. This is a mandatory field if you are creating a bridge on a PON physical interface. This field is not required for non-PON interfaces.

td tdvalue | rxt d rxt dvalue | txt d txt dvalue

Used to specify the traffic descriptor index to be used. Optionally, separate **rxt d rxt dvalue** and **txt d txt dvalue** values may be specified for ADSL connections, where separate traffic descriptors are used for the

upstream and downstream traffic due to the asymmetric nature. This is a mandatory field if you are creating a bridge on an ATM logical interface. This field is not required if you are creating a bridge on an Ethernet interface.

other | llc

The type of AAL5 data encapsulation used: **llc** sets logical link control encapsulation over AAL5, which is commonly used with routers; **other** sets RFC 1483 multiprotocol encapsulation over AAL5, which is commonly used with bridges. If no value is given, the AAL5 encapsulation type default is **llc**.

uplink | downlink | intralink

Indicates bridging behavior of the interface. This field is omitted when creating transparent bridges.

- Uplink

Causes the interface to forward packets to the network. Uplink interfaces support one or more bridging domains and allow VLANs that terminate on a MALC IP interface. Broadcasts received on an uplink port are not sent to any downlink port, except for ARP and DHCP when **customARP** and **customDHCP** options are enabled. Unicast packets received on an uplink are forwarded to the downlink where the MAC address was learned. Uplink ports do not learn MAC addresses and do not strip or insert VLAN tags.

- downlink

Causes the interface to send packets to the customer interface. Requires a specific VLAN ID or VLAN tagging.

Downlink interfaces with a specific VLAN ID perform strip and insert function for outgoing and incoming traffic and learn MAC addresses. All traffic (unicast and broadcast) received on a downlink is sent to the default interface as specified in the **bridge-path default** command.

Tagged downlink interfaces do not strip and insert VLAN tags. Other downlink interface functions are identical.

- Intralink

Causes the interface to forward all traffic from the uplink that is not local.

- No value creates a transparent bridge. Transparent bridges send broadcasts to all ports, learn an unlimited number of MAC addresses on a port, and allow any port to send traffic to any other port.

vlan *vlan_id*

VLAN identifier associated with the interface. This is a mandatory field for downlink interfaces that do not use the tagged option.

slan *slan_id*

SLAN or secondary VLAN identifier associated with the interface.

tagged | untagged

The tagged/untagged status of the bridge. The tagged option is a mandatory field if you are creating a VLAN on a downlink interface and do not specify a specific LAN ID.

cos *cos_value*

Class of Service level associated with the interface.

outgoingCOSOption

Specifies whether to overwrite the VLAN priority bits on packets bridged out this interface with the value specified in the `outgoingCOSValue` parameter. Values are `disable` and `all`. `Disable` indicates the VLAN priority bit is untouched. `All` overwrites all the VLAN priority bits on packets bridged out this interface with the value specified in the `outgoingCOSValue` parameter. The default is `disable`.

outgoingCOSValue

For tagged packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

video *m/n*

Specifies the multicast control list and the `maxvideostreams` for the video signal.

`Maxvideostreams` specifies the maximum number of allowed video streams. To enable this setting, the multicast control list must be used. This option is only available when for bridge video configuration.

`Mcastctrl` specifies the multicast control list to use. This option is only available when for bridge video configuration.

config *configGroupIndex*

Specifies the bridge config group for this bridge interface. A bridge-config-record with this group index must exist.

pppoa

Specifies this is a PPPoA port.

name *ifname*

The name for the interface. This is an optional field.

Syntax `bridge modify interface/type uplink | downlink | intralink | tpid tpid value | vlan vlan_id | slan slan value | tagged | untagged] [cos cosvalue] [outcosall outcos value] scos scos value | soutcosall soutcos value | video mcastctrl/maxvideostreams | config confGroupIndex | pppoa | name ifname`

interface/type

Name and type of the physical interface.



Note:

```
zSH> bridge modify 1-5-*-0/shdsl vc 0/35 maxUnicast 9
zSH> bridge modify 1-5-[1,2]-0/shdsl vc 0/35 vlan 3
```

uplink | downlink | intralink

Indicates bridging behavior of the interface. This field is omitted when creating transparent bridges.

- **Uplink**
Causes the interface to forward packets to the network. Uplink interfaces support one or more bridging domains and allow VLANs that terminate on a MALC IP interface. Broadcasts received on an uplink port are not sent to any downlink port, except for ARP and DHCP when **customARP** and **customDHCP** options are enabled. Unicast packets received on an uplink are forwarded to the downlink where the MAC address was learned. Uplink ports do not learn MAC addresses and do not strip or insert VLAN tags.
- **downlink**
Causes the interface to send packets to the customer interface. Requires a specific VLAN ID or VLAN tagging.
Downlink interfaces with a specific VLAN ID perform strip and insert function for outgoing and incoming traffic and learn MAC addresses. All traffic (unicast and broadcast) received on a downlink is sent to the default interface as specified in the **bridge-path default** command. Tagged downlink interfaces do not strip and insert VLAN tags. Other downlink interface functions are identical.
- **Intralink**
Causes the interface to forward all traffic from the uplink that is not local.
- **No value** creates a transparent bridge. Transparent bridges send broadcasts to all ports, learn an unlimited number of MAC addresses on a port, and allow any port to send traffic to any other port.

vlan *vlan_id*

VLAN identifier associated with the interface. This is a mandatory field for downlink interfaces that do not use the tagged option. Multiple VLAN interfaces can be added to the same physical port and VC.

slan *slan_id*

SLAN or secondary VLAN identifier associated with the interface.

tagged | untagged

The tagged/untagged status of the bridge. The tagged option is a mandatory field if you are creating a VLAN on a downlink interface and do not specify a specific LAN ID.

cos *cos_value*

Class of Service level associated with the interface.

outgoingCOSOption

Specifies whether to overwrite the VLAN priority bits on packets bridged out this interface with the value specified in the outgoingCOSValue parameter. Values are disable and all. Disable indicates the VLAN priority bit is untouched. All overwrites all the VLAN priority bits on packets bridged out this interface with the value specified in the outgoingCOSValue parameter. The default is disable.

outgoingCOSValue

For tagged packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

video m/n

Specifies the multicast control list and the maxvideostreams for the video signal.

Maxvideostreams specifies the maximum number of allowed video streams. To enable this setting, the multicast control list must be used. This option is only available when for bridge video configuration.

Mcastctrl specifies the multicast control list to use. This option is only available when for bridge video configuration.

config configGroupIndex

Specifies the bridge config group for this bridge interface. A bridge-config-record with this group index must exist.

pppoa

Specifies this is a PPPoA port.

name ifname

The name for the interface. This is an optional field.

Syntax `bridge delete Interface/type vc vpi/vci [vlan vlanID]`

delete

Delete a bridge interface from the specified physical interface.

Interface/type

Name and type of the physical interface, such as **1-4-3-0/adsl**.



Note: In the bridge delete command, <slot> and <port> may be replaced with brackets containing numbers in series and/or (dash-separated) ranges; <port> may be replaced with wildcard '*' for all ports on the card.

Examples:

1-[10-13]-[1,3-5,21]-0/ds3 for DS3 ports 1,3,4,5,21 on cards 10,11,12, and 13.

1-[6,7,9]-*-0/adsl for all ADSL ports on cards 6, 7, and 9.

vc vpi/vci

ATM layer information for bridge over ATM (for example, vc 0/35). Omitted for bridge over Ethernet

vlan vlanID

For downlink bridges with VLANS, to delete the bridge the VLAN ID must be specified.

Syntax `bridge show vlan vlan_id | interfaceName/bridge`

show

The **bridge show** command displays a truncated record for the bridge.

vlan *vlan_id*

List all bridge interfaces for the specified VLAN. This includes tagged interfaces, but only the bridge filter table information for the specified VLAN is displayed.

interfaceName/bridge

List only the information for specified bridge interface.

Syntax `bridge showall vlan vlan_id | interfaceName/bridge`

showall

The **bridge showall** command displays the entire contents of bridge record.

Syntax `bridge flush <<interface> <ifIndex>|<name>/<type>> | mac <vlan> <MAC addr>> | all`

ifIndex

ifIndex value of the bridge interface.

interfacetype

Name and type of the bridge interface.

vlan

VLAN identifier associated with the bridge interface. For the **mac** option, the *vlan* must be specified even if it is 0.

MAC_addr

The MAC address associated with the specified VLAN. The **mac_address** is in hexadecimal notation (for example, 00:01:02:03:04:05).

all

Clears all MAC addresses on all interfaces.

Syntax `bridge igmp bridge igmp | slot slotnumber | interfaceName/bridge`

slot *slot number*

Displays IGMP information for the bridges configured on the specified slot.

interfacename bridge

Displays IGMP information for the bridges configured on the specified interface.

Syntax `bridge stats | clear | vlan vlanId | interfaceName/bridge`

Show statistics for bridge interfaces. If no option is specified, statistics are displayed for all bridges.

clear

Clears the statistics for the bridge interfaces.

vlan *vlanId*

Displays bridge interfaces statistics for the specified VLAN.

interfaceName

Displays bridge interfaces statistics for the specified bridge interface.

Example 1 Create an untagged downlink (over ATM):

```
zSH> bridge add 1-7-1-0/shdsl vc 0/35 td 1 downlink vlan vlan-id
```

Example 2 Create a tagged downlink (over ATM):

```
zSH> bridge add 1-7-1-0/shdsl vc 0/35 td 1 downlink tagged
```

Example 3 Create an uplink over Ethernet:

```
zSH> bridge add 1-1-1-0/ethernetcsmacd uplink
```

Example 4 Delete an untagged downlink (over ATM):

```
zSH> bridge delete 1-7-1-0/shdsl vc 0/35
```

Example 5 Delete a tagged downlink (over ATM):

```
zSH> bridge delete 1-7-1-0/shdsl vc 0/35
```

Example 6 Delete an uplink over Ethernet:

```
zSH> bridge delete 1-1-1-0/ethernetcsmacd
```

Example 7 Display bridges created:

```
zSH> bridge show
VLAN   Bridge                               State   Table Data
-----
0 1-8-2-0-ads1-0-101/bridge           UP
0 1-1-1-0-ethernetcsmacd/bridge       UP
```

Example 8 This example adds interface 1-8-22-0/adsl with a vlanIDCOS value of 7. This value is inserted into the priority field of the VLAN header when an untagged packet received on this interface is tagged (VLAN ID inserted) for bridging.

```
bridge add 1-8-22-0/adsl vc 0/35 td 20000 downlink vlan 100 tagged COS 7
```

Example 9 This example adds interface 1-8-22-0/adsl with a vlanIDCOS value of 7 and enables the overwriting of the VLAN ID in all outgoing packets with the value of 7.

```
bridge add 1-8-22-0/adsl vc 0/35 td 20000 downlink vlan 100 tagged COS 7 outCOS
all 7
```

Example 10 Purges the learned MAC entries and IGMP client tables for the specified bridge interface.

```
zSH> bridge showall
VLAN   Bridge                               State   Table Data
-----
```

```

0    1-3-1-0-adsl-0-35/bridge    UP    D 00:00:00:00:00:01
      D00:02:b9:72:9d:41
      D 10.1.1.2
0    ethernet2/bridge            UP    S Global default [3600 sec]
0    1-3-2-0-adsl-0-35/bridge    UP    D 00:00:00:00:00:02
      D 223.30.2.130

```

zSH> bridge flush interface 1-3-1-0-adsl-0-35/bridge

zSH> bridge showall

```

VLAN   Bridge                               State  Table Data
-----
0      1-3-1-0-adsl-0-35/bridge            UP
0      ethernet2/bridge                    UP    S Global default [3600 sec]
0      1-3-2-0-adsl-0-35/bridge            UP    D 00:00:00:00:00:02
      D 223.30.2.130

```

Example 11 Purges the learned MAC entries for the specified VLAN and MAC address.

zSH> bridge showall

```

VLAN   Bridge                               State  Table Data
-----
0      1-3-1-0-adsl-0-35/bridge            UP    D 00:01:38:31:f1:6e
      D 00:02:b9:72:9d:41
      D 223.30.1.130
0      ethernet2/bridge                    UP    S Global default [3600 sec]
0      1-3-2-0-adsl-0-35/bridge            UP    D 00:00:00:00:00:02
      D 00:01:38:31:ee:fb
      D 223.30.2.130

```

zSH> bridge flush mac 0 00:01:38:31:f1:6e

zSH> bridge showall

```

VLAN   Bridge                               State  Table Data
-----
0      1-3-1-0-adsl-0-35/bridge            UP    D 00:02:b9:72:9d:41
      D 223.30.1.130
0      ethernet2/bridge                    UP    S Global default [3600 sec]
0      1-3-2-0-adsl-0-35/bridge            UP    D 00:00:00:00:00:02
      D 00:01:38:31:ee:fb
      D 223.30.2.130

```

Example 12

zSH> bridge stats

Interface Name	Received Packets			Transmitted Packets			
	UCast	MCast	BCast	UCast	MCast	Bcast	Error
1-16-8-0-shdsl-0-35-835	0	0	1	0	0	0	0
1-16-8-0-shdsl-0-35-635	0	0	0	0	0	0	0
1-16-24-0-shdsl-0-35-835	0	0	0	0	0	0	1

zSH> bridge stats vlan 835

Interface	Received Packets	Transmitted Packets
-----------	------------------	---------------------

Name	UCast	MCast	BCast	UCast	MCast	Bcast	Error
1-16-8-0-shdsl-0-35-835	0	0	1	0	0	0	0
1-16-24-0-shdsl-0-35-835	0	0	0	0	0	0	1

```
zSH> bridge stats clear 1-16-24-0-shdsl-0-35-835
Bridge statistics cleared for 1-16-24-0-shdsl-0-35-835
```

Example 13

```
zSH> bridge igmp
```

VlanID	MAC Address	MCAST IP	Ifndx	Host MAC	Last Join
999	01:00:5e:02:7f:fe	224.2.127.254	921	00:02:02:0b:4a:a0	2
999	01:00:5e:02:7f:fe	224.2.127.254	922	00:02:02:0a:bb:6d	106
999	01:00:5e:02:7f:fe	224.2.127.254	923	00:02:02:0a:c0:b7	87
999	01:00:5e:02:7f:fe	224.2.127.254	924	00:02:02:0b:4e:c5	172
999	01:00:5e:02:7f:fe	224.2.127.254	925	00:02:02:0b:4c:7e	65
999	01:00:5e:02:7f:fe	224.2.127.254	926	00:02:02:0b:4f:08	46
999	01:00:5e:02:7f:fe	224.2.127.254	927	00:02:02:09:c1:7d	90
999	01:00:5e:02:7f:fe	224.2.127.254	928	00:02:02:0b:44:cd	71
999	01:00:5e:02:7f:fe	224.2.127.254	929	00:02:02:0b:4c:ca	61
999	01:00:5e:02:7f:fe	224.2.127.254	930	00:02:02:0b:47:bd	7
999	01:00:5e:02:7f:fe	224.2.127.254	931	00:02:02:0b:47:c7	177
999	01:00:5e:02:7f:fe	224.2.127.254	932	00:02:02:0b:4d:35	181
999	01:00:5e:02:7f:fe	224.2.127.254	933	00:02:02:0b:4d:5b	144
999	01:00:5e:02:7f:fe	224.2.127.254	934	00:02:02:0b:4a:a5	59
999	01:00:5e:02:7f:fe	224.2.127.254	935	00:02:02:0b:4c:9e	3
999	01:00:5e:02:7f:fe	224.2.127.254	936	00:02:02:09:c1:78	6
999	01:00:5e:02:7f:fe	224.2.127.254	937	00:02:02:0a:c0:ca	131

```
zSH> bridge igmp slot 3
```

VlanID	MAC Address	MCAST IP	Ifndx	Host MAC	Last Join
999	01:00:5e:02:7f:fe	224.2.127.254	921	00:02:02:0b:4a:a0	166
999	01:00:5e:02:7f:fe	224.2.127.254	922	00:02:02:0a:bb:6d	72
999	01:00:5e:02:7f:fe	224.2.127.254	923	00:02:02:0a:c0:b7	51
999	01:00:5e:02:7f:fe	224.2.127.254	924	00:02:02:0b:4e:c5	134
999	01:00:5e:02:7f:fe	224.2.127.254	925	00:02:02:0b:4c:7e	34
999	01:00:5e:02:7f:fe	224.2.127.254	926	00:02:02:0b:4f:08	14
999	01:00:5e:02:7f:fe	224.2.127.254	927	00:02:02:09:c1:7d	56
999	01:00:5e:02:7f:fe	224.2.127.254	928	00:02:02:0b:44:cd	37
999	01:00:5e:02:7f:fe	224.2.127.254	929	00:02:02:0b:4c:ca	27
999	01:00:5e:02:7f:fe	224.2.127.254	930	00:02:02:0b:47:bd	170
999	01:00:5e:02:7f:fe	224.2.127.254	931	00:02:02:0b:47:c7	140
999	01:00:5e:02:7f:fe	224.2.127.254	932	00:02:02:0b:4d:35	148
999	01:00:5e:02:7f:fe	224.2.127.254	933	00:02:02:0b:4d:5b	105
999	01:00:5e:02:7f:fe	224.2.127.254	934	00:02:02:0b:4a:a5	25
999	01:00:5e:02:7f:fe	224.2.127.254	935	00:02:02:0b:4c:9e	168
999	01:00:5e:02:7f:fe	224.2.127.254	936	00:02:02:09:c1:78	171
999	01:00:5e:02:7f:fe	224.2.127.254	937	00:02:02:0a:c0:ca	96

Access Level admin for bridge add, delete, and show. user for bridge flush.

Products MALC, Raptor 319, Raptor 719, Raptor 723

bridge-path

Use this command to add, modify, delete, or show static-bridge profiles.

Syntax `bridge-path add interface/type`

`global`

`global-intralink`

`intralink`

`vlan vlan_id`

`[age value] default | [mac] mac_address | ip ip_address`

`[flap] default | disable | enable`

`mcastage`

`igmpqueryinterval`

add

Add a static-bridge assignment between an existing MAC address and an interface.

interface

Name and type of the physical interface.

global

Global default route for the whole network. If **global** is specified, no further parameters are required.

global-intralink

Global intralink. All traffic that cannot be resolved will be forwarded out this interface. If **global** is specified, no further parameters are required.

intralink

A type of bridge that receives forwarded traffic from the uplink that is not local traffic.

`vlan vlan_id`

VLAN identifier associated with the interface.

age value

The **AgingPeriod** measured in seconds. This is an optional field.

default

The specified interface is the default destination for bridge packets with the specified *vlan_id*. If **default** is specified, no other parameters are required.

`[mac] mac_address`

Use this option to associate a specific MAC address and VLAN with an interface. The `[mac]` argument is optional. The **mac_address** is in hexadecimal notation (for example, 00:01:02:03:04:05).

ip *ip_address*

Use this option to associate a specific IP address and VLAN with an interface.

flap

Controls how the MALC handles frames when frames with a MAC address that has been previously recorded on a different port in the learning bridge table. If flap enable is false, then the entry will not be learned, and will be dropped instead. If flap enable is true, then the older entry will be flushed from the learning table, and the new port will be recorded with the MAC address. Possible values are:

- default
- enable
If flap enable is enabled, then the older entry will be flushed from the learning table, and the new port will be recorded with the MAC address.
- disable
If flap enable is disabled, then the entry will not be learned, and will be dropped instead.

mcastage

Specifies the multicast aging period per VLAN or as a global setting.

igmpquesryinterval

Specifies the IGMP query injection interval per VLAN or as a global setting. Appears for only devices with bridge video configurations. This parameter cannot be specified on bridge intralinks. If this parameter is set, but mcastage is not specified, the MALC sets the mcastage parameter to 2 times the IGMP query interval, plus 1

Syntax `bridge-path delete interface/type`

`global | global-intralink | vlan vlan_id`
`default | [mac] mac_address | ip ip_address`

delete

Delete a static-bridge assignment thus breaking an association between an IP address and an interface.

Syntax `bridge-path show`

show

List all static-bridge assignments.

Example 1 Create a static bridge between an interface and a specific MAC address and VLAN.

```
zSH> bridge-path add 1-1-1-0/ds3 vlan 22 00:10:c0:ad:79:22
```

Example 2 Create a static bridge between an interface and a specific IP address and VLAN.

```
zSH> bridge-path add 1-1-4-0/ds3 vlan 3 ip 192.16.80.1
```

Example 3 Create a static bridge between an interface and a default destination (specified by the *vlan_id*).

```
zSH> bridge-path add 1-1-3-0/ds3 vlan 2 age 1000 default
```

Example 4 Delete a static bridge between an interface and a specific MAC address and VLAN.

```
zSH> bridge-path delete 1-1-1-0/ds3 vlan 22 00:10:c0:ad:79:22
```

Example 5 Delete a static bridge between an interface and a specific IP address and VLAN.

```
zSH> bridge-path delete 1-1-4-0/ds3 vlan 3 ip 192.16.80.1
```

Access Level user

Products MALC, Raptor 319, Raptor 719, Raptor 723

C

card add

Adds card profiles for specified card settings. Optional parameters are available software load filename, card group ID, linetype, line card voltage (ISDN cards only), and status. By default, new card profiles are enabled..

Syntax `card add card-profile-address [load sw-file-name] [group card-group-id] [linetype card-line-type] [voltage card-line-voltage] [disable]`

Options **card-profile-address**
The slot/slot/type of the current card.

load *sw-file-name*

Optionally, specifies the software load file to be configure for the card. By default, the system determines the software load based on the card type.

group *card-group-id*

Optional, specifies a the card-group-id assigned to the card profile. If no card-group-id is provided, the default group ID for the specified card type is used.

linetype *card-line-type*

Optional, specifies a the card-group-id assigned to the card profile. If no card-group-id is provided, the default group ID for the specified card type is used.

voltage *card-line-voltage*

Optional, specifies a the card-line-voltage for ISDN cards assigned to the card profile. If no line voltage is provided, the default line voltage for the specified ISDN card is used.

disable

Optional, disables the card profile. By default, card profiles are enabled.

Example

```
zSH> card add 1/21/5047
new card-profile 1/21/5047 added, sw-file-name "malcpots48.bin"

zSH> card add 1/21/5049 disable
new card-profile 1/21/5049 added, sw-file-name "malculcs.bin", 1 option:
disable

zSH> card add 1/21/5049 group 5
new card-profile 1/21/5049 added, sw-file-name "malculcs.bin", 1 option:
card-group-id 5

zSH> card add 1/21/5049 linetype isdn-pv
new card-profile 1/21/5049 added, sw-file-name "malculcs.bin", 1 option:
card-line-type isdn-pv

zSH> card add 1/21/5049 load foo.bin voltage 100-volts linetype isdn-pv disable
new card-profile 1/21/5049 added, sw-file-name "malcisdn.bin", 4 options:
sw-file-name malcisdn.bin, card-line-type isdn-pv, card-line-voltage
100-volts, disable
```

Access Level admin

Products MALC

See Also

card change

Update card profiles for new card types. By default, validation is performed to match the software load file and the card type. An optional parameter is available to override validation to use a software load file that does not match the card type.

Syntax `card change [-f] card-profile-address new-card-type [sw-file-name]`

Options -f

Optionally, overrides card type validation so the specified software load file is used regardless of the card type.

card-profile-address

The slot/slot/type of the current card.

new-card-type

The new card type being assigned to the card.

sw-file-name

Optional, software load name associated with the new card-profile. If no software load name is provided, the default software load name for the specified card type is used.

Example

```
zSH> card change 1/21/5036 5065
card-profile 1/21/5036 read, sw-file-name "malcxdsl48.bin"
card-profile changed to 1/21/5065, sw-file-name "malcxdsl48anxam.bin"
```

```
zSH> list card-profile 1/21
card-profile 1/21/5065
1 entry found.
zSH> get card-profile 1/21/5065
sw-file-name: -----> {malcxdsl48anxam.bin}
admin-status: -----> {disable}
upgrade-sw-file-name: ----> {}
upgrade-vers: -----> {}
admin-status-enable: ----> {enable}
sw-upgrade-admin: -----> {reloadcurrrev}
sw-enable: -----> {true}
sw-upgrade-enable: -----> {false}
card-group-id: -----> {0}
hold-active: -----> {false}
weight: -----> {nopreference}
card-line-type: -----> {unknowntype}
card-atm-configuration: -> {notapplicable}
card-line-voltage: -----> {not-used}
```

Access Level admin

Products MALC

See Also

card delete

Remove card profiles for the specified card.

Syntax `card delete card-profile-address`

Options `card-profile-address`

The slot/slot/type of the card to be removed.

Example zSH> `card delete 1/21/5049`
card-profile 1/21/5049 deleted

Access Level admin

Products MALC

See Also

card update

Updates card profiles for specified card settings.

Syntax `card update card-profile-address [load sw-file-name] [adminstatus admin-status] [upgradeload upgrade-sw-file-name] [upgrade upgrade-vers] [adminstatusenable enable|disable] [upgradeadmin sw-upgrade-admin] [swenable true|false] [swupgradeenable true|false] [group card-group-id] [holdactive true|false] [weight weight] [linetype card-line-type] [atmconfig card-atm-configuration] [voltage card-line-voltage] [maxvivci maxvpi-maxvci]`

Options `card-profile-address`

The slot/slot/type of the current card.

load *sw-file-name*

Optionally, specifies the software load file to be configure for the card. By default, the system determines the software load based on the card type.

adminstatus *admin-status*

Optionally, specifies the administrative status of the card. By default, the card is active.

upgradeload *upgrade-sw-file-name*

Optionally, specifies the software load file to be uploaded to the card.

upgradeversion *upgrade-vers*

Optionally, specifies the upgrade version for the new software load.

adminstatusenable *enable/disable*

Optionally, specifies whether the admin status is enabled. By default, the admin status is enabled.

upgradeadmin *sw-upgrade-admin*

Optionally, specifies the software load file to be configure for the card. By default, the system determines the software load based on the card type.

swenable *true|false*

Optionally, specifies the software enable state of the card. By default, the software enable state is true.

swupgradeenable *true|false*

Optionally, specifies the software upgrade enable state of the card. By default, the software upgrade enable state is true.

group *card-group-id*

Optionally, specifies a the card-group-id assigned to the card profile. If no card-group-id is provided, the default group ID for the specified card type is used.

holdactive *true/false*

Optionally, specifies the software load file to be configure for the card. By default, the system determines the software load based on the card type.

weight *weight*

Optionally, specifies the software load file to be configure for the card. By default, the system determines the software load based on the card type.

linetype *card-line-type*

Optional, specifies a the card-line-type assigned to the card profile. If no card-line-type is provided, the default card-line-type for the specified card type is used.

voltage *card-line-voltage*

Optional, specifies a the card-line-voltage for ISDN cards assigned to the card profile. If no line voltage is provided, the default line voltage for the specified ISDN card is used.

maxvpivci *maxvpi-maxvci*

Optional, specifies maximum VPI and VCI for the card.

Example

```
card update 1/21/5049 adminstatusenable disable
```

```
card update 1/21/5049 linetype isdn-pv
```

```
card update 1/20/5036 load malc.bin adminstatus operational upgradeload foof
upgradeversion 99 adminstatusenable disable upgradeadmin upgradenow swenable
false swupgradeenable true group 9 holdactive true weight nopreference
linetype adsl-splitter atmconfig notapplicable voltage 95 maxvp vpi15-vci63
```

Access Level admin

Products MALC

See Also

ccshow

The **ccshow** command shows associated connections and call state information given a range and type of endpoint.

Syntax `ccshow [-d] AAL2|GR303|V52|POTS|ELCPAAL2 address | *`

Displays call related information for the given address(es). Note that the format of the address depends on the type of endpoint.

AAL2 | GR303 | V52 | POTS | ELCPAAL2

The type of endpoint to display.

address

The address for the type of endpoint.

*

Use an asterisk after the endpoint type to display all of the endpoints.

Syntax `ccshow AAL2 lgid [/vpi[/vci[/cid]]]`

lgid

The line group ID of the AAL2 interface. Use the **lineGroup** command to find this number.

vpi/vci/cid

Depending upon the level of detail required, enter the VPI or the VPI/VCI or the VPI/VCI/CID.

Syntax `ccshow V52 ifname [|userid [/ POTS|ISDND|ISDNB [/
bchanid]]]`

ifname

The V5.2 interface name (V52).

userid

The V5.2 user port number. List the v52-user-port profiles to display the user port number. For example, if the profile has the following address:

```
v52-user-port 1/192/2
```

the user port number is 192.

POTS | ISDN | ISDNB

The user endpoint type.

bchanid

The B-channel ID number.

Syntax `ccshow GR303 igname/ crv`

igname

The name of the GR-303 Interface Group (IG).

crv

The GR-303 endpoint Call Reference Value (CRV).

Syntax `ccshow POTS lgid [/potsnumber]`

lgid

The line group ID of the POTS interface. Use the **lineGroup** command to find this number.

potsnumber

The number of the POTS interface.

Example 1 The following example displays call state information for all the AAL2 calls in the system (note the output is abbreviated)

```
zSH> ccs show AAL2 *
AAL2:36/0/304/20 UP V52:ZTL1/29/P UP CallState:ACTV
AAL2:36/0/304/21 UP V52:ZTL1/30/P UP CallState:ACTV
AAL2:36/0/304/22 UP V52:ZTL1/31/P UP CallState:ACTV
AAL2:36/0/304/23 UP V52:ZTL1/32/P UP CallState:ACTV
AAL2:36/0/304/16 UP V52:ZTL1/25/P UP CallState:IDLE
AAL2:36/0/304/17 UP V52:ZTL1/26/P UP CallState:IDLE
AAL2:36/0/304/18 UP V52:ZTL1/27/P UP CallState:IDLE
AAL2:36/0/304/19 UP V52:ZTL1/28/P UP CallState:IDLE
AAL2:36/0/305/16 UP V52:ZTL1/33/P UP CallState:ACTV
```

```

AAL2:36/0/305/17 UP V52:ZTL1/34/P UP CallState:ACTV
AAL2:36/0/305/18 UP V52:ZTL1/35/P UP CallState:ACTV
AAL2:36/0/305/19 UP V52:ZTL1/36/P UP CallState:ACTV
AAL2:36/0/305/20 UP V52:ZTL1/37/P UP CallState:ACTV
AAL2:36/0/305/21 UP V52:ZTL1/38/P UP CallState:ACTV
AAL2:36/0/305/22 UP V52:ZTL1/39/P UP CallState:ACTV
<SPACE> for next page, <CR> for next line, A for all, Q to
quit

```

Example 2 The following example displays call state information for all the V52 calls in the system (note the output is abbreviated):

```

zSH> ccshow v52 *
V52:ZTL1/192/P UP AAL2:36/0/324/23 UP CallState:ACTV
V52:ZTL1/176/P UP AAL2:36/0/322/23 UP CallState:ACTV
V52:ZTL1/177/P UP AAL2:36/0/323/16 UP CallState:ACTV
V52:ZTL1/178/P UP AAL2:36/0/323/17 UP CallState:ACTV
V52:ZTL1/179/P UP AAL2:36/0/323/18 UP CallState:ACTV
V52:ZTL1/180/P UP AAL2:36/0/323/19 UP CallState:ACTV
V52:ZTL1/181/P UP AAL2:36/0/323/20 UP CallState:ACTV
V52:ZTL1/182/P UP AAL2:36/0/323/21 UP CallState:IDLE
V52:ZTL1/183/P UP AAL2:36/0/323/22 UP CallState:IDLE
V52:ZTL1/184/P UP AAL2:36/0/323/23 UP CallState:IDLE
V52:ZTL1/185/P UP AAL2:36/0/324/16 UP CallState:ACTV
V52:ZTL1/186/P UP AAL2:36/0/324/17 UP CallState:ACTV
<SPACE> for next page, <CR> for next line, A for all, Q to
quit

```

Example 3 The following example displays detailed call state information (using the **-d** option) for calls on a with a MALC DS3 Uplink: interface.

First, find the linegroup for the interface:

```

zSH> linegroup 1-1-1-0/ds3
lineGroupId: 36

```

Then use the linegroup to display detailed information about AAL2 calls on the interface (note the output is abbreviated):

```

zSH> ccshow -d AAL2 36 linegroup
  Term Address: PVC-AAL2:36:VPI-0:VCI-304:CID-20
  Term State: UP
Sibling Address: V52:Link-ZTL1:UserID-29:UserType -POTS_USER
Sibling State: UP
  Call state: ACTIVE

  Term Address: PVC-AAL2:36:VPI-0:VCI-304:CID-21
  Term State: UP
Sibling Address: V52:Link-ZTL1:UserID-30:UserType -POTS_USER
Sibling State: UP
  Call state: ACTIVE

  Term Address: PVC-AAL2:36:VPI-0:VCI-304:CID-22
  Term State: UP
Sibling Address: V52:Link-ZTL1:UserID-31:UserType -POTS_USER

```

```

Sibling State: UP
  Call state: ACTIVE

Term Address: PVC-AAL2:36:VPI-0:VCI-304:CID-23
  Term State: UPSibling Address: V52:Link-ZTL1:UserID-32:UserType -POTS_USER
Sibling State: UP
  Call state: ACTIVE
Term Address: PVC-AAL2:36:VPI-0:VCI-304:CID-16
  Term State: UP
Sibling Address: V52:Link-ZTL1:UserID-25:UserType -POTS_USER
Sibling State: UP
  Call state: IDLE

Term Address: PVC-AAL2:36:VPI-0:VCI-304:CID-17
  Term State: UP
Sibling Address: V52:Link-ZTL1:UserID-26:UserType -POTS_USER
Sibling State: UP
  Call state: IDLE
<SPACE> for next page, <CR> for next line, A for all, Q to quit

```

Example 4 The following example shows AAL2 call information for a particular VPI and VCI (0/324) on a MALC Uplink interface (linegroup 36):

```

zSH> ccshow AAL2 36/0/324 linegroup/VPI/VCI
AAL2:36/0/324/16 UP V52:ZTL1/185/P UP CallState:ACTV
AAL2:36/0/324/17 UP V52:ZTL1/186/P UP CallState:ACTV
AAL2:36/0/324/18 UP V52:ZTL1/187/P UP CallState:ACTV
AAL2:36/0/324/19 UP V52:ZTL1/188/P UP CallState:ACTV
AAL2:36/0/324/20 UP V52:ZTL1/189/P UP CallState:ACTV
AAL2:36/0/324/21 UP V52:ZTL1/190/P UP CallState:ACTV
AAL2:36/0/324/22 UP V52:ZTL1/191/P UP CallState:ACTV
AAL2:36/0/324/23 UP V52:ZTL1/192/P UP CallState:ACTV
8 out of 384 records matched

```

Example 5 The following example shows detailed AAL2 call information for a particular VPI/VCI/CID (0/324/20) on a MALC Uplink interface (linegroup 36):

```

zSH> ccshow AAL2 36/0/324/16 linegroup/VPI/VCI/CID
AAL2:36/0/324/16 UP V52:ZTL1/185/P UP CallState:ACTV
1 out of 384 records matched
zSH> ccshow -d AAL2 36/0/324/16
Term Address: PVC-AAL2:36:VPI-0:VCI-324:CID-16
Term State: UP
Sibling Address: V52:Link-ZTL1:UserID-185:UserType -POTS_USER
Sibling State: UP
Call state: ACTIVE
1 out of 384 records matched

```

Example 6 The following example shows detailed V52 call information for the user number 192 in the interface group ZTL1. List the **v52-user-port** profiles to view the userID.

```

zSH> ccshow -d V52 ZTL1/192/POTS ifname/userid/call-type
Term Address: V52:Link-ZTL1:UserID-192:UserType -POTS_USER

```

Term State: UP
 Sibling Address: PVC-AAL2:36:VPI-0:VCI-324:CID-23
 Sibling State: UP
 Call state: ACTIVE
 1 out of 384 records match

Products MALC, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A

See Also `crossconnect`

cd

Changes the current directory on the flash card file system.

Syntax `cd directory [options]`

Options **directory**

Name of directory to change. Prepend a / (forward slash) to the directory to specify an absolute path.

options

The CD command accepts the following options:

`..` moves up one level in the directory structure

`/` moves to the root level of the flash card

Example The following example changes to the second PC card:

```
zSH> cd /card1
zSH> pwd
/card1
```

Access Level admin

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also `dir`, `pwd`

changepass

Changes password for the current user.

Syntax `changepass`

Example `zSH> changepass`

```
Current Password:
New Password :
Confirm New Password :
Password change successful.
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `resetpass`, `adduser`

clkmgrshow

To view the clock information on the system, use the **clkmgrshow** command.

Syntax `clkmgrshow [current | eligible | list]`

Options **current**

Displays the current primary and secondary clock sources.

eligible

Displays only the eligible clock sources. Eligible clock sources are interfaces that are configured as eligible and are active.

list

Lists the eligible and non-eligible clock sources. Non-eligible clock sources are interfaces that either not configured as eligible, or are not active.

Example 1 The following example displays the eligible and non-eligible clock sources:

```
zSH> clkmgrshow list
eligible list has 2 entries
 1 *      eligible  1/21/1/0 (10) : T1 : LOOP
 2      eligible  1/1/1/0 (1) : DS3 : LOOP
ineligible list has 3 entries
 1  not eligible  1/1/2/0 (5) : DS3 : LOOP
 2  not eligible  1/1/3/0 (5) : DS3 : LOOP
 3  not eligible  1/1/4/0 (5) : DS3 : LOOP
```

The asterisk (*) on a clock source indicates it the active clock source.

Example 2 The following example displays the current primary and secondary clock sources:

```
zSH> clkmgrshow current
Primary system clock is 1/21/1/0 (10) : T1
Secondary system clock is 1/1/1/0 (1) : DS3
```

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A

commit

This command is only used by the configuration restore process.

Syntax **N/A**

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

configsync

Manages the config sync process. Config sync is used to keep the configuration of a device and ZMS in sync.

In some situations a device may stop sending config sync files to ZMS and the config sync status becomes stuck in a “syncpending” state. A audit process monitors the config sync process.

The config sync audit runs every six minutes and checks whether the config sync process has been in a “syncpending” state for more than 5 minutes without performing an FTP transfer to ZMS (which indicates that the config sync process has stalled).

In this case, the config sync process is restarted, the config sync status is set to “syncerror,” and a configSyncReset trap is sent.



Note: Zhone recommends that you perform a config sync update from ZMS. For more information, refer to the documentation that came with the ZMS software.

Syntax `configsync stat reg | change | V5.2NameID | GR-303NameID`
reg

Displays detailed config sync statistics, including the registered information for the config sync process.

change

Displays state of change lists and status of FTP transfers.

V5.2NameID

Displays the V5.2 config sync cache list for the specified interface group.

GR-303NameID

Displays the GR-303 config sync cache list for the specified interface group.

Syntax `configsync initiate full | partial`

full

Initiates a manual update of the ZMS database with the device’s configuration. In a full config sync, all profiles are sent to ZMS. This option could cause significant processing by ZMS.

Config sync updates are performed automatically whenever a change is made to the device via the CLI. During a restore, however, the updating process is suspended. After a restore, a full config sync update is required.

partial

Sends only the new or updated profiles to ZMS.

Syntax `configsync reset`

reset

Resets the config sync process.



Caution: Do not use this command unless requested to do so by GSS. Resetting the config sync process may cause a system reboot.

Example To show the status of the config sync process:

```
zSH> configsync stat change
  Config Sync Status:
  -----
  FTP Transfer Stats:
  Last Time The Timer Popped (seconds) = 947898179
  Current Time (seconds) = 947898485
  Last Ftp Time (seconds) = 0
  ConfigSync Status = SYNC_INITIALIZING
```

copy

Copies a file on the flash card file system to another location on the same flash card or to another flash card (BAN only).

Syntax `copy source destination`

Options `source`

Full path name of the target file to copy.

destination

Full path name of the destination file to copy.

Access Level admin

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also delete

create

This command is used only by the configuration restore process.

Syntax N/A

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

crossconnect

Add, delete, or show cross connects on the system.

For the T1/E1 CES card, add, delete, or show cross connects for CES circuits.

Syntax `crossconnect add interface1/type1 vc vpi1/vci1 tc tc1 interface2/type2 vc vpi2/vci2 tc tc2 td_value | txt_d txt_d_value rxtd rxtd_value`



Note: The traffic descriptor and traffic container specified in the **crossconnect add** command must already exist.

The **crossconnect add** command auto-generates a handle ID based on the cc-index number. This ID can be changed to a text string of up to 16 characters by updating the atm-cc profile or through SNMP management.

add

Create and cross connect two ATM VCLs.

interface1/type1

Name and type of the first physical interface in the connection.

vc vpi1/vci1

ATM layer information for the first VC in the connection.

tc tc1

Traffic container information. This is a mandatory field if the first physical interface is PON.

interface2/type2

Name and type of the second physical interface.

vc vpi2/vci2

ATM layer information for the second VC in the connection.

tc tc2

Traffic container information. This is a mandatory field if the second physical interface is PON.

td_value

The traffic descriptor index to be used for the crossconnect. Enter this option if both sides of the crossconnect use the same traffic descriptor.

txtd txtd_value rxtd rxtd_value

Specify a traffic descriptor for the transmit and receive sides of the connection.

Syntax `crossconnect add interface1/atm vc vpi/vci interface2/ds1
vc vpi2/vci2 ds0 start/length unstr|str signal_type
line_type td txtd_value`



Note: The traffic descriptor specified in the **crossconnect add** command must already exist.

add

Create and cross connect two ATM VCLs.

interface1/atm

Name and type of the uplink physical interface in the connection.

vc vpi1/vci1

ATM layer information for the uplink VC in the connection.

interface2/ds1

Name of the downlink DS1 physical interface.

vc vpi2/vci2

ATM layer information for the downlink VC in the connection.

start/length

The starting DS0 and the length of the DS0 bundle. For example, 1/6 indicates a DS0 bundle starting at DS0 1 and containing 6 DS0's

(1+2+3+4+5+6). These fields are required even for unstructured DS0 bundles.

unstr

Indicates that the DS0 bundle is unstructured: 1-24 DS0's for T1, 0-32 DS0's for E1.

str

Indicates that the DS0 bundle is structured: 1-23 DS0's for T1, 0-32 DS0's for E1.

signal_type

The signal type used for the connection. Signal types are basic, e1cas, ds1esfcas, and ds1sfcas. The default signal type basic is used if no signal type is specified.

line_type

The line type used for the connection. line types are e1, e1unframed, e1crc, e1mf, e1crcmf, esf, and ds1unframed. The line type specified in the DS1-profile is used as the default type if no line type is specified.

txtd txtd_value

Specify a traffic descriptor for the transmit and receive sides of the connection.

Syntax `cc vpi add interface1/type1 vp vpi1/0 interface2/type2 vp vpi2/0 maxvci`

Create atm-vpi profiles.

interface1/type1

Name and type of the first physical interface (for example, uplink1/atm) in the connection.

vpi1

ATM layer information for the first atm-vpi profile.

interface2/type2

Name and type of the second physical interface (for example, 1-9-4-0/cellrelayproxy/atm) in the connection.

vpi2

ATM layer information for the second atm-vpi profile.

maxvci

The maximum VCI value (256 for the MALC-DS3/E3-4 card)

Syntax `cc vpl add interface1/type1 vp vpi1/0 interface2/type2 vp vpi2/0 td val | txtd txtd-value rxtd rxtd-val`

Create atm-vpl profiles and crossconnections.

interface1/type1

Name and type of the first physical interface (for example, uplink1/atm) in the connection.

vpi1

ATM layer information for the first VP in the connection (for example, 0/0).

interface2/type2

Name and type of the second physical interface (for example, 1-9-4-0/cellrelayproxy/atm) in the connection.

vpi2

ATM layer information for the second VP in the connection (for example, 16/0).

td val

The assigned traffic descriptor.

txtd-val

Optional transmit traffic descriptor.

rxtd- val

Optional receive traffic descriptor.

Syntax `crossconnect delete interface/type [vc] vpi/vci | cc index`

To delete a cross connect, specify either one of the VCLs in the cross connect or the cross connect index.

delete

Delete an ATM crossconnect and the VCLs it connects.

interface/type

The name and type of one side of the crossconnect. For example, 1-1-1-0/ds1.

vc vpi/vci

ATM layer information for bridge over ATM. For example, **vc 0/35**. If the interface is supplied it can be either end of the connect. If an interface is supplied the **cc index** is omitted

cc index

The cross connect index. If the **cc index** is supplied, the **interface/type** and **vc** are omitted.

Syntax `cc vp delete interface1/type1 vp vpi1/vci1 interface2/type2 vc vpi2/vci2`

Delete atm-vpls, atm-vcls and all related cross connections for the VP-VC.

interface1/type1

Name and type of the first physical interface (for example, uplink1/atm) in the connection.

vpi1/vci1

ATM layer information for the first VP in the connection (for example, 20/35).

interface2/type2

Name and type of the second physical interface (for example, 1-9-4-0/cellrelayproxy/atm) in the connection.

vpi2/vci2

ATM layer information for the second VP in the connection (for example, 21/36).

Syntax `cc vpi delete interface1/type1 vp vpi1/0 interface2/type2 vc vpi2/0`

Delete atm-vpi profiles.

interface1/type1

Name and type of the first physical interface (for example, uplink1/atm) in the connection.

vpi1/

ATM layer information for the first VP in the connection (for example, 20/0).

interface2/type2

Name and type of the second physical interface (for example, 1-9-4-0/cellrelayproxy/atm) in the connection.

vpi2/

ATM layer information for the second VP in the connection (for example, 16/0).

Syntax `crossconnect show [cc index | interface/type vc vpi/vci ces]`

To show a cross connect, specify either one of the VCLs in the cross connect or the cross connect index.

(no arguments)

Displays all crossconnects in the system.

cc index

Displays the cross connect indicated by the index number.

interface/type

The name and type of one side of the crossconnect. For example, **1-1-1-0/ds1**.

vc vpi/vci

List the connection that contains the indicated VCL.

ces

List the ces connection that contains the indicated VCL.

Example 1

```
zSH> crossconnect add 1-1-1-0-ads1/atm vc 0/37 uplink1/atm vc 1/101 td 1
```

Example 2

```
zSH> crossconnect delete 1-1-1-0-ads1/atm vc 0/37
```

Example 3

```
zSH> crossconnect show
```

```
ATM VCL                                CC    ATM VCL                                HANDLE ID
-----
1-1-1-0-propvirtual/atm 0/32  Up 1 Up    1-6-1-0-adsl/atm 0/32  Up handle_1
1-1-1-0-propvirtual/atm 0/33  Up 2 Up    1-6-2-0-adsl/atm 0/32  Up handle_2
1-1-1-0-propvirtual/atm 0/34  Up 3 Up    1-6-3-0-adsl/atm 0/32  Up handle_3
1-1-1-0-propvirtual/atm 0/35  Up 4 Up    1-6-4-0-adsl/atm 0/32  Up handle_4
1-1-1-0-propvirtual/atm 0/36  Up 5 Up    1-6-5-0-adsl/atm 0/32  Up handle_5
1-1-1-0-propvirtual/atm 0/37  Up 6 Up    1-6-6-0-adsl/atm 0/32  Up handle_6
1-1-1-0-propvirtual/atm 0/38  Up 7 Up    1-6-7-0-adsl/atm 0/32  Up handle_7
1-1-1-0-propvirtual/atm 0/39  Up 8 Up    1-6-8-0-adsl/atm 0/32  Up handle_8
1-1-1-0-propvirtual/atm 0/40  Up 9 Up    1-6-9-0-adsl/atm 0/32  Up handle_9
1-1-1-0-propvirtual/atm 0/41  Up 10 Up   1-6-10-0-adsl/atm 0/32  Up handle_10
1-1-1-0-propvirtual/atm 0/42  Up 11 Up   1-6-11-0-adsl/atm 0/32  Up handle_11
1-1-1-0-propvirtual/atm 0/43  Up 12 Up   1-6-12-0-adsl/atm 0/32  Up handle_12
1-1-1-0-propvirtual/atm 0/44  Up 13 Up   1-6-13-0-adsl/atm 0/32  Up handle_13
1-1-1-0-propvirtual/atm 0/45  Up 14 Up   1-6-14-0-adsl/atm 0/32  Up handle_14
1-1-1-0-propvirtual/atm 0/46  Up 15 Up   1-6-15-0-adsl/atm 0/32  Up handle_15
1-1-1-0-propvirtual/atm 0/47  Up 16 Up   1-6-16-0-adsl/atm 0/32  Up handle_16
1-1-1-0-propvirtual/atm 0/49  Up 18 Up   1-6-18-0-adsl/atm 0/32  Up handle_17
```

<SPACE> for next page, <CR> for next line, A for all, Q to quit

The output of this command displays the following information:

Field	Description
ATM VCL	The VCL for both sides of the crossconnect and their admin state. Possible values are Up and Dn. Dn applies to all states other than Up.
CC	The index of the cross connect and its admin state. Possible values are Up and Dn. Dn applies to all states other than Up.
Handle ID	The unique ID assigned to this cross connect based on the cc-index.

Example 4

```
zSH> cc add uplink2/atm 0/53 1/12/2/0/ds1 vc 1/33 ds0 1/24 unstr td 1
```

Example 5

```
zSH> cc delete uplink2/atm 0/53
```

Example 6

```
zSH> cc show
```

```
ATM VCL                                CC    ATM VCL                                HANDLE ID
-----
uplink2/atm 0/53 Up    1 Up    1-12-2-0-ds1/atm 1/33  Up    handle_1
```

Access Level admin

Products MALC, Raptor 319, Raptor 719, Raptor 723

D

datastorestats

The DataStore is a configuration database containing all the provisioning data of the system. The **datastorestats** command provides information about the use of the DataStore configuration database.

Syntax `datastorestats`

Example

```
zSH> datastorestats
Data Store AVL Tree Stats
-----Inserts                :      509
Deletes                        :          0
Records in Data Store         :      509
Current DataStore Size is    348628 bytes used out of 458752 bytes available
HashStats:
  finds: 4
  misses: 0
  addressSearchExcludes: 0
  indexSearchExcludes: 156
  slowSearch: 156
  slowFind: 156
  inserts: 293
  dups: 1362
```

Products Raptor 100, Sechtor 100A

del

Deletes a file from the flash card file system as well as directories and multiple files..

Syntax `del -rv filename|directoryname|*`

Options `-rv`

Recursively deletes files and subdirectories. The 'v' is optionally used for verbose mode so the names of the files being deleted are printed out. This option is not allowed from the root directory.

filename

Full path name of the file to delete.

directoryname

Full path name of the file to delete.

*

Specifies a wildcard so all files in the current or specified directory are deleted. This option is not allowed from the root directory.

Access Level admin

Products BAN, MALC, MALC 100, Raptor 319, Raptor 719, Raptor 723

See Also copy

delete

Deletes a record from the system. Note that for some types of records, such as card profiles, the **delete** command also deletes associated records. For example, if you delete a DSL **card-profile**, the system deletes all the ATM VCLs, VPLs, and cross connects configured on that card. It also deletes any VCLs/VPLs configured on the trunking card if they are part of a cross connect between the DSL card and the trunking card.

Syntax `delete profile-type [index | *] [-orphan]`

Options **profile-type**

The type of profile to delete.

index

An index for the record. Some records, such as line profiles, use an index of the form *shelf-slot-port-subport/type*. Other records, such as ATM traffic descriptors, use an index of the form *n*, where *n* is an integer. Specify a complete address to delete a single record. Specify partial addresses, to delete a group of profiles. See the examples below for more information.

*

A wildcard.

orphan

Deletes orphan records that cannot otherwise be deleted. Note that wildcards cannot be used with the **orphan** option.

Example 1 The following example deletes a single ATM traffic descriptor:

```
zSH> delete atm-traf-descr 2
atm-traf-descr 232
1 entry found.
Delete atm-traf-descr 2? [y]es, [n]o, [q]uit : yes
atm-traf-descr 2 deleted.
```

Example 2 The following example uses a partial address to delete **atm-vcl** profiles configured on shelf 1, slot 13:

```
zSH> delete atm-vcl 1-13
atm-vcl 1-13-1-0-ds3/atm/0/1000
atm-vcl 1-13-2-0-ds3/atm/0/1001
atm-vcl 1-13-3-0-ds3/atm/0/1002
3 entries found.
Confirm prior to each record delete ? [y]es, [n]o, [q]uit : y
Entry 1-13-1-0/ip does not exist.
Delete atm-vcl 1-13-1-0-ds3/atm/0/1000? [y]es, [n]o, [q]uit : y
atm-vcl 1-13-1-0-ds3/atm/0/1000 deleted.
```

```

Entry 1-13-2-0/ip does not exist.
Delete atm-vcl 1-13-2-0-ds3/atm/0/1001? [y]es, [n]o, [q]uit : y
atm-vcl 1-13-2-0-ds3/atm/0/1001 deleted.
Entry 1-13-3-0/ip does not exist.
Delete atm-vcl 1-13-3-0-ds3/atm/0/1002? [y]es, [n]o, [q]uit : y
atm-vcl 1-13-3-0-ds3/atm/0/1002 deleted.

```

Example 3 The following example deletes multiple atm traffic descriptors using the wildcard character (*):

```

zSH> delete atm-traf-descr *
atm-traf-descr 1
atm-traf-descr 2
2 entries found.
Confirm prior to each record delete ? [y]es, [n]o, [q]uit : y
Delete atm-traf-descr 1? [y]es, [n]o, [q]uit : y
atm-traf-descr 1 deleted.
Delete atm-traf-descr 2? [y]es, [n]o, [q]uit : y
atm-traf-descr 2 deleted.
zSH>

```

Example 4 On a BAN, MALC, or Raptor, the **delete** command can also be used to delete a **card-profile** and all profiles associated with the card. After the profiles have been deleted, the card reboots.



Caution: Before deleting card profiles, remove the card from the system as explained in the hardware documentation that came with your unit.



Caution: Back up the system configuration before deleting card profiles. Refer to the release notes that came with your unit for details.

The following example deletes a SHDSL card profile in shelf 1, slot 16:

```

zSH> delete card-profile 1/16/5006 shelf/slot/type
Delete card-profile 1/16/5006? [y]es, [n]o, [q]uit : y
card-profile 1/16/5006 deleted.

```

Access Level admin

Notes You can only delete one **card-profile** at a time. Wildcards are not supported when deleting card profiles.

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also **get, list, new, update, show**

deleteuser

Deletes a user account from system.

Syntax **deleteuser username**

Options **username**
Name of user account to delete.

Example zSH> **deleteuser dmiller**
OK to delete this account? (yes/no): **yes**
Account was deleted.

Access Level useradmin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also **adduser, updateuser**

delt

The MALC supports the DELT commands for Dual-End Loop Tests:

Syntax **delt start** <interface>
delt abort <interface>
delt clear <interface>
delt show status <interface>
delt show noise <interface> [**start-index** [**num-vals**]]

interface

The <interface> can be in the form of ifIndex (432), name/type (1-4-1-0/adsl) or shelf/slot/port/subport/type (1/4/1/0/adsl0).

start-index

(0..511) is the tone index with which to start. 0 is 4.3125 kHz, 1 is 8.625 kHz, up to 511 which is 2208.0000 kHz.. The noise command displays the loop noise floor results of a delt test. There is one noise measurement per ADSL tone. Each noise value has units of dBm/Hz.

num-val

The number of tones to display.

Notes Note that it may take some time (perhaps as much as a minute) for the DELT test to abort.

dhcp-relay

Add, delete, modify or show dhcp-server-subnet profiles configured with an external DHCP server address:

Syntax **dhcp-relay add** [<subnetgroup>] <ip-address> [<interface>/<type>|NULL]

subnetgroup

Add a dhcp-server-subnet profile with indicated subnetgroup and external-server ip-address. The index of the dhcp-server-subnet will be the subnetgroup.

ip-address

The subnet address/mask is derived from the system's floating IP address, if present, or may be specified NULL for use only with bridged interfaces. If multiple floating IP records are present, the desired <name>/<type> may be specified.

interface/type | NULL

The network address/mask is derived from the floating ip-interface-record for the system; if there is none and NULL is not specified, an error will be returned; if there are more than one, specify the desired one in <interface>/<type>. If NULL is specified, the network address/mask will each be 0, and only bridges may be provisioned to use the external server.

dhcp-relay delete

Delete the dhcp-server-subnet profile with indicated index.

dhcp-relay modify <subnetgroup> <ip-address>

Change the external-server address for the indicated index.

dhcp-relay show

Display the list of external-server addresses with subnetgroup and subnet address/mask.

dir

Displays the contents of the directory on the device file system.

Syntax dir

Example

```
zSH> dir
Listing Directory .:
-rwxrwxrwx 1 0 0 668932 Mar 28 17:05 malcoc3fraw.bin
-rwxrwxrwx 1 0 0 5776033 Apr 7 19:23 malcoc3f.bin
-rwxrwxrwx 1 0 0 4197357 Mar 24 00:15 malctl1e132vg.bin
-rwxrwxrwx 1 0 0 4117051 Mar 24 00:15 malctl1e132vgv52.bin
-rwxrwxrwx 1 0 0 392308 Mar 11 15:38 malctl1e132vgrom.bin
-rwxrwxrwx 1 0 0 1563843 Mar 28 17:05 malctl1elatm32.bin
-rwxrwxrwx 1 0 0 1206836 Mar 28 17:05 malcpots.bin
drwxrwxrwx 1 0 0 2048 Apr 13 16:40 datastor/
drwxrwxrwx 1 0 0 2048 Dec 20 2004 bulkstats/
-rwxrwxrwx 1 0 0 668296 Feb 22 14:34 malcoc3raw.bin
-rwxrwxrwx 1 0 0 1855714 Mar 28 17:04 malcgshdsl.bin
-rwxrwxrwx 1 0 0 1030717 Mar 28 17:04 malcmtac.bin
-rwxrwxrwx 1 0 0 2368132 Apr 13 17:43 malcolt.bin
drwxrwxrwx 1 0 0 2048 Mar 30 15:13 onreboot/
27384184 bytes available
```

Access Level admin

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also `cd`, `pwd`

ds1relay

The **ds1relay** command controls the DS1 relay settings. The relays can be set to terminate individual or all of the DS1 circuits on the primary 64-pin connector or on the secondary, redundant 64-pin connector (on the Sechtor 100A) or on the T1/E1 Uplink interface (on the Raptor 100):



Note: The **ds1relay** command does not persist across system reboots.

Syntax `ds1relay [all | circuit-number] [passthru | terminate]`

circuit-number

A DS1 circuit number from 1 to 8 (Sechtor 100A) or 1-4 (Raptor 100).

all

All of the DS1 circuits that terminate on the system.

passthru

The DS1 circuit or circuits that terminate on the Sechtor 100A primary connector are electrically connected to the secondary (redundant) connector. Internal Sechtor 100A hardware that was connected to the DS1 circuit or circuits is connected to a loopback path.

terminate

Terminate the specified DS1 circuit or circuits on the primary 64-pin connector (Sechtor 100A) or the 50-pin Uplink connector (Raptor 100).

Example 1 `zSH> ds1relay all terminate`

All of the DS1 circuits terminate on the primary 64-pin connector (Sechtor 100A) or the 50-pin Uplink connector (Raptor 100).

Example 2 `zSH> ds1relay all passthru`

All of the DS1 circuits are connected to the secondary 64-pin connector.

Example 3 `zSH> ds1relay 1 passthru`

The first DS1 circuit is connected to the secondary 64-pin connector, the other circuits remain unchanged.

Access Level admin

Products Raptor 100, Sechtor 100A

ds1rpshow

Displays information about the T1 interface resource providers on the system.

Syntax `ds1rpshow [linenumbers]`

Options

With no options, displays general information about T1 interfaces.

linenumber

Displays information about the specified line numbers.

Example 1

```
zSH> ds1rpshow
*****          DS1 RP Debug Information          *****
name:          tDS1RP
address:       01:01:106
lineRRLeaseId: 0x022b0000_0000004e
ds1XlatProfLeaseId: 0x022b0000_0000004f
ds1LineProfLeaseId: 0x022b0000_0000004f
ds1GroupProfLeaseId: 0x022b0000_0000004f
ds1CfgProfLeaseId: 0x022b0000_0000004f
systemProfLeaseId: 0x022b0000_0000004f
numUnits:     8
clkStatus:    0
clkSrc:       0
Attached units:
              0 1 2 3 4 5 6 7
```

Example 2

```
zSH> ds1rpshow 1
*****          DS1 RP Debug Information          *****
name:          tDS1RP
address:       01:01:106
lineRRLeaseId: 0x022b0000_0000004e
ds1XlatProfLeaseId: 0x022b0000_0000004f
ds1LineProfLeaseId: 0x022b0000_0000004f
ds1GroupProfLeaseId: 0x022b0000_0000004f
ds1CfgProfLeaseId: 0x022b0000_0000004f
systemProfLeaseId: 0x022b0000_0000004f
numUnits:     8
clkStatus:    0
clkSrc:       0
Attached units:
              0 1 2 3 4 5 6 7
*****          Debug Information for Line 1          *****
state:        3
ifIndex:      3
shelf:        1
slot:         1
port:         2
subPort:      0
xlatProf.ifIndex: 3
xlatProf.ifType: 18
xlatProf.adminStatus: 1
groupProf.groupId: 3
groupProf.groupName: 1/1/2
```

```

groupProf.primaryName:          3
groupProf.secondaryName:       0
groupProf.primaryWeight:       0
groupProf.secondaryWeight:     0
groupProf.adminStatus:         2
alarms                          1
                                -> No Alarm
loopback                        1

```

Products Raptor 100, Raptor 319, Raptor 719, Raptor 723, MALC

ds3rpshow

Displays information about the T1 interface resource providers on the system.

Syntax `ds3rpshow [linenumbers]`

Options

With no options, displays general information about T1 interfaces.

linenumber

Displays information about the specified line numbers.

Example 1

```

zSH> ds3rpshow
***** DS3ATM RP Debug Information *****
name:          tDS3ATMRP
address:       01:01:1091
lineRRLeaseId: 0x022b0000_0000006a
ds3AtmXlatProfLeaseId: 0x022b0000_0000006c
ds3AtmCfgProfLeaseId: 0x022b0000_0000006c
lineRRClientLeaseId: 0x022b0000_0000006b
ds3AtmRpCardGroupId: 1
iamActiveCard: TRUE
Redundancy Mode: CARD
PeerCardAvailable: FALSE
PeerCardShelf: 0
PeerCardSlot: 0
requestLineRRNotification: TRUE
numUnits:     4
Attached units:
              1 2 3 4

```

Example 2

```

zSH> ds3rpshow 1
***** DS3ATM RP Debug Information *****
name:          tDS3ATMRP
address:       01:01:1091
lineRRLeaseId: 0x022b0000_0000006a
ds3AtmXlatProfLeaseId: 0x022b0000_0000006c
ds3AtmCfgProfLeaseId: 0x022b0000_0000006c
lineRRClientLeaseId: 0x022b0000_0000006b
ds3AtmRpCardGroupId: 1

```

```

iamActiveCard:                TRUE
Redundancy Mode               CARD
PeerCardAvailable             FALSE
PeerCardShelf                 0
PeerCardSlot                  0
requestLineERRNotification:   TRUE
numUnits:                     4
Attached units:
    1 2 3 4
***** Debug Information for Line 1 *****
iamActiveLine:                TRUE
state:                        4
ifIndex:                      4
primaryClock:                 FALSE
shelf:                        1
slot:                         1
port:                         1
subPort:                      0
xlatProf.ifIndex:             4
xlatProf.ifType:              30
xlatProf.adminStatus:         1
cnfgProf.lineType:            4
cnfgProf.lineCoding:          2
cnfgProf.sendCode:            1
cnfgProf.circuitId:           ''
cnfgProf.loopbackConfig:      1
cnfgProf.transmitClockSource: 1
cnfgProf.lineLengthMeters:    0
cnfgProf.lineStatusChangeTrapEnable: 1
cnfgProf.channelization:      1
cnfgProf.mediumScrambleConfig: 1
Ds3_Stats_Profile.timeElapsed: 0
Ds3_Stats_Profile.validIntervals: 0
Ds3_Stats_Profile.lineStatus: 0x840
                                -> LOS
                                -> Net-Equip-OOS
Ds3_Stats_Profile.plcpAlarmStatus: 1
                                -> No Alarm
Ds3_Stats_Profile.ifTCAlarmStatus: 2
                                -> LCD Failure
Ds3_Stats_Profile.invalidIntervals: 0
Ds3_Stats_Profile.lineStatusLastChange: 951806042
Ds3_Stats_Profile.loopbackStatus: 0x1
                                -> None

```

Products Raptor 100, Raptor 319, Raptor 719, Raptor 723, MALC

dslstat

Displays the DSL training rates for the DSL cards in a system.

Syntax `dslstat [ifIndex] | [name/type] | [shelf/slot/port/subport/type] [-v]`

Options *ifIndex*

The interface number of the port or port/subport that uniquely identifies the interface across the system. (Use the **linegroup** command to find the *ifIndex* of an interface.)

name

The name of the interface.

type

IANA type for the interface. For example, *adsl*, *ds1*, *ds3*.

shelf

The physical address or number of the shelf where the desired line is located. The first shelf in a system is shelf 1.

slot

The physical slot on the system.

port

The port number defines the physical port number at the shelf-slot location for the line profile. Port numbers begin with 1 and are numbered sequentially.

subport

Used to identify multiple logical subports on a physical port.

-v

Indicates the verbose option to display additional VDSL data.

Example 1 `zSH> dslstat 1-15-1-0/adsl`

```
General Stats:
-----
AdminStatus.....UP
Line uptime (DD:HH:MM:SS).....0:02:27:52
DslUpLineRate (bitsPerSec).....512000
DslDownLineRate (bitsPerSec).....8064000
DslMaxAttainableUpLineRate (bitsPerSec).....565333
DslMaxAttainableDownLineRate (bitsPerSec)....856000
Out Octets.....286571
Out Discards.....0
Out Errors.....0
In Octets.....286571
In Discards.....0
In Errors.....0
ATM OCD Count.....0
ATM NCD Count.....0
ATM HEC Count.....0
ATM far-end OCD Count.....0
ATM far-end NCD Count.....0
ATM far-end HEC Count.....0

ADSL Physical Stats:
-----
Actual Transmission connection standard.....G.dmt
AdslAtucCurrLineSnrMgn (tenths dB).....310
AdslAtucCurrLineAtn (tenths dB).....135
```

```

AdslAtucCurrOutputPwr (tenths dB).....70
AdslAturCurrLineSnrMgn (tenths dB).....90
AdslAturCurrLineAtn (tenths dB).....135
AdslAturCurrOutputPwr (tenths dB).....103
LOFS.....0
LOLS.....0
LOSS.....0
ESS.....0
Inits.....1
Adsl connects.....1
Adsl disconnects.....5407

```

near-end statistics:

```

-----
blocks received.....147087
errored blocks received.....0
CRC errors on interleaved buffer.....0
CRC errors on fast buffer.....0
FEC corrected errors on interleaved buffer...0
FEC corrected errors on fast buffer.....0
background errored blocks received.....0
non-SES blocks received.....0
Severely Errored Seconds.....0
Unavailable Seconds.....59
Loss of Signal Seconds.....0
Seconds with one/more FECs.....0
Seconds declared as high BER.....0

```

far-end statistics:

```

-----
blocks received.....147205
errored blocks received.....1
CRC errors on interleaved buffer.....0
CRC errors on fast buffer.....1
FEC corrected errors on interleaved buffer...0
FEC corrected errors on fast buffer.....0
background errored blocks received.....0
non-SES blocks received.....0
Severely Errored Seconds.....0
Unavailable Seconds.....0
Loss of Signal Seconds.....0
Seconds with one/more FECs.....0
Loss of Power (dying gasps).....0
Seconds declared as high BER.....0
Fast retrains.....0

Fast retrain failures.....0

```

Example 2 zSH> **dslstat 1-20-1-0/shdsl**

General Stats:

```

-----
AdminStatus.....UP
Line uptime (DD:HH:MM:SS).....0:04:27:52
DslUpLineRate (bitsPerSec).....2320

```

```

DslDownLineRate (bitsPerSec).....2320
DslMaxAttainableUpLineRate (bitsPerSec).....2320
DslMaxAttainableDownLineRate (bitsPerSec)....2320
Out Octets.....20442524
Out Discards.....0
Out Errors.....0
In Octets.....20442471
In Discards.....0
In Errors.....0
ATM OCD Count.....1
ATM NCD Count.....0
ATM HEC Count.....0
ATM far-end OCD Count.....0
ATM far-end NCD Count.....0
ATM far-end HEC Count.....0

```

DSL Physical Stats:

```

-----
DslLineSnrMgn (tenths dB).....380
DslLineAtn (tenths dB).....232
DslCurrOutputPwr (tenths dB).....85
LOFS.....1
LOLS.....1
LOSS.....1
ESS.....9
CRC Errors.....0
Inits.....65

```

Example 3 zSH> **dslstat 1-6-3-0/vdsl -v**

General Stats:

```

-----
AdminStatus.....UP
DslUpLineRate (bitsPerSec).....1115
DslDownLineRate (bitsPerSec).....1115
DslMaxAttainableUpLineRate (bitsPerSec).....26523
DslMaxAttainableDownLineRate (bitsPerSec)....41857
Out Octets.....0
Out Pkts/Cells.....0
Out Discards.....0
Out Errors.....0
In Octets.....0
In Pkts/Cells.....0
In Discards.....0
In Errors.....0
DSL Physical Stats:
-----
DslLineSnrMgn (tenths dB).....317
DslLineAtn (tenths dB).....0

DslCurrOutputPwr (tenths dB).....39
LOFS.....0
LOLS.....0
LOSS.....0
ESS.....0

```

```

CRC Errors.....0
Inits.....0
VDSL PHY VTUC Stats:
-----
serialNumber.....(co-0123456)
vendorId.....GSPN
versionNumber.....1.66.35
curSnrMargin.....317
currAtn.....0
currStatus.....NO DEFECT
currOutputPwr.....39
currAttainableRate.....41861
currLineRate.....1115

VDSL CHAN VTUC Stats:
-----
interleaveDelay.....66
crcBlockLength.....40
currTxRate.....992
currTxSlowBurstProt.....9
currTxFastFec.....0
VDSL PHY VTUR Stats:
-----
serialNumber.....ABCDEFGHijkl
MNOP1234
vendorId.....GSPN
versionNumber.....1.66.35
curSnrMargin.....271
currAtn.....0
currStatus.....NO DEFECT
currOutputPwr.....45
currAttainableRate.....26523
cprLineRate.....1115
VDSL CHAN VTUC Stats:
-----
interleaveDelay.....66
crcBlockLength.....40
currTxRate.....992
currTxSlowBurstProt.....9
currTxFastFec.....0

```

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

dump

Saves the Zhone system configuration.

Syntax `dump [console] | [file filename] [network host filename]`

Options `console`
Sends the configuration to the console.

network *host filename*

Sends the configuration to the specified host using trivial file transfer protocol (TFTP) and writes it to the specified filename. The file must exist and be writable before the system can write the configuration to it.

file *filename*

Sends the configuration to the specified file on the flash card. You must specify the full path to the file.

Example 1 The following example dumps the configuration to the file named *zhone.cfg* on the IP host 192.168.9.55:

```
zSH>dump network 192.168.9.55 zhone.cfg
```

Example 2 The next example dumps the configuration to the file named *zhone.cfg* on the first flash card on the system:

```
zSH>dump file /card1/zhone.cfg
```

Access Level useradmin

- Notes**
- Set the TFTP server time-out value to at least 5 seconds, and 5 retries to help prevent TFTP time-out or retry errors.
 - The Z-Edge 64 and the Sector 100A do not support saving the configuration to a local file.

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sector 100A, Z-Edge 64

See Also restore

E

eeset

Sets values in the device EEPROM. This command is only used to configure Sector 100A redundancy.

Syntax `eeset slot [1 | 2] card [1 | 2]`

slot [1 | 2]

The slot number to set the device to. For the Sector 100A this is always 1 for the active unit and 2 for the standby unit.

card [1 | 2]

The card number to set the device to. For the Sector 100A this is always 1 for the active unit and 2 for the standby unit.

Syntax `eeset failover on card 1`

Configures failover mode on the primary device (always card 1).

Syntax `easet peer mac_address card 1`

Sets the MAC address of the redundant peer on the primary device (always card 1).

Access Level user

Products Sechtor 100A

See Also `eeshow`

eeshow

Displays the contents of the specified electrically erasable programmable read-only memory (EEPROM). The information include the serial number of the device, the CLEI code (if any), the Zhone card type, and the type of I/O cards installed.

Syntax `eeshow eeprom-name slot`

Options *eeprom-name*

Name of the EEPROM contents you want to display. Possible values are:

- 1daughter | 2daughter | 3daughter: up to 3 daughter cards are supported on MALC or Raptor cards
- card
- iocard: slots 1 through 17 (BAN only)
- mezz
- shelfme: slot 0 only
- shelfmon: slot 0 only
- backplane: slot 0 only
- fantray: slot 0 only

For the Z-Edge 64 **card** is the only valid *eeprom-name*. For the Sechtor 100A and Raptor 100, **card** and **mezz** are the only valid *eeprom-names*.

slot

Slot number containing the eeprom. If you do not specify a slot number, the eeprom on the current card or on slot 0 (the system EEPROM).

Example 1 To display the Zhone card type, use the **eeshow card** command:

```
zSH> eeshow card 1
EEPROM contents:
EEPROM_ID      : 00 -- CARD
Version        : 01
Size           : 054
CardType       : 05035 -- MALC_GIGE
CardVersion    : 800-01322-02-A
SerialNum      : 04440120
ShelfNumber    : 00001
CLEI Code     : No CLEI
Cksum         : 0x4D60
```

MAC Address are enabled for 2 address(es) starting at:
00:01:47:43:C0:38

Example 2 (BAN only) To display the type of I/O card installed in a slot, use the **eeshow iocard** command:

```
zSH> eeshow iocard 1
EEPROM contents:
EEPROM_ID    : 03 -- MEZZ
Version      : 01
Size         : 018
CardType     : 00013 -- OC3ATM_SM indicates an OC3-c/STM1 interface
CardVersion  : 00001
SerialNum    : 02610001
ShelfNumber  : 00001
CLEI Code    : No CLEI
Cksum        : 0x0531
Feature bits modification date: 0/0/2000 00:00:00
```

Example 3 zSH> **eeshow 1d 5**

```
EEPROM contents:
EEPROM_ID    : 01 -- 1DAUGHTER
Version      : 01
Size         : 022
CardType     : 05050 -- MALC_ULCS_ISDN_2B1Q
CardVersion  : 00001
SerialNum    : 00210003
ShelfNumber  : 00001
CLEI Code    : No CLEI
Cksum        : 0x92A6
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also eeset

F

featurebitdisplay

Displays the features enabled on the system.

Syntax **featurebitdisplay** *featurenumber*

Options (no option)

Displays all available features.

featurenumber

Indicates whether the feature is enabled.

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `featurebitset`

featurebitset

Enables certain features on Zhone systems. You must obtain a hash code from Zhone GSS before using this command.

Syntax `featurebitset offset mask value hashcode`

Options *offset*

Number of bits to offset.

mask

Mask to apply to the EEPROM.

value

New value to write to the serial EEPROM bits as specified by the offset and mask.

hashcode

The hash code that enables the feature.

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `featurebitdisplay`

fhrameping

Pings a specified location within the device. You can only ping slot cards, you cannot ping I/O cards.

Syntax `fhrameping shelf slot [port]`

Options *shelf*

Destination shelf number. Currently this is always 1 (one).

slot

Destination slot number. Slots are numbered from 1 to 17, left to right.

port

Destination port number.

Example 1 The first example shows the **fhrameping** response received from an inactive card.

```
zSH> fhrameping 1 14
Pinging Shelf 1, slot 14
FhramePing Timeout with Shelf 1, Slot 14
```

Example 2 The next example shows the **fhrameping** response received from an active card.

```
zSH> fhramping 1 3 1
Pinging Shelf 1, slot 3 port 1
Shelf 1, Slot 3, Port 1, is Alive!
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also ping

file

Transfers files to or from a TFTP server without verifying the image header. This command can be used to download a dump file previously made to the network or upload one that was made to a local file.



Note: The **file** command should be used only for general purpose file transfer, not for upgrading system software. To upgrade software, use the **image** command.

Syntax `file [download | upload] tftphost sourcefilepath targetfilepath`

Options *download*

Downloads the file to the flash card on the device. This option is typically used to restore a configuration created using the **dump** command.

upload

Uploads the specified file to the TFTP server. This option is typically used to save a copy of the software image files.

sourcefile

The full path name of the source file. On the BAN Infoservice card flash cards, the path is */card1/file* or */card2/file*, depending on the flash cards installed. On a MALC or Raptor, do not specify the card.

targetfile

The full path name of the target file. On the BAN Infoservice card flash cards, the path is */card1/file* or */card2/file*, depending on the flash cards installed. On a MALC or Raptor, do not specify the card.

If you are transferring a file to a TFTP server, the file must exist and be writable.

Example The following example downloads a file to the host 192.168.9.55 named *savedump* and writes it to the file named *localdump* on the first Infoservices flash card (*/card1*).

```
zSH> file download 192.168.9.55 saveddump localdump
```

Access Level admin

Notes Set the TFTP server time-out value to at least 5 seconds, and 5 retries to help prevent TFTP timeout or retry errors.

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also [image](#)

filter

IP filtering is typically performed to enhance network security by limiting access between two networks. IP filtering is based on the recognition and selective transmission or blocking of individual IP packets. Packets meeting some criterion are forwarded, and those that fail are dropped. On BAN, IP filtering is used to block inbound traffic to the management network.

Syntax The following command adds a rule to the currently loaded filter. If the rule argument (line and rule are interchangeably used to signify a user-defined value for the filtering rule) is omitted, the line number of the rule will be 100 greater than the highest numbered rule in the filter. That is, the rule will be appended to the end of the rule list with the default stride.

```
filter add rule [from | to] [IP address] [permit | deny]
```

rule

A user-defined value for the filtering rule.

from | to

Defines incoming or outgoing.

IP address

The interface address.

permit | deny

Permit or deny traffic flow.

Syntax The following command deletes the specified line (also known as rule) from the currently loaded filter.

```
filter delete line
```

line

The filter identifier.

Syntax The following command sets the description field of the currently loaded filter.

```
filter description description_string
```

description_string

A string of text and spaces describing the purpose of the filter.

Syntax The following command deletes the specified filter.

```
filter destroy specIndex
```

specIndex

The user-defined value for the filter.

Syntax The following command discards the currently loaded filter along with any uncommitted changes.

```
filter discard
```

Syntax The following command displays help for the specified filter command.

```
filter help [command]
```

```
[command]
```

The specific argument to the filter command.

Syntax The following command lists all defined filters showing specIndex, name, version, and description.

```
filter list
```

Syntax The following command loads a filter into the CLI for modification.

```
filter load specIndex
```

```
specIndex
```

The index value for the filter.

Syntax The following command replaces rule in the currently loaded filter with newrule.

```
filter modify line newrule
```

```
line
```

The user-defined value for the filter.

```
newrule
```

A number value defining the new rule.

Syntax The following command sets the name field of the currently loaded filter.

```
filter name name
```

```
name
```

An arbitrary string, containing no spaces, that is considered a name for this filter. While it is desirable, it is not required that this name be unique.

Syntax The following command locates a new specIndex, and establishes a new filter in the CLI for modification.

```
filter new [name] [description_string]
```

```
[name]
```

An arbitrary string, containing no spaces, that is considered a name for this filter. While it is desirable, it is not required that this name be unique.

[description_string]

A string of text and spaces describing the purpose of the filter.

Syntax The following command lists each interface that is configured to use the specified filter. If `specIndex` is omitted, it lists each interface that is configured to use any filter.

filter references [specIndex]

[specIndex]

The index value for the filter.

Syntax The following command renumbers all rules in the currently loaded filter with the default stride of 100 or the stride given.

filter renumber [stride]

renumber [stride]

The range between rule numbers.

Syntax The following command commits the currently loaded filter for modification.

filter save

Syntax The following command displays the filter currently committed to Infostore. If the `specIndex` is omitted, it displays the filter currently loaded for modification.

filter show [specIndex]

[specIndex]

The user-defined value for the filter.

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

find

Searches through available commands.

Syntax `find [-s(ubSearch) | -d(etailed)] stringToSearch`

Options `-s`

Search the previous search results for the specified string.

`-d`

Search the online help for each command for the specified string.

`-ds` or `-sd`

Search the online help of the commands in the previous search for the specified string.

substring

The string to search for.

Example 1 For example, the following command finds all commands containing the string “show”:

```
zSH> find show
eeshow                show
showdatetime         showhost
showinetstat         showipstat
showlinestatus       showmem
showresolver         showuser
showzhonecpe
```

Example 2 You can also search within results. For example:

```
zSH> find -s ip
showipstat
```

Example 3 To search command online help for a particular string, use the **-d** option. For example, the following command searches all the online help for the commands for the word *profile*:

```
zSH> find -d profile
delete                get                list
new                   show               update
```

Example 4 After you have performed a command search, the **lst** command lists only the results of the last search. For example:

```
zSH> lst
delete                get                list
new                   show               update
```

Example 5 To reset the **lst** command so it displays all the available commands, use the **-m** option with the **lst** command:

```
zSH> lst -m
adduser                ata
bootstate             cd
changeypass          commit
copy                  create
del                   delete
deleteuser           dir
dump                  eeshow
featurebitdisplay    featurebitset
fhrameping           file
find                  get
help                  history
ifxlate              image
interface            list
load                 log
logout               lst
mkdir                msg
new                  ping
pollzhonecpe         pwd
resetcliprov         resetpass
restore              rip
```

```

rmdir          route
set           setdatetime

```

Type A<CR> to print all, <CR> to continue, Q<CR> to stop:

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also get, show

find-matching-data

The **find-matching-data** command displays the provisioned data path through the system which includes the specified ATM VCL.

Syntax `find-matching-data ATM interface/type vpi vci`

ATM

Keyword

interface/type

Name and type of the physical interface.

vpi

Virtual path indicator.

vci

Virtual channel indicator

Example

```

zSH> find-matching-data ATM 1-3-1-0-ads1/atm 0 35
VCL 1-3-1-0-ads1/atm 0 35 is used in atm-cc 1
The far end of this cross connect is 1-1-1-0-aal5proxy/atm 0 32

```

Products MALC, Raptor 319, Raptor 719, Raptor 723

find-matching-subvoice

The **find-matching-subvoice** command displays the other endpoint of a **subscriber-voice** connection, given one endpoint. You can find endpoints for the following voice connections:

- AAL2
- CLASS5
- DS1
- ELCPAAL2
- GR-303
- ISDN

- POTS
- V52
- VOIP

The system displays information about each endpoint and the **subscriber-voice** profile that links them. If there are provisioning errors that prevent the matching profile from being displayed, the system reports an error.

Syntax `find-matching-subvoice AAL2 LGID/VPI/VCI/CID`

AAL2

The type of voice endpoint.

LGID

The line group identifier (also known as the ifIndex). Use the **linegroup** command to find the line group ID for an interface.

VPI

Virtual Path Identifier of the AAL2 connection. You can find this in the **aal2-vcl profile**.

VCI

Virtual Channel Identifier of the AAL2 connection. You can find this in the **aal2-vcl-profile**.

CID

Channel Identifier. You can find this in the **aal2-cid-profile**.

Syntax `find-matching-subvoice CLASS5 ID/EndPointIndex`

CLASS5

The type of voice endpoint.

ID

ID for the Class5 switch.

EndPointIndex

Index of the voice connection endpoint.

Syntax `find-matching-subvoice DS1 LGID/ChannelID`

DS1

The type of voice endpoint.

LGID

The line group identifier (also known as the ifIndex). Use the **linegroup** command to find the line group ID for an interface.

ChannelID

Matching channel ID of the DS0 signal.

Syntax `find-matching-subvoice ELCPAAL2 LGID/VPI/VCI/PortID/PortType/ChannelID`

ELCPAAL2

The type of voice endpoint.

LGID

The line group identifier (also known as the ifIndex). Use the **linegroup** command to find the line group ID for an interface.

VPI

Virtual Path Identifier of the ELCP AAL2 connection.

VCI

Virtual Channel Identifier of the AAL2 connection.

PortID

The port Identifier.

PortType

Port type.

ChannelID

Matching channel ID of the AAL2 signal.

Syntax `find-matching-subvoice GR303 IG name/CRV`

GR303

The type of voice endpoint.

IG name

Interface Group name.

CRV

Call Reference Value.

Syntax `find-matching-subvoice ISDN groupID/portType/channelID`

ISDN

The type of voice endpoint.

Group ID

The line group identifier (also known as the ifIndex). Use the **linegroup** command to find the line group ID for an interface.

port type

The ISDN D or B channel. Values are **isdndchannel** or **isdnbchannel**.

channel id

The channel identifier. Values are 1 (D channel), 2 (B channel) or 3 (B channel).

Syntax `find-matching-subvoice POTS LGID`

POTS

The type of voice endpoint.

LGID

The line group identifier (also known as the ifIndex). Use the **linegroup** command to find the line group ID for an interface.

Syntax `find-matching-subvoice VOIP LGID/EndPointIndex`

CLASS5

The type of voice endpoint.

LGID

The line group identifier (also known as the ifIndex). Use the **linegroup** command to find the line group ID for an interface.

EndPointIndex

Index of the voice connection en

Syntax `find-matching-subvoice V52 Interface name/portId/user type/channelId`

V52

The type of voice endpoint.

Interface name

Name of the V5.2 interface group.

portId

The port ID of the V5.2 connection. This is the **local-interface-id** from the **v52-interface-group** profile.

user type

The type of voice connection. Value can be POTS or ISDN.

channel id

The channel identifier. For POTS this is 0.

Example 1 In this example, the AAL2 voice connection is associated with a V5.2 interface.

```
zSH> list subscriber-voice-aal2
```

```
subscriber-voice-aal2 5
```

```
subscriber-voice-aal2 7
```

```
subscriber-voice-aal2 9
```

```
...
```

```
zSH> get subscriber-voice-aal2 5
```

```
voice-aal2-line-group-id: -> {134}
```

```
voice-aal2-vpi: -----> {2}
```

```
voice-aal2-vci: -----> {701}
```

```
voice-aal2-cid: -----> {16}
```

```
zSH> find-matching-subvoice AAL2 134/2/701/16
```

```
INPUT:
```

```
profile type: subscriber-voice-aal2
```

```
logical address: LGID: 134 VPI: 2 VCI: 701 CID: 16
```

```
profile address: 5
```

```
subscriber-voice INFO:
```

```
voice-connection-type = AAL2TOV52
```

```
voice-endpoint1-addr-index = 5
```

```
voice-endpoint2-addr-index = 6
```

```
voice-admin-status = Enabled
```

```

subscriber-voice addr: subId: 2 LGId: 134
subVoiceId: 1
MATCHING:
  profile type: subscriber-voice-v52
  logical address: IfName: rtl UserId: 1
IsdnBChannelId: 0
  profile address: 6

```

The endpoint on the other end of the **subscriber-voice** connection is described under the **MATCHING** heading. The system lists the endpoint profile types, their logical addresses, and each endpoint profile address (the profile number).

The **find-matching-subvoice** command also displays information about the **subscriber-voice** profile that links endpoints, including the voice connection type, the addresses of each endpoint, the administrative status of the profile, and its address.

Example 2 This example finds the endpoint associated with a GR-303 interface.

```

zSH> list subscriber-voice-gr303
subscriber-voice-gr303 10001
subscriber-voice-gr303 10002
subscriber-voice-gr303 10003
...

zSH> get subscriber-voice-gr303 10001
voice-GR303-ig-name: -> {RTL}
voice-GR303-ig-crv: --> {1}

zSH> find-matching-subvoice GR303 RTL/1
INPUT:
  profile type: subscriber-voice-gr303
  logical address: IgName: RTL Crv: 1
  profile address: 10001
subscriber-voice INFO:
  voice-connection-type          = AAL2TOGR303
  voice-endpoint1-addr-index     = 1
  voice-endpoint2-addr-index     = 10001
  voice-admin-status             = Enabled
  subscriber-voice addr: subId: 1 LGId: 36
subVoiceId: 1
MATCHING:
  profile type: subscriber-voice-aal2
  logical address: LGID: 36 VPI: 5 VCI: 202 CID: 17
  profile address: 1

```

Example 3 If there is no profile found for the address entered, the system returns **Address not found**. The following example asks for the other endpoint of an AAL2 **subscriber-voice-aal2** profile that has an undefined CID of 232:

```

zSH> find-matching-subvoice AAL2 1/1/1/232
INPUT:
  profile type: subscriber-voice-aal2

```

```
logical address: LGID: 1 VPI: 1 VCI: 1 CID: 232
profile address: Address not found
```

If there is more than one endpoint with the same address, the system returns a message that includes the duplicate end point address:

```
zSH> find-matching-subvoice AAL2 1/1/1/25
INPUT:
  profile type: subscriber-voice-aal2
  logical address: LGID: 1 VPI: 1 VCI: 1 CID: 25
  profile address: 11
subscriber-voice INFO:
  More than 1 subscriber-voice have the same end point
  address: 11
```

Example 4 If the AAL2 address exists, but is not configured as part of a **subscriber-voice** profile, the system will display an error message as in the following example:

```
zSH> find-matching-subvoice AAL2 1/1/1/33
INPUT:
  profile type: subscriber-voice-aal2
  logical address: LGID: 1 VPI: 1 VCI: 1 CID: 33
  profile address: 33
subscriber-voice INFO:
  No subscriber-voice has end point address: 33
```

Example 5 If the **subscriber-voice-aal2** endpoint does not have a second endpoint configured, the system will return an error that the other endpoint can not be found:

```
zSH> find-matching-subvoice AAL2 1/1/1/44
INPUT:
  profile type: subscriber-voice-aal2
  logical address: LGID: 1 VPI: 1 VCI: 1 CID: 44
  profile address: 44
subscriber-voice INFO:
  voice-connection-type          = AAL2TOGR303
  voice-endpoint1-addr-index     = 44
  voice-endpoint2-addr-index     = 1111
  voice-admin-status             = Disabled
subscriber-voice addr: subId: 1 LGId: 1 subVoiceId: 44
MATCHING:
  profile address: Matching subscriber-voice endpoint with
  address 1111 not found
```

Example 6 ISDN

This example finds the other end of an ISDN endpoint.

```
zSH> list subscriber-voice-isdn
subscriber-voice-isdn 6012
subscriber-voice-isdn 6013
subscriber-voice-isdn 6021
...
```

```

zSH> get subscriber-voice-isdn 6012
voice-isdn-line-group-id: -> {89}
voice-isdn-port-type: -----> {isdnbchannel}
voice-isdn-channel-id: -----> {2}

zSH> find-matching-subvoice ISDN 89/isdnbchannel/2
INPUT:
    profile type: subscriber-voice-isdn
    logical address: LGId: 89 PortType: ISDNBCHANNEL
ChannelId: 2
    profile address: 6012
subscriber-voice INFO:
    voice-connection-type          = UNKNOWN
    voice-endpoint1-addr-index     = 6012
    voice-endpoint2-addr-index     = 16012
    voice-admin-status             = Enabled
    subscriber-voice addr: subId: 6 LGId: 29
subVoiceId: 16012
MATCHING:
    profile type: subscriber-voice-v52
    logical address: IfName: rtl UserId: 601
IsdnBChannelId: 1
    profile address: 16012

```

Example 7 POTS

This example finds the AAL2 endpoint that is associated with a POTS interface.

```

zSH> list subscriber-voice-pots
subscriber-voice-pots 3001
subscriber-voice-pots 3002
subscriber-voice-pots 3003
...

zSH> get subscriber-voice-pots 3001
voice-pots-line-group-id: -> {33}

zSH> find-matching-subvoice POTS 33
INPUT:
    profile type: subscriber-voice-pots
    logical address: LGId: 33 PotsNumber: 1
    profile address: 3001
subscriber-voice INFO:
    voice-connection-type          = POTSTOAAAL2
    voice-endpoint1-addr-index     = 3001
    voice-endpoint2-addr-index     = 301
    voice-admin-status             = Enabled
    subscriber-voice addr: subId: 33 LGId: 5
subVoiceId: 1
MATCHING:
    profile type: subscriber-voice-aal2
    logical address: LGID: 5 VPI: 0 VCI: 301 CID: 17
    profile address: 301

```

Example 8 V52

This example finds the AAL2 endpoint that is associated with a V5.2 user port.

```

zSH> list subscriber-voice-v52
subscriber-voice-v52  6
subscriber-voice-v52  8
subscriber-voice-v52 10
subscriber-voice-v52 34
...

zSH> get subscriber-voice-v52 6
voice-V52-interface-name: --> {rtl}
voice-V52-user-port-id: ----> {1}
voice-V52-user-type: -----> {pots}
voice-V52-isdn-channel-id: -> {0}

zSH> find-matching-subvoice V52 rtl/1/pots/0
INPUT:
    profile type: subscriber-voice-v52
    logical address: IfName: rtl UserId: 1
IsdnBChannelId: 0
    profile address: 6
subscriber-voice INFO:
    voice-connection-type          = AAL2TOV52
    voice-endpoint1-addr-index     = 5
    voice-endpoint2-addr-index     = 6
    voice-admin-status             = Enabled
    subscriber-voice addr: subId: 2 LGID: 134
subVoiceId: 1
MATCHING:
    profile type: subscriber-voice-aal2
    logical address: LGID: 134 VPI: 2 VCI: 701 CID: 16
    profile address: 5

```

Products BAN, MALC, Sechtor 100A, Z-Edge 64

G**get**

The **get** command displays the contents of record and its configured parameters.

Syntax `get profile-type index`

Options *profile-type*

Shows the parameters in the specified profile with the parameter value ranges.

index

Record to display.

Example To view the configuration of a particular record, use the **get** command and specify the address of the record:

```
zSH> get ip-interface-record ethernet1/ip
vpi: -----> {0}
vci: -----> {0}
rdindex: -----> {1}
dhcp: -----> {none}
addr: -----> {192.24.200.223}
netmask: -----> {255.255.255.0}
bcastaddr: -----> {192.24.200.255}
destaddr: -----> {0.0.0.0}
farendaddr: -----> {0.0.0.0}
mru: -----> {1500}
reasmmaxsize: -----> {0}
ingressfiltername: -> {}
egressfiltername: --> {}
pointtopoint: -----> {no}
mcastenabled: -----> {yes}
ipfwdenabled: -----> {yes}
mcastfwdenabled: ----> {yes}
natenabled: -----> {no}
bcastenabled: -----> {yes}
ingressfilterid: ----> {0}
egressfilterid: ----> {0}
ipaddrdynamic: -----> {static}
dhcpserverenable: --> {false}
subnetgroup: -----> {0}
unnumberedindex: ----> {0}
mcastcontrollist: --> {}
vlanid: -----> {0}
maxVideoStreams: ----> {0}
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also list, show

gpononu

For GPON configurations, sets and displays ONU and serial number associations. The default bandwidth is 1 Mbps.

Syntax **gpononu clear slot/onu | set [bw] slot/onu [bandwidth] | show slot/onu | showall [slot/onu] [enabled] [free]**

Example

```
zSH> gpononu show 8/1
Free ONUs for slot 8 olt 1:
```

```

 1   2   4   5   6   7   8   9  10  11  12  13
14  15  16  17  18  19  20  21  22  23  24  25
26  27  28  29  30  31  32  33  34  35  36  37
38  39  40  41  42  43  44  45  46  47  48  49
50  51  52  53  54  55  56  57  58  59  60  61
62  63  64

```

Discovered serial numbers for slot 8 olt 1:

sernoID	Vendor	Serial Number	sernoID	Vendor	Serial Number
1	ZNTS	220001			
2	ZNTS	220002			

Assign the available ONU 2 with serial number ID (sernoID) 2. By not specifying a name, the default name is used. The default ONU bandwidth is 1 Mbps. The ONU number can also be used to specify a ONU. For example, ONU2 instead of 8/1/2.

```
zSH> gpononu set 8/1/2 2 bw 4.5
```

Onu 2 successfully enabled with serial number ZNTS 220002

Bandwidth has been successfully changed from 1 to 4.5 Mb/sec

```
zSH> MAR 12 11:53:01: alert : 1/8/1025: alarm_mgr: 01: 8:01:02 Critical ONU Up
Line 1/8/1/2/gpononu CAUSE: active
```

Check the ONU bandwidth setting.

```
zSH> gpononu bw 8/1/2
```

Current bandwidth allocation is 4.5 Mbits/sec

Show all ONU's on the MALC.

```
zSH> gpononu showall
```

Slot 8 olt 1

Onu	Name	Enabled	Serial Number	BW(Mb)	GponPorts
1	1-8-1-1	Yes	ZNTS 220001	1	1-8-1-501/gponport
2	1-8-1-2	Yes	ZNTS 220002	4.5	1-8-1-502/gponport
3	1-8-1-3	No	ZNTS 0	0	1-8-1-503/gponport
4	1-8-1-4	No	ZNTS 0	0	1-8-1-504/gponport
5	1-8-1-5	No	ZNTS 0	0	1-8-1-505/gponport

<SPACE> for next page, <CR> for next line, A for all, Q to quit

Show only the ONU 2.

```
zSH> gpononu showall 8/1/2
```

Slot 8 olt 1

Onu	Name	Enabled	Serial Number	BW(Mb)	GponPorts
1	1-8-1-2	Yes	ZNTS 220002	4.5	1-8-1-502/gponport

Show only the enabled ONU's.

```
zSH> gpononu showall 8/1 enabled
```

Slot 8 olt 1

Onu	Name	Enabled	Serial Number	BW(Mb)	GponPorts
1	1-8-1-1	Yes	ZNTS 220001	1	1-8-1-501/gponport
2	1-8-1-2	Yes	ZNTS 220002	18.5	1-8-1-502/gponport

Total onus = 2 bandwidth = 19.5

Clear or deactivate ONU 2.

```
zSH> gpononu clear 8/1/2
Onu 2 (previously enabled with serial number ZNTS 220002) has been cleared
zSH> MAR 12 14:17:13: alert : 1/8/1025: alarm_mgr: 01: 8:03:01 Critical ONU
Down
Line 1/8/1/2/gpononu CAUSE: inactive
```

gr303showcrv

The **gr303showcrv** command displays information about GR-303 call reference values (CRVs). This command is available when T1/E1 uplink and voicegateway cards are installed.

Syntax `gr303showcrv igName crvNumber`

Options `igName`

The GR-303 interface group (IG) name.

`crvNumber`

The GR-303 call reference value (CRV) number.

Example 1 To view information on all CRVs within an IG, use the **gr303showcrv** command with only the IG name specified:

```
zSH> gr303showcrv test
ig: 0 crv: 1 in-serivce this CRV is operational on the switch and the device
ig: 0 crv: 2 in-serivce
ig: 0 crv: 3 in-serivce
ig: 0 crv: 4 in-serivce
ig: 0 crv: 5 in-serivce
ig: 0 crv: 6 in-serivce
ig: 0 crv: 7 in-serivce
ig: 0 crv: 8 in-serivce
ig: 0 crv: 9 in-serivce
ig: 0 crv: 10 in-serivce
ig: 0 crv: 11 out-of-serivce - SWITCH NOT PROV this CRV is provisioned on the device but is not
provisioned on the switch
ig: 0 crv: 12 out-of-serivce - SWITCH NOT PROV
ig: 0 crv: 13 out-of-serivce - SWITCH NOT PROV
ig: 0 crv: 14 out-of-serivce - SWITCH NOT PROV
...
```



Note: This is a truncated response to the **gr303showcrv** *igname* command.

Example 2 To view information on one CRV within the IG, use the **gr303showcrv** command with the IG name and CRV specified:

```
zSH> gr303showcrv test 1
ig: 0 crv: 1 in-serivce
```

Access Level user

Products MALC, Sechtor 100A

H

help

Displays help text for a command.

Syntax `help [-p][command]`

Options (no option)

Displays the available commands with a brief explanation.

command

Displays detailed help for the specified command.

-p

Displays the available commands, a brief explanation of the command, and the access level.

Example 1 Enter the **help** command without options to display the available commands:

```
zSH> help
 1 adduser
 2 ata - initialize/show ATA flash partitions.
 3 bootstate - <slot> display the boot state of a given
slot card
 4 cd - change current directory.
 5 changepass
 6 commit <profile-type> <profile-storage-key>
 7 copy - copy a file.
 8 create <profile-type> <profile-storage-key>
 9 del - Delete a file.
10 delete <profile-type> <profile-storage-key>
11 deleteuser <userName>
12 dir - list directory contents.
13 dump <[console] | [file filename] | [network host
filename]>
14 eeshow eepromName <slot>
15 featurebitdisplay <featurenum>
16 featurebitset offset mask value hashCode
17 fhrameping shelf/slot</port>
18 file - download/upload files.
19 find [-s(ubSearch) | -d(etailed)] <stringToSearch>
20 get <profile-type> <profile-storage-key>
21 help [commands]
```

Type A<CR> to print all, <CR> to continue, Q<CR> to stop:

Example 2 To get help on a particular command, enter the **help** command followed by the name of the command. For example:

```
zSH> help slots
```

Use: slots [<slotNum>]

This command displays the card type present in each slot. If <slotNum> is provided, it shows detailed information about the card.

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

history

Displays the commands stored in the command buffer.

Syntax `history [size]`

Options

With no options, **history** displays the commands stored in the command buffer.

size

Specifies the number of commands to store in the history buffer.

Example

```
zSH> history
1  addroute
2  addhost
3  help
4  showinetstat
5  showversion
6  list subscriber
7  list
8  showhost
9  showroute
10 setprompt
11 help
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

host

The **host** command is used to add, delete, or show hosts in a point-to-multipoint network.

Syntax `zSH> host add interface/type vc vpi/vci [tc tcvalue] td tdvalue | txt dvalue rxd tdvalue other | llc static x.x.x.x | dynamic SubnetGroup count [video MulticastControllist/NumberOfVideoStreams] vlan vlanid slan slanid [cos cosValue] [scos scosValue] [tosDisable | tosOrig tosValue | tosAll tosValue]`

add

Add hosts to an IP multi-point subnet. Hosts may be given static IP addresses or dynamically assigned addresses using DHCP.

*interface***type**

Name and type of the physical interface, such as **1-4-3-0/adsl**.



Note: In the host add command, <slot> and <port> may be replaced with brackets containing numbers in series and/or (dash-separated) ranges; <port> may be replaced with wildcard '*' for all ports on the card.

Examples:

1-[10-13]-[1,3-5,21]-0/ds3 for DS3 ports 1,3,4,5,21 on cards 10,11,12, and 13.

1-[6,7,9]-*-0/adsl for all ADSL ports on cards 6, 7, and 9.

vc vpi/vci

Used to specify the VPI and VCI values for ATM circuits. For example: **vc 0/23**.

tc terval

Used to specify the traffic container index to be used. This is a mandatory field if the physical interface type is PON.

td tdvalue | rxd rxdvalue txt txtvalue

Used to specify the traffic descriptor index to be used. Optionally, separate **rxd rxdvalue** and **txt txtvalue** values may be specified for ADSL connections, where separate traffic descriptors are used for the upstream and downstream traffic due to the asymmetric nature.

other | llc

The type of AAL5 data encapsulation used: **other** sets RFC 1483 multiprotocol encapsulation over AAL5, which is commonly used with bridges; **llc** sets logical link control encapsulation over AAL5, which is commonly used with routers. If no value is given, the default **other** is the AAL5 encapsulation type.

static x.x.x.x

Add a host to the given subnet with the static IP addresses of *x.x.x.x*.

dynamic subnetgroup count

Add *count* number of hosts to the given subnet and have their IP addresses assigned dynamically using DHCP from IP addresses that are in the subnet group as specified by *subnetgroup*.

video MulticastControlList/NumberofVideoStreams

Adds a video client connection using the specified multicast control list entry and maximum number of video streams. By default, the multicast control list enables subscriptions up to the number of maximum video streams on the interface without control list checking. Video streams can be configured on 10/100 and GigE interfaces.

When the **video** argument is specified, the VCL cast type for the subscriber interface (**vcl_cast_type**) is set to **p2mpleaf**.

vlan

Specifies the VLAN ID to apply to this interface.

slan

Specifies the SLAN (second VLAN) ID to apply to this interface.

cos

For tagged packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

scos

For SLAN packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

tosDisable/tosOrig//tosAll

Specifies the TOS settings and values to apply to this interface.

Syntax `host modify interface/type vc vpi/vci vlan vlanID`

modify

Modify hosts to an IP multi-point subnet. Hosts may be given static IP addresses or dynamically assigned addresses using DHCP.

interfacename/type

Name and type of the physical interface, such as 1-4-3-0/adsl.



Note: In the **host modify** command, <slot> and <port> may be replaced with brackets containing numbers in series and/or (dash-separated) ranges; <port> may be replaced with wildcard '*' for all ports on the card.

Examples:

1-[10-13]-[1,3-5,21]-0/ds3 specifies DS3 ports 1,3,4,5,21 on cards 10,11,12, and 13.

1-[6,7,9]-*-0/adsl specifies all ADSL ports on cards 6, 7, and 9

vc vpi/vci

Used to specify the VPI and VCI values for ATM circuits. For example: **vc 0/23**.

vlan vlanID

Specifies that VLAN ID that was assigned to the host. If a VLAN ID was assigned to the host when it was configured, the VLAN ID must be specified when deleting the host.

Syntax `host delete interface/type vc vpi/vci ip x.x.x.x | unused count | all vlan vlanID`

delete

Delete a host or hosts from an IP multi-point subnet.

interfacename/type

Name and type of the physical interface, such as **1-4-3-0/adsl**.



Note: In the **host delete** command, <slot> and <port> may be replaced with brackets containing numbers in series and/or (dash-separated) ranges; <port> may be replaced with wildcard '*' for all ports on the card.

Examples:

1-[10-13]-[1,3-5,21]-0/ds3 for DS3 ports 1,3,4,5,21 on cards 10,11,12, and 13.

1-[6,7,9]-*-0/adsl for all ADSL ports on cards 6, 7, and 9.

vc vpi/vci

Used to specify the VPI and VCI values for ATM circuits. For example:
vc 0/23.

ip x.x.x.x

Delete the host with the IP address of *x.x.x.x*. This host may have been assigned its address either via DHCP or statically.

unused count

Delete up to *count* number of DHCP host entries that have not yet been assigned an IP address.

all

Delete all hosts on this subnet and the subnet itself.

video MulticastControlList/NumberOfVideoStreams

Deletes the video client connection using the specified multicast control list entry and maximum number of video streams.

vlan

Specifies that VLAN ID that was assigned to the host. If a VLAN ID was assigned to the host when it was configured, the VLAN ID must be specified when deleting the host.

Syntax `host show interface interface/type vc vpi/vci | addr x.x.x.x | host x.x.x.x`

show

Show hosts that are part of an IP multi-point subnet.

interface *interfacename/type*

Show only hosts on this physical interface.

vc *vpi/vci*

Must be used with interface keyword. Show only hosts on given interface with this VCL value.

addr *x.x.x.x*

Show only hosts with on the interface with the address of *x.x.x.x*.

host *x.x.x.x*

Show only the host with the address of *x.x.x.x*.

Example 1

```
zSH> host add 1-11-1-0/adsl vc 0/35 td 1 llc dynamic 1 3
```

Example 2

```
zSH> host delete 1-11-1-0/adsl vc 0/35 all
```

Example 3

```
zSH> host show interface 1-11-1-0/adsl vc 0/35
```

Example 4

```
zSH> host add 1-11-1-0/adsl vc 0/35 td 1 llc dynamic 1 3 video 1/4
```

Example 5

```
host add 1-6-9-0/adsl vc 0/37 td 1 tpid 0x8200 vlan 100 slan 10 cos 2 scos 3
dynamic 1 3
```

Products MALC, Raptor 319, Raptor 719, Raptor 723

I

ifxlate

Translates between ifindex values and physical interfaces (of the form *shelf-slot-port-subport-type*).

Syntax `ifxlate ifindex`

Options `ifindex`

The interface index to translate into a physical interface.

Example The following example displays the associated *shelf-slot-port-subport-type* of the interface:

```
zSH> ifxlate 1
ifIndex: -----> {1}
shelf: -----> {1}
slot: -----> {3}
port: -----> {1}
subport: -----> {0}
type: -----> {ethernetcsmacd}
adminstatus: -----> {up}
physical-flag: -----> {true}
iftype-extension: -> {none}
ifName: -----> {1-3-1-0}
redundancy-param1: -> {0}
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

image

Downloads software to the system from a TFTP server, updates the boot partition, or verifies the flash card file system.



Note: The **image** command should be used to download software image files, because it verifies the image header as part of the download process.

Syntax `image download tftphost file_path [destination]`

Downloads the software image and verifies the image header.

tftphost

The name or IP address of the TFTP server.

file_path

The full path name of the software image file on the TFTP server.

destination

The full path name where the software image file should be downloaded to. If not specified, the file is downloaded to the current directory with the original file name.



Note: BAN system software is loaded onto the flash cards on the Infoservices card. The path to the software image file is either `/card1/file` or `/card2/file`, depending on which PC card contains the software.

Syntax `image flash file port [standby | all]`

Updates the boot partition on the PC card.

file

Full path to the software image file. For example, `/card1/infoservraw.bin` is the full path to the software image on the first PC card.

port

The PC card port that contains the boot partition. For the MALC or Raptor this value is always 1.

standby

Performs the image flash on the standby card.

all

Performs the image flash on both the active and the standby card.

Syntax `image verify file`

Verifies the specified file.

file

Full path to the software image file. For example, `/card1/infoservraw.bin` is the full path to the software image on the first PC card.

Example The following example verifies the image file on the first PC card:

```
zSH> image verify malcgige.bin
File: malcgige.bin
Size: 7749520 bytes
Header Version: 1
Card Type: MALC GIGE
Load Type: compressed binary
Load Address: 0x00010000
Checksum: 0xb5443578
Image verify successful
```

Access Level admin

Products BAN, Raptor 100, MALC, Raptor 319, Raptor 719, Raptor 723

See Also file

imalink

The **imalink** command enables you to move, add, delete, or view IMA (inverse multiplexing over ATM) links.

Syntax `imalink move SourceIMAGroup DestinationIMAGroup ds1Interface`

Moves an IMA link from one group to another.

SourceIMAGroup

The IMA group to move the link from, in the form *shelf-slot-port-subport/atmima*.

DestinationIMAGroup

The IMA group to move the link to, in the form *shelf-slot-port-subport/atmima*.

ds1Interface

The link group to move, in the form *shelf-slot-port-subport/ds1*.

Syntax `imalink show [IMAGroup]`

Displays information about or IMA groups or only the specified IMA group.

IMAGroup

The IMA group to view, in the form *shelf-slot-port-subport/atmima*.

Syntax `imalink mkuni ds1Interface`

Rectifies an orphan DS1 by making it a User to Network Interface (UNI).

ds1Interface

The link to move in the form *shelf-slot-port-subport/ds1*.

Syntax `imalink add IMAGroup ds1Interface`

Adds an IMA link. Do not use this command unless requested to by GSS.

IMAGroup

The IMA group to remove, in the form *shelf-slot-port-subport/atmima*.

dsInterface

The link group to add, in the form *shelf-slot-port-subport/ds1*.

Syntax `imalink remove IMAGroup dsInterface`

Removes an IMA link.



Note: This option should not be used. If you do not want a link to belong to any IMA group, it is recommended that you admin down the interface in the **if-translate** profile.

IMAGroup

The IMA group to remove, in the form *shelf-slot-port-subport/atmima*.

dsInterface

The link group to remove, in the form *shelf-slot-port-subport/ds1*.

Example 1 To move a link:

```
zSH> imalink move 1-1-1-0/atmima 1-1-4-0/atmima 1/1/8/0/
ds1
```

Stack unbind successful.

Link moved successfully.

Then view the group with the new link:

```
zSH> imalink show 1-1-4-0/atmima
DS1 Links for IMA Group 1-1-4-0/atmima:
If Index      If Name
-----
000011        1-1-8-0
```

Example 2 To view information about the links in an IMA group:

```
zSH> imalink show 1-3-1-0/atmima
DS1 Links for IMA Group 1-3-1-0/atmima:
```

```
If Index      If Name
-----
000736        1-3-1-0
000737        1-3-2-0
000738        1-3-3-0
000739        1-3-4-0
```

```
zSH> imalink show
DS1 Links for IMA Group 1-1-1-0/atmima:
```

```
If Index      If Name
-----
000004        1-1-1-0
000005        1-1-2-0
000006        1-1-3-0
000007        1-1-4-0
```

```

000008      1-1-5-0
000009      1-1-6-0
000010      1-1-7-0
DS1 Links for IMA Group 1-1-2-0/atmima:
If Index    If Name
-----
000011      1-1-8-0
IMA Group 1-1-3-0/atmima has no assigned links.
IMA Group 1-1-4-0/atmima has no assigned links.
DS1 Links for IMA Group 1-6-1-0/atmima:
If Index    If Name
-----
000090      1-6-4-0
DS1 Links for IMA Group 1-6-2-0/atmima:
If Index    If Name
-----
000091      1-6-5-0
000092      1-6-6-0
000093      1-6-7-0
000094      1-6-8-0
000089      1-6-3-0
DS1 Links for IMA Group 1-6-3-0/atmima:
If Index    If Name
-----
000095      1-6-9-0
000096      1-6-10-0
000097      1-6-11-0
000098      1-6-12-0
DS1 Links for IMA Group 1-6-4-0/atmima:
If Index    If Name

```

- Access Level** admin
- Products** MALC, Raptor, Raptor 100
- See Also** [showline](#)

imarps show

The **imarps show** command displays resource provider information about the MALC IMA group. This command is available only when an uplink card with IMA support is installed. The command uses the following syntax:

Syntax `imarps show [index]`

Options `index`
The IMA group number (currently, 1 (one) is the only supported value).

Example 1 `zSH> imarps show`

```

RP Info:
rp state -----> RP_INITIALIZED
address -----> 01:01:113
rp shelf -----> 1
rp slot -----> 1
rp ima core started -----> TRUE

```

```

imaGrpProfLeaseId -----> 0x02070000_00000057
LineRRProvLeaseId -----> 0x02070000_00000055
LineRRClientLeaseId -----> 0x02070000_00000056
numImaGroups -----> 1
ImaGroupIndecies: 1

```

Example 2 To display complete information about an IMA group, specify the group number:

```

zSH> imarpshow 1
RP Info:
  rp state -----> RP_INITIALIZED
  address -----> 01:01:113
  rp shelf -----> 1
  rp slot -----> 1
  rp ima core started -----> TRUE
  imaGrpProfLeaseId -----> 0x02070000_00000057
  LineRRProvLeaseId -----> 0x02070000_00000055
  LineRRClientLeaseId -----> 0x02070000_00000056
  numImaGroups -----> 1
  ImaGroupIndecies: 1
IMA Group Index =1
.....
  group status =====> OOS
  .....
  group ne state ----->
INSUFFICIENTLINKS
  group fe state -----> OPERATIONAL
  .....
  group ctrl state -----> GRP_INITIALIZED
  group ifIndex -----> 11
  group in service -----> TRUE
  driver attached -----> TRUE
  driver unit -----> 0
  auto-created -----> FALSE
  ifxLeaseId -----> 0x02070000_00000057
  lineProfLeaseId -----> 0x02070000_00000057
  lineGrpLeaseId -----> 0x02070000_00000057
  ifStackLeaseId -----> 0x02070000_00000057
  dslLeaseId -----> 0x00000000_00000000
  .....
  ifxlateProfValid -----> TRUE
  ifxlatProf.ifIndex -----> 11
  ifxlatProf.shelf -----> 1
  ifxlatProf.slot -----> 1
  ifxlatProf.port -----> 2
  ifxlatProf.ifType -----> ATMIMA
  ifxlatProf.adminStatus -----> UP
  .....
  lineProfValid -----> TRUE
  lineProf.profileName -----> Atm IMA Group default line profile
  lineProf.physicalAddress.shelf --> 1
  lineProf.physicalAddress.slot ---> 1
  lineProf.physicalAddress.port ---> 2
  lineProf.lineGroupName -----> 11

```

```

.....
lineGrpProfValid -----> TRUE
lineGrpProf.groupName -----> 1/1/1
lineGrpProf.primaryName -----> 11
lineGrpProf.secondaryName -----> 0
lineGrpProf.primaryWeight -----> 0
lineGrpProf.secondaryWeight -----> 0
lineGrpProf.adminState -----> UP
.....
imaGrpProfValid -----> TRUE
imaGrpProf.groupSymmetry -----> SYMMETRICAL
imaGrpProf.minNumTxLinks -----> 1
imaGrpProf.minNumRxLinks -----> 1
imaGrpProf.txClkMode -----> CTC
imaGrpProf.txImaId -----> 1
imaGrpProf.txFrameLength -----> M128
imaGrpProf.diffDelayMax -----> 75
imaGrpProf.alphaValue -----> 1
imaGrpProf.betaValue -----> 1
imaGrpProf.gammaValue -----> 1
imaGrpProf.testLinkIfIndex -----> 0
imaGrpProf.testPattern -----> -1
imaGrpProf.testProcStatus -----> DISABLED
imaGrpProf.txTimingRefLink -----> 0
imaGrpProf.rxTimingRefLink -----> 0
.....
Link#1
linkType -----> DS1_PROFILE_LINETYPE_ESF
ifIndex -----> 2
framerstatus -----> OOS
netxlinkstatus -----> NOT-IN-GROUP
nerxlinkstatus -----> NOT-IN-GROUP
.....
...
...
...

```

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

imatppshow

Displays the status of an IMA test pattern procedure. This command is available only when an uplink card with IMA support is installed.

Syntax `imatppshow [group]`

Options `group`

Number of the IMA group to display information about.

Example 1 If the test is successful, `imaGroupTestProcStatus` displays **OPERATING**:

```

zSH> imatppshow 1
TestLink .....: 2
imaGroupTestPattern .....: 23

```

```
imaGroupTestProcStatus .....: OPERATING
```

Example 2 If the test fails (if, for example, the remote link is down), **imaGroupTestProcStatus** displays **LINKFAIL**:

```
zSH> imatppshow 1
TestLink .....: 2
imaGroupTestPattern .....: 71
imaGroupTestProcStatus .....: LINKFAIL
```

Example 3 After the test is disabled, the **imaGroupTestProcStatus** displays **DISABLED**:

```
zSH> imatppshow 1
TestLink .....: 2
imaGroupTestPattern .....: 23
imaGroupTestProcStatus .....: DISABLED
```

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

initiateconfigsync

Initiates a manual update of the ZMS database with the device's configuration. Config sync updates are performed automatically whenever a change is made to the device via the CLI. During a restore, however, the updating process is suspended. After a restore, a full config sync update is required.



Note: Zhone recommends that you perform a config sync update from ZMS. For more information, refer to the documentation that came with the ZMS software.

Syntax `initiateconfigsync [full | partial]`

Options **full**

Sends all profiles to ZMS. This option could cause significant processing by ZMS.

partial

Sends only the new or updated profiles to ZMS.

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

interface

The **interface** command can add, delete, or show numbered and unnumbered (floating) interfaces in different subnets.

Syntax `interface add interface/type vc vpi/vci [tc tcvalue] td tdvalue | txt dvalue rxd tdvalue llc | other vlan`

```
vlanid slan slanid [cos cosValue] [scos scosValue]
[tosDisable | tosOrig tosValue | tosAll tosValue] client
| IPaddr netmask server name [video MulticastControlList/
NumberofVideoStreams]
```

```
interface add float [interface name] IPaddr netmask
```

float

Adds a floating or unnumbered IP interface with the specified IP address and network mask.

add

Provides one-line configuration of IP interfaces, including the creation of the **ip-interface-record**, **if-translate**, and **atm-vcl** records.

interfacename/type

Name and type of the physical interface.

vc vpi/vci

Used to specify the VPI and VCI values for ATM circuits. For example: **0/23**.

td tdvalue | rxt rxtvalue txt txtvalue

Used to specify the traffic descriptor index to be used. Optionally, separate **rxt** *rxtvalue* and **txt** *txtvalue* values may be specified for ADSL connections, where separate traffic descriptors are used for the upstream and downstream traffic due to the asymmetric nature.

tc tvalue

Used only for PON interfaces to specify the traffic container index to be used.

llc | other

The type of AAL5 data encapsulation used: **llc** sets logical link control encapsulation over AAL5, which is commonly used with routers; **other** sets RFC 1483 multiprotocol encapsulation over AAL5, which is commonly used with bridges. If no value is given, the default **llc** is the AAL5 encapsulation type.

vlan

Specifies the VLAN ID to apply to this interface.

slan

Specifies the SLAN (second VLAN) ID to apply to this interface.

cos

For tagged packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

scos

For SLAN packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

tosDisable/tosOrig//tosAll

Specifies the TOS settings and values to apply to this interface.

client/IPaddress

Client name and IP address.

IPaddr

Address will given as a static IP address. The IP address can have a subnet portion denoted by */x*.

netmask

Masks out certain parts of host address and all of the network portion of the IP address.

server

Server name.

name**video MulticastControlList/NumberOfVideoStreams**

Adds a video client connection using the specified multicast control list entry and maximum number of video streams. By default, the multicast control list entry enables subscriptions up to the number of maximum video streams on the interface without control list checking.

When the **video** argument is specified, the VCL cast type for the subscriber interface (**vcl_cast_type**) is set to **p2mpleaf**.

Syntax `interface delete physicalInterface vpi/vci`

delete

Removes all of the configuration done by the **interface add** command.

physicalInterface

Name and type of the physical interface, such as **1-4-3-0/hdsl2**.

vpi/vci

Used to specify the VPI and VCI values for ATM circuits. For example: **0/23**.

Syntax `interface delete physicalInterface vpi/vci`

a

Displays all provisioned interfaces, including floating (unnumbered) interfaces and internal interfaces such as the loopback interface.

l

Displays the interface IfIndex values and flag information.

i

Displays just the specified interface.

Syntax `interface delete float [interface name] IPaddr netmask`

float

Removes the floating interface associated with the specified interface name, IP address, and network mask.

Example 1

```
zSH> interface add 1-11-1-0/adsl vc 0/35 td 1 10.0.0.1 netmask 255.255.255.0
```

Example 2

```
zSH> interface delete 1-11-1-0/adsl vc 0/35
```

Example 3

```
zSH> interface show
```

579 interfaces

Interface	Status	Rd/Address	Media/Dest Address	IfName
1/1/1/0/ip	UP	1 192.24.200.223/24	00:01:47:43:c0:38	ethernet1
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/772 multipoint	1-10-21-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/764 multipoint	1-10-13-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/756 multipoint	1-10-5-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/614 multipoint	1-9-4-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/530 multipoint	1-8-10-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/472 multipoint	1-7-29-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/446 multipoint	1-7-16-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/388 multipoint	1-6-35-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/304 multipoint	1-5-41-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/240 multipoint	1-5-9-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/220 multipoint	1-4-47-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/156 multipoint	1-4-15-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/72 multipoint	1-3-21-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/1092 multipoint	1-14-44-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/1044 multipoint	1-13-27-0-adsl-0-35
1/1/1/0/ip	DOWN	1 [10.223.8.1]	0/960 multipoint	1-12-33-0-adsl-0-35

<SPACE> for next page, <CR> for next line, A for all, Q to quit

Example 4 This example adds interface 1-8-13-0/adsl with a COS value of 7.

```
interface add 1-8-13-0/adsl vc 0/35 td 20000 other vlan 1 cos 7 23.23.23.23
255.255.255.0
```

Example 5 This example adds interface 1-8-13-0/adsl with a COS value of 1 and specifies to add this value to all packets originating from this interface.

```
interface add 1-8-13-0/adsl vc 0/35 td 20000 other vlan 1 cos 1 tosOrig 1
23.23.23.23 255.255.255.0
```

Example 6 This example adds interface 1-8-13-0/adsl with a COS value of 5 and specifies to add the value to all outgoing packets on this interface.

```
interface add 1-8-13-0/adsl vc 0/35 td 20000 other tos all cos 5 23.23.23.23
255.255.255.0
```

Example 7 This example adds interface 1-8-13-0/adsl and disables the TOS feature.

```
interface add 1-8-13-0/adsl vc 0/35 td 20000 other tosDisable 23.23.23.23
255.255.255.0
```

Example 8 This example adds a floating (unnumbered) interface using the name IP210 and the IP address 172.24.5.210 with a subnet mask of 255.255.255.0.

```
interface add float IP210 172.24.5.210 255.255.255.0
```

Products MALC, Raptor 319, Raptor 719, Raptor 723

ip igmpstat

Displays the IGMP statistics.

Syntax `ip igmpstat active | summary`

Options `active`

Displays IGMP statistics for only the active interfaces.

summary

Displays only IGMP statistics summary data.

Example The following example displays the current IGMP statistics:

```
zSH> ip igmpstat
ICMP:
    0 call to icmp_error
    0 error not generated because old message was icmp
Output histogram:
    echo reply: 1
    0 message with bad code fields
    0 message < minimum length
    0 bad checksum
    0 message with bad length
Input histogram:
    destination unreachable: 120
    echo: 1
    1 message response generated

zSH>
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip ifstat

Displays the interface statistics. The statistics are complete only for the interfaces that exist on the card. Virtual or non-local interfaces will not show received packets.

Syntax `ip ifstat [[ifname] | [ifindex [ifindex2]] | [shelf/slot/port [s/s/p]]]`

Options `ifname`

The name of the physical interface.

ifindex

The interface index to translate into a physical interface.

ifindex2

The second interface index to translate into a physical interface.

shelf/slot/port

The shelf/slot/port for which statistics are displayed.

Example The following example displays the current interface statistics:

```
zSH> ip ifstat
      ifName          rxpkt      txpkt      rxmc      txmc      ierr      oerr      sqsz      sqdp
      lo              14392      14392      0          0          0          0          0          0
      1-2-1-0         56187      13742      42460      22         0          0          0          0
2 interfaces
zSH>
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip ifsum

Displays a summarized list of interfaces known to the card.

Syntax `ip ifsum [ifname]`

Options *ifname*

The name of the physical interface.

Example The following example displays the current interfaces:

```
zSH> ip ifsum
lo SOFTWARELOOPBACK ifindex 0 (ifp 0x23e3bd0, 6|3)
  Flags: UP LOOPBACK MCAST ARP RUNNING
  inet 127.0.0.1 netmask 255.0.0.0
1-1-1-0 ETHERNETCSMACD ifindex 69 (ifp 0x256b5e0, 10|7)
  Flags: UP BCAST MCAST IPFWD MCASTFWD ARP RUNNING CFGCURRENT
  inet 172.16.88.20 netmask 255.255.255.0 bcast 172.16.88.255
1-5-1-0-aal5proxy-0-32 RFC1483 vpi/vci 0/32 ifindex 582 (ifp 0x256b92c, 4|1)
  Flags: UP POINT-TO-POINT MCAST IPFWD MCASTFWD RUNNING CFGCURRENT
MEDIAP2PUNNUMBERED
  inet 10.10.20.1 netmask 255.255.255.255 destinet 0.0.0.0
3 interfaces
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip inetstat

Displays the active TCP/UDP/RAW endpoints terminating on this card.

Syntax `ip inetstat [-s]`

Options `-s`

Displays additional data.

Example The following example displays the active TCP/UDP/RAW endpoints terminating on this card:

```
zSH> ip inetstat
```

```
Active Internet connections (including servers)
```

PCB	Proto	Recv-Q	Send-Q	Local Address	Foreign Address	(state)
32169c0	TCP	0	214	172.16.80.101.23	172.16.48.84.1762	ESTABLISHED
3215c58	TCP	0	0	172.16.80.101.23	172.16.41.218.4908	ESTABLISHED
3216078	TCP	0	0	172.16.80.101.23	172.16.41.176.4893	ESTABLISHED
3215a48	TCP	0	0	0.0.0.0.23	0.0.0.0.0	LISTEN
3216288	UDP	0	0	0.0.0.0.2427	0.0.0.0.0	
3216180	UDP	0	0	0.0.0.0.5060	0.0.0.0.0	
3215eec	UDP	0	0	0.0.0.0.67	0.0.0.0.0	
3215bd4	UDP	0	0	0.0.0.0.520	0.0.0.0.0	
3215b50	UDP	0	0	0.0.0.0.162	0.0.0.0.0	
3215acc	UDP	0	0	0.0.0.0.161	0.0.0.0.0	
32160fc	RAW	0	0	0.0.0.0.0	0.0.0.0.0	

```
Active Internet connections (additional data)
```

PCB	Socket	ProtoPCB	Domain	Route	MAMA Address	MAMADom
32169c0	79cbf70	7db396c	1	793a610	255.255.255.255.0	0
3215c58	79cb2f0	7db3a70	1	793a610	255.255.255.255.0	0
3216078	7954910	7db355c	1	793a610	255.255.255.255.0	0
3215a48	7955270	7db3458	1	793a610	255.255.255.255.0	0
3216288	7958470	0	1	0	255.255.255.255.0	0
3216180	7954aa0	0	1	0	255.255.255.255.0	0
3215eec	795a540	0	1	0	255.255.255.255.0	0
3215bd4	7959410	0	1	0	255.255.255.255.0	0
3215b50	79571b0	0	1	0	255.255.255.255.0	0
3215acc	795bcb0	0	1	0	255.255.255.255.0	0
32160fc	7958dd0	0	1	0	255.255.255.255.0	0

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip ipstat

Displays the IP statistics.

Syntax `ip ipstat [clear]`

Options `clear`

Clears the current statistics.

Example The following example displays the current IP statistics:

```
zSH> ip ipstat
```

```

        total 46595
        badsum 0
        tooshort 0
        toosmall 0
        badhlen 0
        badlen 0
        infragments 0
        fragdropped 0
        fragtimeout 0
        forward 0
        cantforward 14007
        redirectsent 0
        unknownprotocol 0
        nobuffers 0
        reassembled 0
        outfragments 0
        noroute 0
        fastfwd 0
        fastfwdnoroute 0
        ffwdnointerface 0
        nointerface 0
        c2ctotal 0
        c2cbadptr 0
        c2cnopkt 0
        c2cnoipktmem 0
        c2ccorruptpkt 0
        c2cttlexp 0
        c2clastchance 0
        flingnoipkt 0
        flingerror 0
        flung 0
        rawflung 0
        rawnofling 0
        fwdloopdrop 0
        localfastpath 32203
        pendingarpoverflow 0
    
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip tcpstat

Displays the TCP statistics.

Syntax ip tcpstat

Example The following example displays the current TCP statistics:

```

zSH> ip tcpstat
TCP:
    20071 packets sent
    10457 data packets (4305315 bytes)
    
```

```

1 data packet (7 bytes) retransmitted
9531 ack-only packets (1 delayed)
0 URG only packet
0 window probe packet
47 window update packets
35 control packets
20103 packets received
10366 acks (for 4305330 bytes)
43 duplicate acks
0 ack for unsent data
9817 packets (4150800 bytes) received in-sequence
3 completely duplicate packets (6 bytes)
0 packet with some dup. data (0 byte duped)
5 out-of-order packets (0 byte)
0 packet (0 byte) of data after window
0 window probe
49 window update packets
0 packet received after close
0 discarded for bad checksum
0 discarded for bad header offset field
0 discarded because packet too short
4 connection requests
32 connection accepts
36 connections established (including accepts)
37 connections closed (including 0 drop)
0 embryonic connection dropped
10367 segments updated rtt (of 10393 attempts)
0 retransmit timeout
    0 connection dropped by rexmit timeout
0 persist timeout
10 keepalive timeouts
    10 keepalive probes sent
    0 connection dropped by keepalive
0 pcb cache lookup failed
0 mama cache lookup failed
0 mama flings
0 mama alloc drops

```

zSH>

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip udpstat

Displays the UDP statistics.

Syntax ip udpstat

Example The following example displays the current UPD statistics:

```

zSH> ip udpstat
UDP:

```

```

20323 total packets
12221 input packets
8102 output packets
0 incomplete header
0 bad data length field
0 bad checksum
4116 broadcasts received with no ports
0 full socket
0 allocated but not bound drops
8100 pcb cache lookups failed
0 pcb hash lookup failed
0 mama cache lookup failed
0 packets flung to other card

```

zSH>

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip arpdelete

Deletes an entry from the ARP table.

Syntax `ip arpdelete ipaddress`

Options `ipaddress`
Specifies the IP address of the ARP table entry to be deleted.

Example The following example deletes ARP table entry for IP address :

```

zSH> ip arpdelete
QQQ

```

zSH>

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip arpflush

Flushes the ARP table of all entries.

Syntax `ip arpflush`

Example The following example flushes the ARP table of all entries:

```

zSH> ip arpflush
QQQ

```

zSH>

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

ip arpshow

Displays the ARP table.

Syntax `ip arpshow`

Example The following example displays the ARP table:

```
zSH> ip arpshow
LINK LEVEL ARP TABLE
destination      gateway          flags  Refcnt  Use          Interface
-----
172.16.80.201    08:00:20:b1:9a:ab  405    0       8102         1-2-1-00
172.16.80.252    08:00:20:b8:f8:20  405    0       2089         1-2-1-00
172.16.80.254    00:02:16:75:3b:e1  405    1       0            1-2-1-00
-----
              7 routes, 3 arp routes
-----
SRC ROUTE: 0 routes, 0 arp routes
zSH>
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

L

lineGroup

Displays the line group number of the interface.

Syntax `linegroup index`

Options *index*

The shelf-slot-port-subport/type or user-defined string of the interface.

Example 1 zSH> `linegroup 1-1-1-0/ds3`
lineGroupId: 5

Example 2 zSH> `linegroup uplink2/other`
lineGroupId: 7

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

line-red

Sets the redundancy behavior of Ethernet lines so Ethernet uplink cards, such as GigE card, will switchover from an active to a standby card when the active link goes down. The standby card must be in a running state for the switchover to occur.

Syntax `line-red set | clear | show ifname/type [timeout seconds] [revertive | nonrevertive] [timeout seconds]`

Options **set**

Sets the line redundancy behavior on the specified interface to the specified settings.

clear

Removes any line redundancy settings on the specified interface.

show

Displays the current line redundancy settings.

ifname/type

Specifies the physical interface name and type. For example, ethernet1/ip specifies the uplink Ethernet interface on the malcGigE card.

timeout seconds

Specifies the amount of time to wait after a failure occurs before performing the switchover. If no timeout value is specified, a value of 0 is used.

revertive

After a redundancy switchover occurs and the failure is resolved, this setting forces the currently active card to wait the specified timeout period and then reboot to return traffic back to the other card.

nonrevertive

After a redundancy switchover occurs and the failure is resolved, this setting allows the currently active card to remain active, until another redundancy switchover occurs.

timeout seconds

Specifies the amount of time to wait after a failure is resolved before the revertive switch is performed. If no timeout value is specified, a value of 0 is used.

Example 1 This example enables redundancy on the ethernet1 physical interface with options set to timeout of 30 seconds, revertive, and revertive timeout of 600 seconds.

```
zSH> line-red set ethernet1/ip timeout 30 revertive timeout 600
```

Example 2 This example shows the display of the current line redundancy settings for the physical interface ethernet1:

```
zSH> line-red show ethernet1/ip
redundancy status for ethernet1/ip:
    REBOOT timeout 30 REVERTIVE revert timeout 600
```

Example 3 This example enables redundancy on the ethernet1 physical interface with options set to nonrevertive, and revertive timeout of 200 seconds. Because no switchover timeout value is specified, a value of 0 is used.

```
zSH> line-red set ethernet1/ip nonrevertive timeout 200
```

Access Level user

Products MALC, Raptor

list

Displays system profiles or records.

Syntax `list [profile-type] [*]`

Options (no options)

Without options, displays available profiles.

profile-type

The type of profile to display. This option displays all the profiles of the specified type, along with their profile indexes.

*

A wildcard that can be added anywhere in the command line after the list command:

- If it is the only option, it lists all records in the system, along with their index values.
- When added after *profile-type*, it lists all the records of that type, along with their indexes.
- When added as part of the *profile-index*, it lists all the profiles matching the specified index elements.

Example 1 The following example displays the available profiles:

```
zSH> list
aal2-audio-profile: audioProfileIdentifier/apIndex
aal2-cid-profile: ifIndex/vpi/vci/cid
aal2-vcl-profile: ifIndex/vpi/vci
adsl-co-profile: shelf/slot/port
adsl-cpe-profile: shelf/slot/port
adsl-profile: shelf/slot/port
atm-cc: atmVcCrossConnectIndex
atm-if: ifIndex
atm-if-stats: ifIndex
atm-traf-descr: index
atm-traf-descr-idx-next: index
atm-traf-descr-stats: index
atm-vcl: ifIndex/vpi/vci
atm-vcl-param: index
atm-vcl-stats: ifIndex/vpi/vci
atm-vpi: ifIndex/vpi
atm-vpl: ifIndex/vpi
bulk-statistic: index
```

```
bulk-statistics-config: index
<SPACE> for next page, <CR> for next line, A for all, Q to
quit
```

Example 2 The following example displays the **atm-vcls** configured on the system:

```
zSH> list atm-vcl
atm-vcl 1-7-4-0-ds3/atm/0/101
atm-vcl 1-7-4-0-ds3/atm/0/102
atm-vcl 1-9-2-0-hdsl2/atm/0/35
atm-vcl 1-9-4-0-hdsl2/atm/0/35
atm-vcl 1-5-1-0-sonet/atm/0/301
atm-vcl 1-7-4-0-ds3/atm/0/301
atm-vcl 1-7-4-0-ds3/atm/0/103
atm-vcl 1-15-1-0-ds3/atm/0/103
atm-vcl 1-15-1-0-ds3/atm/0/104
atm-vcl 1-9-6-0-hdsl2/atm/0/36
atm-vcl 1-9-6-0-hdsl2/atm/0/35
atm-vcl 1-15-1-0-ds3/atm/1/104
atm-vcl 1-7-4-0-ds3/atm/0/104
atm-vcl 1-15-1-0-ds3/atm/1/105
atm-vcl 1-9-6-0-hdsl2/atm/0/37
atm-vcl 1-7-4-0-ds3/atm/1/201
atm-vcl 1-5-1-0-sonet/atm/1/201
atm-vcl 1-7-4-0-ds3/atm/1/202
atm-vcl 1-5-1-0-sonet/atm/1/202
<SPACE> for next page, <CR> for next line, A for all, Q to
quit
```

Example 3 The following example displays all the records configured on the system:

```
zSH> list *
aal2-audio-profile 7/1
aal2-audio-profile 7/2
aal2-audio-profile 7/3
aal2-audio-profile 8/1
aal2-audio-profile 8/2
aal2-audio-profile 9/1
aal2-audio-profile 10/1
aal2-audio-profile 10/2
aal2-audio-profile 11/1
aal2-audio-profile 11/2
aal2-audio-profile 12/1
aal2-audio-profile 12/2
aal2-audio-profile 12/3
atm-cc 14
atm-cc 5
atm-cc 6
atm-cc 7
atm-cc 8
atm-cc 1
<SPACE> for next page, <CR> for next line, A for all, Q to
quit
```

Example 4 The following example displays all the **if-translate** profiles associated with shelf 1, slot 1:

```
zSH> list if-translate 1/1/*
if-translate 1-1-1-0/ethernetcsmaad
if-translate 1-1-1-0/rs232
if-translate 1-1-1-0/ip
3 entries found.
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also [get](#), [show](#)

load

Loads new software onto the system.



Note: The **image** command should be used to download software image files, because it verifies the image header as part of the download process.

Syntax `load tftphost image-file destination`

Options *tftphost*

The name or IP address of the TFTP server.

image-file

The full path name of the software image file on the TFTP server.

destination

The full path name where the software image file should be downloaded to.

System software is loaded onto the system flash memory. On a BAN, the path to the software image file is either:

/card1/file or */card2/file*

depending on which PC card contains the software.

On a MALC or Raptor, it is not necessary to specify a card in the destination.

Access Level admin

Notes Set the TFTP server time-out value to at least 5 seconds, and 5 retries to help prevent TFTP time-out or retry errors.

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also [image](#)

log

Configures logging levels for messages on the system. The system sends log messages to a management session (either on the console or over a telnet session), a log file on the device, and, optionally, a syslog server.

The **log** command configures the type of information sent in these messages. By default, the system sends the same type of information to all log message destinations, and logging is disabled on both the serial craft port and over telnet sessions.

If the messages sent to the syslog server are configured the same as the log messages sent to the console or the persistent storage (the default) the **log** command also configures the **syslog** message contents. If the syslog messages have been modified (using the **log-module** profile or the **syslog** command), use the **syslog** command to modify syslog levels.

Syntax `log help`

help

Displays the help menu.

Syntax `log show`

show

Displays the currently configured logging levels for each software module.

Syntax `log level module level`

module

The system module to set the level for. Use the **log show** command to display all the system modules.

level

Sets the logging level for the specified module. Logging levels are:

- 1 emergency
- 2 alert
- 3 critical
- 4 error
- 5 warning
- 6 notice
- 7 information
- 8 debug

You can specify either the name of the level or the number.

Syntax `log option type [on | off]`

Specifies the information to include in logging messages.

type on

Specifies that the type of information be included in log messages. For example, ticks on displays current tick counts in place of date and time. To view the type of information you can include in a logging message, enter the **log option** command without any arguments.

type off

Specifies that the type of information not be included in log messages.

Syntax `log [enable | disable] module`

enable module

Enables logging for the specified module. Use the **log show** command to display all the system modules and whether they are enabled or not.

disable module

Disables logging for the specified module.

Syntax `log session [on | off]`

on

Enables logging for the current session only.

off

Disables logging for the current session.

Syntax `log serial [on | off]`

on

Enables logging on the serial craft port. This setting persists across reboots.

off

Disables logging on the serial craft port. This setting persists across reboots.

Syntax `log display`

Displays entries in the persistent log.

Syntax `log cache [max | grep pattern | size | clear | help]`



Note: The **cache** option is only supported on the BAN, MALC, and Raptor.

log cache

Displays the log cache.

log cache max length

Sets the maximum number of log messages to store. The maximum log cache size is 2147483647, depending in the amount of memory available.

log cache grep pattern

Searches through the log cache for the specified regular expression.

log cache clear

Clears the log cache.

log cache size

Sets the maximum amount of memory for the log cache. Without options, displays the current log size.

log cache help

Displays help on the **log cache** command.

Example 1 The following example displays the logging levels and enabled status for the system modules:

```
zSH> log show
MODULE                                LEVEL          STATUS
message                               error          enabled
taskclock                             error          enabled
card                                    error          enabled
bds_client                             error          enabled
alarm_mgr                              error          enabled
tnsxmgt                                error          enabled
leaseapi                               error          enabled
vcs-client                             error          enabled
dirserclient                           error          enabled
rebootserver                           error          enabled
pcmciadiag                             error          enabled
...
...
...
```

Example 2 The following example sets the logging level for the card module to information:

```
zSH> log level card info
Module: card at level: information
```

Example 3 zSH> log option ticks on
time: date: level: address: log: port: category: system:
ticks: (0xf07)

Example 4 The following example shows how to configure what information to include in log messages.

```
zSH> log option all on
time:date:level:address:log:taskname:taskid:file:function
:line:(0xff)
```

Example 5 To return the log messages to their default format, enter the following command:

```
zSH> log option default on
time: date: level: address: log: taskname: (0xf)
```

Example 6 The following example configures the log cache size:

```
zSH> log cache max 200
Maximum number of log messages that can be saved: 200
```

Example 7 following example searches through the log cache for the word “IMA”:

```
zSH> log cache grep IMA
Searching for: "IMA"
[1]: JAN 06 20:36:10: alert : 1/2/50 : alarm_mgr:
tLineAlarm: 01:02:02 Critical IMA Down Line
[2]: JAN 06 20:36:46: alert : 1/2/50 : alarm_mgr:
tLineAlarm: 01:02:02 Critical IMA Up Line
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also syslog

log filter

Restrict the display of log messages to only the log messages for a specified entity.

Syntax `log filter show | set (ifindex|port slotport|vcl ifindex vpi vci|subscriber endpoint)| delete`

Example 1 zSH> log filter set ifindex 12
New filter saved.

Example 2 zSH> log filter set port 5 24
New filter saved.

Example 3 zSH> log filter set vcl 100 0 1
New filter saved.

Example 4 zSH> log filter set subscriber 22
New filter saved.

Example 5 zSH> log filter show

Index	Type	Filter Parameters
1	Port	slot=1, port=1
2	Port	slot=1, port=4
3	IfIndex	IfIndex=12
4	Port	slot=5, port=24
5	ATM VCL	IfIndex=100, vpi=0, vci=1
6	IfIndex	IfIndex=100
7	IfIndex	IfIndex=104
8	IfIndex	IfIndex=109
9	IfIndex	IfIndex=103
10	IfIndex	IfIndex=107

Example 6 zSH> log filter delete 10

Log filter 10 deleted

logout

Terminates the current session. If a previous user is still connected as an inactive user of the current session, the previous user becomes the active user of the session. If there is only one user connected in current session, the logout command terminates the connection. If the session is over the local serial port, the current user is logged out and the system prompts appears.

Syntax `logout`

Example The following example shows logging out from a local serial port session:

```
zSH> logout
Connecting.....
Tips:(`lst' 2 list)(`find' 2 search)(`s' 2 skip)
User Name:
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

lst

Lists available commands.

Syntax `lst [-m]`

Options

With no option, displays all the available commands for the current user. If a search has been performed using the **find** command, and the **-m** option has not been specified since the search was performed, the **lst** command displays only the results of the most recent search.

-m

Lists all commands, not just the results of the previous search.

Example The following example shows the **lst** command with no search results:

```
zSH> lst
?                adduser
ata              bootstate
cd               changepass
commit          copy
create          del
delete          deleteuser
dir             dump
eeset           eeshow
featurebitdisplay featurebitset
fhramping       file
filter          find
find-matching-subvoice get
help           history
```

```

ifxlate
initiateconfigsync
list
log
lst
msg
ping
pwd
resetpass
image
interface
load
logout
mkdir
new
pollzhonecpe
resetcliprov
restore
Type A<CR> to print all, <CR> to continue, Q<CR> to stop:

```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also find

M

mcast

Displays multicast control lists.

Syntax `mcast show mcl [entry | precedence]`

Options *entry*

Entry number to be displayed.

all

Sends the message to all users.

Example zSH> `mcast show mcl 1`
MCAST CONTROL LIST : 1
224.10.10.10 224.10.10.11 224.10.10.12
224.10.10.13

zSH> `mcast show mcl 2/1`
MCAST CONTROL LIST : 2
192.24.84.144

```

zSH> mcast show mcl
MCAST ID      IP Address
^^^^^^^^^^^^
1             192.24.2.10
2             192.24.84.144

```

Access Level user

Notes Entering this command without any options displays all configured multicast control lists.

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

mkdir

Creates a directory on the system card flash card file system.

Syntax `mkdir directoryname`

Access Level admin

Products BAN, MALC

See Also `rmdir`

msg

Enables users to send text messages to a specific user, or to all users currently logged into the system.

Syntax `msg [username | all] message`

Options *username*

The recipient of the message.

all

Sends the message to all users.

message

The text of the message to send. The message must be in quotes.

Example The following command:

```
zSH> msg all "please log off."
```

Results in the following message being sent to every user logged into the system:

```
Msg: root: please log off.
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

mtac-linetest (MTAC-Ring card)

Enables connecting a third-party device to the MALC MTAC card to set any line card port to the MTAC card test port. The default baud rate is 9600 bps but can be changed in the **rs232-profile**.



Note: This command is only available through the MTAC card control port.

Syntax `mtac-linetest shelf/slot/port mode [force]`

Options *shelf/slot/port*

The port address in shelf/slot/port format. Valid shelf value is 1. Maximum slot value is 21. Maximum port value is 48.

mode lookout [*InterfaceType*] release | bridge | lookin

Sets the relay mode. Only lookout and release modes are currently supported. The optional **InterfaceType** specifies the type of interface for a lookout test. Lookout testing is supported for ADSL, DS1, SHDSL, ISDNU, VDSL, and voice FXS interfaces. With no **InterfaceType** specified, the relay is set for a POTS interface.

The release mode sets the relay back to idle mode.



Note: There is a 5 minute maximum time limit for activating a relay. If this time limit is reached, the relay automatically goes back to idle mode.

force

Forces an override and sets the relay on the port even if the line is in use. This option applies only to POTS cards.

Example The following command:

```
zSH> mtac-linetest 1/8/48 lookout
```

```
Successful - In TestMode
```

```
zSH> mtac-linetest 1/8/48 release
```

```
Successful - Return to operational state
```

Access Level user

Products MALC

mtac-linetest (MTAC-ENH card)

Enables the MALC MTAC-ENH card to set any line card port to the MTAC card test port without connecting to a third-party device.

Syntax `mtac-linetest shelf/slot/port mode testID | linetype | force`

Options *shelf/slot/port*

The port address in shelf/slot/port format. Valid shelf value is 1. Maximum slot value is 21. Maximum port value is 48.

mode [interfaceType] lookout | release | bridge | lookin

Sets the relay mode. Only lookout and release modes are currently supported. The optional **InterfaceType** specifies the type of interface for a lookout test. Lookout testing is supported for ADSL, DS1, SHDSL, ISDNU, VDSL, and voice FXS interfaces. With no **InterfaceType** specified, the relay is set for a POTS interface.

The release mode sets the relay back to idle mode.



Note: There is a 5 minute maximum time limit for activating a relay. If this time limit is reached, the relay automatically goes back to idle mode.

testID

Specifies the type of test to be performed.

linetype

Optionally, specifies the POTS line type. Valid line types are adsl, ds1, shdsl, isdn, vdsl, and voicefxs. Default is voicefxs.

force

Forces an override and sets the relay on the port even if the line is in use. This option applies only to POTS cards.

Example

```
zSH> mtac-linetest 1/4/1 lookout dcloopresistance force
Successful - In TestMode
Time Started: 000 days 02:50:56:03
Time Ended: 000 days 02:50:57:71

DC loop resistance Test Results
  RLOOP=3885.349121 Ohms
  ILG1=0.000034 A
  ILG2=0.000077 A
  Voltage Saturation=Yes
  CMC Degradation=No
-----
Successful - Returned to operational state
zSH>
```

Access Level user

Products MALC

N

new

Creates new records of the specified profile type.

Syntax *new profile-type index*

Options *profile-type*

The type of profile to create.

index

An index for the record. Some records, such as line profiles, use an index of the form **shelf-slot-port-subport-interface/type**. Other records, such as subscriber records, use an index of the form **n**, where **n** is an integer.

Example The following example creates a new **ip-interface-record**. Pressing Enter accepts the default values:

```
zSH> new ip-interface-record 1-1-0-0/ip
Please provide the following: [q]uit.
vpi: -----> {0}:
```

```

vci: -----> {0}:
rdindex: -----> {1}:
dhcp: -----> {none}: ** read-only **
addr: -----> {0.0.0.0}: 192.168.8.21
netmask: -----> {0.0.0.0}: 255.255.255.0
bcastaddr: -----> {0.0.0.0}: 192.168.8.0
destaddr: -----> {0.0.0.0}:
farendaddr: -----> {0.0.0.0}:
mru: -----> {1500}:
reasmmaxsize: -----> {0}:
ingressfiltername: -> {}:
egressfiltername: --> {}:
pointtopoint: -----> {no}:
mcastenabled: -----> {yes}:
ipfwdenabled: -----> {yes}:
mcastfwdenabled: ---> {yes}:
natenabled: -----> {no}:
bcastenabled: -----> {yes}:
ingressfilterid: ---> {0}:
egressfilterid: ---> {0}:
ipaddrdynamic: -----> {static}:
dhcpserverenable: --> {false}:
subnetgroup: -----> {0}:
unnumberedindex: ---> {0}:
mcastcontrollist: --> {}:
vlanid: -----> {0}:
maxVideoStreams: ---> {0}:
.....
Save new record? [s]ave, [c]hange or [q]uit: s
Record created.

```

After entering the values, the system displays the values you have entered and prompts you to save the record. If you want to save the changes, press **s**. If you want to make changes, press **c** to re-enter values. Press **q** to quit without saving changes.

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also delete, update

P

ping

The ping command uses an ICMP ECHO_REQUEST datagram to elicit an ICMP ECHO_RESPONSE from the specified host or network gateway. The ping command can be interrupted by pressing any key during its operation.

Syntax `ping [-c rxcount] [-i txwait] [-s packet-size] [-w timeout] [-t] [-h] host [-l] ip address`

Options `-c rxcount`

Stop after receiving *rxcount* ECHO_RESPONSE packets. If this option is not specified, ping will operate until interrupted by the user.

`-i txwait`

Wait *txwait* seconds between sending ECHO_REQUEST packets. The value of *txwait* must be a positive integer. If not specified, a value of 1 is used.

`-s packet-size`

Specifies the packet size of the ICMP ECHO_REQUEST. The default is 56 (which results in a 64 byte ICMP datagram when combined with an 8 byte ICMP header).

`-t timeout`

Specifies the timeout for the ping. The default is 1 second.

`-t`

Continue the ping until it is interrupted by the user.

`-h`

Display the hostname of the source for any returned ICMP packet instead of the network address.

`host`

Host name or IP address of destination host.

`-l`

Use source based routing to determine the interface to send ping out on.

Example 1 The following example shows the **ping** command able to successfully reach the destination:

```
zSH> ping ietf.org
PING ietf.org (132.151.1.19): 64 data bytes
!!!!
----ietf.org PING Statistics----
5 packets transmitted, 5 packets received
round-trip (ms)  min/avg/max = 80/99/160
```

Example 2 The following example shows the **ping** command unable to reach the destination:

```
zSH> ping 192.168.211.2
PING 192.168.211.2: 64 data bytes
UUUUU
----192.168.211.2 PING Statistics----
5 packets transmitted, 0 packets received, 100% packet
loss
```

Example 3 `zSH> ping -l 10.10.203.2 10.10.203.1`

```
PING 10.10.203.1: 64 data bytes
!!!!
----10.10.203.1 PING Statistics----
```

```
5 packets transmitted, 5 packets received
round-trip (ms)  min/avg/max = 10/10/10
zSH>
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also [Telnet](#), [traceroute](#)

pollzhonecpe

The **pollzhonecpe** command polls attached Zhone customer premises equipment (CPE) devices to determine their status.

Syntax `pollzhonecpe`

Example

```
zSH> pollzhonecpe
Polling all connected Zhone CPE devices...
Zhone CPE at vrd:0 ip:192.16.199.205 status:UP
Total Zhone CPE devices: 1 (1 up) (0 down)
```

Access Level admin

Notes If the device detects that a CPE is down, it sends a trap to ZMS (if configured to do so). If a ZMS is not connected or its connection is inactive, the device does not send a trap.

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also [showzhonecpe](#)

powermon

Displays the power monitoring status for the ZRG. Command output strings are:

- No battery
- No UPS
- Low Charge
- Bad Battery
- Normal Power

Output strings can appear individually or in combination.

Syntax `powermon`

Example

```
zSH> powermon
Power Status: (Normal power)

zSH> powermon
```

Power Status: (No Battery)

zSH> **powermon**

Power Status: (On battery)

zSH> **powermon**

Power Status: (On battery) (Low Charge)

Access Level admin

Products ZRG

See Also **alarm show, pwd**

pwd

Displays the current directory on the system flash card file system.

Syntax **pwd**

Example zSH> **pwd**

zSH> /card1

Access Level admin

Products BAN, MALC, Raptor

See Also **cd, dir**

R

resetcliprov

Enables provisioning from a CLI session. Provisioning using the CLI is usually enabled, except when the device is being managed by ZMS.

Syntax **resetcliprov [index | all]**

Options *index*

Re-enables CLI provisioning for the specified CLI session. CLI session indexes are displayed in the output of the **who** command.

all

Re-enables CLI provisioning for all active CLI sessions.

Access Level admin

Notes CLI provisioning is automatically disabled after logging out of the session.

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also **setcliprov**

resethold

The **resethold** command puts a card into a persistent non-operational state. The physical card, card profiles and provisioning are retained.

Syntax `resethold shelf slot-list, [slot-range]`

Options **shelf**

Specifies the shelf containing the card(s).

slot-list

List the slots of the cards to be reset to hold status.

slot-range

Optionally, specifies a range of slots of the cards to be reset to hold status.

Access Level useradmin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `resetrelease`

resetpass

Resets a user password.

Syntax `resetpass username`

Options **username**

User whose password is being reset.

Example In the following example, the user jjsmith is assigned a new password (newpassword):

```
zSH> resetpass jjsmith
Password: newpassword the password is not displayed on the screen
```

Access Level useradmin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `changepass`

resetrelease

Release a card from hold status, after the **resethold** command was used.

Syntax `resetrelease shelf slot`

Options **shelf**

Specifies the shelf containing the card to be released.

slot

Specifies the slots of the card to be released.

Access Level useradmin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `resethold`

restore

Restores a previously saved Zhone system configuration.

Syntax `restore [console] | [network host filename] | [file filename] | [validate filename]`

Options `console`

Restores the configuration displayed on the local console terminal. Note that when restoring a file from the console, specify a line an character delay to allow the system to interpret the command. A delay of 40 milliseconds is usually sufficient.

network *host filename*

Restores the configuration from the specified host and filename using TFTP. This option is not supported on the BAN or the MALC.

file *filename*

Restores the configuration from specified file on the flash card. You must specify the full path to the file. This option is only available on the BAN and the MALC.

validate *filename*

Parses the specified restore file to check for syntax errors. When an error is encountered, it prints out error information including line number of the error. This command does not write any information to the database.

Example `restore validate /card1/onreboot/restore`

Access Level useradmin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `dump`

rip

Administers how routing information protocol (RIP) operates on Zhone devices.

Syntax The following command enables or disables RIP for the entire system.

`rip [domain domain-spec] enable|disable`

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

enable

Enables RIP.

disable

Disables RIP (the default).

Syntax The following command displays the administrative and operational status of RIP.

```
rip domain domain-spec show
```

domain *domain-spec*

The domain spec identifies the IP address range of the subnet. One (1) is the only supported value.

show

Displays RIP information for the system.

Syntax The following command specifies the interval between RIP advertisements.

```
rip domain domain-spec timer seconds
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

timer *seconds*

The RIP advertisement in seconds. The default is 30 seconds.

Syntax The following command specifies the type of advertisements to transmit on an interface.

```
rip [domain domain-spec] interface interface-address talk
v1 | v1compat | v2 | disabled
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

interface *interface-address*

Interface address to transmit RIP advertisements on.

talk v1 | v2 | v1v2 | disabled

The type of RIP packets to transmit:

- v1: RIP version 1 advertisements
- v1v2: RIP version 2 advertisements using RFC 1058 subsumption rules
- v2: RIP version 2 advertisements
- disabled: RIP advertisements disabled (default)

Syntax The following command specifies the type of interface to receive on an interface.

```
rip [domain domain-spec] interface interface-address
listen v1 | v1v2 | v2 | disable
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

interface *interface-address*

Interface address to receive RIP advertisements on.

listen v1 | v2 | v1v2 | disabled

The type of RIP packets to receive:

- v1: RIP version 1 advertisements

- v1v2: RIP version 1 and version 2 advertisements
- v2: RIP version 2 advertisements
- disabled: RIP advertisements disabled (the default)

Syntax The following command specifies whether poison-reverse updates are transmitted on an interface.

```
rip [domain domain-spec] interface interface-address
poison on | off
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

interface *interface-address*

Interface address to transmit poison-reverse RIP advertisements on.

poison on | off

On enables poison reverse updates.

Off disables poison reverse updates. In this case, the system uses split-horizon updates. The default is off.

Syntax The following command specifies the default metric value to be advertised for an interface.

```
rip [domain domain-spec] interface interface-address
metric metric-number
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

interface *interface-address*

Interface address to assign a metric to.

metric *metric-number*

Metric number for an interface.

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Z-Edge 64

See Also route

rmdir

Removes a directory.

Syntax rmdir *directory*

Options *directory*

Name of directory to remove.

Access Level admin

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723

See Also cd, dir, mkdir, pwd

romversion

Displays the read-only memory (ROM) version of a slot card.

Syntax `romversion 1-17`

Example 1 The following example displays the ROM version of an Ethernet card in slot 17:

Example 2

```
zSH> romversion 4
MALC CAN 1.10.0.6
Jun 21 2004, 13:11:49
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `swversion`

route

Administers the routing information base (RIB). The **route add** and **route delete** commands take a keyword called **source** which indicates that a source route is used and must be added or removed from the source routing table. The user must also specify the IP interfaces of the next hop. The **route show** command now accepts an optional keyword of either **source** or **destination** which specifies the type of routing table to be displayed. If the keyword is not used, both source and destination routing tables are displayed.

Syntax The following command displays the forwarding information base.

```
route [domain domain-spec] [list] show
[source|destination]
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

list

Displays all provisioned static routes.

show

Displays the routes in the route domain for source and destination routing.

Syntax The following command adds a high-preference static route for the destination IP address with the specified network mask (dotted decimal format) to the specified next hop with the specified routing cost. The word 'default' may be substituted for a 0.0.0.0 destination and mask. If a 'fallback' route is also specified, a second next hop, ping interval (in milliseconds), and ping maximum failure count must be specified.

Fallback routes have the same destination and mask as the original route, but use a different next hop. After a route and fallback route are configured, the current next hop is pinged once every ping interval. If the number of ping

maximum failures is exceeded, the fallback next hop becomes the current next hop. The next hop validation continues once every ping interval.

```
route [ domain domain-spec ] add [source]
destination-address netmask nexthop-address
nexthop-interface metric [fallback nexthop2 ping-interval
ping-fail-max]
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

source

Indicates that a source address based route is being added. The *interface* is the name of the outbound (egress) interface for this route (minus the /ip suffix).

destination-address netmask

Adds a static route with the specified destination and network mask.

nexthop-address

IP address of the next hop.

nexthop-interface

Interface for the next hop. This is valid only when the next-hop address is 0.0.0.0. Otherwise, this should be 0 (zero). This option is currently unsupported.

metric

A numeric value specifying the metric for the route. Lower metrics indicate more preferred routes.

nexthop2

IP address of the fallback or redundant next hop.

ping-interval

The ping interval with a minimum of 500 milliseconds to a maximum of 60000 milliseconds (1 minute).

ping-fail-max

The minimum retry count is 2 and maximum retry count is 10.

maxretry

The max retry (fail) count for the pings. When this limit is reached, the fallback next hop is used.

Syntax The following command deletes a static route from the system routing table. The word 'default' may be substituted for a 0.0.0.0 destination and mask. The fallback and nexthop2 options must be specified to delete routes configured with fallback routes.

```
route [ domain domain-spec ] delete [source]
destination-address netmask nexthop-address
nexthop-interface [fallback nexthop2 ping-interval
ping-fail-max]
```

domain *domain-spec*

Specifies the routing domain. Only domain 1 is supported.

source

Specifies that a source address based route is being removed. The interface is the name of the outbound (egress) interface for this route (without the /ip suffix).

destination-address netmask

Deletes the destination address and netmask from the routing table.

nexthop-address

IP address of the next hop address.

nexthop-interface

Interface for the next hop. This is valid only when the next-hop address is 0.0.0.0. Otherwise, this should be 0 (zero). This option is currently unsupported.

nextHop2

IP address of the fallback or redundant next hop.

ping-interval

The ping interval with a minimum of 500 milliseconds to a maximum of 60000 milliseconds (1 minute).

ping-fail-max

The minimum retry count is 2 and maximum retry count is 10.

maxretry

The max retry (fail) count for the pings. When this limit is reached, the fallback nextHop is used.

Example

```
zSH> route show
```

```
Source Routing Table
```

Dest	Nexthop	Cost	Owner	Interface
10.10.201.2/32	10.10.201.1	1	STATIC	1/1/1/0/ip
10.10.204.2/32	10.10.204.1	1	STATIC	1/1/1/0/ip

```
Destination Routing Table
```

Dest	Nexthop	Cost	Owner
0.0.0.0/0	172.24.94.254	1	STATICLOW
10.10.201.2/32	1/1/1/0/ip	1	LOCAL
10.10.204.0/30	1/1/1/0/ip	1	LOCAL
172.24.94.0/24	1/1/1/0/ip	1	LOCAL
172.16.80.0/24	172.24.94.254	1	STATIC

```
zSH> route show source
```

```
Source Routing Table
```

Dest	Nexthop	Cost	Owner	Interface
10.10.201.2/32	10.10.201.1	1	STATIC	1/1/1/0/ip
10.10.204.2/32	10.10.204.1	1	STATIC	1/1/1/0/ip

```
zSH> route show destination
```

```
Destination Routing Table
```

```

Dest                Nexthop            Cost    Owner
-----
0.0.0.0/0           172.24.94.254    1       STATICLOW
10.10.201.2/32     1/1/1/0/ip       1       LOCAL
10.10.204.0/30     1/1/1/0/ip       1       LOCAL
172.24.94.0/24     1/1/1/0/ip       1       LOCAL
172.16.80.0/24     172.24.94.254    1       STATIC
zSH>

```

```
zSH> route add source 198.168.1.1 255.255.255.255 198.168.1.101 1 uplink1-0-36
```

```
zSH> route add default 192.168.34.254 1 fallback 192.168.34.201 2000 3
```

```
zSH> route add 10.10.1.0 255.255.255.0 192.168.34.254 1 fallback
192.168.34.201 3000 5
```

```
zSH> show route ...
Source Routing Table
```

```

Dest                Nexthop            Cost    Owner    Interface
-----

```

Destination Routing Table

```

Dest                Nexthop            Cost    Owner    Fallback
-----

```

```

0.0.0.0/0           192.168.34.254    1       STATICLOW
10.10.1.0/24       192.168.34.254    1       STATIC    192.168.34.201
192.168.34.0/24    1/1/1/0/ip       1       LOCAL

```

```
zSH> route delete source 198.168.1.1 255.255.255.255 198.168.1.101
uplink1-0-36
zSH>
```

```
zSH> route delete 10.10.1.0 255.255.255.0 192.168.34.254 fallback \
192.168.34.201
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also rip

rpr

Displays information about the resilient packet ring (RPR) configuration. This command is available only when an GigE uplink card with RPR support is installed.

Syntax `rpr show topo | stats | config | status`

Options topo

Displays the RPR topology.

stats [clear | noclr]

Displays RPR statistics. The optional argument **clear** will clear the statistics. The **noclr** argument (the default) will not clear the statistics.

config

Displays the current RPR configuration.

status

Displays the status of the nodes in the RPR ring.

Example 1 This example shows a closed ring (no broken spans).

```
zSH> rpr show topo
total number of ring nodes= 4 (ringlet 0= 3, ringlet 1= 3)
ring protection= STEERING, ring topology= CLOSED ring
V=valid; R=reachable; E=ringlet edge states; PSW/PSE=protect state; prot/pref=raw
values
hop ----macAddr_0---- VR EE PSW PSE prot pref ----macAddr_1-- VR EE PSW PSE prot/pref
0 00:01:47:5c:34:59 tt ff IDL IDL 0x00 0x0d
1 00:01:47:59:1f:ea tt ff IDL IDL 0x00 0x04 00:01:47:59:1f:f3 tt ff IDL IDL 0x00 0x0c
2 00:01:47:5d:b0:f1 tt ff IDL IDL 0x00 0x0a 00:01:47:5d:b0:f1 tt ff IDL IDL 0x00 0x0a
3 00:01:47:59:1f:f3 tt ff IDL IDL 0x00 0x0c 00:01:47:59:1f:ea tt ff IDL IDL 0x00 0x04
4 00:01:47:5c:34:59 tt ff IDL IDL 0x00 0x0d 00:01:47:5c:34:59 tt ff IDL IDL 0x00 0x0d
```

The output of the **rpr show topo** command displays the information for each ringlet (*MacAddress_0* for ringlet 0; and *MacAddress_1* for ringlet 1). The fields are described in the table below.

Field	Description
total number of ring nodes	The total number of nodes on the ring. On an unbroken ring, the number of nodes on each ringlet will be equal.
ring protection	Type of ring protection. This is configured in the wrap-config parameter in the rpr-config profile. Values: steering wrapped
ring topology	Whether the ring is closed (no broken spans and traffic can be sent on either ring) or open (at least one broken span is detected).
hops	Number of hops upstream this node is. The current node is always displayed with a hop count of 0.
<i>MacAddress_x</i>	The MAC address of the node on ringlet <i>X</i> .
V	Valid. t indicates the entry is valid, f indicates not valid.
R	Reachable. t indicates the entry is valid, f indicates not valid. f indicates the span is broken between node and its immediate downstream neighbor.

Field	Description
E	Ringlet edge state on the west and east span. An edge indicates the span is broken. t indicates an edge exists, f indicates an edge does not exist.
PSW/PSE	The protection state on the west (PSW) and east (PSE) span. Values: IDL : Signal OK. Link is up with neighbor. WTR : Wait-to-restore. The span has recovered from a fault but it's been configured to wait a period of time before declaring it's OK to other nodes on the ring. The wait-to-restore time is configured in the protection-wtr parameter in the rpr-config profile. MS : User has requested the span to deactivate. Not supported. SD : Signal degraded. Not supported. SF : Signal failure. Link is down with neighbor. FS : User has forced span to deactivate. Not supported.
prot/pref	Raw values used by the system to display edge and protection information.

Example 2 This example shows that east span is broken on the current node:

```
zSH> rpr show topo
total number of ring nodes= 3 (ringlet 0= 2, ringlet 1= 0)
ring protection= STEERING, ring topology= OPEN ring
V=valid; R=reachable; E=ringlet edge states; PSW/PSE=protect state; prot/pref=raw
values
hop ----macAddr_0---- VR EE PSW PSE prot pref ----macAddr_1--- VR EE PSW PSE prot/pref
 0 00:01:47:5a:aa:1a tt ft IDL SF 0x44 0x09
 1 00:01:47:5a:aa:22 tt ff IDL IDL 0x00 0x05
 2 00:01:47:5a:aa:2a tt tf SF IDL 0xa0 0x06
```

Notice the PSE (protection span east) for the current node (hop 0) is SF (signal failure) and its neighbor across the broken span (hop 2) agrees since its PSW (protection state west) is also SF.

Example 3 This example shows that span is broken between the other 2 nodes in the ring:

```
zSH> rpr show topo
total number of ring nodes= 3 (ringlet 0= 1, ringlet 1= 1)
ring protection= STEERING, ring topology= OPEN ring
V=valid;R=reachable;E=ringlet edge states;PSW/PSE=protect state; prot/pref=raw values
hop ----macAddr_0-- VR EE PSW PSE prot pref ----macAddr_1-----VR EE PSW PSE prot/ pref
 0 00:01:47:5a:aa:1a tt ff IDL IDL 0x00 0x0d
 1 00:01:47:5a:aa:22 tt tf SF IDL 0xa0 0x06 00:01:47:5a:aa:2a tt ft IDL SF 0x44 0x09
```

Notice the PSW (protection span west) and the PSE (protection span east) for the current node is IDL (link up), but that the PSW for the upstream node

(hop 1) is SF (signal failure) and its neighbor agrees since its PSE (protection state east) is also SF.

Access Level user

Products MALC, Raptor

S

sar8260

The **sar8260** command shows operational and status information about the Sechtor 100A ATM 8260 driver. This command can be used only after the ATM driver is added to the system log list.

For more information about system logging, see the **log show**, **log level** and **showtask** command descriptions.



Note: The Sechtor 100A can only perform **sar8260 ping** when connected to IADs that support OAM F5 loopbacks.

Syntax **sar8260**

startLog

This option entered after the **sar8260** command will enable log messages. Once enabled, the log level can be set with the **log level** command.

stopLog

This option used with the **sar8260** command will disable log messages.

Syntax **log level sar8260 log level**

sar8260

Use **sar8260** as a modifier with the **log level** command to set the level of logging for the Sechtor 100A ATM driver. Log level NOTICE will log AAL2 control packets. Log level INFO will log AAL2 voice packet headers. Log level DEBUG will log AAL2 voice packet payloads. See the example, below.

Syntax **sar8260**

stats

This level of ATM driver logging shows high-level information about the Sechtor 100A ATM driver.

stats vpi vci

Using the VPI and VCI address with the **sar8260** command displays statistics only for the Virtual Circuit (VC) with this address.

stats vpi vci cid

Using the `sar8260` command with the VPI VCI and CID numbers gives information about the ATM driver at the CID level.

Syntax `sar8260 ping vpi vci`

vpi
VPI to ping.

vci
VCI to ping.

Example 1 This is an example of a `sar8260 ping`:

```
zSH> sar8260 ping 0 501
Pinging vpi 0, vci 501 ..
zSH> Ping response received from vpi 0, vci 501
```

Example 2 This example shows the `sar8260` command with the `startLog` option.

```
zSH> sar8260 startLog
```

Example 3 This example shows the log level options.

```
zSH> log level
Usage: log level < module > < emergency | 1 >
                        < alert       | 2 >
                        < critical    | 3 >
                        < error       | 4 >
                        < warning     | 5 >
                        < notice      | 6 >
                        < information | 7 >
                        < debug       | 8 >
```

Example 4 The following example sets the **log level** for the 8260 ATM driver at the **notice** level

```
zSH> log level sar8260 notice
Module: sar8260 at level: notice
```

Example 5 This example shows the result of using the **stats** modifier with the `sar8260` command. The system displays the highest level of information available about the 8260 ATM driver.

```
zSH> sar8260 stats
MPC8260 mask 17, AAL2 microcode rev 26

ATM Driver Statistics

Open VCs..... 59
CPS Tx..... 0           CPS Rx..... 0
SAR Tx..... 0           SAR Rx..... 11313
OAM Tx..... 0           OAM Rx..... 0
Faults..... 0
Inv. Lookup... 0        Inv. Vc..... 0
rxInt..... 11626       txInt..... 46164
swErrCount.... 0       swWarnCount... 0
```

```
totSeqErr.... 0
```

ATM AAL2 Statistics

```
Open VCs..... 59           Open CIDs..... 314
Active Calls..... 0         Cumulative Calls... 0
Voice Tx..... 0           Voice Rx..... 0
CAS Tx..... 33033         CAS Rx..... 0
Alarm Tx..... 0           Alarm Rx..... 0
I3661 Tx..... 13136       I3661 Rx..... 11130
3661 Chains..... 7825
Unsupported Rx..... 0       Errors..... 13
RP state errors.... 0      RP CFs..... 0
Critical Timeouts.. 0      TxVoiceDrop.....0
```

Example 6 This example shows the statistics displayed when a VPI of 0 (zero) and a VCI of 501 are used as arguments.

```
zSH> sar8260 stats 0 501
ATM Driver VC Statistics
VPI..... 0           VCI..... 501
CC..... 258          PCR..... 182
DelyPcr. 182         pcrTick... 0
Tx..... 9112780       Tx Err.... 0
CPS Rx.. 9103499     SAR Rx.... 1769           Rx Errs.. 0
CPS Errs 1
RxPAR... 0           RxSEQ..... 1           RxOSF.... 0
RxHEC... 0           RxLEN..... 0           RxBusy... 0
RxOVL... 0           RxSPL..... 0
SAR Errs 10
RxRTE... 0           RxSDU..... 0           RxOS..... 0
RxLast.. 1769        RxNotL.... 0
noBuf... 0           badLength. 0
OAM State: ENABLED
Tx OAM.. 10775       Rx OAM.... 299           Faults... 4
ATM AAL2 VC Statistics
Open CIDs..... 13       Pending Events..... 0
Active Calls..... 0     Cumulative Calls... 5
Voice Tx..... 9111039   Voice Rx..... 9103499
Voice Tx Errors.... 0   Voice Rx Errors.... 0
CAS Tx Requests.... 0   CAS Rx Delivered... 0
CAS Tx Redundant... 0   CAS Rx Redundant... 0
CAS Tx Refresh..... 0   CAS Rx Refresh..... 0
CAS Tx Errors..... 0   CAS Rx Errors..... 0
Alarm Tx..... 0        Alarm Rx..... 0
Alarm Tx Errors.... 0   Alarm Rx Errors.... 0
I3661 Tx..... 1741     I3661 Rx..... 1769
I3661 Tx Errors.... 0   I3661 Rx Errors.... (n/a)
Type 3 CRC Errors.. 0   OOS Conditions..... 0
IllegalUUI..... 0      IllegalCID..... 0
```

The **OAM State** field in the response details the status of VCL fault detection. Possible values for the **OAM State** field include:

- **ENABLED:** VCL fault detection is enabled. CPE responded to the loopback. There is no fault on the VCL.
- **ENABLED DIAG LOOP FAULT:** VCL fault detection is enabled. No response to the loopback. There is a fault on the VCL.
- **ENABLED AIS FAULT:** VCL fault detection is enabled. BAN is receiving AIS cells indicating a fault on the VCL going toward the downstream endpoint.
- **ENABLED RDI FAULT:** VCL fault detection is enabled. BAN is receiving RDI cells indicating a fault on the VCL coming from the remote endpoint of the VCL.
- **DISABLED:** VCL fault detection is disabled.

Example 7 Using the **sar8260** command with the VPI, VCI, and CID numbers gives information about the ATM interface at the CID level.

```
zSH> sar8260 stats 0 201 16

ATM AAL2 CID Statistics [VPI 0 VCI 201 CID 16]

Channel Type..... POTS          Status..... OK
Active..... 0          Cumulative Calls... 0
Voice Tx..... 0          Voice Rx..... 0
Voice Tx Errors.... 0          Voice Rx Errors.... 0
CAS Tx Requests.... 1          CAS Rx Delivered... 0
CAS Tx Refresh..... 115        CAS Rx Refresh..... 0
CAS Tx Redundant... 3          CAS Rx Redundant... 0
CAS Tx Errors..... 0          CAS Rx Errors..... 0
Alarm Tx..... 0          Alarm Rx..... 0
Alarm Tx Errors.... 0          Alarm Rx Errors.... 0
Type 3 CRC Errors.. 0
```

Example 8 Issue the **sar8260** command with the **dchannelcids** option to view CIDs allocated for ISDN D channels by ELCP. The command syntax is **sar8260 dchannelcids vpi vci**.

```
zSH> sar8260 dchannelcids 0 40
128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147
148 149 150 151 152 153 154 155 156 157 158 159
```

Products Sechtor 100A

selftest

Runs diagnostics on the device.



Caution: Running a diagnostics test can interrupt traffic on the card.

Syntax `selftest get index repetition type`**index**

The user-defined index number of the test to run.

repetition

Number of times to repeat the test.

type

Type of test to run. The possible tests are:

Table 8: Supported diagnostics

Test	Devices supported
Back Plane Test verifies the card can access the back plane by verifying the back plane EEPROM checksum.	All cards except MTAC cards
Card EEPROM Test verifies the main card EEPROM checksum.	All
Daughter 1 card EEPROM Test verifies the daughter 1 card is present by verifying the daughter 1 card EEPROM checksum.	MALC ADSL-24 card MALC and Raptor ADSL-32 cards MALC and Raptor ADSL-32 + splitter cards MALC ADSL+POTS 24 card MALC and Raptor G.SHDSL card MALC POTS-24 card MALC and Raptor Uplink cards
Daughter 2 card EEPROM Test verifies the daughter 2 card is present by verifying the daughter 2 card EEPROM checksum.	MALC ADSL-24 card MALC and Raptor ADSL-32 cards MALC and Raptor ADSL-32 + splitter cards MALC ADSL+POTS 24 card
Fan Tray Test verifies the fan tray is operational by verifying the fan tray EEPROM checks	BAN Infoservices cards MALC and Raptor Uplink cards
Fhrame Bus Test verifies the card can access the fhrame bus by executing a loopback test.	All cards except MALC and Raptor G.SHDSL card
Flash Test verifies the card can access the PCMCIA flash card I/O by creating, writing, and reading a 4000-byte file.	BAN Infoservices cards MALC and Raptor Uplink cards
I/O Card Test verifies the I/O card is present by verifying the I/O card EEPROM checksum.	BAN ADSL 24 card MALC and Raptor ADSL-32 cards MALC and Raptor ADSL-32 + splitter cards BAN ATM AAL2/5 T3 card BAN ATM AAL5 OC3-c/STM1 card BAN ATM AAL5 T3 card BAN SDSL/G.SHDSL cards BAN T3/E3 cards

Table 8: Supported diagnostics (Continued)

Test	Devices supported
Mezzanine Card Test verifies the mezzanine card is operational by verifying the mezzanine card EEPROM checksum.	BAN SDSL/G.SHDSL cards BAN T3/E3 cards BAN ATM AAL5 OC3-c/STM1 card BAN ATM AAL5 T3 card BAN ADSL 24 card
Mid Plane Test verifies the mid plane card is present by verifying the mid plane EEPROM checksum.	BAN ATM AAL2/5 T3 card BAN Ethernet 10/100 card BAN Infoservices cards BAN SDSL/G.SHDSL cards
Real Time Clock Test verifies the real time clock increments.	BAN Infoservices cards MALC and Raptor Uplink cards
Self Test executes all individual tests.	All
Shelf Lamp Test illuminates the shelf alarm indicators for 1.5 seconds. Once the diagnostic completes, the indicators return to their original settings.	BAN Infoservices cards MALC and Raptor Uplink cards
Shelf Monitor Test verifies the shelf monitor board is operational by checking the POST status register and verifying the shelf monitor board EEPROM checksum.	BAN Infoservices cards MALC and Raptor Uplink cards
Supervisory Bus Test verifies the card can access the supervisory bus by executing a loopback test.	BAN Infoservices cards MALC and Raptor Uplink cards

Syntax `selftest start index repetition type`

start

Starts the specified test.

Syntax `selftest stop index repetition type`

stop

Stops the specified test.

Syntax `selftest del index repetition type`

del

Deletes the specified test.

Syntax `selftest list`

list

Lists test results.

Example 1 To display the tests on a MALC:

```
zSH> selftest list
```

```

Name      Id      FuncPtr   Record   Time   Status      Details
-----
Flash-1   5      0x075760 0x2f8fae8 30     PASS Flash:1 shelf:1 slot:1
Shelf Mon 9      0x180bdc 0x2a54070 15     PASS Shelf:1 slot:1.
Supv Lpbk 2      0x1807e4 0x2b24000 15     PASS Wr:0x5aa5 rd:0x00a5 shelf:1 sl
Fan Tray  8      0x1809dc 0x2b24090 15     PASS FANTRAY EEPROM checksum shelf:
Lamp Test 6      0x1805e0 0x27f7700 10     PASS Shelf:1 slot:1.
Card EEprom 3      0x226cd4 0x27f7670 5      PASS CARD EEPROM checksum slot:1.
Daughter-1 13     0x226cd4 0x2b42f20 5      PASS 1DAUGHTER EEPROM checksum slot
Back Plane 12     0x226cd4 0x27f75e0 5      PASS BACKPLANE EEPROM checksum slot
RT Clock  7      0x226cd4 0x27ef590 5      PASS RTC POST slot:1
List memory allocated: 972 bytes.

```

Example 2 To display the tests on a BAN:

```

zSH> selftest list
Name      Id      FuncPtr   Record   Time   Status      Details
-----
Flash-1   5      0x075760 0x2f8fae8 30     PASS Flash:1 shelf:1 slot:1
0x212118 0x7dcfad0 30     PASS Flash:1 shelf:1 slot:3
Flash-2   5      0x21229c 0x7dcfa40 30     FAIL Flash:2 card absent.
Shelf Mon 9      0x22d8f8 0x7b92350 15     PASS Shelf:1 slot:3.
Supv Lpbk 2      0x22d4cc 0x7babb80 15     PASS Wr:0x5aa5 rd:0x00a5 shelf:1 sl
Fan Tray  8      0x22d6dc 0x7bac5f0 15     PASS FANTRAY EEPROM checksum shelf:
Lamp Test 6      0x22d2b0 0x7bac090 10     PASS Shelf:1 slot:3.
frbus-1  4      0x2a1a70 0x7b14d70 30     PASS Fhramelpbk> shelf:1 slot:3 frb
frbus-2  4      0x2a1a70 0x7b1dba0 30     PASS Fhramelpbk> shelf:1 slot:3 frb
frbus-3  4      0x2a1a70 0x7b14980 30     PASS Fhramelpbk> shelf:1 slot:3 frb
Card EEprom 3      0x358170 0x7b1dcc0 5      PASS CARD EEPROM checksum slot:3.
Mid-Plane 13     0x358170 0x7b04030 5      FAIL MIDPLANE EEPROM checksum slot:
RT Clock  7      0x358170 0x7b12b30 5      PASS RTC POST slot:3
Back Plane 12     0x358170 0x7b040c0 5      PASS BACKPLANE EEPROM checksum slot
List memory allocated: 1404 bytes.

```

Example 3 To start all the tests and run them one time (this example is from a MALC):

```
zSH> selftest start 1 1 1
```

Use the **list** option to view the results of the test:

```

zSH> selftest list
Name      Id      FuncPtr   Record   Time   Status      Details
-----
Flash-1   5      0x075760 0x2f8fae8 30     PASS Flash:1 shelf:1 slot:1
Shelf Mon 9      0x180bdc 0x2a54070 15     PASS Shelf:1 slot:1.
Supv Lpbk 2      0x1807e4 0x2b24000 15     PASS Wr:0x5aa5 rd:0x00a5 shelf:1 sl
Fan Tray  8      0x1809dc 0x2b24090 15     PASS FANTRAY EEPROM checksum shelf:
Lamp Test 6      0x1805e0 0x27f7700 10     PASS Shelf:1 slot:1.
Card EEprom 3      0x226cd4 0x27f7670 5      PASS CARD EEPROM checksum slot:1.
Daughter-1 13     0x226cd4 0x2b42f20 5      PASS 1DAUGHTER EEPROM checksum slot
Back Plane 12     0x226cd4 0x27f75e0 5      PASS BACKPLANE EEPROM checksum slot
RT Clock  7      0x226cd4 0x27ef590 5      PASS RTC POST slot:1
List memory allocated: 972 bytes.

```

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

selt

The MALC supports the SELT commands for Single-End Loop Tests.

```
Syntax selt start interface
selt abort interface
selt clear interface
selt set units awg | metric | japan
selt set max-duration interface num-seconds
selt show status interface
selt show noise interface [start-index [num-vals]]
selt set gauge interface wire-gauge
selt set cable interface cable-type
```

interface

The *interface* can be in the form of ifIndex (432), name/type (1-4-1-0/adsl) or shelf/slot/port/subport/type (1/4/1/0/adsl0).

num-seconds

The maximum amount of time, in seconds, that a SELT test is allowed to run on an ADSL interface. If a selt test runs for more than <num-seconds> it will be aborted. Setting max-duration to zero disables SELT timeout on an interface. Note that, in order to get valid results, a SELT test must be allowed to run to completion, and this may take several minutes, depending on the speed of the processor used to do the computation.

start-index

(0..511) is the tone index with which to start. 0 is 4.3125 kHz, 1 is 8.625 kHz, up to 511 which is 2208.0000 kHz. The noise command displays the loop noise floor results of a selt test. There is one noise measurement per ADSL tone. Each noise value has units of dBm/Hz.

num-val

The number of tones to display.

wire-guage

Sets the expected diameter of the wire connected to an interface. The diameter may be set using any units, regardless of the display units set with the **selt set units** command. The wire-gauge option must use one of these settings:

- unknown - unknown wire gauge
- awg19 - 19 gauge
- awg22 - 22 gauge
- awg24 - 24 gauge
- awg26 - 26 gauge
- 32mm - 0.32 millimeters

- 40mm - 0.40 millimeters
- 50mm - 0.50 millimeters
- 63mm - 0.63 millimeters
- 65mm - 0.65 millimeters
- 90mm - 0.90 millimeters

The chip used to implement the `set` test may restrict which values can be configured. The Conexant-g24 chip accepts these settings:

- `awg24`
- `awg26`
- 40mm (as an alias for `awg26`)
- 50mm (as an alias for `awg24`)

cable-type

Sets the type of cable being tested, real or simulated. The *real* setting indicates that an actual physical cable is connected to the interface. In a lab or test environment, the cable may be simulated and use the *dsl90* or *dsl400* setting.

- `real`: indicates a physical cable is connected to the interface.
- `dsl90`: a Consultronics/Spirent DLS90 is simulating the cable.
- `dsl400`: a Consultronics/Spirent DLS400 is simulating the cable.

Notes Note that it may take some time (perhaps as much as a minute) for the SELT test to abort.

set

This command is used only by the configuration restore process.

Syntax `N/A`

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

set2default

Erases the system configuration and restores the factory default settings.



Caution: This command erases your system configuration, reboots the system, and causes all connections and subscriber traffic to drop.



Note: This command is not available on standby uplink cards in a protection group

Syntax `set2default`

Example

```
175.5> set2default
Ok to reset to default (system will reboot) ? [yes] or [no]: yes
```

Do you want to exit from this request? (yes or no) [yes] **no**
 Are you sure? (yes or no) [no] **yes**

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `systemreboot`

setcliprov

Enables or disables provisioning from a CLI session. If CLI provisioning cannot be re-enabled using this command, use the **resetcliprov** command.

Syntax `setcliprov [enable | disable] [index | all] [-d]`

Options `enable | disable`

Enables or disables provisioning from the CLI.

index

Enables or disables CLI provisioning from a single CLI session with the specified index. CLI session indexes are displayed in the output of the **who** command.

all

Enables or disables CLI provisioning for all active CLI sessions.

-d

Indicates which CLI sessions are enabled for provisioning.

Example The following example displays the CLI sessions that enabled for provisioning:

```
zSH> setcliprov -d
Note: Provisioning is only available when Flag Count = 0
CLI session = 0: Flag Count = 0.
CLI session = 1: Flag Count = 0.
CLI session = 2: Flag Count = 0.
CLI session = 3: Flag Count = 0.
CLI session = 4: Flag Count = 0.
CLI session = 5: Flag Count = 0.
CLI session = 6: Flag Count = 0.
CLI session = 7: Flag Count = 0.
CLI session = 8: Flag Count = 0.
CLI session = 9: Flag Count = 0.
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `resetcliprov`

setdatetime

Sets the date and time.

Syntax `setdatetime [month day yr hr min sec]`

Options *month*

Month in the format *mm*.

date

Day in the format *dd*.

yr

Year in the format *yyyy*.

hr

Hour in the format *hh*.

min

Minutes in the format *mm*.

sec

Seconds in the format *ss*.

Access Level admin

Notes If Network Time Protocol (NTP) is enabled, the **setdatetime** command is disabled.

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `showdatetime`

setline

Specifies the maximum number of lines to be displayed at once.

Syntax `setline [number-of-lines]`

Options

Displays the current number of lines.

number-of-lines

Changes the number of lines displayed per page.

Example `zSH> setline 52`
cli lines per pager changed to: 52

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

setprompt

Sets the system prompt.

Syntax `setprompt [session | user] prompt`

Options *session*

Changes the system prompt to the specified string for the current session.

user

Changes the system prompt for the user to the specified string. This prompt appears every time the user logs in.

prompt

A string of up to 20 characters for the prompt

Example The following example sets the system prompt to **Zhone>** for the current session:

```
zSH> setprompt session Zhone>
Prompt set to Zhone>
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

shelfctrl

Displays overall status of the system.

Syntax `shelfctrl [monitor | show | stats]`

Options **monitor**

Displays system status, including temperature, power supply status, and fan status.

show

Displays state of the shelf monitor.

stats

Displays device stats, including messaging errors, card updates, and clock messages.

Example 1 The following example displays the overall system status, including alarms on the slot cards:

```
zSH> shelfctrl monitor
Shelf uptime: 1 day, 23 hours, 26 minutes
Shelf Monitor CPLD version: 0.5
Shelf Monitor Firmware version: 0.6
Outlet temperature sensor: 77 degrees (normal)
Fan Power A: normal
Fan Power B: normal
Power Supply A: normal
Power Supply B: normal
Fan status: OK.
System: Minor alarm set.
Card 1: Minor alarm set.
```

Note that not all information is available for all products.

Example 2 The following example displays overall system status for a Raptor 100:

```
zSH> shelfctrl monitor
```

```

Shelf uptime: 4 hours, 21 minutes
Shelf start time: 49
Control CPLD version: 2.1
Outlet temperature sensor: 46 degrees Celsius (normal)
Fan Power A: failure
Fan Power B: failur

```

Example 3 The following example displays general system statistics:

```

zSH> shelfctrl stats
Shelf Controller Message Statistics
-----

Card updates: 32
Card ECHO: 0
Directory services messages: 2
Clock messages: 513905
Lease messages: 1427
Heartbeat messages: 2217639

Card update errors: 0
Card ECHO errors: 0
Directory services errors: 0
Clock errors: 0
Lease errors: 0
Heartbeat errors: 0
Receive errors: 0
No Peer heartbeat check errors: 0

```

Example 4 The following example (on a MALC) displays whether the shelf is active and the state of each of the slot cards:

```

zSH> shelfctrl show
Shelf Controller Address: 01:01:12
Shelf Registry Address: 01:01:1036
Lease ID: 0x02070000_00000032
State: active
Slot 1:
    prevState: CONFIGURING currentState: RUNNING
    mode: FUNCTIONAL startTime: 1064226409
Slot 2:
    prevState: CONFIGURING currentState: RUNNING
    mode: FUNCTIONAL startTime: 1064226942
Slot 3:
    prevState: CONFIGURING currentState: RUNNING
    mode: FUNCTIONAL startTime: 1064236395
Slot 4:
    prevState: CONFIGURING currentState: RUNNING
    mode: FUNCTIONAL startTime: 1064226590
Slot 5:
    prevState: CONFIGURING currentState: RUNNING
    mode: FUNCTIONAL startTime: 1064226590
Slot 6:
    prevState: CONFIGURING currentState: RUNNING
    mode: FUNCTIONAL startTime: 1064226558

```

```

Slot 7:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 8:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 9:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 10:
  prevState: CONFIGURING currentState: RUNNING mode:
  FUNCTIONAL startTime: 1064226589
Slot 11:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 12:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 13:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 14:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 15:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 16:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 17:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 18:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226590
Slot 19:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064234610
Slot 20:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226592
Slot 21:
  prevState: CONFIGURING currentState: RUNNING
  mode: FUNCTIONAL startTime: 1064226493

```

Example 5 The following example is from a Raptor 100:

```

zSH> shelfctrl show
Shelf Controller Address: 01:01:12
Shelf Registry Address: 01:01:1032
Lease ID: 0x022b0000_00000033
State: active
Slot 1:

```

```
prevState: CONFIGURING currentState: RUNNING
mode: NONE startTime: 1061243734
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also slots

shelfreboot

Resets the shelf. When you reset a shelf, all connections are dropped.



Caution: This command reboots the system, and causes all connections and subscriber traffic to drop.

Syntax `shelfreboot shelf`

Options `shelf`

Shelf to reset. The only supported value is 1.

Access Level admin

Products BAN, MALC

See Also `systemreboot`

show

The **show** command displays the default contents of profile and its parameter value ranges. The command uses the following syntax:

Syntax `show profile-type`

Options `profile-type`

Shows the parameters in the specified profile with the parameter value ranges.

Example To view the options available for a profile, use the **show** command and specify the profile type:

```
zSH> show ip-interface-record
vpi:-----> {0 - 4095}
vci:-----> {0 - 65535}
rdindex:-----> {0 - 2147483647}
dhcp:-----> none client server both
addr:-----> {0 - -1}
netmask:-----> {0 - -1}
bcastaddr:-----> {0 - -1}
destaddr:-----> {0 - -1}
farendaddr:-----> {0 - -1}
mru:-----> {0 - 2147483647}
reasmmxsize:-----> {0 - 65535}
ingressfiltername:-> {33}
```

```

egressfiltername:--> {33}
pointtopoint:-----> no yes
mcastenabled:-----> no yes
ipfwdenabled:-----> no yes
mcastfwdenabled:----> no yes
natenabled:-----> no yes
bcastenabled:-----> no yes
ingressfilterid:----> {0 - 2147483647}
egressfilterid:----> {0 - 2147483647}
ipaddrdynamic:-----> static ppp dhcpclient
unnumbered
dhcpserverenable:--> true false
subnetgroup:-----> {0 - 2147483647}
unnumberedindex:----> {0 - 2147483647}
mcastcontrollist:--> {264}
vlanid:-----> {0 - 4095}
maxVideoStreams:----> {0 - 6}
NOTE: Supported VPI/VCI ranges vary based on card type.
See documentation for the exact range of supported VPI/
VCI values.

```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also [get, list](#)

showactivecards

Displays information about the active cards in a redundant card group.

Syntax `showactivecards`

Example zSH> `showactivecards`

Shelf/Slot	Group Id	Card Type
1: 1/21 2		MALC MTAC
2: 1/1 1		MALC DS3

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also [showredundancy](#)

showdatetime

Displays the date and time.

Syntax `showdatetime`

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A

See Also [setdatetime](#)

showhostname

Displays a list of remote hosts, along with their Internet addresses and aliases.

Syntax `showhostname`

Access Level user

Notes This command is persistent across reboots.

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

showinetstat

Displays information about the active IP sockets.

Syntax `showinetstat`

Example

```
zSH> showinetstat
Active Internet connections (including servers)
PCB      Proto Recv-Q Send-Q Local Address      Foreign Address    (state)
-----
382806c  TCP        0    214 192.24.94.223.23  192.16.41.183.5169 ESTABLISHED
3827cd0  TCP        0     0  0.0.0.0.23       0.0.0.0.0         LISTEN
3827dd8  UDP        0     0  0.0.0.0.162     0.0.0.0.0
3827d54  UDP        0     0  0.0.0.0.161     0.0.0.0.0
```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

showipstat

Displays IP statistics.

Syntax `showipstat [-r]`

Options

Displays IP protocol statistics.

-r

Resets counters to 0 (zero).

```
Example zSH> showipstat
total 81601
badsum 0
tooshort 0
toosmall 0
badhlen 0
badlen 0
infragments 0
fragdropped 0
fragtimeout 0
```

```

        forward 11141
        cantforward 4303
        redirectsent 0
        unknownprotocol 2
        nobuffers 0
        reassembled 0
        outfragments 0
        noroute 0
        fastfwd 6447695
        fastfwdnoroute 0
        ffwdnointerface 0
        nointerface 0
        c2ctotal 6447695
        c2cbadptr 0
        c2cnopkt 0
        c2cnoipktmem 0
        c2cttlexp 0
        c2clastchance 0
        flingnoipkt 0
        flingerror 0
        flung 0
        rawflung 0
        rawnofling 0
        fwdloopdrop 0
        localfastpath 55532
        pendingarpoverflow 835
    
```

Access Level admin

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

showline

Displays information on registered lines in line resource registry's database.

Syntax `showline [shelf | slot | -c number of columns]`

Options **shelf**

Displays all registered lines on the specified shelf.

slot

Displays all registered lines on the specified shelf-slot.

-c number of columns

Specifies the number of columns (1 -12) to display for each line group.

Example `zSH> showline 1 -c 5`
 Search in progress

```

-----
shelf = 1, slot = 1, line type = DSPPROXY
line
1-5      NONE ACT
    
```

```

-----
shelf = 1, slot = 1, line type = AAL5PROXY
line
    
```

```

1-5    ACT
-----
shelf = 1, slot = 1, line type = SONET
line
1-5    OOS
-----
shelf = 1, slot = 1, line type = T1
line
1-5    OOS OOS OOS OOS OOS
6-10   OOS OOS OOS
-----
shelf = 1, slot = 1, line type = ETHERNET
line
1-5    ACT OOS
-----
shelf = 1, slot = 8, line type = DSL
line
1-5    OOS OOS OOS OOS OOS
6-10   OOS OOS OOS OOS OOS
11-15  OOS OOS OOS OOS OOS
16-20  OOS OOS OOS OOS OOS
21-25  OOS OOS OOS OOS
-----
shelf = 1, slot = 15, line type = POTS
line
1-5    OOS OOS OOS OOS OOS
6-10   OOS OOS OOS OOS OOS
11-15  OOS OOS OOS OOS OOS
16-20  OOS OOS OOS OOS OOS
21-25  OOS OOS OOS OOS
-----
shelf = 1, slot = 15, line type = DSL
line
1-5    OOS OOS OOS OOS OOS
6-10   OOS OOS OOS OOS OOS
11-15  OOS OOS OOS OOS OOS
16-20  OOS OOS OOS OOS OOS
21-25  OOS OOS OOS OOS

```

Access Level user

Notes The time-out values persists across resets.

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

showlinestatus

Displays information about all the lines in the system.

Syntax `showlinestatus [shelf slot port subport]`

Options

With no options, displays status on all available lines.

shelf

Displays status of all lines on the specified shelf. Currently, 1 (one) is the only supported value.

slot

Displays status of all lines on the specified slot.

subport

Displays status of all lines on the specified subport. Note that not all interfaces support subports.

Example 1 The following example displays the line status of the lines in shelf 1, slot 2 (in this example, an ATM trunking card):

```
zSH> showlinestatus 1 7
Search in progress .....
.....
Line Type-----> DS3 (1)
GroupId -----> 260
Status -----> OOS (3)
Redundancy -----> ACTIVE (3)
TxClk -----> LOOP (4)
RefClkSrc -----> NO
If_index -----> 259
Shelf -----> 1
Slot -----> 7
Port -----> 1
SubPort -----> 0
.....
Line Type-----> DS3 (1)
GroupId -----> 262
Status -----> OOS (3)
Redundancy -----> ACTIVE (3)
TxClk -----> THROUGH (5)
RefClkSrc -----> NO
<SPACE> for next page, <CR> for next line, A for all, Q to
quit
```

For each connection, the system lists the line type (such as an Ethernet, DS3, SONET, or T1/E1 line), the number of registered lines, their group ID, the line status, the ifindex (interface line number), the peer ifindex (the peer line number), and the shelf, slot, and port where the interface resides.

A value of **ACTIVE** in the **Status** field indicates that the physical circuit is detected. **OSS** (Out of Service) means that the physical interface is not active.

Example 2 The next example displays the line status of the line in shelf 1, slot 9, port 1 (in this example, an SDSL/G.SHDSL card):

```
zSH> showlinestatus 1 9 1
Search in progress .....
.....
Line Type-----> DSL (10)
GroupId -----> 20
Status -----> OOS (3)
Redundancy -----> NONE (0)
```

```

TxClk -----> NONE (1)
RefClkSrc -----> NO
If_index -----> 19
Shelf -----> 1
Slot -----> 9
Port -----> 1
SubPort -----> 0

```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

showmem

Displays system memory partition blocks and statistics.

Syntax `showmem [-a]`

Options

Displays all memory partition blocks and pools.

-a

Displays all memory partition blocks and pools as well as the free memory blocks in the system partition.

Example The following example displays all the system memory blocks:

```

zSH> showmem -a
memory partition blocks and statistics...

FREE LIST:
  num      addr      size
  ---      -
  1  0xffffa9f0    19968
  2  0x19b5400   97336376
  3  0x7d61858   179992

SUMMARY:
  status  bytes      blocks  avg block  max block
  -----
current
  free   97536336         3   32512112  97336376
--this represents free blocks not yet allocated to the
memory pools

```

FIXED MEMORY POOLS:

Block Size (Bytes)	Total Blocks	Free Blocks
32	7540	59
64	5780	2705
128	5988	85
256	664	33
512	372	105

```

1024      1532      3
2048      184      4
4096      65      1
8192     107      2
16384     34      1
32768     88      2
65536     13      0
131072    2      0

```

```

Pool Totals:
Number of Total Blocks in all Pools: 22369
Number of Free Blocks in all Pools: 3000
Total Bytes in all Pools: 9739152
Total Free Bytes in all Pools: 409760
Total Allocated Bytes in all Pools: 9329392

```

```

Statistics on Large Block Allocations:
Number of Large Blocks Allocated: 18
Total Bytes Allocated: 134201072

```

```

Access Level admin
Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor
100A, Z-Edge 64

```

showredundancy

Displays system redundancy information.

Syntax `showredundancy`

Options

With no option specified, displays basic redundancy information.

-d

Displays detailed redundancy information such as active and standby times.

```

Example zSH> showredundancy
Redundancy status for card 01:01 - Not Safe, some
services are standalone
01:01 is active storage
No standby storage

```

```

zSH> showredundancy -d
Redundancy status for card 01:01 -
Taskname      Active Addr      Standby Addr      Stdby Ready?
=====
RdsServer     01:01:03         01:02:03         Yes
InfoServer    01:01:02         01:02:02         Yes
zCardRed      01:01:26         01:02:26         Yes
tMAXTask      01:01:1036       01:02:1036       Yes
trapSrv       01:01:25         01:02:25         Yes
tShelfRR      01:01:1035       01:02:1035       Yes
NpRedSrv      01:01:58         01:02:58         Yes

```

LogServer	01:01:08	01:02:08	Yes
tFTD	01:01:67	01:02:67	Yes
tNumSrv	01:01:1030	01:02:1030	Yes
DhcpServerTask	01:01:1033	01:02:1033	Yes
filterupdate	01:01:1031	01:02:1031	Yes
ifcfgtask	01:01:1038	01:02:1038	Yes
Ccrr-1/1	01:01:64	01:02:64	Yes
MPRR-1/1	01:01:1044	01:02:1044	Yes
CTRR-1/1	01:01:1045	01:02:1045	Yes
VoiceCallSup	01:01:1046	01:02:1046	Yes
L-RR-1/1	01:01:1041	01:02:1041	Yes
TadSrvTask	01:01:1039	01:02:1039	Yes
tRprRP	01:01:63	01:02:63	Yes
tDS1RP	01:01:1061	01:02:1062	Yes
_RedSpawnSvrTask	01:01:1050	01:02:1050	Yes
connmgr	01:01:16	01:02:16	Yes

Safe, all services have redundant peers
01:01 is active storage
01:02 is standby storage

Products BAN, MALC

See Also `showactivecards` (MALC)

showresolver

Displays information about the Domain Name System (DNS) resolver on the device. The DNS resolver is configured in the **resolver** profile.

Syntax `showresolver [-d domain-ID]`

Options

With no option specified, displays all DNS resolver information.

-d *domain-ID*

Displays DNS resolver information for the specified domain ID.

Example zSH> `showresolver`

```
Resolver Configuration:
Routing Domain: 0
Query Order: QUERY_LOCAL_FIRST
Domain Name: zhone.com
Nameserver[0]: 192.168.9.43
Nameserver[1]: 201.12.4.68
Nameserver[2]:
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

showsonetrp

Reports detailed status for an OC3-c/STM1 interface resource provider, including the following line conditions: This command is available only when a SONET interface is configured.

- Loss of signal (LOS)
- Loss of frame (LOF)
- Alarm indication signal (AIS)

Syntax `showsonetrp [line]`

Options `line`

The number of the interface to display status information for. With no options, the command displays overall information about the line.

Example The following example shows the `showsonetrp` command output for line 1:

```
zSH> showsonetrp 1
*****          SONET RP Debug Information          *****
name:          tSONETRTP
address:       01:01:1085
lineRRLeaseId: 0x02070000_0000004f
sonetXlatProfLeaseId: 0x02070000_00000050
sonetCfgProfLeaseId: 0x02070000_00000050
sonetLineRRNotifyLeaseId: 0x00000000_00000000
_sonetRpCardGroupId: 1
iamRedundantCard: TRUE
iamActiveCard: TRUE
Redundancy Mode: CARD
PeerCardInfoAvailable: TRUE
PeerCardShelf: 1
PeerCardSlot: 2
PeerCardAlive: TRUE
numUnits:     2
Attached units:
              1 2
```

```
*****          Debug Information for Line 1          *****
iamRedundantLine: TRUE
iamActiveLine:   TRUE
state:           4 ( OOS )
ifIndex:         4
LineGroup ifIndex: 5
primaryClock:    FALSE
shelf:           1
slot:            1
port:            1
subPort:         0
xlatProf.ifIndex: 4
xlatProf.ifType: 39
xlatProf.adminStatus: 1
sectionAlarms    6 ( LOS LOF )
```

lineAlarms	2 (AIS)
pathAlarms	1 (NODEFECT)
mediumType	sonet
mediumLineCoding	sonetmediumnrz
mediumLineType	sonetshortsinglemode
mediumCircuitIdentifier	
mediumLoopbackConfig	sonetnolooop
pathCurrentWidth	sts3cstm1
clockExternalRecovery	enabled
clockTransmitSource	looptiming
mediumScrambleConfig	TRUE
mediumLineScrmConfig	TRUE
Send APS stats	FALSE

Products BAN, MALC, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A

showuser

Displays information about all users on the system, or for a specific user.

Syntax `showuser [username]`

Options

If the current user has useradmin privileges, displays information about all users in the system. Otherwise, displays information only about the current user.

username

Displays information about the specified user.

Example The following example displays information a specific user:

```
zSH> showuser jjsmith
Full Name: jay_smith
User Name: jjsmith
Access Levels:(user)
.....
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `adduser`, `deleteuser`, `updateuser`

showzhonecpe

Displays the Zhone Customer Premises Equipment (CPE) connected to the system, including the virtual routing domain, IP address, and current connection status.

Syntax `showzhonecpe`

Example zSH> showzhonecpe
 1: Zhone CPE at vrd:0 ip:192.168.199.205 status:UP
 failures:0
 Total Zhone CPE devices: 1 (1 up) (0 down)

Access Level admin

Products BAN

See Also pollzhonecpe

slotreboot

Resets the specified slot card. When you reset a system, all connections are dropped.

Syntax slotreboot *slot*

Options *slot*

The individual slot(s) or range of slots to reboot. Confirmation messages prompt to reboot all slots or select slots.

Example

```
zSH> slotreboot 2,3,[4-7],17,[8-10]
None interactive reboot all 10 slots? (yes or no) [no] yes
Do you want to exit from this request? (yes or no) [yes] no
Are you sure? (yes or no) [no] yes
JUL 24 19:29:18: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 2
JUL 24 19:29:19: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 3
JUL 24 19:29:20: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 4
JUL 24 19:29:21: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 5
JUL 24 19:29:22: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 6
JUL 24 19:29:23: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 7
JUL 24 19:29:24: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 17
JUL 24 19:29:25: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 8
JUL 24 19:29:26: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 9
```

```
JUL 24 19:29:27: critical: 1/1/1027: rebootserver: rebootShelfSlot.c:
RebootMessageSend(): l=1455: tCliInit0:
* * * * Slot Reboot : type = 2, shelf = 1, slot = 10
```

Access Level admin

Products BAN, MALC

See Also shelfreboot, systemreboot, bootstate

slots

Displays the type of cards installed in the chassis.

The **slots** command displays an asterisk (*) as a visual indicator for active cards in a redundant configuration.

The **slots** command also now displays the ROM and software versions.

The **slots** command can report any of the following states:

- NONE: Card inserted in shelf.
- BOOT: Card is running ROM code.
- LOAD: Card is loading code over the backplane.
- CONFIGURING: Card is loading code over the backplane.
- RUNNING: Card is fully functional.

Syntax **slots** *slot-number*

Options *slot-number*

Displays information about the specified slot card.

Example 1 To view information about all the slot cards in the system, use the **slots** command without any arguments:

```
zSH> slots
1: INFOSERVICES (RUNNING)
3: ETHERNET (RUNNING)
5: ATM TRNK CR/OC3 ATM SM (RUNNING)
7: ATM TRNK/E3 ATM (RUNNING)
9: HDSL2 (RUNNING)
10: ATM TRNK (LOADING)
12: ATM TRNK CR (LOADING)
15: ATM TRNK CR/T3 ATM (RUNNING)
```

Example 2 To view information about a particular slot card, use the **slots** command and specify a slot number. For example:

```
zSH> slots 3
Type           : INFOSERVICES
Card Version   : 1
EEPROM Version : 1
Serial #       : 4010042
CLEI Code      : No CLEI
Card-Profile ID : 1/3/3
```

```

Shelf          : 1
Slot           : 3
State          : RUNNING
Mode           : FUNCTIONAL
Heartbeat check : enabled
Longest hbeat  : 180
Fault reset    : enabled
Uptime         : 2 hours, 45 minutes

```

Example 3 zSH> **slots**

```

2: MALC UPLINK T1/E1 TDM (RUNNING)
5: MALC ULCS/ISDN 2B1Q (RUNNING)
6: MALC ULC (RUNNING)
8: MALC ULC (RUNNING)
9: MALC MTAC (RUNNING)

```

```

zSH> slots 5
Type           : MALC ULCS
Sub-Type       : ISDN 2B1Q
Card Version   : 1
EEPROM Version : 1
Serial #       : 210003
CLEI Code      : No CLEI
Card-Profile ID : 1/5/5049
Shelf          : 1
Slot           : 5
State          : RUNNING
Mode           : FUNCTIONAL
Heartbeat check : enabled
Longest hbeat  : 4543
Fault reset    : enabled
Uptime         : 3 hours, 40 minutes
Start time     : 1124907219

```

Example 4 This example shows active cards with redundant configurations in slots 1 and 17.

```

zSH> slots
1:*MALC RPR GIGE (RUNNING)
2: MALC RPR GIGE (RUNNING)
5: MALC XDSL 48 (RUNNING)
8: MALC POTS 48/with Packet Voice (RUNNING)
17:*MALC MTAC (RUNNING)
17: MALC MTAC (RUNNING)

```

Example 5 zSH> **slots 1**

```

Type           :*MALC UPLINK T1/E1 TDMF
Card Version   : 12740102
EEPROM Version : 1
Serial #       : 4340666
CLEI Code      : No CLEI
Card-Profile ID : 1/1/5114
Shelf          : 1
Slot           : 1

```

```

ROM Version      : MALC 1.9.0.1
Software Version: MALC 1.12.0.102
State           : RUNNING
Mode            : FUNCTIONAL
Heartbeat check : enabled
Longest hbeat   : 50
Fault reset     : enabled
Uptime         : 1 hour, 8 minutes
Start time     : 1131462988
zSH>

```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also bootstate

snmp

Provides access to standard SNMP commands.

Syntax `snmp [get|set|next|walk|xlate] ipAddr Community OID [type] [value]`

Options **get**

Gets the value of the specified OID.

set

Sets the specified OID. Currently unsupported.

next

SNMP next request. Currently unsupported.

walk

Starts a MIB walk on the specified device. Currently unsupported.

xlate

Translates between OIDs and object names.

ipAddr

The IP address of the device.

Community

The SNMP community name for the device.

OID

The OID for the request.

type

SNMP type. Used only in **set** requests.

value

The value for the OID. Used only in **set** requests.

Example 1 The following example translates the object name **sysDescr** to an OID value:

```

zSH> snmp xlate sysDescr
1.3.6.1.2.1.1.1

```

Example 2 The following example displays the upstream and downstream line rates for an SDSL interface.

First, find the ifIndex for the interface you want to get the information for:

```
zSH> ifxlate 1-7-1-0/hdsl2
ifIndex: -----> {868} use this value in the SNMP get command
shelf: -----> {1}
slot: -----> {7}
port: -----> {1}
subport: -----> {0}
type: -----> {hdlsl2}
adminstatus: -----> {up}
physical-flag: -----> {true}
iftype-extension: -> {none}
ifName: -----> {1-7-1-0}
```

Then use the ifIndex in the SNMP get command:

```
zSH> snmp get 192.240.200.111 ZhonePrivate zhoneDslUpLineRate.868
zhoneDslLineEntry.zhoneDslUpLineRate.868 Value: 1552 (0x610)
```

```
zSH> snmp get 192.240.200.111 ZhonePrivate zhoneDslDownLineRate.868
zhoneDslLineEntry.zhoneDslDownLineRate.868 Value: 1552 (0x610)
```

Example 3 The following example displays the upstream and downstream line rates for an ADSL interface.

First, find the ifIndex for the interface you want to get the information for:

```
zSH> ifxlate 1-3-1-0/adsl
ifIndex: -----> {58} use this value in the SNMP get command
shelf: -----> {1}
slot: -----> {3}
port: -----> {1}
subport: -----> {0}
type: -----> {adsl}
adminstatus: -----> {up}
physical-flag: -----> {true}
iftype-extension: -> {none}
ifName: -----> {1-3-1-0}
```

Then use the ifIndex in the SNMP get command:

```
zSH> snmp get 192.240.200.114 ZhonePrivate zhoneDslUpLineRate.58
zhoneDslLineEntry.zhoneDslUpLineRate.58 Value: 1088000 (0x109a00)
zSH> snmp get 192.240.200.114 ZhonePrivate zhoneDslDownLineRate.58
zhoneDslLineEntry.zhoneDslDownLineRate.58 Value: 8128000 (0x7c0600)
```

Example 4 The following example displays the upstream and downstream line rates for a SHDSL interface.

First, find the ifIndex for the interface you want to get the information for:

```
zSH> ifxlate 1-3-1-0/shdsl
ifIndex: -----> {364} use this value in the SNMP get command
```

```

shelf: -----> {1}
slot: -----> {3}
port: -----> {1}
subport: -----> {0}
type: -----> {shdsl}
adminstatus: -----> {up}
physical-flag: -----> {true}
iftype-extension: -> {none}
ifName: -----> {1-3-1-0}

```

Then use the ifIndex in the SNMP get command:

```

zSH> snmp get 192.240.200.123 ZhonePrivate zhoneDslUpLineRate.364
zhoneDslLineEntry.zhoneDslUpLineRate.364 Value: 2320 (0x910)
zSH> snmp get 192.240.200.123 ZhonePrivate zhoneDslDownLineRate.364
zhoneDslLineEntry.zhoneDslDownLineRate.364 Value: 2320 (0x910)

```

Example 5 The following example displays information about an ATM T1/E1 interface.

First, find the ifIndex for the interface you want to get the information for:

```

zSH> ifxlate 1-16-1-0/ds1
ifIndex: -----> {8} use this value in the SNMP get command
shelf: -----> {1}
slot: -----> {16}
port: -----> {1}
subport: -----> {0}
type: -----> {ds1}
adminstatus: -----> {up}
physical-flag: -----> {true}
iftype-extension: -> {none}
ifName: -----> {1-16-1-0}

```

Then use the ifIndex in the SNMP get command. The following two commands get the valid intervals for the DS1 interface and the current number of severely errored seconds:

```

zSH> snmp get 192.240.200.111 ZhonePrivate zhoneValidIntervals.8
zhoneDslEntry.zhoneValidIntervals.8 Value: 26 (0x1a)

zSH> snmp get 192.240.200.111 ZhonePrivate zhoneCurrentSESS.8
zhoneDslCurrentEntry.zhoneCurrentSESS.8 Value: 0 (0x0)

```

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechter 100A, Z-Edge 64

sonetStatsShow

Displays performance monitoring statistics for the current SONET connections. This command is available only when a SONET interface is configured.

Syntax `sonetStatsShow ifIndex`

Options ifIndex

The ifIndex number or component name (for example, 1-1-1-0/sonet) of the SONET interface.

Example

zSH> **sonetStatsShow 29**

```
***** Pmon Statistics of Line 29 *****

-----Driver Raw Counts-----
TxCell    RxCell    HECCor    HECUncor    FifoOv    Locd
  73815    73817         0         0         0         0

  LineBIP    SectBIP    PathBIP    LineFEBE    PathFEBE    OOF
     0         0         0        426       73387     0

-----Near-End Current Stats-----
...Section Stats.....Line Stats.....Path Stats.....
ESs  SESs SEFs CVs    ESs  SESs CVs    UAS  ESs  SESs CVs    UAS
0    0    0    0      0    0    0      0    0    0    0      0

-----Far-End Current Stats-----
.....Line Stats.....Path Stats.....
ESs  SESs CVs    UAS  ESs  SESs CVs    UAS
426  0    426    0   138  10  194    298

-----Near-End Interval Stats-----
.....Section Stats.....Line Stats.....Path Stats.....
INT  ESs  SESs SEFs CVs    ESs  SESs CVs    UAS  ESs  SESs CVs    UAS
1    0    0    0    0      0    0    0      0    0    0    0      0
2    0    0    0    0      0    0    0      0    0    0    0      0
3    0    0    0    0      0    0    0      0    0    0    0      0
4    0    0    0    0      0    0    0      0    0    0    0      0
5    0    0    0    0      0    0    0      0    0    0    0      0
6    0    0    0    0      0    0    0      0    0    0    0      0
7    0    0    0    0      0    0    0      0    0    0    0      0
8    0    0    0    0      0    0    0      0    0    0    0      0
9    0    0    0    0      0    0    0      0    0    0    0      0
10   0    0    0    0      0    0    0      0    0    0    0      0
11   0    0    0    0      0    0    0      0    0    0    0      0
12   0    0    0    0      0    0    0      0    0    0    0      0
13   0    0    0    0      0    0    0      0    0    0    0      0
14   0    0    0    0      0    0    0      0    0    0    0      0
15   0    0    0    0      0    0    0      0    0    0    0      0
16   1    1    0    0      0    0    0      0    0    0    0      0

-----Far-End Interval Stats-----
.....Line Stats.....Path Stats.....
INT  ESs  SESs CVs    UAS  ESs  SESs CVs    UAS
1    301  0    301    0   299  0    537    0
2    287  0    287    0   286  0    410    0
3    589  0    589    0   588  18   3423   0
4    248  0    248    0   247  1    989    0
5    474  0    474    0   474  0    2219   0
6    515  0    515    0   511  8    2121   0
7    233  0    233    0   228  0    391    0
```

```

8      227  0    227    0    227  0    302    0
9      269  0    269    0    268  0    452    0
10     274  0    274    0    272  0    359    0
11     461  0    461    0    456  0    1083   0
12     425  0    425    0    422  0    804    0
13     257  0    257    0    255  0    420    0
14     255  0    255    0    250  0    366    0
15     397  0    397    0    397  7    1492   0
16     899  1    898    0    899  80    7532   0
*****
                                End
*****

```

Access Level user

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

sonetstatusshow

Displays performance monitoring statistics for the current SONET connections. This command is available only when a SONET interface is configured.

Syntax `sonetstatusshow ifIndex`

Options `ifIndex`

The ifIndex number or component name (for example, 1-1-1-0/sonet) of the SONET interface.

Example

```
zSH> sonetStatusShow 29
```

```

Current Time: FRI SEP 24 16:28:21 2004
_____ Status of Line 29 _____
no section alarms
no line alarms
no path alarms
_____ End _____

```

Access Level user

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

stack

Binds, unbinds, and shows the logical protocol stacks used in the system.

Syntax `stack bind [upperlayer lowerlayer]`

The command can be used in two forms: If no arguments are provided to **stack bind**, it will prompt for the upper and lower interfaces. Alternately, the interfaces can be provided on the command line.

upper layer

The upper layer of the interfaces to be bound. Interfaces can be specified using either the *name/type* or the *shelf/slot/port/subport/type* notations.

lower layer

The lower layer of the interfaces to be bound. Interfaces can be specified using either the *name/type* or the *shelf/slot/port/subport/type* notations.

Syntax `stack unbind [upperlayer lowerlayer]`

Unbinds the specified interface.

upper layer

The upper layer of the interfaces to be unbound. Interfaces can be specified using either the *name/type* or the *shelf/slot/port/subport/type* notations.

lower layer

The lower layer of the interfaces to be unbound. Interfaces can be specified using either the *name/type* or the *shelf/slot/port/subport/type* notations.

Syntax `stack show interface`

Displays the protocol stack for the specified interface.

interface

The interface. Interfaces can be specified using either the *name/type* or the *shelf/slot/port/subport/type* notations.

Syntax `stack showall interface`

Displays all the associated layers of the specified interface.

Example 1 `zSH> stack bind`
 Enter the upper layer: `1-1-2-0/ip`
 Enter the lower layer: `1-1-2-0-ethernetcsmacd/other`
 Stack bind successful.

Example 2 `zSH> stack show 1-9-48-0-hdsl2/aal5`
 1483 layer: 1-9-48-0-hdsl2/rfc1483
 AAL5 layer: 1-9-48-0-hdsl2/aal5
 ATM layer: 1-9-48-0-hdsl2/atm
 Line Group: 1-9-48-0-hdsl2/other
 Physical: 1/9/48/0/hdsl2

Example 3 `zSH> stack showall 1-5-1-0/sonet`
 ATM layer: 1-5-1-0-sonet/atm
 Line Group: 1-5-1-0-sonet/other
 Physical: 1/5/1/0/sonet

Example 4 `zSH> stack showall 1-3-1-0/ip`
 IP Layer: 1-3-1-0 197.170.1.254
 Line Group: 1-3-1-0-ethernetcsmacd/other
 Physical: 1/3/1/0/ethernetcsmacd

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

SU

Logs in the specified user.

Syntax `su username`

Options `username`
The superuser name.

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `logout`

swact

Following the **swupgrade** command, this command switches the active device after software upgrade is complete.

Syntax `swact [abort]`

Options `abort`
This optional parameter terminates the software upgrade and reboots the standby device.

Access Level admin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `swupgrade`

swupgrade

Initiates the software upgrade process. This command reboots the standby device, informing it of upgrade. This command must be followed by the **swact** command, unless the **autoswact** option is used.

Syntax `swupgrade`

Options `autoswact`
This option allows a one-step software upgrade.

Access Level admin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also `swact`

swversion

Displays the current system software version.

Syntax `swversion`

Example `zSH> swversion`
`Zhone malcOc12 software version release 1.13`

Access Level `user`

Products `BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64`

See Also `romversion`

syslog

Configures logging levels for messages on the system. The system sends log messages to a management session (either on the console or over a telnet session), a log file on the device, and, optionally, a syslog server.

The **log** command configures the type of information sent in these messages. By default, the system sends the same type of information to all log message destinations, and logging is disabled on both the serial craft port and over telnet sessions.

If the messages sent to the syslog server are configured the same as the log messages sent to the console or the persistent storage (the default) the **log** command also configures the **syslog** message contents. If the syslog messages have been modified (using the **log-module** profile or the **syslog** command), use the **syslog** command to modify syslog levels.

Syntax `syslog help`

help
 Displays the help menu.

Syntax `syslog show`

show
 Displays the currently configured logging levels for each software module.

Syntax `syslog level module level`

module
 The system module to set the level for. Use the **syslog show** command to display all the system modules.

level
 Sets the logging level for the specified module. Logging levels are:

- 1 emergency
- 2 alert
- 3 critical
- 4 error

- 5 warning
- 6 notice
- 7 information
- 8 debug

You can specify either the name of the level or the number.

Syntax `syslog option type [on | off]`

Specifies the information to include in logging messages.

type on

Specifies that the type of information be included in syslog messages. To view the type of information you can include in a logging message, enter the **syslog option** command without any arguments.

type off

Specifies that the type of information not be included in syslog messages.

Syntax `syslog [enable | disable] module`

enable module

Enables logging for the specified module. Use the **syslog show** command to display all the system modules and whether they are enabled or not.

disable module

Disables logging for the specified module.

Syntax `syslog session [on | off]`

on

Enables logging for the current session only.

off

Disables logging for the current session.

Syntax `syslog serial [on | off]`

on

Enables logging on the serial craft port. This setting persists across reboots.

off

Disables logging on the serial craft port. This setting persists across reboots.

Syntax `syslog display`

Displays entries in the persistent log.

Syntax `syslog cache [max | grep pattern | size | clear | help]`



Note: The **cache** option is only supported on the BAN and MALC.

syslog cache

Displays the syslog cache.

syslog cache max length

Sets the maximum number of syslog messages to store. The maximum syslog cache size is 2147483647, depending in the amount of memory available.

syslog cache grep pattern

Searches through the syslog cache for the specified regular expression.

syslog cache clear

Clears the syslog cache.

syslog cache size

Sets the maximum amount of memory for the syslog cache. Without options, displays the current log size.

syslog cache help

Displays help on the **syslog cache** command.

Example 1 The following example displays the logging levels and enabled status for the system modules:

```
zSH> syslog show
MODULE                                LEVEL          STATUS
message                               error         enabled
taskclock                             error         enabled
card                                   error         enabled
bds_client                             error         enabled
alarm_mgr                              error         enabled
tnsxmgt                                error         enabled
leaseapi                               error         enabled
vcs-client                             error         enabled
dirserclient                           error         enabled
rebootserver                           error         enabled
pcmcadiag                              error         enabled
...
...
...
```

Example 2 The following example sets the logging level for the card module to information:

```
zSH> syslog level card info
Module: card at level: information
```

Example 3 The following example shows how to configure what information to include in syslog messages.

```
zSH> syslog option all on
```

```
time:date:level:address:log:taskname:taskid:file:function
:line:(0xff)
```

Example 4 To return the log messages to their default format, enter the following command:

```
zSH> syslog option default on
time: date: level: address: log: taskname: (0xf)
```

Example 5 The following example configures the log cache size:

```
zSH> syslog cache max 200
Maximum number of log messages that can be saved: 200
```

Example 6 following example searches through the log cache for the word “IMA”:

```
zSH> syslog cache grep IMA
Searching for: "IMA"
[1]: JAN 06 20:36:10: alert : 1/2/50 : alarm_mgr:
tLineAlarm: 01:02:02 Critical IMA Down Line
[2]: JAN 06 20:36:46: alert : 1/2/50 : alarm_mgr:
tLineAlarm: 01:02:02 Critical IMA Up Line
```

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also log

systemreboot

Resets the system.



Caution: When you reset a system, all connections are dropped.

Syntax `systemreboot`

A warning appears when a restore file exists in the system Flash to prevent unintentional deletions of the restore file with a new restore file.

Example

```
zSH> systemreboot
>> A restore file (/card1/onreboot/restore) is present.
>> A system reboot will result in a database restore.
>> Continue? (yes or no) [no]: yes
>>
>> Do you want to reboot the system? (yes or no) [no] yes
>>
>> Do you want to exit from this request? (yes or no) [yes] no
>>
>> Are you sure? (yes or no) [no] yes
```

- Access Level** admin
- Products** BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64
- See Also** **shelfreboot**, **slotreboot**

systemrpshow

Displays general information about the system resource provider, including memory and flash usage.

- Syntax** **systemrpshow**
- Example**

```
zSH> systemrpshow
System RP Info:
  RP Address.....01:02:98
  % Memory used.....87.16
  % Flash used.....10.04
```

- Access Level** admin
- Products** BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

T

telnet

Initiates an outbound telnet session.

- Syntax** **telnet** *host*
- Options** **host**
The hostname or IP address to telnet to.

- Products** BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723
- See Also** **ping**

thermoshow

The **thermoshow** command returns temperature information about the system. The system has two thermometers. From the front of the unit, thermometer 1 is located to the right of the MPC750 microprocessor, and thermometer 2 is located on the right side of the system circuit board.

- Syntax** **thermoshow**
- Example** The example below shows the system response to the command.

```
zSH> thermoshow
THERMO1 :
```

```

Temperature      : 24 C
High Threshold   : 65
Low Threshold    : -5
THERMO2:
Temperature      : 29 C
High Threshold   : 60
Low Threshold    : -5

```

Products Sechtor 100A

timeout

Specifies a the period of inactivity after which administrative telnet sessions will be automatically disconnected. The default time out is set to 10 minutes.

Syntax `timeout [-d | off | minutes]`

Options `off`

Disables the timer.

`-d`

Resets the timer to the default value of 10 minutes.

minutes

Specifies the timeout period in minutes.

Access Level useradmin

Notes The time-out values persists across resets.

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also `logout`

traceroute

The **traceroute** command uses Internet Control Message Protocol (ICMP) echo and User Datagram Protocol (UDP) to determine the path between two network hosts.

The value of the Time To Live (TTL) field in the IP header is set when the IP packet is sent. Each router that processes the datagram reduces the TTL value by one. When a router receives a TTL with a 0 (zero) or one (1) value, it discards the datagram and sends a time exceeded message to the originating host.

The **traceroute** command sends an IP datagram with a TTL value of one (1) to the destination host. The first router discards the datagram and sends the time exceeded message back to the originator. This identifies the first router along the route. This process is repeated using incrementally higher TTL values until all of the routers are identified. When the datagram reaches the destination host, the host recognizes that the packet is for an unused port, and generates a port unreachable error.

Syntax `traceroute [-I] [-f first_ttl] [-m max_ttl] [-p port] [-q nqueries] [-s src_addr] [-w waittime] [-z pausesecs] host [packetlen] [-l ip address]`

Options **-I**

Use ICMP ECHO instead of UDP datagrams.

-f *first_ttl*

Sets the initial TTL used in the first outgoing probe packet. The default is one (1).

-m *max_ttl*

Sets the maximum time-to-live (number of hops) to be used in outgoing probe packets. The default is 30 hops.

-p *port*

Sets the base UDP port number used in probes. The default is 33434.

-q *nqueries*

The number of probes sent to each ttl setting.

-s *src_addr*

Tells the system to use the following IP address (which usually is given as an IP number, not a hostname) as the source address in outgoing probe packets. This option is used with hosts that have more than one IP address to force the source address to be other than the IP address of the interface that the probe packet is sent on.

-w *waittime*

Sets the time, in seconds, to wait for a response to a probe. The default is 5 seconds.

-z *pausesecs*

Sets the time, in milliseconds, to pause between probes. The default is 0 (zero).

host

The destination host name or IP address in dotted quad format.

packetlen

The packet length, in bytes, of the probe datagram. The default is 40 bytes.

-l

Specifies the use of source based routing to determine the interface on which to probe packets.

Example The following example traces a route to a host with an IP address of 192.16.41.218, which is four routers away from the originating host.

The next example traces a source route to a host with an IP address of 10.10.203.1, which is one router away from the originating host.

```
zSH> traceroute 192.16.41.218
traceroute to 192.16.41.218 (192.16.41.218), 30 hops max,
40 byte packets
 1  192.16.92.254  0 ms  0 ms  0 ms
 2  192.16.252.121 64 ms 64 ms 64 ms
```

```

3 192.16.3.254 64 ms 64 ms 64 ms
4 192.16.41.218 64 ms * *

```

```

zSH> traceroute -1 10.10.203.2 10.10.203.1
traceroute to 10.10.203.1 (10.10.203.1), 30 hops max, 40
byte packets
 1 10.10.203.1 10 ms
traceroute Complete

```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also ping, telnet

U

update

The update command changes an existing record.

Syntax `update profile-type index`

Options *profile-type*

The type of profile to update.

index

An index for the record. Some records, such as line profiles, use an index of the form *shelf-slot-port-subport-interface/type*. Other records, such as subscriber records, use an index of the form *n*, where *n* is an integer.

Example The following example updates the system profile:

```

zSH> update system 0
Please provide the following: [q]uit.
syscontact: -----> {Zhone Global Services and Support 7001 Oakport Road
Oakland Ca. (877) Zhone20 (946-6320) Fax (510)777-7113 support@zhone.com}:
sysname: -----> {BAN-2000}:
syslocation: -----> {Oakland}:
enableauthtraps: -----> {disabled}: enabled
setserialno: -----> {0}:
zmsexists: -----> {false}:
zmsconnectionstatus: -> {inactive}:
zmsipaddress: -----> {0.0.0.0}:
configsyncexists: -----> {false}:
configsyncoverflow: --> {false}:
configsyncpriority: --> {high}:
configsyncaction: -----> {noaction}:
configsyncfilename: --> {}:
configsyncstatus: -----> {syncinitializing}:
configsyncuser: -----> {}:
configsyncpasswd: -----> {}:

```

```

numshelves: -----> {1}:
shelvesarray: -----> {}:
numcards: -----> {3}:
ipaddress: -----> {0.0.0.0}: 192.168.8.21
alternateipaddress: --> {0.0.0.0}:
countryregion: -----> {unknown}:
primaryclocksource: --> {0/0/0/0/0}:
ringsource: -----> {internalringsourcelabel}:
revertiveclocksource: -> {true}:
voicebandwidthcheck: --> {false}:
.....
Save changes? [s]lave, [c]hange or [q]uit: s
Record updated.

```

Access Level admin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also **del, get, list, new, show**

updateuser

Updates access levels for a user.

Syntax **updateuser username**

Example zSH> **updateuser jjsmith**

Updating access levels for user (jjsmith)

Please provide the following: [q]uit.

admin: -----> {yes}: **no**

zhonedebug: --> {no}:

voice: -----> {no}:

data: -----> {no}:

manuf: -----> {no}:

database: -----> {no}:

systems: -----> {no}:

tool: -----> {no}:

useradmin: ---> {yes}:

Save changes? [s]lave, [c]hange or [q]uit: **s**

User record updated.

Access Level useradmin

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also **showuser**

upgrade

Displays upgrade status and enables control of the upgrade process.

Syntax **upgrade[show] [set slot boot|nboot] [stop] [continue] [log]**

Options show

Displays the status of the running or terminate upgrade process.

set slot boot|nboot

Specifies whether to reboot or skip a card in the specified slot.

stop

Terminates the upgrade task.

continue

Restarts the upgrade task after termination.

log

Displays contents of the upgrade log file.

Example 1 zSH> upgrade show

```
Upgrade task is running
Status is waiting for peer
```

Example 2 zSH> upgrade show

```
Upgrade task is running
Status is rebooting slot cards
Status of slot 3 is reboot not required
Status of slot 4 is reboot not required
Status of slot 5 is reboot not required
Status of slot 6 is reboot complete
Status of slot 7 is reboot not required
Status of slot 8 is reboot not required
Status of slot 9 is reboot not required
Status of slot 10 is reboot not required
Status of slot 11 is reboot not required
Status of slot 12 is reboot not required
Status of slot 13 is reboot not required
Status of slot 14 is reboot not required
Status of slot 15 is reboot not required
Status of slot 16 is reboot not required
Status of slot 17 is reboot not required
Status of slot 18 is reboot not required
Status of slot 19 is rebooting
Status of slot 20 is reboot not required
Status of slot 21 is reboot not required
```

Example 3 zSH> upgrade show

```
Upgrade task is not running
Status is completed successfully
Message is:
Software upgrade completed successfully!
Status of slot 3 is reboot not required
Status of slot 4 is reboot not required
Status of slot 5 is reboot not required
Status of slot 6 is reboot complete
Status of slot 7 is reboot not required
Status of slot 8 is reboot not required
Status of slot 9 is reboot not required
Status of slot 10 is reboot not required
```

```
Status of slot 11 is reboot not required
Status of slot 12 is reboot not required
Status of slot 13 is reboot not required
Status of slot 14 is reboot not required
Status of slot 15 is reboot not required
Status of slot 16 is reboot not required
Status of slot 17 is reboot not required
Status of slot 18 is reboot not required
Status of slot 19 is reboot complete
Status of slot 20 is reboot not required
Status of slot 21 is reboot not required
```

Example 4

```
zSH> upgrade stop
zSH> No rfc1483 layer on aal5Proxy 24
JUL 06 17:08:41: alert : 1/1/1030: infosrv: _UpgradeTask(): 1=2524:
UpgradeTask: DBUpgrade failed.
Database unchanged.
Software upgrade failed!, 0x21b001c errno = 0x21b001c
```

Access Level admin

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

See Also swact, swupgrade

V

verbose-restore-off

This command is only used by the configuration restore process.

Syntax N/A

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

verbose-restore-on

This command is only used by the configuration restore process.

Syntax N/A

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

videosource

The **videosource** command is used to add, show, and delete interfaces for video signals.

Syntax `videosource add [domain routing-domain] multicast-address interface [vpi/vci]`

routing-domain

Optional domain used for routing.

multicast-address

Address of the multicast interface.

interface

Interface used as the video source.

Syntax `videosource show [multicast-address] [interface]`

multicast-address

Address of the multicast interface.

interface

Interface used as the video source.

Syntax `videosource delete [domain routing-domain]
multicast-address interface [vpi/vci]`

routing-domain

Optional domain used for routing.

multicast-address

Address of the multicast interface.

interface

Interface used as the video source.

Example `zSH> videosource add 224.1.1.2 1-1-1-0/ip`
Added video-source profile

`zSH> videosource show`

Domain: 0 multicastAddr: 224.1.1.1 IfName: 1-1-1-0/ip

Domain: 0 multicastAddr: 224.1.1.2 IfName: 1-1-1-0/ip

Domain: 0 multicastAddr: 224.1.1.3 IfName: 1-1-1-0/ip

Domain: 0 multicastAddr: 224.1.1.4 IfName: 1-1-1-0/ip

`zSH> videosource delete 224.1.1.2 1-1-1-0/ip`

Deleted video-source profile

Access Level Admin

voice

The **voice** command can add, delete, or show voice connections. The following types of voice connections are supported:

- POTS to AAL2, DS1, GR303, V5.2, or VOIP
- ISDN to AAL2 or V5.2

Syntax `voice add subscriber-endpoint remote-endpoint [sub descr]
[enable] framesperpkt number-frames`

add

Add a voice connection between *subscriber-endpoint* and *remote-endpoint*.

subscriber-endpoint

Name and type of the physical interface on the subscriber's side of the voice connection. Values:

pots *interface* [**alaw** | **mulaw**]

isdn *interface*

aal2 *interface* **vp|vc** *VPI/VCI* [**td** *Tx/Rx*] **cid** *CID* [**alaw** | **mulaw**] [**aud** *audio-prf-id*] [**ap** *preferred-ap-id*]

elcp *interface* **vp|vc** *VPI/VCI* [**td** *Tx/Rx*] **port** *port* [**alaw**|**mulaw**] [**aud** *audio-prf-id*] [**ap** *preferred-ap-id*]

voip *IPinterface* **dn** *directory-number* [**name** *username*] [**pw** *password*] [**plar** *dest-ipaddr*] [*codec*] [*t38fax t38-fax*]

interface is the physical interface in format *name/type*.

IPinterface is the IP interface name with the type **ip**.

For GR-303, the interface group must already exist.

For V5.2, the V5.2 interface group must already exist.

For ATM interfaces, the VPI/VCI, the CID, and the traffic descriptor must exist. The **voice add** command will automatically create the VCL if it does not exist.

For VOIP, the IP interface must already exist. The optional *codec* argument sets the preferred-codec when creating a voice connection.

remote-endpoint

Name and type of the physical interface on the remote side of the voice connection. Values:

gr303 *IG/CRV*

v52 *IG/userport* **type** *type* [**cpath** *cpath*]

aal2 *physicalIF* **vc** *vpi/vci* **cid** *cid* [**aud** *aud-prf-id*] [**ap** *pref-ap-id*]

voip *IPinterface* **dn** *directory-number* [**name** *username*] [**pw** *password*] [**plar** *dest-ipaddr*] [*t38fax t38-fax*]

isdnsig *ID*

ds1 *interface* **ds0** *channelnum*

IG is the interface name. This must already exist.

CRV is the GR-303 call reference value.

userport is the V5.2 user port number.

type is isdn or pots.

cpath is the V5.2 cpath.

physicalIF is the address of the physical interface, in the form shelf-slot-port-subport/type. For example, **1-1-1-0/adsl**.

vpi/vci is the VPI/vci pair for the AAL2 interface.

cid is the channel identifier.

aud-prf-id is the audio profile ID.

pref-ap-id is the preferred audio encoding format. 1 is for G.711, 2 is for G.726.

IPinterface is the IP interface for the VOIP connection. This interface must already exist.

directory-number is the VOIP directory number.

username is the VOIP username.

password is the VOIP password.

ID is the ISDN ID.

interface is the address of the physical iDS1 interface, in the form shelf-slot-port-subport/type. For example, **1-1-1-0/adsl**.

channelnum is the number of the DSO for the call.

For ATM interfaces, the VPI/VCI, the traffic descriptor, and the VCL must exist; the **voice add** command will not create them.

esa-ep

Specifies Emergency Standalone support.

```
IpIfname dn dir-num [name username] [pw password] [plar dest-ipaddr]
[reg serverId] [codec pref-codec] [t38fax t38-fax]
```

alaw | mulaw

Indicates whether the voice connection uses Alaw or Mulaw companding. This option sets the following parameters:

For POTS, the **analog-if-cfg-profile** profile **pcmEncoding** parameter.

For AAL2 (non-ISDN), the **aal2-vcl-profile** and **aal2-cid-profile** profile **pcmEncoding** parameter.

sub

Adds a text description to the subscriber-voice profile.

enable

Sets the administrative status of the if-translate of the interface to 'up'.

For ISDN voice connections, this parameter automatically sets the following parameters for the voice connection:

- atm-vcl: vcc aal5 pcs transmit and receive sdu size
- aal2-vcl-profile: timer-cu, frame-mode-data, cas, trunk-type, pcm-encoding, and ras-timer
- aal2-cid-profile: frame-mode-data, cas, and pcm-encoding

framesperpkt

Specifies the number of frames per packet in a voice connection. The available range is 1 to 7 packets. This parameter updates the setting in the subscriber-voice-voip profile.

Syntax `voice delete subscriber-endpoint`

delete

Delete the voice connection from **subscriber** *subscr-info*.

subscriber-endpoint

Name and type of the physical voice connection.

Syntax `voice show [-l POTSPHysicalIf] | [endpoint] [-v]`

-l POTSPHysicalIf

Displays the voice connections for the specified POTS physical interface.

endpoint

Displays the voice connections on the system. For V5.2 voice connections, also displays POTS or ISDN connection type. For AAL2 voice connections, also displays VP for VP-switched or VC for VC-switched.

This command can also be used to display voice connection data for a specific endpoint.

-v

Displays verbose out for voice connections.

Example 1 This example adds a voice connection from subscriber's POTS line to a GR-303 interface with IG 1 and CRV 45.

```
zSH> voice add pots 1-4-5-0/voicefxs gr303 1/45
```

Example 2 This example displays the voice connections currently configured on the system and displays the voice connections for a specified POTS interface.

```
zSH> voice show
Subscriber end-point          Remote end-point          STA
-----
1-1-1-0/voicefxs            1-1-1-0/fast VC 0/38 CID 16  ENA
1-1-2-0/voicefxs            1-1-1-0/fast VC 0/38 CID 17  ENA
Total number of voice connections : 2
```

```
zSH> voice show -l 1-9-9-0/voicefxs
Subscriber end-point          Remote end-point          STA
-----
1-9-9-0/voicefxs            uplink4-0-32/ip 9824008  DIS
```

Example 3 This example adds a POTS to AAL2 connection over an ATM VCL with a VPI/VCI of 0/38 and a CID of 16:

```
zSH> voice add pots 1-1-1-0/voicefxs aal2 1-1-1-0/adsl vc 0/38 cid 16
Created subscriber 1/12
Created subscriber-voice 1/12/1
Created subscriber-voice-pots 7
```

```
Created aal2-cid-profile 13/0/38/16
Created subscriber-voice-aal2 8
```

Example 4 This example deletes a POTS subscriber profile:

```
zSH> voice delete pots 1-1-1-0/voicefxs
Deleted aal2-cid-profile 13/0/38/16

Deleted subscriber-voice 1/12/1 and its
subscriber-voice-xxx profiles
```

Example 5 This example creates a POTS to VOIP subscriber profile:

```
zSH> voice add pots 1-1-3-0/voicefxs voip 1-1-1-0/ip DN 5105220428
Created subscriber-voice 1/66/2
Created subscriber-voice-pots 1004
Created subscriber-voice-voip 1005
```

Example 6 This example creates a VOIP to ISDN subscriber profile:

```
zSH> voice add voip 1-1-1-0/ip DN 1055558724 isdnsig 1
Created subscriber 1/4
Created subscriber-voice 1/4/1
Created subscriber-voice-voip 1024
Created subscriber-voice-isdnsig 1025
```

Example 7 This example creates a POTS to GR303 subscriber profile with IG 1 and CRV 2:

```
zSH> voice add pots 1-8-1-0/voicefxs gr303 1/2
Created subscriber 1/13
Created subscriber-voice 1/13/1
Created subscriber-voice-pots 20
Created gr303-ig-crv 1/2
Created subscriber-voice-gr303 21
```

Example 8 This example creates an AAL2 to GR303 VP-switched connection between the uplink interface uplink1 and the voice gateway card:

```
zSH> voice add atm uplink1/atm vp 0/101 td 1/1 cid 1 alaw
gr303 1/1 type pots
Created subscriber-voice 1/51/2
Created aal2-cid 109/16/101/1/1
Created subscriber-voice-aal2 15
Created gr303-cid 1/1/2
Created subscriber-voice-gr303 16
```

Example 9 This example creates an ELCP to V5.2 VP-switched connection between the uplink interface uplink2 and the voice gateway card:

```
zSH> voice add elcp uplink2/atm vc 7/111 td 1/1 port 1
alaw v52 1/0
type isdn cpath 5
Created subscriber-voice 1/35/16
Created atm-vcl uplink2/atm/7/111
```

```

Created atm-vcl 1-3-3-0-aal2proxy/atm/0/32
Created atm-cc 8
Created aal2-vcl-profile 1-3-3-0-aal2proxy/atm/0/32
Created aal2-elcp-port 109/0/32/1/2
Created subscriber-voice-elcp-aal2 39
Created v52-user-port 1/0/3
Created subscriber-voice-v52 40
Created subscriber-voice 1/35/17
Created subscriber-voice-elcp-aal2 41
Created subscriber-voice-v52 42
Created subscriber-voice 1/35/18
Created subscriber-voice-elcp-aal2 43
Created subscriber-voice-v52 44

```

Example 10

```
zSH> voice show pots 1-7-9-0/voicefxs
```

```
INPUT:
```

```

profile type: subscriber-voice-pots
logical address: LGId: 330 PotsNumber: 1
profile address: 39

```

```
subscriber-voice INFO:
```

```

voice-connection-type      = VOIPTOPOTS
voice-endpoint1-addr-index = 40
voice-endpoint2-addr-index = 39
voice-admin-status        = Enabled
subscriber-voice addr: subId: 1 LGId: 3

```

```
subVoiceId: 5
```

```
MATCHING:
```

```

profile type: subscriber-voice-voip
logical address: LGId: 72 EndPtIdx: 40
profile address: 40

```

```
zSH> voice show elcp 1-1-1-0/sonet VP 0/331 port 1 type pots
```

```
INPUT:
```

```

profile type: subscriber-voice-elcp-aal2
logical address: LGID: 93 VPI: 16 VCI: 331 PortId:1 PortType:1

```

```
isdnChannelId:0
```

```
profile address: 1
```

```
subscriber-voice INFO:
```

```

voice-connection-type      = ELCPAAL2TOV52
voice-endpoint1-addr-index = 1
voice-endpoint2-addr-index = 2
voice-admin-status        = Enabled
subscriber-voice addr: subId: 1 LGId: 25 subVoiceId: 1

```

```
MATCHING:
```

```

profile type: subscriber-voice-v52
logical address: IfName: IG-107 UserId: 20 IsdnBChannelId: 0
profile address: 2

```

```
zSH> voice show v52 1/20 type pots
```

```
INPUT:
```

```

profile type: subscriber-voice-v52
logical address: IfName: IG-107 UserId: 20 IsdnBChannelId: 0

```

```

    profile address: 2
subscriber-voice INFO:
    voice-connection-type      = ELCPAAL2TOV52
    voice-endpoint1-addr-index = 1
    voice-endpoint2-addr-index = 2
    voice-admin-status         = Enabled
    subscriber-voice addr: subId: 1 LGID: 25
subVoiceId: 1
MATCHING:
    profile type: subscriber-voice-elcp-aal2
    logical address: LGID: 93 VPI: 16 VCI: 331 PortId:1
PortType:1 isdnChannelId:0
    profile address: 1

zSH> voice show elcp 1-1-1-0/sonet VP 1/2020 port 1 type isdn
INPUT:
    profile type: subscriber-voice-elcp-aal2
    logical address: LGID: 250 VPI: 17 VCI: 2020 PortId:1 PortType:2
isdnChannelId:0
    profile address: 11133
subscriber-voice INFO:
    voice-connection-type      = ELCPAAL2TOV52
    voice-endpoint1-addr-index = 11133
    voice-endpoint2-addr-index = 11134
    voice-admin-status         = Enabled
    subscriber-voice addr: subId: 1 LGID: 182 subVoiceId: 1862
MATCHING:
    profile type: subscriber-voice-v52
    logical address: IfName: IG-117 UserId: 20 IsdnBChannelId: 0
    profile address: 11134
INPUT:
    profile type: subscriber-voice-elcp-aal2
    logical address: LGID: 250 VPI: 17 VCI: 2020 PortId:1 PortType:3
isdnChannelId:1
    profile address: 11135
subscriber-voice INFO:
    voice-connection-type      = ELCPAAL2TOV52
    voice-endpoint1-addr-index = 11135
    voice-endpoint2-addr-index = 11136
    voice-admin-status         = Enabled
    subscriber-voice addr: subId: 1 LGID: 182 subVoiceId: 1863
MATCHING:
    profile type: subscriber-voice-v52
    logical address: IfName: IG-117 UserId: 20 IsdnBChannelId: 1
    profile address: 11136
INPUT:
    profile type: subscriber-voice-elcp-aal2
    logical address: LGID: 250 VPI: 17 VCI: 2020 PortId:1 PortType:3
isdnChannelId:2
    profile address: 11137
subscriber-voice INFO:
    voice-connection-type      = ELCPAAL2TOV52
    voice-endpoint1-addr-index = 11137
    voice-endpoint2-addr-index = 11138

```

```

voice-admin-status          = Enabled
subscriber-voice addr: subId: 1 LGId: 182 subVoiceId: 1864
MATCHING:
profile type: subscriber-voice-v52
logical address: IfName: IG-117 UserId: 20 IsdnBChannelId: 2
profile address: 11138

zSH> voice show v52 2/20 type isdn
INPUT:
profile type: subscriber-voice-v52
logical address: IfName: IG-117 UserId: 20 IsdnBChannelId: 0
profile address: 11134
subscriber-voice INFO:
voice-connection-type      = ELCPAAL2TOV52
voice-endpoint1-addr-index = 11133
voice-endpoint2-addr-index = 11134
voice-admin-status        = Enabled
subscriber-voice addr: subId: 1 LGId: 182 subVoiceId: 1862
MATCHING:
profile type: subscriber-voice-elcp-aal2
logical address: LGID: 250 VPI: 17 VCI: 2020 PortId:1 PortType:2
isdnChannelId:0
profile address: 11133
INPUT:
profile type: subscriber-voice-v52
logical address: IfName: IG-117 UserId: 20 IsdnBChannelId: 1
profile address: 11136
subscriber-voice INFO:
voice-connection-type      = ELCPAAL2TOV52
voice-endpoint1-addr-index = 11135
voice-endpoint2-addr-index = 11136
voice-admin-status        = Enabled
subscriber-voice addr: subId: 1 LGId: 182 subVoiceId: 1863
MATCHING:
profile type: subscriber-voice-elcp-aal2
logical address: LGID: 250 VPI: 17 VCI: 2020 PortId:1 PortType:3
isdnChannelId:1
profile address: 11135
INPUT:
profile type: subscriber-voice-v52
logical address: IfName: IG-117 UserId: 20 IsdnBChannelId: 2
profile address: 11138
subscriber-voice INFO:
voice-connection-type      = ELCPAAL2TOV52
voice-endpoint1-addr-index = 11137
voice-endpoint2-addr-index = 11138
voice-admin-status        = Enabled
subscriber-voice addr: subId: 1 LGId: 182 subVoiceId: 1864
MATCHING:
profile type: subscriber-voice-elcp-aal2
logical address: LGID: 250 VPI: 17 VCI: 2020 PortId:1 PortType:3
isdnChannelId:2
profile address: 11137

```

```

zSH> voice show voip voip-1-1/ip DN 7292004
INPUT:
  profile type: subscriber-voice-voip
  logical address: LGId: 126 EndPtIdx: 63
  profile address: 63
subscriber-voice INFO:
  voice-connection-type      = VOIPTOGR303
  voice-endpoint1-addr-index = 63
  voice-endpoint2-addr-index = 64
  voice-admin-status         = Enabled
  subscriber-voice addr: subId: 1 LGId: 112
subVoiceId: 32
MATCHING:
  profile type: subscriber-voice-gr303
  logical address: IgName: 1 Crv: 2004
  profile address: 64

```

```

zSH> voice show gr303 1/2004
INPUT:
  profile type: subscriber-voice-gr303
  logical address: IgName: 1 Crv: 2004
  profile address: 64
subscriber-voice INFO:
  voice-connection-type      = VOIPTOGR303
  voice-endpoint1-addr-index = 63
  voice-endpoint2-addr-index = 64
  voice-admin-status         = Enabled
  subscriber-voice addr: subId: 1 LGId: 112
subVoiceId: 32
MATCHING:
  profile type: subscriber-voice-voip
  logical address: LGId: 126 EndPtIdx: 63
  profile address: 63

```

Access Level admin

voice ring

Verify voice connection without placing a call. The **voice status** command can be used to verify the phone's ring status if the ringing cannot be heard.

Syntax `voice ring pots-intfc [ring-cadence] [time]`

- *pots-intfc* is the physical interface, for example 1-14-1-0/voicefxs.
- *ring-cadence* is r0 to r7, rc or rs. The default setting is rc.
- *time* is the number of seconds to ring the phone. This number must be greater than 0. The default time is 15 seconds.

Options `pots-intfc`

Specifies the physical interface, for example 1-14-1-0/voicefxs.

ring-cadence

Optional ring-cadence of r0 to r7, rc or rs. The default setting is rc.

time

Optionally, specifies the number of seconds to ring the phone. This number must be greater than 0. The default time is 15 seconds.

Example `voice ring 1-14-1-0/voicefxs`

See Also `voice status`

voice status

Display runtime status of voice ports. Only status for POTS connections is currently supported.

Syntax `voice status [-t] [type] [shelf [slot [port]]] [endpoint]`

Options **t**

Displays only voice status totals.

type

Displays voice status for the specified call type.

shelf

Displays voice status for the specified shelf.

slot

Displays voice status for the specified slot.

port

Displays voice status for the specified port.

endpoint

Displays voice status for the specified endpoint.

Example

```
zSH> voice status -t
Totals: ports: 576, admin-state up: 4, active calls: 0
```

```
zSH> voice status
      port          term state  destination          call state  hook  ring
      ----          -
1-10-48-0/voicefxs Inact Not  provisioned          ON        Ring
1-10-47-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-46-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-45-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-44-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-43-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-42-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-41-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-40-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-39-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-38-0/voicefxs Inact Not  provisioned          ON       NoRing
1-10-37-0/voicefxs Inact Not  provisioned          ON       NoRing
```

```

1-10-36-0/voicefxs  Inact Not provisioned           ON  NoRing
1-10-35-0/voicefxs  Inact Not provisioned           ON  NoRing
1-10-34-0/voicefxs  Inact Not provisioned           ON  NoRing
1-10-33-0/voicefxs  Inact Not provisioned           ON  NoRing
1-10-32-0/voicefxs  Inact Not provisioned           ON  NoRing
Type A<CR> to print all, <CR> to continue, Q<CR> to stop:

```

zSH> voice status 1 10 48

```

      port          term state  destination          call state  hook  ring
      ----          -
1-10-48-0/voicefxs  Inact Not provisioned          ON  RING
Totals:  ports: 1, admin-state up: 0, active calls: 0

```

zSH> voice status pots 1-6-1-0/voicefxs

```

      port          term state  destination          call state  hook  ring
      ----          -
1-6-1-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-2-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-3-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-4-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-5-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-6-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-7-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-8-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-9-0/voicefxs   Inact Not provisioned          ON  NoRing
1-6-10-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-11-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-12-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-13-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-14-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-15-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-16-0/voicefxs  Inact Not provisioned          ON  NoRing
1-6-17-0/voicefxs  Inact Not provisioned          ON  NoRing
Type A<CR> to print all, <CR> to continue, Q<CR> to stop: q
Totals:  ports: 576, admin-state up: 4, active calls: 0

```

voice status ig

Display real-time status of voice ports.

Syntax `voice ig gr303|v52 igName`

Options `ig`

Displays voice status for the specified GR303 or V5.2 interface group.

Example `zSH> voice status ig gr303 test`
Status for gr303 interface group test:
Admin status = in service
Oper status = inoperable
Active calls = 0
Switch type = norteldms100
TMC primary state = out of service

```
TMC secondary state = out of service
EOC primary state = out of service
EOC secondary state = out of service
```

```
zSH> voice status ig v52 one
Status for v52 interface group one:
Admin status = in service
Oper status = inoperable
Oper status cause = local disable
Active calls = 0
Switch vendor = ericsson
  LinkId 0  TS 15  Channel status failed
  LinkId 0  TS 16  Channel status failed
  LinkId 1  TS 15  Channel status failed
  LinkId 1  TS 16  Channel status failed
  CPath 1   Oper status down
  CPath 2   Oper status down
  CPath 3   Oper status down
  CPath 4   Oper status down
  CPath 5   Oper status down
zSH>
```

voice vpdelete

The **voice vpdelete** command deletes the specified VP tunnel between the uplink interface and the voice gateway card.

Syntax `voice vpdelete interface vpi`
interface

Specifies the uplink card interface.

vpi

Specifies the VPI to be deleted.

Example This command deletes the VP tunnel for VP 0 between the uplink interface and the voice gateway card.

```
zSH>voice uplink/atm 0
```

Access Level admin

voice vpiadd

The **voice vpiadd** command builds the ATM VPI between the uplink card and the voice gateway card aal2proxy on the specified VP. This command is used for VP-switched connections

Syntax `voice vpiadd interface vpi gr303|v52 ig MaximumVcis`
interface

Specifies the uplink card interface.

vpi

The VPI to be used for this connection.

gr303 | v52

Indicates whether the voice connection connects to a GR-303 or V5.2 protocol switch.

ig

Specifies the interface group (IG) to be used for this connection.

For V5.2 and GR-303, the IG must already exist.

MaximumVcis

Specifies the maximum number of VCIs to be used for this VP-switched connection.

Example This example uses the uplink interface *uplink/atm* with VP 0. The voice call type is V5.2 with IG 1. The maximum number of VCs allocated to the specified VP-switched VPI is 2004.

```
zSH>voice vpiadd uplink/atm 0 v52 1 2004
Created atm-vpi 1-3-3-0-aal2proxy/atm/20
Created atm-vpi uplink1/atm/7
```

Access Level admin

voice vpladd

The **voice vpladd** command builds the VPLs and cross connects for VP-switched connections. This command applies to the voice gateway card only.

Syntax `voice vpladd interface vpi td rx/rx gr303|v52 ig`

interface

Specifies the uplink card interface.

vpi

The VPI to be used for this connection.

td rx/tx

The receive and transmit traffic descriptors to be used for this connection.

gr303 | v52

Indicates whether the voice connection connects to a GR-303 or V5.2 protocol switch:

ig

Specifies the interface group (IG) to be used for this connection.

The IG must already exist.

Example This command builds atm-vpl uplink1/atm/0 on the uplink card using traffic descriptor 1/1 and atm-vpl 1-3-3-0-aal2proxy/atm/16 on the voice gateway card. VP 16 is the first available VP in the allowed VP range on the voice gateway card. The ATM cross connect number is 6.

```
zSH>voice vpladd uplink/atm 0 td 1/1 v52 1
Created atm-vpl 1-3-3-0-aal2proxy/atm/20
Created atm-vpl uplink1/atm/7
Created atm-cc 6
```

Access Level admin

voicegateway

The **voicegateway** command can add, show or delete voicegateway connections. The following types of voice connections are supported:

- VoATM: BLES to GR303 or V5.2
- VoATM: ELCP to V5.2
- VoIP: SIP-PLAR to GR303 or V5.2

Syntax `voicegateway add [-v] interface td traffic-descriptor ip-address`

add

Add a voicegateway connection for the specified AAL5 proxy physical interface or slot number of the voicegateway card, traffic descriptor, and IP address. This command also automatically creates the voip-server-entry 255/255 for multiple SIP server support if it does not already exist.

interface

A valid AAL5 proxy physical interface or slot number of the voicegateway card.

traffic-descriptor

The desired traffic descriptor.

ip-address

The IP address that is part of the configured ip-unnumbered-record.

Syntax `voicegateway delete interface`

interface

A valid AAL5 proxy physical interface or slot number of the voicegateway card.

Syntax `voicegateway show interface`

interface

A valid AAL5 proxy physical interface or slot number of the voicegateway card.

Example 1 These examples add a host on the voicegateway line card in slot 8 and assign the IP address 10.10.10.2.

```
zSH> voicegateway add 1-8-1-0/aal5proxy td 1 10.10.10.2
```

```
zSH> voicegateway add 8 td 1 10.10.10.2
```

Example 2 These examples display the voicegateway connection for the specified interface and AAL5 proxy or slot number of the voicegateway card.

```
zSH> voicegateway show 1-8-1-0/aal5proxy
Rd/Address      Interface
-----
1 10.10.10.1    1-8-1-0-aal5proxy-0-32  0/32  0      S 10.10.10.2
```

```
zSH> voicegateway show 1-8-1-0/aal5proxy
Rd/Address      Interface
-----
1 10.10.10.1    1-8-1-0-aal5proxy-0-32  0/32  0      S 10.10.10.2
```

Example 3 This example adds an ATM voice interface on the uplink card in slot 1, port 1 and assigns the virtual connection vpi 0, vci 139 and cid 48. The TDM connection uses GR303 protocol and interface group 1 with crv 131.

```
zSH> voice add aal2 1-1-1-0/ds1 vc 0/139 cid 48 gr303 1/131
Created subscriber-voice 1/266/6
Created aal2-cid-profile 340/0/32/48
Created subscriber-voice-aal2 171
Created gr303-ig-crv 1/131
Created subscriber-voice-gr303 172
```

Example 4 This example displays the voicegateway connection for the configured ATM interface:

```
zSH> voicegateway show aal2 1-1-1-0/ds1
Subscriber end-point      Remote end-point      Voice Prof Id      STA
-----
.....
1-1-1-0/ds1 VC 0/139 CID 48  GR303 one/131      1/266/6      ENA
```

Example 5 These examples delete the voicegateway connection for the configured interface 1-8-1-0/aal5proxy. To remove the configured voice gateway connection, use the **voicegateway delete** command with the configured interface and aal5proxy or slot number of the voicegateway card. Do not attempt to manually remove or edit the related subscriber-voice profiles.

```
zSH>voicegateway delete 1-8-1-0/aal5proxy
```

```
zSH>voicegateway delete 8
```

Access Level admin

voice stat

The **voice stat** command displays the following statistics for voice connections.:

- POTS port

- Incoming Calls Completed
- Incoming Calls Blocked
- Outgoing Calls Completed
- Outgoing Calls Blocked
- Active Calls
- SIP UA/MGCP
 - Incoming Calls Completed
 - Incoming Calls Blocked
 - Outgoing Calls Completed
 - Outgoing Calls Blocked
 - Active Calls
- Card and System Call Statistics
 - Incoming Calls Completed
 - Incoming Calls Blocked
 - Outgoing Calls Completed
 - Outgoing Calls Blocked
 - Active Calls

Syntax `voicestat type [shelf slot] | [subscriber endpoint index] | [endpt-info]`

Type

Specifies voice statistics to be displayed for system, card, or subscriber.

Shelf

For card type, enter the shelf number of the card.

Slot

For card type, enter the slot number of the card.

Subscriber endpoint index

End point index for a subscriber. The subscriber endpoint index can be displayed using the **list subscriber-voice** command.

Endpt-info

Endpoint of a voice connection. For example, gr303 1/92 for a GR-303 voice endpoint or pots 1-7-3-0/voicfxs for a POTS voice endpoint.

Example 1 This example displays voice statistics for the current system.

```
zSH> voicestat system
zSH> ***** Voice stats *****
Incoming blocked           0
Incoming completed        0
Outgoing blocked          0
Outgoing completed        0
```

```
Active calls          5
```

Example 2 This example displays voice statistics for the card in shelf 1 and slot 8.

```
zSH> voicestat card 1 8
zSH> ***** Voice stats *****
Incoming blocked      0
Incoming completed    0
Outgoing blocked      0
Outgoing completed    0
Active calls          5
```

Example 3 This example displays voice statistics for specified POTS subscriber with index 3. Use the **list subscriber-voice** commands to list the current POTS voice subscribers and the subscriber index numbers.

```
zSH> list subscriber-voice-pots
subscriber-voice-pots 1
subscriber-voice-pots 3
subscriber-voice-pots 5
subscriber-voice-pots 7
4 entries found.
```

```
zSH> voicestat subscriber 3
***** Subscriber Voice Stats *****
Incoming blocked      0
Incoming completed    2
Outgoing blocked      0
Outgoing completed    0
Active calls          0
```

Access Level admin

W

who

Displays the names of all users currently logged into the system.

Syntax who

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sechtor 100A, Z-Edge 64

See Also logout

whoami

Displays the username of the current session.

Syntax whoami

Access Level user

Products BAN, MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723, Sehtor 100A, Z-Edge 64

See Also `logout`, `su`

Z

zrgconfig

For the ZRG 800 series devices, you must assign the VPI to be used for the ATM connections. If you are connecting to a MALC PON OLT card, each ZRG connected must have a unique VPI/VCI pair. (ZRG devices connected to different PON OLT cards can use the same VPI/VCI.) You can assign a VPI from 1 to 32.

Optionally, you can use this command to provision the ZRG to support VOIP calls.

Syntax `zrgcfg pon vpi [voatm | voip]`

Options `voatm`

Configures the **card-line-type** in the **card-profile** as **pots-pv** for packet voice.

`voip`

Configures the **card-line-type** in the **card-profile** as **pots** for non-packet voice.

Example To have the ZRG autcreate the necessary voice, data, and video profiles using VPI 1, enter the following command:

```
zSH> zrgcfg pon 1
```

Notes If there are pre-existing voice connections, you must delete them before changing to VOIP mode. For example:

```
zSH> voice delete pots 1-1-1-0/voicefxs
```

```
Deleted aal2-cid-profile 13/0/39/16
```

```
Deleted subscriber-voice 1/6/1 and its
subscriber-voice-xxx profiles
```

Products ZRG

ALPHABETIC LIST OF PARAMETERS

access-table-index.....	368	atmVplTransmitTrafficDescrIndex.....	231
accm-enable.....	342	audio-profile-identifier.....	232
acfc-enable.....	342	audio-service.....	232
ackedseqno.....	414	audio-service.....	299
addr.....	327	auth-key.....	356
admin_status.....	229	auth-type.....	356
admin-state.....	355	auto-learn.....	341
admin-status.....	229	autoNegCap.....	302
admin-status.....	251	autonegstatus.....	303
adminstatus.....	302	bcastaddr.....	327
adminStatus.....	313	bcastenabled.....	327
adminStatus.....	319	betaValue.....	325
admin-status.....	381	block (V5.2 link).....	383
admin-status-enable.....	252	block (V5.2 user port).....	382
adslAlarmConfProfile.....	217	bootfile.....	264
adslChannelMode.....	217	boot-server.....	264
adslLineDTMConfMode.....	217	bridgeConfigType.....	247
adslMaxDownstreamToneIndex.....	218	bridgeConfigValue.....	247
adslMaxUpstreamToneIndex.....	218	bridgeIfConfigGroupIndex.....	247
adslMinDownstreamToneIndex.....	218	bridgeIfCustomDHCP.....	248
adslMinUpstreamToneIndex.....	218	buf-max-size.....	259
adslNTRModeEnabled.....	219	cac-divider.....	233
adslPotsBypassRelayMaxDuration.....	219	callback-dial-string.....	342
AdslTransmissionMode.....	219	callback-enable.....	343
AdslTrellisModeEnabled.....	219	callback-type.....	343
algorithm.....	229	call-mode.....	343
alphaValue.....	325	capable-line-rate-limit.....	376
alternateipaddress.....	327	card-atm-configuration.....	252
app-id.....	230	card-group-id.....	252
apsChanConfigAdminStatus.....	370	card-line-type.....	254
apsChanConfigGroupName.....	370	cas.....	233
apsChanConfigNumber.....	371	cas.....	259
apsChanConfigPriority.....	371	cc-index.....	233
apsConfigCreationTime.....	371	cell-loss-integration-period.....	260
apsConfigDirection.....	371	cell-scramble.....	279
apsConfigExtraTraffic.....	371	channelization.....	280
apsConfigMode.....	372	channelization.....	287
apsConfigRevert.....	372	channel-number.....	313
apsConfigsdBerThreshold.....	372	chap-enable.....	344
apsConfigsfBerThreshold.....	372	chap-name.....	344
apsConfigWaitToRestore.....	373	chap-secret.....	344
atmVplAdminStatus.....	230	check-id.....	383
atmVplCastType.....	231	circuit-id.....	280
atmVplConnKind.....	231	circuit-id.....	288
atmVplReceiveTrafficDescrIndex.....	231	client-hostname.....	264

client-identifier	264	ds0-channel-id	395
client-match-length	265	ds1-for-remote-loop	288
client-match-offset	265	ds1-group-number	281
client-match-string	265	ds1-line-group	395
clksrc	304	ds1LM:array[1..28]	314
clock-external-recovery	373	ds1-mode	281
clock-source-eligible	280	dsn-lg-id	384
clock-transmit-source	261	dsx-line-length	282
clock-transmit-source	373	echo-cancellation-type	395
community-name	368	echo-return-loss	396
comp-slot-id	344	egressfilterid	328
config-line-rate	293	enable	328
connect-mode	294	enableauthtraps	378
control-channel-t303	313	ends	268
control-channel-t396	313	expires-invite-value	406
coset-polynomial	281	expires-register-method	407
countryregion	378	expires-register-value	406
c-path-valid-flag	383	external-server	268
csu-line-length	281	farendaddr	329
ctrlChannel	314	far-end-equip-code	288
customARP	248	far-end-fac-id-code	288
data-access	404	far-end-frame-id-code	289
database-access	404	far-end-loc-id-code	289
debug access	404	far-end-unit-code	289
decoder-coeffA	294	fastMaxTxRate	220
decoder-coeffB	295	fastMinTxRate	221
defaultLease	265	fault-detection-type	233
default-lease-time	266	fcs-alt-enable	345
default-metric	356	fcs-size	345
default-router	266	fdl	282
destaddr	328	features	396
destination-ip-address	260	filterBroadcast	248
destination-name	406	first-nameserver	278
destination-port	260	fix-bit-rate	295
dhcp	266	flags	268
dhcpClientErrors	266	forwardToDefault	249
dhcpClientId	267	forwardToMulticast	249
dhcpserverenable	328	forwardToUnicast	249
dialplan-type	406	frame-mode-data	234
diffDelayMax	324	framer-type	295
directory-number	406	frames-per-packet	407
dns	267	frame-sync-word	295
dns-fwd-name	267	frame-type	345
dns-rev-name	267	fxo-cfg-signal-type	307
domain	267	g711-fallback	407
domain	277	g726-byte-order	407
domainName	267	gammaValue	325
domain-name	268	groupSymmetry	322
downshiftSnrMgn	220	guaranteed-bw	341
ds0-bundle	260	hardware-address	269

high-if-index	234	ip-ifindex	346
high-vci	234	ip-interface-index	408
high-vpi	234	ip-tos	408
hold-active	256	ipUnnumberedinterface	330
hookflash-max-timer	397	isdn-channel-id	299
hookflash-min-timer	397	isdnds-cpath-id	335
hostalias1	278	isdnds-cpath-id	385
hostalias2	278	isdn-env-func-start-address	335
hostalias3	278	isdn-env-func-start-address	384
hostalias4	278	isdnf-cpath-id	385
hostName	269	isdnp-cpath-id	385
hostname	278	jitter-buffer-size	398
huntgroup	397	jitter-buffer-type	398
hunt-group-index	397	keep-alive-timer	408
iad-type	376	learnIP	249
id (V5.2 link)	384	learnMulticast	250
id (V5.2 path)	384	learnUnicast	250
idt-admin-state	314	lease-time	270
if-cfg-impedence	308	lgid	347
if-cfg-pcm-encoding	308	line-code	283
if-cfg-receive-tlp	309	line-coding	289
if-cfg-receive-tlpNum	310	line-group-id	300
if-cfg-transmit-tlp	310	line-group-id	335
if-cfg-transmit-tlpNum	310	line-group-id	376
if-cfg-trunk-conditioning	308	line-length-meters	290
ifindex	320	line-power	283
ifIndex	337	line-rate-limit	377
if-maintenance-mode	308	line-status-change-trap-enable	283
ifname	320	line-status-trap-enable	290
ifType	304	line-status-trap-enable	296
iftype-extension	320	line-type	284
inbound-calls	384	line-type	290
ingressfilterid	329	line-type	296
initFailureTrapEnable	221	link-is-timer	385
initial-mru	345	link-oos-timer	386
inter-arriv-jit-threshold	397	link-type	347
interdigit-timeout	408	link-valid-flag	386
interleaveMaxTxRate	221	local-admin-state	314
interleaveMinTxRate	222	local-interface-id	386
ipaddr1	269	local-ipaddr	330
ipaddr2	269	local-port	330
ipaddr3	270	local-prov-variant	386
ipaddr4	270	local-timezone	339
ipaddrdynamic	329	logical-channel-id (C-channel)	387
ip-addr-enable	346	logical-channel-id (C-path)	386
ipaddress	278	logical-id	314
ip-address	368	loopback-config	284
ipaddress	378	loopback-config	291
ip-comp-protocol	346	low-if-index	234
ipfwdenabled	329	low-vci	235

low-vpi	235	min-lease-time	271
lqr-period	347	minNumRxLinks	323
lqr-status	347	minNumTxLinks	323
magic-number	348	minSnrMgn	224
magic-number-enable	348	minUpshiftSnrMgn	224
malicious-caller-uri	399	min-uuui	271
manuf-access	378	mode	394
match-string	409	mru	331
mauType	305	mru-enable	350
max-cid-for-aal2-user-channels	235	multicastAgingPeriod	331
max-config-retries	348	n200	387
max-cps-sdu-size	235	n201	387
max-fail-retries	349	name	256
max-failure-retries	349	name	271
maximum-bw	341	name	377
maxInterleaveDelay	222	name-group-id	377
max-lease-time	270	name-id	315
max-length-frame	235	natenabled	332
max-length-frame	300	national-pstn-region	388
max-number-multiplex-channels	235	netmask	272
max-outstanding-frames	387	netmask	332
max-pad	349	network	272
max-sdu-length	236	ntr	297
max-sdu-length	300	number-of-digits	409
max-slot-id	349	numcards	379
maxSnrMgn	223	num-channels	350
max-terminate-retries	350	num-mode-enable	351
max-term-retries	350	numshelves	379
maxUnicast	250	numunits	321
max-uuui	270	olt-onu-password	341
maxVideoStreams	330	olt-onu-serial-num	342
mcastcontrollist	330	outgoingCOSOption	332
mcastenabled	330	outgoingCOSValue	332
mcastfwdenabled	331	pap-enable	348
medium-atmframe-config	291	pap-password	351
medium-cell-scramble-config	373	pap-peer-id	351
medium-cell-scramble-config	375	partial-fill	260
medium-circuit-identifier	374	path-current-width	376
medium-frame-config	291	pcm-encoding	236
medium-line-coding	374	pcm-encoding	300
medium-line-scramble-config	374	permissions	379
medium-line-type	374	pfc-enable	352
medium-loopback-config	375	physical-flag	321
medium-scramble-config	292	pkts-lost-threshold	399
medium-type	375	pkt-time	236
metric	331	pointtopoint	297
min-cid-for-aal2-user-channels	236	poison	356
minDownshiftSnrMgn	223	port	321
minDownshiftTime	223	port-alignment-request	388
minLease	271	port-id	300

port-type.....	300	remotefault	357
portType.....	332	resendseqno	414
power-scale	297	reserve-end	274
preferred-ap-index	236	reserve-start	274
preferred-ap-index	301	restart.....	275
preferred-codec	409	restart.....	306
prefix-add.....	409	restart-timer	352
prefix-strip	409	restart-timer	354
primaryclocksource.....	262	reversion-mode.....	307
primaryclocksource.....	379	revertiveclocksource	262
primary-name-server.....	272	revertiveclocksource	380
primary-ntp-server-ip-address	338	ring-back	311
protection-fast-timer	306	ring-frequency	311
protection-group	388	ringSource	337
protection-slow-timer	306	ringsource	380
protection-wtr	306	role.....	315
protocol.....	410	role.....	390
protocol-emulation.....	285	rs232AsyncPortAutobaud	361
protocol-spec.....	389	rs232AsyncPortBits.....	361
prov-variant-request.....	389	rs232AsyncPortParity	361
pstn-layer-3-start-address	389	rs232AsyncPortStopBits	361
public-ipaddr.....	333	rs232PortInFlowType	360
public-port.....	333	rs232PortInSpeed	360
quality-protocol.....	352	rs232PortOutFlowType.....	360
query-order	279	rs232PortOutSpeed	360
range1-end	272	rtcp-enabled.....	410
range1-start	273	rtcp-packet-interval	410
range2-end	273	rx-acc-map.....	353
range2-start	273	rxTimingRefLink	327
range3-end	273	sapi-0-max-outstanding-frames.....	316
range3-start	273	sapi-0-n-200	316
range4-end	274	sapi-0-pps-mode.....	316
range4-start	274	sapi-0-t-200	316
ras-timer.....	237	sapi-0-t-203	317
rateChanRatio	224	sapi-1-max-outstanding-frames.....	317
rateMode.....	224	sapi-1-n-200	317
rdindex	333	sapi-1-pps-mode.....	317
rdt-admin-state.....	315	sapi-1-t-200	318
reachExtendedAdsl2.....	225	sapi-1-t-203	318
reasmmaxsize.....	333	sdp-enable	353
receive_traffic_descr_index.....	237	sdu-multiples	237
receive-auth-enable.....	352	secondary-name-server	275
receive-auth-protocol.....	353	secondary-ntp-server-ip-address	338
receive-type.....	357	second-nameserver	279
redundancy-over-subscription-type	399	send-auth-enable	354
redundancy-param1	321	send-auth-identity.....	353
reg-or-lease-user	390	send-auth-protocol.....	354
reject-enabled.....	400	send-call-proceeding-tone	410
remote-admin-state	315	send-code.....	285
remotefault.....	306	send-code.....	292

send-type.....	358	sw-pri-load-server	257
sent-updates	358	sw-upgrade-admin.....	257
server-max-timer.....	411	syscontact	381
service-provider-id.....	377	syslocation.....	381
setserialno	380	sysname	381
shdsl-clock-offset.....	362	system-access	381
shdsl-config-line-rate (2-wire G.SHDSL card).....	362	system-clock-eligibility	263
shdsl-config-line-rate (4-wire G.SHDSL card).....	363	system-clock-weight	263
shdsl-decoder-coeffA/shdsl-decoder-coeffB ..	363	system-domain-name	411
shdsl-dsp-version	363	t200.....	392
shdsl-firmware-version	364	t203.....	392
shdsl-fix-bit-rate	364	targetSnrMgn.....	225
shdsl-frame-sync.....	364	td_frame_discard.....	238
shdsl-ntr	364	td_index.....	238
shdsl-power-scale	365	td_param1	239
shdsl-repeater-id	366	td_param2.....	239
shdsl-standard	366	td_param3.....	239
shdsl-startup-margin	366	td_param4.....	239
shdsl-transmit-power-back-off-mode	366	td_param5.....	239
shdsl-wire-mode	367	td_service_category.....	240
shelf.....	322	td_type.....	240
shelf.....	390	test_mode	337
shelvesarray	380	testLinkIfIndex.....	325
signal-mode.....	286	testPattern	326
signal-type.....	287	testProcStatus	326
signal-type.....	311	tftp	276
signal-type.....	318	thermo-a-lower-threshold.....	367
silence-suppression-type.....	400	thermo-a-upper-threshold.....	368
sip-ip-address	411	thermo-b-lower-threshold	367
slot.....	322	thermo-b-upper-threshold	368
source-ip-address	261	third-nameserver	279
source-port	261	thresh15min-badseq	369
src-address	358	thresh15min-congestion	369
sroute-advertise.....	359	thresh15MinESs	226
sscs-type.....	238	thresh15MinLofs	226
starts.....	275	thresh15MinLols	226
startup-check-link-id.....	391	thresh15MinLoss	227
startup-unblock-user-ports.....	391	thresh15MinLprs	227
state	276	threshFastRateDown	225
status	354	threshFastRateUp	227
stickyaddr.....	275	threshInterleaveRateDown.....	228
StripAndInsert.....	250	threshInterleaveRateUp.....	228
stuff-bits.....	298	threshold-15min-lofs	298
subnetgroup.....	276	threshold-15min-lols	298
subnetgroup.....	333	threshold-15min-loss	298
subport	322	timer-cu	241
sw-enable	256	time-slot-index	392
sw-file-name	257	tools-access	377
switch-type.....	319	traffic-container-index.....	241
switch-vendor	391	transmit_traffic_descr_index.....	241

transmit-clock-source	263	vcl-rate-params (1 through 32).....	244
transmit-clock-source	287	vendor-match-length	276
transmit-clock-source	293	vendor-match-offset	277
transmit-power-back-off-mode.....	298	vendor-match-string	277
trapadminstatus	369	version	277
trapdestination.....	369	version	359
traplevel	369	vlanId.....	251
traptype	370	vlanId.....	334
trnk-vcl-rate	241	vlanIDCOS	334
trunk-type.....	242	voice-aal2-cid	400
tx-acc-map	355	voice-aal2-line-group-id.....	400
txClkMode	323	voice-aal2-vci	400
txFramLength	324	voice-aal2-vpi.....	401
txImaId.....	324	voice-access.....	401
txTimingRefLink	326	voice-admin-status	377
type	258	voicebandwidthcheck	245
type	333	voice-connection-description	401
type	392	voice-connection-type	301
ulc-port-type	335	voice-connection-type	401
ulc-trap-enable	336	voice-ebs-line-group-id	402
unit-mode.....	293	voice-endpoint1-addr-index	403
unit-mode.....	299	voice-endpoint2-addr-index	403
unnumberedindex	334	voice-ext-type.....	403
update-time	359	voice-GR303-ig-crv	403
upgrade-sw-file-name	258	voice-GR303-ig-name.....	403
upgrade-vers	258	voice-isdn-channel-id.....	336
up-line-rate.....	299	voice-isdn-line-group-id.....	336
upperiftype.....	334	voice-isdn-port-type	336
upperlayer	334	voice-pots-line-group-id.....	312
upshiftSnrMgn	228	voice-pots-line-group-id.....	404
usage-parameter-control	242	voice-V52-interface-name.....	393
user-admin-access.....	404	voice-V52-isdn-channel-id.....	394
user-id	405	voice-V52-user-port-id.....	394
user-name.....	405	voice-V52-user-type.....	394
user-pass	405	voip-password	411
user-prompt.....	405	voip-plar	411
us-max-const.....	394	voip-plar-dest-ipaddr.....	412
v52-c-channel:array[1..3]	393	voip-plar-dest-ipaddrtype	412
v52-c-path:array[1..48].....	393	voip-server-entry-index	412
v52-ig-lapv.....	393	voip-udp-port.....	412
v52-link[1..16]	393	voip-username	413
vcc_aal_type	243	vpi.....	246
vcc_aal5_encaps_type	242	vpi.....	251
vcc-i	243	vpi.....	261
vci	243	vpi.....	355
vci	250	weight	258
vci	261	working-mode	319
vci	355	wrap-config	307
vcl_cast_type	243	zhone-access.....	405
vcl_conn_kind.....	243	zhoneAtmMaxVciPerVp.....	246

zhoneAtmVpiMaxVci.....	246
zhoneAtmVpiSwitched.....	247
zhoneVoipServerAddr	413
zhoneVoipServerAddrType	413
zhoneVoipServerUdpPortNumber.....	413
zmsconnectionstatus	414
zmsexists.....	414
zmsipaddress.....	415

3 PARAMETERS

This chapter provides a reference to the Zhone CLI parameters.

ADSL

adslAlarmConfProfile

This parameter is used internally by the system.

Access This parameter is read-only.

Location **adsl-profile**

adslChannelMode

Specifies the channelization of the ADSL modem.

Values **fastonly**

No channelization, fast transmission mode.

interleavedonly

No channelization, interleaved transmission mode.

fastAndInterleaved

Unsupported.

fastOrInterleaved

Unsupported.

Default **fastonly**

Access This parameter is read-write.

Location **adsl-profile**

Notes G.lite supports only interleaved mode.

adslLineDTMConfMode

Discrete Multi-Tone parameter that selects whether there is overlap (echoCancel) or no overlap (freqDivMux) of bins.

Access This parameter is read-write.

Location adsl-profile

adslMaxDownstreamToneIndex

Specifies the maximum downstream active tone.

Values 32 (128KHz) to 511 (2044KHz)
Each value represents 4KHz.

Default 511

Location adsl-profile

- Notes**
- Changing this value causes the DSL modems to retrain.
 - The parameter is only supported on single-slot ADSL (AC5) card

adslMaxUpstreamToneIndex

Specifies the maximum upstream active tone.

Values 6 (24KHz) to 30 (120KHz)
Each value represents 4KHz.

Default 30

Location adsl-profile

- Notes**
- Changing this value causes the DSL modems to retrain.
 - The parameter is only supported on single-slot ADSL (AC5) card

adslMinDownstreamToneIndex

Specifies the minimum downstream active tone.

Values 32 (128KHz) to 255 (1020KHz)
Each value represents 4KHz.

Default 32

Location adsl-profile

- Notes**
- Changing this value causes the DSL modems to retrain.
 - The parameter is only supported on single-slot ADSL (AC5) card

adslMinUpstreamToneIndex

Specifies the minimum upstream active tone.

Values 6 (24KHz) to 30 (120KHz)
Each value represents 4KHz.

Default 6

Location adsl-profile

- Notes**
- Changing this value causes the DSL modems to retrain.
 - The parameter is only supported on single-slot ADSL (AC5) card

adsINTRModeEnabled

Enables or disables network timing recovery (NTR) mode.

Values **true**
NTR mode enabled.

false
NTR mode disabled.

Default **true**

Access This parameter is read-write.

Location **adsl-profile**

adslPotsBypassRelayMaxDuration

The maximum duration in seconds that an ADSL POTS low-pass filter bypass relay will remain active (closed). The relay will automatically return a line back to normal (open) mode when this timer has expired.

Values **1 to 300**

Default **60**

Access This parameter is read-write.

Location **adsl-profile**

Notes This object is only valid for MALC ADSL-SPLTR-32 cards.
This parameter can only be set from ZMS.

Products MALC

AdslTrellisModeEnabled

Enables or disables trellis mode on the ADSL interface.

Values **true**

false

Default **true**

Access This parameter is read-write.

Location **adsl-profile**

AdslTransmissionMode

Specifies the line transmission mode for each ADSL line.

Values autonegotiate

Automatically negotiates all supported transmission modes. The modem uses the G.hs protocol to negotiate a transmission mode in this order: T1.413, then G.dmt, then G.lite.

fullrate

Automatically negotiates full-rate modes (G.dmt and T1 mode). G.dmt has priority over T1 mode.

glite

The modem negotiates only G.lite mode.

t1

The modem negotiates only full-rate T1 mode. Use this value if the Zhone device is connecting to full rate T1.413 issue 2 modems.

gdmt

The modem negotiates only G.dmt mode.

ghs

The modem negotiates only G.dmt and G.lite modes. G.dmt has priority over G.lite.

adsl2

the modem negotiates ADSL2 only. (Supported on ADSI 48 port cards only).

adsl2Plus

the modem negotiates ADSL2+ only. (Supported on ADSI 48 port cards only).

Default autonegotiate

Access This parameter is read-write.

Location adsl-profile

downshiftSnrMgn

The configured signal-to-noise margin for rate downshift. If the noise margin falls below this level, the modem attempts to decrease its transmit rate.

Values 0 to 310 (in tenths dBs)

Default 0

Access This parameter is read-write.

Location adsl-co-profile, adsl-cpe-profile

Notes If rate adaption is not enabled on the interface, this parameter is 0 (zero).

fastMaxTxRate

Configured maximum transmit rate (bps) for ADSL Fast channels.

- Values** 8160Kbps (1536Kbps for G.Lite) downstream 896Kbps (512Kbps for G.Lite) upstream, 12Mbps for S=1/2
- Default** 8160kbps
- Access** This parameter is read-write.
- Location** adsl-co-profile, adsl-cpe-profile
- Notes** fastMaxTxRate must be greater than fastMinTxRate.

fastMinTxRate

Minimum transmit rate (bps) for channels configured for fast transmission mode.

- Values** 32Kbps to 8160Kbps (1536Kbps for G.Lite) downstream 32Kbps to 896Kbps (512Kbps for G.Lite) upstream
- Default** 0
- Access** This parameter is read-write.
- Location** adsl-co-profile, adsl-cpe-profile
- Notes** fastMinTxRate must be less than fastMaxTxRate.

See **rateChanRatio** for information regarding RADSL mode and ATUC transmit rate for ATUR receive rates.

initFailureTrapEnable

Enables and disables the InitFailureTrap. This trap controls whether line up or line down traps are sent while the system is booting up.

- Values** enable
disable
- Default** disable
- Access** This parameter is read-write.
- Location** adsl-co-profile

interleaveMaxTxRate

Maximum transmit rate (bps) for channels configured for interleaved transmission mode.

- Values** 32Kbps to 8160Kbps (1536Kbps for G.Lite) downstream 32Kbps to 896Kbps (512Kbps for G.Lite) upstream, 12Mbps for S=1/2
- Default** 8160kbps
- Access** This parameter is read-write.
- Location** adsl-co-profile, adsl-cpe-profile

Notes **interleaveMaxTxRate** must be greater than **interleaveMinTxRate**.

See **rateChanRatio** for information regarding RADSL mode and ATUC transmit rate for ATUR receive rates.

interleaveMinTxRate

Minimum transmit rate (bps) for channels configured for interleaved transmission mode.

Values **32Kbps to 8160Kbps (1536Kbps for G.Lite) downstream 32Kbps to 896Kbps (512Kbps for G.Lite) upstream**

Default **0**

Access This parameter is read-write.

Location **adsl-co-profile, adsl-cpe-profile**

Notes **interleaveMinTxRate** must be less than **interleaveMaxTxRate**.

See **rateChanRatio** for information regarding RADSL mode and ATUC transmit rate for ATUR receive rates.

maxInterleaveDelay

Maximum interleave delay for this channel. Interleave delay applies only to the interleave channel and defines the mapping (relative spacing) between subsequent input bytes at the interleaver input and their placement in the bit stream at the interleaver output. Larger numbers provide greater separation between consecutive input bytes in the output bit stream allowing for improved impulse noise immunity, but at the expense of payload latency.

Values **0**
0.5 ms

1
1 ms

2
2 ms

4
4 ms

8
8 ms

16
16 ms

32
32 ms

63
63 ms

Default 0
Access This parameter is read-write.
Location **adsl-co-profile, adsl-cpe-profile**

maxSnrMgn

Maximum acceptable signal to noise margin. If the noise margin rises above this level, the modem reduces its power output to optimize its operation.

Values 0 to 310 (in tenths dBs)
Default 310
Access This parameter is read-write.
Location **adsl-co-profile, adsl-cpe-profile**

minDownshiftSnrMgn

Minimum time that the current signal to noise margin is below **DownshiftSnrMgn** before a rate downshift occurs.

Values 0 to 16383 seconds
Default 0
Access This parameter is read-write.
Location **adsl-cpe-profile**
Notes If rate adaption is not enabled on the interface, this parameter is 0 (zero).
Unsupported.

minDownshiftTime

Minimum time that the current margin is below **DownshiftSnrMgn** before a downshift occurs.

Values 0 to 16383 seconds
Default 0
Access This parameter is read-write.
Location **adsl-co-profile, adsl-cpe-profile**
Notes If rate adaption is not enabled on the interface, this parameter is 0 (zero).
This parameter is not supported.

minSnrMgn

Minimum acceptable signal-to-noise margin. If the noise margin falls below this level, the modem attempts to increase its power output. If that is not possible, the modem will attempt to reinitialize or shut down.

Values 0 to 310 tenths of dBs

Default 0

Access This parameter is read-write.

Location adsl-cpe-profile

minUpshiftSnrMgn

Minimum time that the current margin is above **UpshiftSnrMgn** before an upshift occurs.

Values 0 to 16383 seconds

Default 0

Access This parameter is read-write.

Location adsl-co-profile, adsl-cpe-profile

Notes If rate adaption is not enabled on the interface, this parameter is 0 (zero).

rateChanRatio

The percentage of excess bit rate that the ADSL modem will distribute to the fast channel. The ratio is defined by the following formula:

$$[\text{fastMinTxRate} / (\text{fastMinTxRate} + \text{interleaveMinTxRate})] \times 100.$$

For example, a ratio of 50 percent means that 50 percent of the additional bit rate (in excess of the fast minimum plus the interleaved minimum bit rate) will be assigned to the fast channel, and 50 percent to the interleaved channel.

Values 50

Default 50

Access This parameter is read-write.

Location adsl-co-profile, adsl-cpe-profile

Notes See ADSL Forum TR-005 [3] for more information.

rateMode

The transmit rate adaptation configured on this modem.

Values **fixed**

The rate is determined by the **fastMaxTxRate** or the **interleaveMaxTxRate**. If the line is unable to support the specified line rate, it fails to connect.

adaptatstartup

The rate is negotiated at startup and remains fixed. The modem speed is determined by the **fastMaxTxRate** or **interleaveMaxTxRate** parameters. If the line is able to support a higher rate, the rate above the minimum is distributed between the fast and interleaved paths in the ratio specified in the **rateChanRatio** parameter.

adaptatruntime

The rate is negotiated dynamically and can vary between the maximum and minimum configured rates.

Default **adaptatruntime**

Access This parameter is read-write.

Location **adsl-co-profile, adsl-cpe-profile**

Notes See ADSL Forum TR-005 [3] for more information.

reachExtendedAdsl2

Enables and disables extended reach for ADSL2 long loops.

Access This parameter is read-write.

Location **adsl-co-profile, adsl-cpe-profile**

targetSnrMgn

Target signal to noise margin. This is the noise margin the modem must achieve with a Bit Error Rate (BER) of 10^{-7} or better to successfully complete initialization.

Values **0 to 310 tenths of dBs**

Default **0**

Access This parameter is read-write.

Location **adsl-co-profile, adsl-cpe-profile**

threshFastRateDown

Applies to Fast channels only. The change in the configured rate that causes the system to send an **adslAturRateChangeTrap**.

The system sends a trap whenever:

$\text{ChanCurrTxRate} \leq \text{ChanPrevTxRate} - \text{value of this parameter}$.

Default **0**

0 disables the trap.

Access This parameter is read-write.

Location **adsl-co-profile**

thresh15MinESs

The number of Errored seconds encountered by an ADSL interface within any given 15 minutes performance data collection period that will cause the SNMP agent to send an adslAtucPerfESsThreshTrap (CO) or adslAturPerfESsThreshTrap (CPE) trap. One trap is sent per interval per interface.

Values **0 to 900 seconds**
0 disables the trap.

Default **0**

Access This parameter is read-write.

Location **adsl-co-profile, adsl-cpe-profile**

thresh15MinLofs

The number of Loss of Frame Seconds encountered by an ADSL interface within any given 15 minutes performance data collection period that will cause the SNMP agent to send an adslAtucPerfLofsThreshTrap (CO) or adslAturPerfLofsThreshTrap (CPE) trap. One trap is sent per interval per interface.

Values **0 to 900 seconds**
0 disables the trap.

Default **0**

Location **adsl-co-profile, adsl-cpe-profile**

thresh15MinLols

The number of Loss of Link seconds encountered by an ADSL interface within any given 15 minutes performance data collection period that will cause the SNMP agent to send an adslAtucPerfLolsThreshTrap (CO) or adslAturPerfLolsThreshTrap (CPE) trap. One trap is sent per interval per interface.

Values **0 to 900 seconds**
0 disables the trap.

Default **0**

Access This parameter is read-write.

Location **adsl-co-profile, adsl-cpe-profile**

thresh15MinLoss

The number of Loss of Signal seconds encountered by an ADSL interface within any given 15 minutes performance data collection period that will cause the SNMP agent to send an adslAtucPerfLossThreshTrap (CO) or adslAturPerfLossThreshTrap (CPE) trap. One trap is sent per interval per interface.

- Values** 0 to 900 seconds
0 disables the trap.
- Default** 0
- Access** This parameter is read-write.
- Location** adsl-co-profile, adsl-cpe-profile

thresh15MinLprs

The number of Loss of Power seconds encountered by an ADSL interface within any given 15 minutes performance data collection period that will cause the SNMP agent to send an adslAtucPerfLprsThreshTrap (CO) or adslAturPerfLprsThreshTrap (CPE) trap. One trap is sent per interval per interface.

- Values** 0 to 900 seconds
0 disables the trap.
- Default** 0
- Access** This parameter is read-write.
- Location** adsl-co-profile, adsl-cpe-profile

threshFastRateUp

Applies to Fast channels only. The change in the configured rate that causes the system to send an adslAtucRateChangeTrap.

The system sends a trap whenever:

$\text{ChanCurrTxRate} \leq \text{ChanPrevTxRate} - \text{value of this object}$

- Values** 0
0 disables the trap.
- Default** 0
- Access** This parameter is read-write.
- Location** adsl-co-profile, adsl-cpe-profile

threshInterleaveRateDown

Applies to Interleave channels only. The change in the configured rate that causes the system to send an adslAtucRateChangeTrap.

The system sends a trap whenever:

$\text{ChanCurrTxRate} \leq \text{ChanPrevTxRate}$ minus the value of this object.

Values 0
0 disables the trap.

Default 0

Access This parameter is read-write.

Location adsl-co-profile, adsl-cpe-profile

threshInterleaveRateUp

Applies to Interleave channels only. The change in the configured rate that causes the system to send an adslAturRateChangeTrap. The system sends a trap whenever: $\text{ChanCurrTxRate} \geq \text{ChanPrevTxRate}$ plus the value of this object.

Values 0
0 disables the trap.

Default 0

Access This parameter is read-write.

Location adsl-co-profile, adsl-cpe-profile

upshiftSnrMgn

The configured signal to noise margin for rate upshift. If the noise margin rises above this level, the modem attempts to increase its transmit rate.

Values 0 to 310 tenths of dBs

Default 0

Access This parameter is read-write.

Location adsl-co-profile, adsl-cpe-profile

Notes If rate adaption is not enabled on the interface, this parameter is 0 (zero).
This parameter is not supported.

ATM

admin_status

Specifies the desired administrative state of the virtual channel link (VCL).

Values up

down

Default down

Location atm-vcl

Notes This parameter should be set to tell the system whether or not to establish the connection.

The admin status must be set to down before changing or deleting VCLs.

admin-status

Administrative status of the link.

Values up

down

Default down

Location aal2-cid-profile, atm-cc

algorithm

The AAL2 encoding algorithm.

Values G.711

Pulse Code Modulation (PCM). Two encoding laws are recommended, referred to as A-law and Mu-law.

G.722

Sub-Band Adaptive Pulse Code Modulation (SB-ADPCM).

G.723.1

Not currently supported.

G.726

Adaptive Pulse Code Modulation (ADPCM).

G.727

Embedded Adaptive Pulse Code Modulation (EADPCM).

G.728

Low Delay Code Excited Linear Prediction (LD-CELP).

G.729-8

EDU format.

G.729

Silence Insertion Descriptor (SID) packet format.

G.729-6.4

Encoding data unit format.

G.729-12

Encoding data unit format for the forward adaptive mode.

Generic SID

Generic SID packet format.

Default **G.711**

Location **aal2-audio-profile**

Notes Refer to STR-VMOA-LES-01-00 Annex A, I.366.1 7.7.1, and I.366.2 Annex B through I for more information.

app-id

Application Identifier. It specifies the protocol used between the IAD and the ATM switch.

Values **caspotsonlynoelcp**

Loop Emulation Service using Channel Associated Signaling (CAS) without Emulated Loop Control Protocol (ELCP), which is used for POTS.

dss1brionlynoelcp

Loop Emulation Service using Digital Subscriber Signaling System number 1 (DSS1) in support of ISDN BRI without ELCP.

dss1brionlyelcp

Loop Emulation Service using Digital Subscriber Signaling System number 1 (DSS1) in support of ISDN BRI with ELCP.

pstnpotsonlyelcp

Loop Emulation Service using PSTN signalling (POTS only) with ELCP.

Default **caspotonlynoelcp**

Location **aal2-vcl-profile**

atmVplAdminStatus

Administrative status of the VPL.

Values **up**

down

Default **down**

Location **atm-vpl**

Notes This parameter should be set to tell the system whether or not to establish the connection.

The admin status must be set to down before changing or deleting VPLs.

atmVplCastType

Type of connection.

- Values** **p2p**
Point-to-point.
- p2mproot**
Point-to-multipoint root. Currently not supported.
- p2mpleaf**
Point-to-multipoint leaf. Supported for IP video connections only.
- Location** **atm-vpl**

atmVplConnKind

The type of VCL.

- Values** **pvc**
- Location** **atm-vpl**

atmVplReceiveTrafficDescrIndex

Specifies the ATM traffic descriptor which applies to the receive direction of this VPL.

- Values** **The index value of an existing atm-traf-descr.**
- Location** **atm-vpl**
- Notes** Currently this value must be set equal to the value used for the **atmVplTransmitTrafficDescrIndex**.
- Traffic descriptors used in active VPLs cannot be modified. You must bring down the VPL before you can modify the traffic descriptor.
- See Also** **atmVplTransmitTrafficDescrIndex**

atmVplTransmitTrafficDescrIndex

Specifies the ATM traffic descriptor which applies to the transmit direction of this VPL.

- Values** **The index value of an existing atm-traf-descr.**
- Location** **atm-vpl**
- Notes** Currently this value must be set equal to the value used for the **atmVplReceiveTrafficDescrIndex**.
- Traffic descriptors used in active VPLs cannot be modified. You must bring down the VPL before you can modify the traffic descriptor.

See Also `atmVplReceiveTrafficDescrIndex`

audio-profile-identifier

An index number that refers to the type of audio service provided.

Values 7

For PCM-64, ADPCM-32 and silence-suppression (`pcm64Adpcm32Silence`). Supported on the BAN, MALC, Raptor, Sechtor 100A, Z-Edge.

8

For PCM-64 and silence (`pcm64Silence`). Supported on the Sechtor 100A, Z-Edge.

9

For PCM-64 without silence (`pcm64`). Supported on the BAN, Sechtor 100A.

10

For PCM-64, ADPCM-32 without silence (`pcm64Adpcm32`). Supported on the BAN, Sechtor 100A.

Location `aal2-vcl-profile`

Notes For pre-defined audio profiles, the range of valid identifier values is 1 to 255, inclusive. If the audio profile is user-defined, the range of valid identifiers is 256 to 512.

audio-service

The audio-service setting is inherited by the CIDs attached to the AAL2 VCL.

Values **enabled**

Audio services enabled, including echo cancellation, silence suppression, and compression algorithms.

disabled

Audio services disabled. This is used for data and video calls.

enabledechocanceloff

Audio service enabled with echo cancellation and silence suppression disabled.

enableddynamic

Audio service enabled with ability to dynamically disable silence suppression, silence detection, echo cancellation, and compression algorithms on a per-call basis.

Default `enabled`

Location `aal2-vcl-profile`, `aal2-cid-profile`

cas

Channel Associated Signaling (CAS). This setting is inherited by the CIDs attached to the AAL2 VCL.

Values **enabled**

disabled

Default **enabled**

Location **aal2-vcl-profile, aal2-cid-profile**

cac-divider

Enables oversubscription for an ATM VCL. During CAC calculations, the system divides the SCR (for nrt-VBR or rt-VBR VCLs) bandwidth by the value specified in the **cac-divider**. It then uses that value to determine if the VCL can be created.

For example, to configure a 4:1 oversubscription, set **cac-divider** to 4.

Default **1**

Location **atm-traf-descr**

cc-index

A unique value used to identify the cross connect.

Location **atm-cc**

fault-detection-type

Used to determine faults on the VCL.

Values **disabled**

Fault detection is disabled.

oamF5Loopback

On POTS-based AAL2 connections, the unit sends an OAM F5 loopback if the CAS does not refresh after 10 seconds. If there is no response to the F5 loopback, the VCL is blocked and a trap is generated.

On ISDN-based AAL2 connections, there is no CAS refresh; the unit sends an F5 loopback every 5 seconds. If there is no response to the F5 loopback, the VCL is blocked and a trap is generated.

F5 loopbacks on AAL5 connections are not supported.

Default **disabled**

Access This parameter is read-write.

Location **atm-vcl**

frame-mode-data

The transport of data units as specified in the transmission error detection service of Recommendation I.366.1. This setting is inherited by the CIDs attached to the AAL2 VCL.

Values **enabled**
disabled

Default **disabled**

Location **aal2-vcl-profile, aal2-cid-profile**

high-if-index

The index (in the form *shelf-slot-port-subport-interface/atm* or a user-defined string) of the ATM interface for this cross connect. The **high-if-index** is arbitrary, but by convention it indicates the ATM interface with a numerically higher ifIndex value than the other ATM interface identified in the same cross connect.

Location **atm-cc**

Notes The **low-if-index** and the **high-if-index** cannot be equal.

high-vci

The VCI value associated with the interface specified in the **high-if-index**. For VP switched connections, specify 0.

Location **atm-cc**

high-vpi

The VPI value associated with the interface specified in the **high-if-index**.

Location **atm-cc**

low-if-index

The index (in the form *shelf-slot-port-subport-interface/atm* or a user-defined string) of the ATM interface for this cross connect. The **low-if-index** is arbitrary, but by convention it indicates the ATM interface with a numerically lower ifIndex value than the other ATM interface identified in the same cross connect.

Location **atm-cc**

Notes The **low-if-index** and the **high-if-index** cannot be equal.

low-vci

The VCI value associated with the interface specified in the **low-if-index**. For VP switched connections, specify 0.

Location atm-cc

low-vpi

The VPI value associated with the interface specified in the **low-if-index**.

Location atm-cc

max-cid-for-aal2-user-channels

Maximum Channel Identifier (max-cid) value for AAL2 user channels as defined by the ATM Forum.

Values For an app-id values of **caspotonlynoelcp** and **dss1brionlynoelcp**, the following Channel Identification (CID) value ranges apply:

CID 16..127: Bearer channels for POTS

CID 128..159: D-channels for ISDN BRI

CID 160..223: B-channels for ISDN BRI

Location aal2-vcl-profile

Notes For more information, refer to the ATM Forum AF-VMOA-0145.000.

max-cps-sdu-size

Specifies the AAL2 payload in octets that can be sent and received.

Values 64 octets

45 octets

Default 45

Location aal2-vcl-profile

max-length-frame

The maximum length of the frame that this channel will accept.

Values This setting is inherited by the CIDs attached to the AAL2 VCL.

Location aal2-vcl-profile, aal2-cid-profile

max-number-multiplex-channels

The maximum number of channels that can be multiplexed within the VCL.

Values 1 to 259, inclusive
Default 239
Location aal2-vcl-profile

max-sdu-length

The maximum size of the SDU, in octets, that is allowed to be reassembled.

Values 1 to 65568, inclusive
Location aal2-vcl-profile, aal2-cid-profile

min-cid-for-aal2-user-channels

The minimum number of Channel Identifiers (CID) allowed for AAL2 user channels.

Values For an app-id values of caspotonlynoelcp and dss1brionlynoelcp, the following Channel Identification (CID) value ranges apply:

CID 16..127: Bearer channels for POTS

CID 128..159: D-channels for ISDN BRI

CID 160..223: B-channels for ISDN BRI

Location aal2-vcl-profile

Notes For more information, refer to the ATM Forum AF-VMOA-0145.000.

pcm-encoding

The type of Pulse Code Modulation encoding used.

Values muLaw
aLaw
Location aal2-vcl-profile, aal2-cid-profile

pkt-time

Packet time in tenths of milliseconds.

Values 50 to 110, inclusive
Default 55
Location aal2-audio-profile

preferred-ap-index

Defines the preferred audio encoding format.

Values **1**
Used for G.711 encoding

2
Used for G.726 encoding

Default **1**

Location **aal2-cid-profile**

ras-timer

The maximum time allowed for ReASsembly of a SSSAR-SDU.

Values **milliseconds**

Location **aal2-vcl-profile, aal2-cid-profile**

receive_traffic_descr_index

Specifies the ATM traffic descriptor which applies to the receive direction of this VCL.

Values **The index value of an existing atm-traf-descr.**

Location **atm-vcl**

Notes Currently this value must be set equal to the value used for the **transmit_traffic_descr_index**.

Traffic descriptors used in active VCLs cannot be modified. You must bring down the VCL before you can modify the traffic descriptor.

See Also **transmit_traffic_descr_index**

sdu-multiples

Indicates the multiples of the service data unit (SDU) for each algorithm that occurs. SDUs for audio are defined in relation to the profile of encoding formats adopted on an AAL type 2 connection. Each algorithm that occurs in a given profile may appear in multiple entries corresponding to packets of different lengths. These packet lengths align in a simple sequence, where each is an integral multiple of the smallest packet length that occurs for the algorithm (at a given bit rate). The smallest packet length is the SDU of the algorithm, in relation to the given profile.

Values **1 to 8**

Default **1**

Location **aal2-audio-profile**

See Also **algorithm**

sscs-type

The Service Specific Convergence Sublayer (SSCS) is the portion of the convergence sublayer that is dependent upon the type of traffic that is being converted.

Values **i3661**

For channels that carry control and management plane traffic (such as CCS, ELCP, ISDN D channels, and LES-EOC).

i3662

For channels carry media streams (such as POTS or ISDN B channels).

Default **i3662**

Location **aal2-cid-profile**

td_index

This parameter is used by the **atm-vcl** profile to identify a traffic descriptor.

Location **atm-traf-descr**

td_frame_discard

Enables and disable early-packet-discard (EPD) and partial-packet-discard (PPD). This allows selective discarding of all cells in a frame if one cell is lost or discarded.

In EPD, the ATM interface monitors the AAL5 traffic and discards an entire data frame if its output buffers do not have the space to process it. In PPD, the ATM interface drops the remaining cells of the packet if other cells of the packet have already been dropped. Both of these techniques increase the efficiency of the data transfer by dropping frames that have already been determined to be errored and will have to be retransmitted.

Values **true**

Indicates that the network is requested to treat data for this connection, in the given direction, as frames (that is, AAL5 CPCS PDUs) rather than as individual cells. While the precise implementation is network-specific, this treatment may involve discarding entire frames during congestion, rather than a few cells from many frames.

false

This is the recommended setting for voice connections.

Default **false**

Location **atm-traf-descr**

td_param1

The peak cell rate (PCR) of the interface. Once the peak cell rate (PCR) has been set, traffic policing ensures that the PCR limitations are enforced. The system will discard cells of incoming (ingress) traffic that exceed the PCR.

Location atm-traf-descr

- Notes**
- Refer to the documentation that came with your device for information about supported traffic parameters.
 - The **td_param1** and **td_param2** parameters in the **atm-traf-descr** profile must be set to one of the configured rates in the **atm-vcl-param** profile.
 - Refer to the following specifications for more information about PCR:
 - ATM Forum, ATM User-Network Interface, Version 3.0 (UNI 3.0) Specification, 1994.
 - ATM Forum, ATM User-Network Interface, Version 3.1 (UNI 3.1) Specification, November 1994.

td_param2

Sustained cell rate (SCR) of the interface. Refer to the documentation that came with your device for information about supported traffic parameters.

Location atm-traf-descr

- Notes** The **td_param1** and **td_param2** parameters in the **atm-traf-descr** profile must be set to one of the configured rates in the **atm-vcl-param** profile.

td_param3

Maximum burst size (MBS) of the interface. Refer to the documentation that came with your device for information about supported traffic parameters.

Location atm-traf-descr

td_param4

Cell delay variation tolerance (CDVT) of the interface. Refer to the documentation that came with your device for information about supported traffic parameters.

Location atm-traf-descr

td_param5

Currently not supported.

Location atm-traf-descr

td_service_category

The ATM service category. Zhone devices support currently support the following classes of traffic:

- Unspecified bit rate (UBR) for data. Supported on the BAN, MALC, Raptor, Z-Edge.
- Constant bit rate (CBR) for voice. Supported on the MALC, Raptor, Sechtor 100A, Z-Edge.
- Real time variable bit rate (rt-VBR) for voice or data, depending on the application. Supported on the BAN, MALC, Raptor, Sechtor 100A.
- Non-real time variable bit rate (nrt-VBR) for voice or data, depending on the application. Supported on the MALC.

Location atm-traf-descr

td_type

Traffic descriptor type. Note that not all products support all traffic types. Refer to the documentation that came with your device for information about supported traffic categories.

- Values**
- atmNoClpNoScr**
(OID 1.3.6.1.2.1.37.1.1.2)
No CLP and no Sustained Cell Rate.
 - atmClpTaggingNoScr**
(OID 1.3.6.1.2.1.37.1.1.4)
CLP with tagging and no Sustained Cell Rate.
 - atmClpNoTaggingScr**
(OID 1.3.6.1.2.1.37.1.1.6)
CLP with no tagging and Sustained Cell Rate.
 - atmClpTaggingScr**
(OID 1.3.6.1.2.1.37.1.1.7)
CLP with tagging and Sustained Cell Rate.
 - atmClpTransparentNoScr**
(OID 1.3.6.1.2.1.37.1.1.9)
CLP transparent and no Sustained Cell Rate.
 - atmClpTransparentScr**
(OID 1.3.6.1.2.1.37.1.1.10)
CLP transparent and Sustained Cell Rate.
 - atmNoClpNoScrCdvT**
(OID 1.3.6.1.2.1.37.1.1.12)
No CLP and no Sustained Cell Rate.

atmClpNoTaggingScrCdvT
(OID 1.3.6.1.2.1.37.1.1.14)

CLP with no tagging, Sustained Cell Rate.

atmClpTaggingScrCdvT
(OID 1.3.6.1.2.1.37.1.1.15)

CLP with tagging, Sustained Cell Rate.

Location atm-traf-descr

timer-cu

The **timer-cu** is always set to 0. Each transmitted ATM contains one AAL2 packet.

Values 0

Location aal2-vcl-profile

traffic-container-index

This parameter associates a VCL with a traffic container, and is used to retrieve PON channel provisioning information.

Location atm-vcl

transmit_traffic_descr_index

Specifies the ATM traffic descriptor which applies to the transmit direction of this VCL.

Values The index value of an existing atm-traf-descr.

Location atm-vcl

Notes Currently this value must be set equal to the value used for the **receive_traffic_descr_index**.

Traffic descriptors used in active VCLs cannot be modified. You must bring down the VCL before you can modify the traffic descriptor.

See Also [transmit_traffic_descr_index](#)

trnk-vcl-rate

This parameter is used to describe the minimum guaranteed rate for a VCL which is bound to this traffic descriptor for BAN ATM Trunk cards. It is applicable only for the rt-VBR service category.

Access This parameter is read-write.

Location atm-traf-descr

Notes The **trnk-rate-vcl** parameter in **atm-traf-descr** profiles is only used on BAN release 1.5.2. In other releases, it does not apply.

trunk-type

Specifies supervisory line states, for example, on-hook, off-hook, idle, and ringing. The **trunk-type** used for the IAD (Z-Edge) must match the ATM switch trunk type. This parameter is used only for **app-id** values of **caspotsonlynoelcp**.

Values **unknown**
loopstart
groundstart
loopreversebattery

Default **loopstart**

Location **aal2-vcl-profile**

usage-parameter-control

UPC is the process of monitoring and controlling the ATM traffic by enforcing the traffic parameters. By using this parameter, you can disable on a per-traffic descriptor basis. This is typically only done during debugging.

Values **true**
 Enforcement of traffic descriptor parameters is enabled.
false
 Enforcement of traffic descriptor parameters is disabled.

Default **true**

Location **atm-traf-descr**

Notes The **usage-parameter-control** parameter must be set to **true** if the ATM service category is CBR.

vcc_aal5_encaps_type

This parameter applies only when the local VCL end-point is also the VCC end-point, and AAL5 is in use. The type of data encapsulation used over the AAL5 SSCS layer. The definitions reference RFC 1483 Multiprotocol Encapsulation over ATM AAL5 and to the ATM Forum LAN Emulation specification.

Values **llcapsulation**
 Logical link control encapsulation over AAL5. Used for connections terminated on the device.

other
 RFC 1483 multiprotocol encapsulation over AAL5. Used for bridged termination connections.

Default **llcapsulation**

Location atm-vcl

vcc_aal_type

The type of AAL used on this VCC. This parameter applies only when the local VCL end-point is also the VCC end-point, and AAL is in use.

Values aal5

For AAL5 terminated data.

other

For cell relay.

aal2

For AAL2 voice. When a VCL is set to AAL2 (either manually or with the **voice add** command), the system automatically creates associated **aal2-vcl-profiles**.

Default aal5

Location atm-vcl

vcc-i

The VCC Identifier. It is used to differentiate **aal2-vcl-profiles** and is used to match profiles between IADs and ATM switches.

Values integer

Location aal2-vcl-profile

vci

The VCI value for this virtual channel link (VCL). This must match the remote end of the connection.

Location atm-vcl

Notes The maximum VCI value cannot exceed the value allowable by atmInterfaceMaxVciBits defined in the ATM-MIB.

vcl_cast_type

The connection topology type.

Default p2p

Location atm-vcl

vcl_conn_kind

The use of call control.

Default pvc

Location **atm-vcl**

vcl-rate-params (1 through 32)

The **atm-vcl-param** profile defines the allowable values for the PCR and SCR for certain traffic types. The values in this profile are used as follows:

- The SCR for rt-VBR traffic descriptors must use one of the first 16 rates.
- The PCR for CBR traffic descriptors can use any of the 32 rates.
- For a UBR traffic descriptor, if **usage-parameter-control** in an ATM traffic descriptor is set to **false**, or if PCR is greater than modem trained rate, then the UBR traffic is shaped to one of the 32 rates. The shaper will pick a rate that is equal to or less than the modem trained rate. If there are multiple rates less than the modem trained rate, the one closest to the trained rate will be selected.



Note: If your device is being managed by ZMS, changes to the **atm-vcl-param** profile should be made using ZMS. If you use the CLI to change the profile, perform a full config sync update after making the change.

Note the following about the values in this profile:

- Rates are in cells per second (CPS)
- Duplicate rates are not permitted
- Rates must be in ascending order within the first 16 rates and also within the second 16 rates.

Location **atm-vcl-param**

- Notes**
- The **td_param1** and **td_param2** parameters in the **atm-traf-descr** profile must be set to one of the configured rates in the **atm-vcl-param** profile.
 - Changing the values in the **atm-vcl-param** profile requires a system reboot.
 - [Table 9](#) explains the **atm-vcl-param** default settings.

Table 9: atm-vcl-param settings

Setting (in CPS)	Application
38	1 to 2 DS0s at 5:1 to 10:1 oversubscription
76	2 to 4 DS0s at 5:1 to 10:1 oversubscription
151	4 to 8 DS0s at 5:1 to 10:1 oversubscription

Table 9: atm-vcl-param settings (Continued)

Setting (in CPS)	Application
189	1 DS0 no oversubscription
302	8 to 16 DS0s at 5:1 to 10:1 oversubscription
378	2 DS0 no oversubscription
604	16 to 32 DS0s at 5:1 to 10:1 oversubscription
755	4 DS0 no oversubscription
1208	32 to 64 DS0s at 5:1 to 10:1 oversubscription
1510	8 DS0 no oversubscription
3661	Full T1
4825	Full E1
28302	8 T1s
37736	8 E1s
106133	DS3
365567	OC3-c/STM1

voicebandwidthcheck

Enables or disables ATM bandwidth checking for voice calls. The system will reject a call if there is not enough bandwidth. On a MALC or a Z-Edge, if a call is rejected, the device sends a fast busy to the caller. On the BAN or the Sechtor 100A, if a call is rejected, the switch sends a busy signal to the caller.



Note: Bandwidth calculations are enabled or disabled for the entire system.

The bandwidth check is based on the configuration of the transmit and receive ATM traffic descriptors for the ATM VC/CID used by the call. The system uses the following parameters to calculate the required bandwidth:

- rt-VBR traffic: SCR
- CBR traffic: PCR
- All other traffic types: calls are always accepted, there are no voice quality guarantees.

The system will reject calls if:

$[\text{Receive or transmit cell rate} - (180 * \text{number of active calls on the VC})] < 180$

(The bandwidth calculations assume that approximately 180 AAL2 cells per second are used for each voice call.)

Values **true**

false

Default **false**

Location **system** profile

vpi

The VPI value for a VPL or VCL. This must match the remote end of the connection.

Values

Valid values differ depending on the type of device and its revision level. Refer to the configuration guide for your device for valid ranges.

Location **atm-vcl**

Notes The maximum VPI value cannot exceed the value allowable by atmInterfaceMaxVpiBits defined in the ATM-MIB.

See Also **vci**

zhoneAtmMaxVciPerVp

Specifies the maximum number of VCIs supported in a VP-switched VPI on the MALC Voice Gateway card.

Default **0**

Location **atm-vpi**

Notes Refer to the release notes for the maximum values for a particular device.

zhoneAtmVpiMaxVci

For the selected VPI, this value specifies the maximum VCI. For VP switched VPIs, this value must be zero. For VC switched VPIs, this value must be a power of 2.

Default **0**

Location **atm-vpi**

Notes Refer to the release notes for the maximum values for a particular device.

zhoneAtmVpiSwitched

Indicates whether the VPI is VP or VC switched.

Values **vp**
vc
Default **vp**
Location **atm-vpi**

Bridging

bridgeConfigType

Specifies the type of filter to be applied to packets on the interface.

Values **bridgeinsertoption82**
 Inserts identification text into the DHCP packet.
bridgeforbidoui
 Drops packets with matching OUI.
Access This parameter is read-write.
Location **bridge-config-record**
Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

bridgeConfigValue

If the **bridgeConfigType** is set to **bridgeforbidoui**, this parameter specifies the OUI or first 3-bytes of the MAC address in the format nn:nn:nn, where nn represents a hex number designating a byte. If the **bridgeConfigType** is set to **bridgeinsertoption82**, this parameter contains a text string that is inserted into the DHCP packet.

Values **A string in the form nn:nn:nn, where nn represents a hexadecimal number designating a byte.**
Access This parameter is read-write.
Location **bridge-config-record**
Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

bridgelfConfigGroupIndex

Index used for bridge groups.

Default **0**
Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

bridgeIfCustomDHCP

Determines the handling of DHCP offer messages from remote DHCP servers.

Values **true**

Forwards broadcast DHCP OFFER or DHCPACK packets even if bridgeFilterBroadcast is TRUE for that interface when the correspondent MAC address is found.

false

Does not forward broadcast DHCP OFFER or DHCPACK packets.

Default **false**

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

customARP

Determines how the BAN treats ARP packets. When a BAN receives a ARP packet, it compares and filters the requested IP address with the current forwarding table. If a match is found, the ARP broadcast is forwarded out the interface that has the appropriate host. This host will then reply to the ARP with a standard response. If a match is not found, then the ARP is filtered and it gets dropped as if it were a non-ARP broadcast.

Values **true**

Drops the packet if there is no match for the requested IP address.

false

Sends the ARP packet out regardless of the whether a match is found for the requested IP address. (If true, sends ARP requests selectively or by flood.)

Default **false**

Access This parameter is read-write.

Location **bridge-interface-record**

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

filterBroadcast

Determines how the BAN handles non-ARP broadcast packets.

Values **true**

Non-ARP broadcast packets are discarded.

false

Non-ARP broadcast packets are forwarded.

Default false

Access This parameter is read-write.

Location **bridge-interface-record**

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

forwardToDefault

If true, attempt to forward via VLAN default paths.

Default false

Access This parameter is read-write.

Location **bridge-interface-record**

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

forwardToMulticast

If true, attempt to forward via multicast MAC paths.

Default false

Access This parameter is read-write.

Location **bridge-interface-group**

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

forwardToUnicast

If true, attempt to forward via unicast MAC paths.

Default false

Access This parameter is read-write.

Location **bridge-interface-record**

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

learnIP

If true, snoop unicast packets to build ARP table.

Default false

Access This parameter is read-write.

Location **bridge-interface-record**

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

learnMulticast

If true, snoop multicast packets for IGMP joins/leaves.

Default false

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

learnUnicast

If true, snoop unicast packets to build MAC paths.

Default false

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

maxUnicast

Maximum number of unicast addresses for I/F.

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

StripAndInsert

If true, enable VLAN Tagging.

Default false

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

vci

If this bridge interface is on an ATM VCL, this is the ATM VCI. If the bridge interface is not an ATM VCL, (for example an Ethernet interface), this parameter is 0.

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

vlanId

The Virtual LAN Id for VLAN tag insertion.

Default 0

Access This parameter is read-write.

Location bridge-interface-record

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

vpi

The VPI value for a VPL or VCL. The VPI value of 0 is only allowed for a VCL.

Default 0

Access This parameter is read-write.

Location bridge-interface-group

Products MALC, Raptor 100, Raptor 319, Raptor 719, Raptor 723

Card

admin-status

Specifies the administrative status of the unit or card.

Values **operational**

The unit or card enters the operational state if it is able. In the operational state the unit or card is able to accept requests from other devices; or, if it is a stand-alone device, it is able to process requests from the wide area network (WAN) or local interfaces.

disable

The unit or card ceases to accept requests from other devices. If the unit or card is operational and receives this command it completes processing of open requests if able.

maintenance

Enter a special maintenance state if available. If not available enter the disabled state and set **admin-status** to disabled.

warm reset

Perform a warm reset of system software that does not reinitialize or reset hardware resources.

reset

Perform an immediate full reset. Following a successful reset the unit or card should enter the operational state.

Location `card-profile`

See Also `sw-status`

admin-status-enable

Enables the collection and forwarding of historical statistics on the unit or card.



Note: This value should be combined with the system statistics to determine if the collection and forwarding of statistics should be enabled.

Values `enabled`

`disabled`

Default `disabled`

Location `card-profile`

card-group-id

The unique redundancy group to which the card is assigned. A card group can contain at most two cards and redundant card pairs must be in the same card group.

Values `0 to 65535`

Default `0 (indicates no redundancy group configured)`

Notes Redundancy group IDs must be non-zero.

A non-zero **card-group-id** cannot be changed. You must delete the **card-profile** and recreate it.

card-atm-configuration

Specifies bandwidth allocation for rt-VBR and UBR traffic and used by Connection Admission Control (CAC). This parameter only applies to ATM trunking interfaces, such as MALC and Raptor Uplink cards, as well as BAN ATM trunking cards.



Note: The Raptor 100 does not support CBR.

Values `notapplicable`

cellrelayonly (BAN only)

The only supported value for ATM trunking (cell relay) card. Specifies the following bandwidth allocation:

- AAL2/cell relay 99%
- AAL5 1%

For ATM-AAL2/AAL5card, 50% of AAL2/cell relay bandwidth is rt-VBR.

cellrelayandmanagement (BAN only)

Specifies the following allocation:

- AAL2/cell relay 95%
- AAL5 5%

For ATM-AAL2/AAL5card, 50% of AAL2/cell relay bandwidth is rt-VBR.

dataterm (BAN only)

Specifies the following allocation:

- AAL2/cell relay 5%
- AAL5 95%

For ATM-AAL2/AAL5card, 50% of AAL2/cell relay bandwidth is rt-VBR.

voiceGateway (BAN only)

Specifies the following allocation:

(only supported for ATM-AAL2/AAL5 card)

- AAL2/cell relay 95%
- AAL5 5%

For ATM-AAL2/AAL5card, 95% of AAL2/cell relay bandwidth is rt-VBR.

hybridlowaal5data (BAN only)

Specifies the following allocation:

- AAL2/cell relay 75%
- AAL5 25%

For ATM-AAL2/AAL5card, 95% of AAL2/cell relay bandwidth is rt-VBR.

hybriddefault (BAN only)

Specifies the following allocation:

- AAL2/cell relay 60%
- AAL5 40%

For ATM-AAL2/AAL5 card, 75% of AAL2/cell relay bandwidth is rt-VBR.

hybridhighaal5data (BAN only)

Specifies the following allocation:

- AAL2/cell relay 25%
- AAL5 75%

For ATM-AAL2/AAL5 card, 50% of AAL2/cell relay bandwidth is rt-VBR.

vbnrt95rt5 (MALC, Raptor)

Specifies the following allocation:

- UBR: 1%
- nrt-VBR: 94%
- CBR/rt-VBR: 5%

vbnrt80rt15 (MALC, Raptor)

Specifies the following allocation:

- UBR: 5%
- nrt-VBR: 80%
- CBR/rt-VBR: 15%

vbnrt65rt30 (MALC, Raptor)

Specifies the following allocation:

- UBR: 5%
- nrt-VBR: 65%
- CBR/rt-VBR: 30%

vbnrt50rt45 (MALC, Raptor)

Specifies the following allocation:

- UBR: 5%
- nrt-VBR: 50%
- CBR/rt-VBR: 45%

vbnrt35rt60 (MALC, Raptor)

Specifies the following allocation:

- UBR: 5%
- nrt-VBR: 35%
- CBR/rt-VBR: 60%

vbnrt20rt75 (MALC, Raptor)

Specifies the following allocation:

- UBR: 5%
- nrt-VBR: 20%
- CBR/rt-VBR: 75%

vbnrt5rt95 (MALC, Raptor)

Specifies the following allocation:

- UBR: 1%
- nrt-VBR: 5%
- CBR/rt-VBR: 94%

Location card-profile

card-line-type

Specifies the line type of the card and the signaling that runs over it. Does not apply to MALC OC3-c/STM1 Uplink cards.

Values	unknowntype Unknown mode. Used for cards that do not support this parameter.
	e1 E1 UNI mode.
	ds1 DS1 UNI mode
	e1-ima E1 ATM IMA mode (MALC T1/E1 IMA Uplink card)
	ds1-ima DS1 ATM IMA mode (MALC T1/E1 IMA Uplink card)
	e3 E3 UNI mode
	ds3 DS3 UNI mode
	t1-uni-gr303 T1 UNI mode of ATM and GR-303 TDM signaling (MALC T1/E1 TDM Uplink card)
	t1-ima-gr303 T1 IMA mode of ATM and GR-303 TDM signaling (MALC T1/E1 TDM Uplink card)
	e1-uni-v52 E1 UNI mode of ATM and V5.2 TDM signaling (MALC T1/E1 TDM Uplink card)
	e1-ima-v52 E1 IMA mode of ATM and V5.2 TDM signaling (MALC T1/E1 TDM Uplink card)
	gshdsl SHDSL (Raptor 100 SHDSL Uplink model).
	t1-uni-t1cas Used for POTS to DS1 connections on the T1/E1 TDM card or OC12-c/STM4 Uplink cards.
	t1-ima-t1cas Used for POTS to E1 connections on the T1/E1 TDM card or OC12-c/STM4 Uplink cards.
	rpr RPR data-only mode (the default for the 2 port GigE RPR card).
	rpr-t1-gr303 RPR with data and GR-303 voice.
	rpr-e1-v52 RPR with data and V5.2 voice
	rpr-t1cas RPR with data and T1 CAS voice

adsl-pots

ADSL and TDM POTS. Supported on ADSL 48 port cards only.

adsl-pots-pv

ADSL and packet voice. Supported on ADSL 48 port cards only.

adsl-splitter

ADSL with splitter. Supported on ADSL 48 port cards only.

pots

TDM POTS. Supported on the POTS 48 port card only.

pots-pv

Packet voice. Supported on the POTS 48 port card only.

Location **card-profile**

Notes Does not apply to DSL card, the MALC ULC card, or POTS cards.

hold-active

When set to true, this indicates that the card, when Active, should remain in the Active state regardless of any system events. This effectively disables redundancy for the card group.

Location **card-profile**

name

Name of the software image to load for the card. If the name is not specified, the slot card loads the image specified in the **card-profile** for the slot.

Location **card-profile**

sw-enable

Specifies whether a software download for the slot card is enabled.

Values **true**

Enables the system to download the binary for that slot card when the card is reset.

false

Software is not downloaded to the slot card. This effectively disables the slot card.

Default **false**

Location **card-profile**

Notes The slot card loads the software binary specified in the **type-module** record for the card if it is not specified in the **card-profile** record for that slot.

See Also **name, upgrade-sw-file-name**

sw-file-name

The file or code image name of the software version that should be loaded by the unit or card for operation.

The operation of this parameter varies depending on the type of device.

- BAN, MALC, and Raptor: The card will load the specified software image. If the **sw-file-name** is not specified, the card will load the image specified in the **type-module** for the slot card.
- Z-Edge or Sechtor 100A: If the unit is a Z-Edge or a Sechtor 100A, the system will first check for a local copy of the specified software image. If a copy is there, the device will load from the local copy. If the local copy is not the same revision as the **sw-file-name** the card will load the new image.

Location **card-profile**

Notes If a failure occurs when loading an upgrade version, the system automatically reverts to a software version specified in the **sw-file-name**. If the **sw-file-name** is not specified, the card will load the image specified in the **type-module** for the slot card.

See Also **name**

sw-pri-load-server

The IP address of the primary software load server. This parameter is not used by BAN, MALC, or Raptor cards. If the value of this parameter is set to 0.0.0.0 then no primary load server is available.

Location **card-profile**

Notes If the system is unable to load the software file from the primary load server, the system attempts to load the software from the secondary load server.

sw-upgrade-admin

How the unit should be upgraded.

Values **loadupgradesw**

The device requests a load of the upgrade software from the image previously downloaded to the system. If an upgrade version of the software is not available or the upgrade server is unable to respond to the load request, the card will set **sw-status** to **upgradeloadFailed**.

upgradenow

The device upgrades to the already loaded upgrade software if warm upgrade is supported or it will reboot and load the upgrade software if warm upgrade is not supported. If the upgrade software has not been loaded or there is no grade software load available, the device will set

sw-status to **upgradeFailed**. When this value is set, the **sw-upgrade-enable** parameter is set to true.

upgradeonreset

The device upgrades to the already loaded software the next time it is reset. If the upgrade software is not loaded the card will set **sw-status** to **upgradeFailed** following a reset.

reloadcurrrev

The device will reset and load the version of code that was running prior to the most recent upgrade.

Location **card-profile**

type

This parameter definition differs depending on its location:

- In an **if-translate** profile, it indicates the type of interface, as specified in the Interface MIB (RFC 2233).
- In a **card-resource** profile, it indicates the type of slot card.

Location **card-profile**

upgrade-sw-file-name

The file name of the software image that should be loaded by the unit or card at the next upgrade. If this is not specified, the name of the image specified in the type-module record for the slot card is downloaded instead.

Location **card-profile**

See Also **name**

upgrade-vers

The software version that is loaded into the unit or card memory that can be loaded after a warm reboot of the system.

Location **card-profile**

weight

A weight given to this card that determines whether this card should become the active card after both cards are reset. Cards in a card group negotiate which cards are active and standby by comparing weights. Cards with higher preferences become active. If multiple cards have the same weight, the card in the lower numbered slot becomes active.

Values **noPreference**

No preference.

neveractive

The card never becomes active.

slightpreference**mediumpreference****highpreference**

Default noPreference

Channel Emulation Service (CES)

buf-max-size

Defines maximum the size of the reassembly buffer in 10 microsecond increments.

Default 128

Access This parameter is read-write.

Location ces-config

Products MALC

cas

Specifies which AAL1 Format should be used. This applies to structured interfaces only.

For unstructured interfaces this value, if present, must be set to the default of **basic**.

Values **basic**

No CAS bits with a single 125 usec frame. Default. Required for unstructured channels.

e1cas

CAS bits used in E1 multiframe structure.

ds1esfcas

CAS bits used in DS1 ESF multiframe structure.

ds1sfcas

CAS bits used in DS1 SF multiframe structure.

Default **basic**

Access This parameter is read-write.

Location ces-config

Products MALC

cell-loss-integration-period

The time in milliseconds for the cell loss integration period.

Default 2500

Access This parameter is read-write.

Location ces-config

Products MALC

destination-ip-address

Shows the configured destination IP address of the CES over IP connection.

Access This parameter is read-only.

Location ces-config

Products MALC

destination-port

Shows the configured destination UDP port number of the CES over IP connection.

Access This parameter is read-only.

Location ces-config

Products MALC

ds0-bundle

Lists the specified DS0 bundles.

Access This parameter is read-only.

Location ces-config

Products MALC

partial-fill

Specifies the number of user octets per cells. Setting this parameter to zero disables partial cell fill, and causes all cells to be completely filled before they are sent.

Default 0

Access This parameter is read-write.

Location ces-config

Products MALC

source-ip-address

Shows the configured source IP address of the CES over IP connection.

- Access** This parameter is read-only.
Location ces-config
Products MALC

source-port

Shows the configured source UDP port number of the CES over IP connection.

- Access** This parameter is read-only.
Location ces-config
Products MALC

vci

The VCI used by the ATM VCL mapped through this CES IWF to a CBR interface. Zero indicates that no ATM VCL has been specified.

- Default** 0
Access This parameter is read-write.
Location ces-config
Products MALC

vpi

The VPI used by the ATM VCL mapped through this CES IWF to a CBR interface.

- Default** 0
Access This parameter is read-write.
Location ces-config
Products MALC

Clocking

clock-transmit-source

Specifies the OC3-c/STM1 or OC12-c/STM4 clocking mode. The default is looptiming.

Values **looptiming**

The recovered receive clock from the interface is used as the transmit clock.

localtiming

A local (to the interface) clock source is used on the transmit signal.

throughtiming

The transmit clock is derived from the recovered receive clock of another interface. Interfaces that are designated as eligible clock sources cannot be set to through timing.

Default **looptiming****Location** **sonet-profile****Products** BAN, MALC, Raptor, Sechtor 100A

primaryclocksource

The *shelf-slot-port-subport/type* of an interface to provide clocking for the system.



Note: system-clock-profiles (if supported on the device) are the preferred method of configuring clock sources.

Values **A valid interface on the system.**

For the BITS clock on the MALC MTAC/Ring card, specify the address in the form *shelf-slot-1-0/ds1*.

Location **system**

Notes If configured, the setting in the **primaryclocksource** parameter overrides settings in the **system-clock-profile** for all interfaces that provide clocking.

Products BAN, MALC, Raptor, Sechtor 100A

revertiveclocksource

If a standby clock source becomes active after the failure of a primary clock source, the system will revert to the primary clock source after that clock source becomes active again. Note that the clock source must be active for 30 seconds before the system will revert back to the primary clock source.

Values **true**

The system clock is revertive.

false

The system clock is non-revertive.

Default **true****Location** **system****Products** BAN, MALC, Raptor, Sechtor 100A

transmit-clock-source

Specifies the DS1/DS3 clocking mode.

Values **looptiming**

The recovered receive clock from the DS1/DS3 is used as the transmit clock.

locltiming

A local (to the DS1/DS3 interface) clock source is used on the DS1/DS3 transmit signal.

throughtiming

The transmit DS1/DS3 clock is derived from the recovered receive clock of another DS1/DS3 interface. Interfaces that are designated as eligible clock sources cannot be set to through timing.

Default **looptiming (DS3) throughtiming (DS1)**

Location **ds1-profile, ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

system-clock-eligibility

Specifies whether the interface is eligible to provide clocking for the system. The source must be active in order to provide clock. The following types of interfaces can provide clock:

- T1/E1
- DS3/E3
- OC3-c
- OC12-c

Values **true**

false

Default **false**

Location **system-clock-profile**

Products BAN, MALC, Raptor, Sechtor 100A

system-clock-weight

Assigns a weight to the clock source. If you assign weight to a clock source that is higher than the currently active clock source, the system will switch over to that clock source.

Values **1 to 10**

1 is the lowest priority, 10 is the highest

Default **5**

Location **system-clock-profile**

Notes If you assign weight to a clock source that is higher than the currently active clock source, or if you assign a clock source in the **system** profile, the system will switch over to the new clock source.

Products BAN, MALC, Raptor, Sechtor 100A

DHCP

bootfile

The name of the initial boot file loaded by the client. The filename should be recognizable to the file transfer protocol that the client will be using to load the file.

Default **An empty string**

Location **dhcp-server-subnet, dhcp-server-group, dhcp-server-host**

boot-server

The IP address of the server from which the initial boot file (specified in the **bootfile** parameter) is to be loaded. If this IP address is specified as 0.0.0.0 then the primary interface address of the DHCP server is used.

Default **An empty string**

Location **dhcp-server-subnet, dhcp-server-host, dhcp-server-group**

Products BAN, MALC, Raptor, Z-Edge, ZRG

client-hostname

Client host name (if any) that the client used to acquire its address.

Default **An empty string**

Location **dhcp-server-lease**

Products BAN, MALC, Raptor, Z-Edge, ZRG

client-identifier

The DHCP client identifier.

Default **An empty string**

Access This parameter is read-write.

Location **dhcp-server-host**

Products BAN, MALC, Raptor, Z-Edge, ZRG

client-match-length

The length of the client identifier substring to match.

Default -1

Specifies that the entire string beginning at the match offset value should be matched.

Access This parameter is read-write.

Location dhcp-server-group

Products BAN, MALC, Raptor, Z-Edge, ZRG

client-match-offset

The offset into the client passed client identifier string where the string match should start.

Default 0 (zero)

Access This parameter is read-write

Location dhcp-server-group

Products BAN, MALC, Raptor, Z-Edge, ZRG

client-match-string

Client identifier match string that determines which clients should be placed in this group.

Access This parameter is read-write

Location dhcp-server-group

Products BAN, MALC, Raptor, Z-Edge, ZRG

defaultLease

The default requested lease length, in seconds.

Values From 100 to 604800 (1 week).

Default 604800

Location dhcp-client-resource

Notes This value should be greater than or equal to the **minLease**.

Products BAN, MALC, Raptor, Z-Edge, ZRG

default-lease-time

The default time, in seconds assigned to a lease if the client requesting the lease does not request a specific expiration time.

Values From -1 - 2147483647

Default -1

Indicates the parameter is ignored.

Access This parameter is read-write.

Location dhcp-server-subnet, dhcp-server-group, dhcp-server-host

Notes This value should be greater than or equal to the **min-lease-time**.

Products BAN, MALC, Raptor, Z-Edge, ZRG

default-router

The IP address of the client default gateway.

Default 0.0.0.0

Access This parameter is read-write.

Location dhcp-server-subnet, dhcp-server-group, dhcp-server-host

Products BAN, MALC, Raptor, Z-Edge, ZRG

dhcp

Specifies whether the IP interface is a DHCP client or server.

Values none

The interface is neither a DHCP client or a server.

client

The interface is a DHCP client.

server

The client is a DHCP server.

both

The interface is both a DHCP client and a server.

Default none

Location ip-interface-record

Products BAN, MALC, Raptor, Z-Edge, ZRG

dhcpClientErrors

The number of errors that the DHCP client has encountered.

Access This parameter is read-only.

Location `dhcp-client-resource`
Products BAN, MALC, Raptor, Z-Edge, ZRG

dhcpClientId

The DHCP client ID.

Location `dhcp-client-lease-resource`
Products BAN, MALC, Raptor, Z-Edge, ZRG

dns

A list of the DNS server and router IP addresses that the system will use.

Location `dhcp-client-lease-resource`
Products BAN, MALC, Raptor, Z-Edge, ZRG

dns-fwd-name

Dynamic DNS forward host name. Not currently used.

Location `dhcp-server-lease`
Products BAN, MALC, Raptor, Z-Edge, ZRG

dns-rev-name

Dynamic DNS reverse host name. Not currently used.

Location `dhcp-server-lease`
Products BAN, MALC, Raptor, Z-Edge, ZRG

domain

The routing domain to which this subnet, group, or host parameter applies.

Values `0 to 2147483647, inclusive`
Access This parameter is read-write.
Location `dhcp-server-subnet, dhcp-server-group, dhcp-server-host`
Products BAN, MALC, Raptor, Z-Edge, ZRG

domainName

The name of the DHCP domain.

Access This parameter is read-only.
Location `dhcp-client-lease-resource`

Products BAN, MALC, Raptor, Z-Edge, ZRG

domain-name

The default domain name that the client should use when resolving host names using DNS. The default is an empty string.

Default **The default is an empty string.**

Access This parameter is read-write.

Location **dhcp-server-subnet, dhcp-server-group, dhcp-server-host**

Products BAN, MALC, Raptor, Z-Edge, ZRG

ends

The time in Greenwich Mean Time (GMT) that the DHCP lease will expire.

Values **0 to 2147483647, inclusive.**

Location **dhcp-server-lease**

Products BAN, MALC, Raptor, Z-Edge, ZRG

external-server

Non-null IP address value indicates use of external DHCP server instead of internal DHCP for this subnet.

Default **00000000**

Location **dhcp-server-subnet**

Products MALC

flags

Indicates how the DHCP host acquired its lease.

Values **Static**

The lease is static. Static leases typically should not appear in the lease database.

bootp

The lease was allocated using the BOOTP protocol. BOOTP leases are unsupported.

abandonedlease

A client appears to exist (for example, the device responds to a ping command) on the network even though the DHCP server has not allocated the lease address to the client. In this case, the server abandons that lease and tries to reuse it only when it runs out of available addresses.

zhonecpe

The client that was allocated a lease identified itself as a Zhone CPE device (such as a Z-Edge).

Location **dhcp-server-lease**

Products BAN, MALC, Raptor, Z-Edge, ZRG

hardware-address

In the **dhcp-server-lease** profile, this parameter is the MAC address of the network interface that was used to acquire the lease.

In the **dhcp-server-host** profile, this parameter is the hardware address of the client that matches this host parameter. If the **client-identifier** parameter is specified, the hardware address is ignored.

Default **0 (zero)**

Access This parameter is read-write

Location **dhcp-server-lease, dhcp-server-host**

Notes Configure either the **hardware-address** or **client-identifier** for host parameters.

Products BAN, MALC, Raptor, Z-Edge, ZRG

hostName

Name of the DHCP host. This will not be a fully-qualified host name.

Access This parameter is read-only.

Location **dhcp-client-lease-resource**

Products BAN, MALC, Raptor, Z-Edge, ZRG

ipaddr1

The fixed IP address that should be assigned to this client.

Default **0.0.0.0**

Location **dhcp-server-host**

Products BAN, MALC, Raptor, Z-Edge, ZRG

ipaddr2

The fixed IP address that should be assigned to this client.

Default **0.0.0.0**

Location **dhcp-server-host**

Products BAN, MALC, Raptor, Z-Edge, ZRG

ipaddr3

The fixed IP address that should be assigned to this client.

Default 0.0.0.0

Location dhcp-server-host

Products BAN, MALC, Raptor, Z-Edge, ZRG

ipaddr4

The fixed IP address that should be assigned to this client.

Default 0.0.0.0

Location dhcp-server-host

Products BAN, MALC, Raptor, Z-Edge, ZRG

lease-time

The global default time in seconds that will be assigned to a DHCP lease if the client requesting the lease does not request a specific expiration time.

Values 0 to 21474836471

Default 43200 seconds (12 hours).

Location dhcp-server-options

Products BAN, MALC, Raptor, Z-Edge, ZRG

max-lease-time

The maximum time in seconds that will be assigned to a lease regardless of the value specified by a client.

Values -1 to 2147483647
-1 indicates that this parameter is ignored.

Default The default in the dhcp-server-options record is 86,400 seconds.

The default for dhcp-server-group, dhcp-server-host, and dhcp-server-subnet is -1.

Location dhcp-server-options, dhcp-server-subnet, dhcp-server-group, dhcp-server-host

Products BAN, MALC, Raptor, Z-Edge, ZRG

max-uui

Maximum user to user indicator.

Values 0 to 15
Specify 15 for audio.

Default 15

Location aal2-audio-profile

Products BAN, MALC, Raptor, Z-Edge, ZRG

min-uuu

Minimum user to user indicator.

Values 0 to 15
Specify 0 for audio.

Default 0

Location aal2-audio-profile

Products BAN, MALC, Raptor, Z-Edge, ZRG

minLease

The minimum acceptable lease length.

Values 1 to 604800 (one week)

Default 300

Location dhcp-client-resource

Notes This value should not be greater than the **defaultLease**.

Products BAN, MALC, Raptor, Z-Edge, ZRG

min-lease-time

The minimum expiration time in seconds that will be assigned to a DHCP lease by the server, regardless of the value specified by a client.

Values -1 to 2147483647

Default -1, which indicates that the parameter is ignored.

Location dhcp-server-options, dhcp-server-subnet, dhcp-server-group, dhcp-server-host

Notes This value should not exceed the **default-lease-time** setting.

Products BAN, MALC, Raptor, Z-Edge, ZRG

name

In a **dhcp-server-host** record this indicates the host name for the client. This may be fully qualified with the local domain name but it is recommended that you use the **domain-name** parameter to specify the domain name.

In a **dhcp-server-group** record this indicates the group parameter name.

- Default** The default is an empty string.
- Location** **dhcp-server-host, dhcp-server-group**
- Products** BAN, MALC, Raptor, Z-Edge, ZRG

netmask

The subnet mask associated with the IP interface. The value of the mask is an IP address with all the network bits set to 1 and all the hosts bits set to 0.

- Access** This parameter is read-write.
- Location** **dhcp-server-subnet, ip-interface-record**
- Products** BAN, MALC, Raptor, Z-Edge, ZRG

network

The IP network address of this subnet parameter.

- Access** This parameter is read-write.
- Location** **dhcp-server-subnet**
- Products** BAN, MALC, Raptor, Z-Edge, ZRG

primary-name-server

The IP address of the primary domain name server that the client should use for DNS resolution.

- Default** **0.0.0.0.**
- Access** This parameter is read-write.
- Location** **dhcp-server-subnet, dhcp-server-group, dhcp-server-host**
- Products** BAN, MALC, Raptor, Z-Edge, ZRG

range1-end

The last IP address of the first address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

- Default** **0.0.0.0**
- Location** **dhcp-server-subnet**
- Products** BAN, MALC, Raptor, Z-Edge, ZRG

range1-start

The starting IP address of the first address pool in this subnet. If either the start or end range has a value of 0 then the entire address pool is ignored.

Default 0.0.0.0
Location dhcp-server-subnet
Products BAN, MALC, Raptor, Z-Edge, ZRG

range2-end

The last IP address of the second address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

Default 0.0.0.0
Location dhcp-server-subnet
Products BAN, MALC, Raptor, Z-Edge, ZRG

range2-start

The starting IP address of the second address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

Default 0.0.0.0
Location dhcp-server-subnet
Products BAN, MALC, Raptor, Z-Edge, ZRG

range3-end

The last IP address of the third address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

Default 0.0.0.0
Location dhcp-server-subnet
Products BAN, MALC, Raptor, Z-Edge, ZRG

range3-start

The starting IP address of the third address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

Default 0.0.0.0
Location dhcp-server-subnet
Products BAN, MALC, Raptor, Z-Edge, ZRG

range4-end

The last IP address of the fourth address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

Default 0.0.0.0

Location dhcp-server-subnet

Products BAN, MALC, Raptor, Z-Edge, ZRG

range4-start

The starting IP address of the fourth address pool in this subnet. If either the start or end range has a value of 0, then the entire address pool is ignored.

Default 0.0.0.0

Location dhcp-server-subnet

Products BAN, MALC, Raptor, Z-Edge, ZRG

reserve-end

The default number of IP addresses at the end of a subnet IP address space that are reserved by the DHCP server. To override this default, create a specific subnet rule for each subnet that needs to be handled differently.

Values 0 to 255

Default 5

Access This parameter is read-write.

Location dhcp-server-options

Products BAN, MALC, Raptor, Z-Edge, ZRG

reserve-start

The default number of IP addresses at the start of a subnet IP address space that are reserved by the DHCP server. To override this default, create a specific subnet rule for each subnet that needs to be handled differently.

Values 0 to 255

Default 5

Access This parameter is read-write.

Location dhcp-server-options

Products BAN, MALC, Raptor, Z-Edge, ZRG

See Also send-type

restart

Restarts the DHCP server. A restart should only be done after making manual changes to the DHCP server lease table. All other configuration changes done using SNMP are automatically loaded by the server.

Values **true**

The server should restart by completely reloading its configuration.

false

This value is automatically assigned to the parameter once the restart command has been acknowledged by the server.

Default **false**

Access This parameter is read-write.

Location **dhcp-server-options**

Products BAN, MALC, Raptor, Z-Edge, ZRG

secondary-name-server

The IP address of the secondary domain name server that the client should use for DNS resolution.

Default **0.0.0.0.**

Access This parameter is read-write.

Location **dhcp-server-subnet, dhcp-server-group, dhcp-server-host**

Products BAN, MALC, Raptor, Z-Edge, ZRG

stickyaddr

Specifies that the DHCP server attempts to hand out the same IP address to the same host, whenever possible, based on hardware address.

Values **disable**

enable

Default **enable**

Location **dhcp-server-subnet**

Products BAN, MALC, Raptor, Z-Edge, ZRG

starts

The time in GMT that the lease was assigned.

Values **0 to 2147483647**

Location **dhcp-server-lease**

Products BAN, MALC, Raptor, Z-Edge, ZRG

state

The current state of the lease.

Values **init**
reboot
bound
verify
release
invalid
bind

Location **dhcp-client-lease-resource**

Notes Only **init**, **verify** and **release** can be changed.

Products BAN, MALC, Raptor, Z-Edge, ZRG

subnetgroup

The DHCP Subnet group ID used to indicate which address pool grouping may be used for the CPE subnet.

Default **0 (zero)**

Location **dhcp-server-subnet**

Products MALC

tftp

The tftp address for the current interface.

Access This parameter is read-only

Location **dhcp-client-lease-resource**

Products BAN, MALC, Raptor, Z-Edge, ZRG

vendor-match-length

The length of the vendor class identifier substring to match.

Default **-1, which indicates that the entire string starting at the match offset value should be matched.**

Location **dhcp-server-group**

Products BAN, MALC, Raptor, Z-Edge, ZRG

vendor-match-offset

The offset into the client passed vendor class identifier string where the string match should start.

Default 0 (zero)

Location dhcp-server-group

Products BAN, MALC, Raptor, Z-Edge, ZRG

vendor-match-string

The vendor class identifier match string that is used to determine which clients should be placed in the group.

Default An empty string.

Location dhcp-server-group

Products BAN, MALC, Raptor, Z-Edge, ZRG

version

The version number of the current DHCP server configuration. If this value changes, the server will reload all of its configuration rules and reinitialize itself. Any configuration rules modified before this field is changed will not affect the DHCP server configuration once it is reset.

Values 0 (zero) to 2147483647

Default 0 (zero)

Location dhcp-server-options

Products BAN, MALC, Raptor, Z-Edge, ZRG

DNS

domain

The routing domain to which this host parameter applies.

Values A string, maximum length 255 characters.

Default The default is an empty string.

Access This parameter is read-write.

Location resolver

first-nameserver

The IP address of the first or primary name server for this routing domain.

Default The default is an empty string.

Access This parameter is read-write.

Location resolver

hostalias1

Host name alias for specified host. The host name can be qualified or hostname only. The maximum length for this name is 255 characters.

Location host-name

hostalias2

Host name alias for specified host. The host name can be either fully-qualified or hostname only. The maximum length for this name is 255 characters.

Location host-name

hostalias3

Host name alias for specified host. The host name can be either fully-qualified or hostname only. The maximum length for this name is 255 characters.

Location host-name

hostalias4

Host name alias for specified host. The host name can be either fully-qualified or hostname only. The maximum length for this name is 255 characters.

Location host-name

hostname

Client host name (if any) that the client used to acquire its address.

Default The default is an empty string.

Location host-name

ipaddress

The IP address of this system or interface on the indicated subnet. For unnumbered interfaces, a unique internal identifier is used.

Location host-name

query-order

The type of resolver query for this routing domain.

- Values**
- hosts-first**
Searches the local hosts table first, then the list of nameservers.
 - dns-first**
Searches the list of nameservers first, then the local hosts table
 - dns-only**
Searches only the list of nameservers.
- Default** **hosts-first**
- Access** This parameter is read-write.
- Location** **resolver**

second-nameserver

The IP address of the secondary name server for this routing domain. This nameserver is queried if the first nameserver cannot resolve the query. If a secondary name server has not been defined, this field is set to 0.0.0.0

- Access** This parameter is read-write.
- Location** **resolver**

third-nameserver

The IP address of the third name server for this routing domain. This nameserver is queried if the first nameserver and the secondary nameserver cannot resolve the query. If a third name server has not been defined, this field is set to 0.0.0.0

- Access** This parameter is read-write.
- Location** **resolver**

DS1

cell-scramble

Indicates whether ATM cell scrambling is enabled for this interface. Both sides of the connection must agree on whether scrambling is enabled.

- Values**
- true**
Cell scrambling enabled.
 - false**
Cell scrambling disabled.

Default true
Products BAN, MALC, Raptor, Sechtor 100A

channelization

Indicates whether this DS1/E1 is channelized.

Values **disabled**
Not currently supported.

enabledDs0
This is a DS1 channelized into DS0s.

enabledDs1
This is a DS2 channelized into DS1s. Not currently supported.

Default enabledDs0

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

circuit-id

The transmission vendor circuit identification number.

Values integer

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

clock-source-eligible

Whether the clock source is eligible to become the transmit clock source.

Values **not-eligible**
The interface is not eligible to be used as the transmit clock source.

eligible
The interface can be used as the transmit clock source.

Default not-eligible

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

coset-polynomial

Indicates whether the coset polynomial is used to calculate the ATM header error control (HEC) value. Both sides of the connection must agree on the method of calculating the HEC value.

Values	true The coset polynomial is used to calculate the HEC value.
	false The coset polynomial is not used to calculate the HEC value.
Default	true
Location	ds1-profile
Products	BAN, MALC, Raptor, Sechtor 100A

csu-line-length

The length of the CSU WAN interface in feet. This objects provides information for line build out circuitry.

Values	csu00 0 dB line build out.
	csu75 -7.5 dB line build out.
	csu150 -15.0 dB line build out.
	csu225 -22.5 dB line build out.
Default	csu00
Location	ds1-profile
Products	BAN, MALC, Raptor, Sechtor 100A

ds1-group-number

The group index to which this DS1 belongs.

Default	0
Access	This parameter is read-write.
Location	ds1-profile
Products	BAN, MALC, Raptor, Sechtor 100A

ds1-mode

The type of T1 interface to which the system connects.

Values other
The T1 interface is neither DSX nor CSU.

dsx
The T1 interface is DSX.

csu
The T1 interface is CSU.

Default csu

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

dsx-line-length

The physical length of the T1 line. This setting is used to compensate for the attenuation of the line due to its length.

Values dsx0
Indicates the line is 0 feet.

dsx133
Indicates the line is 133 feet.

dsx266
Indicates the line is 266 feet.

dsx399
Indicates the line is 399 feet.

dsx533
Indicates the line is 533 feet.

dsx655
Indicates the line is 655 feet.

Default dsx0

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

fdl

Specifies the facilities data link protocol in use.

Values other
Indicates that a protocol other than one following is used.

ansit1403
FDL exchange recommended by ANSI.

att54016

ESF FDL exchanges.

fdlnone

The device does not use the FDL.

Default **fdlnone**

Access This parameter is read-write.

Location **ds1-profile**

Notes Not supported on E1.

Products BAN, MALC, Raptor, Sechtor 100A

line-code

The type of Zero Code Suppression used on the interface.

Values **b8zs**

Bipolar 8 Zero Substitution. A specific pattern of normal bits and bipolar violations used to replace a sequence of eight zeros. Used for T1.

hdb3

High Density Bipolar of order 3. Used for E1.

ami

Alternate Mark Inversion. No zero code suppression is present and the line encoding does not solve the problem directly. In this application, the higher layer must provide data which meets or exceeds the pulse density requirements Used for T1. Also used for E1 lines, with or without CRC.

Default

b8zs for T1

hdb3 for E1

Location **ds1-profile**

Products BAN, MALC, Raptor, Sechtor 100A

line-power

Enables and disables line power for the DS1 interface.

Default **Disabled**

Location **ds1-profile**

Products BAN, MALC, Raptor, Sechtor 100A

line-status-change-trap-enable

Whether zhoneLineStatusChange traps should be generated for this interface.

Values	enabled disabled
Default	disabled
Access	This parameter is read-write.
Location	ds1-profile
Products	BAN, MALC, Raptor, Sechtor 100A

line-type

The type of DS1 line used on this circuit. The type of circuit affects the number of bits per second that the circuit can reasonably carry, as well as the interpretation of the usage and error statistics.

Values	esf Extended SuperFrame DS1 (T1.107). d4 AT&T D4 format DS1 (T1.107). e1 ITU-T Recommendation G.704 (Table 4a). e1Crc ITU-T Recommendation G.704 (Table 4b). e1Mf G.704 (Table 4a) with TS16 multiframing enabled. e1crcmf G.704, table 4b, with TS16 multiframing and cyclic redundancy check enabled for E1 circuits. Used for V5.2.
Default	esf for T1 e1CrcMf for E1
Location	ds1-profile
Notes	<ul style="list-style-type: none"> • For more information see ITU-T Recommendation G.704. • D4 is not supported on the BAN, MALC, or Raptor.
Products	BAN, MALC, Raptor, Sechtor 100A

loopback-config

The loopback configuration of the DS1 interface.

Values	noloop Not in the loopback state. A device that is not capable of performing a loopback on the interface always returns this as its value.
---------------	--

lineloop

The received signal on this interface does not go through the device (minimum penetration) but is looped back out.

localloop

The transmitted signal on this interface is looped back and received by the same interface. What is transmitted onto the line is product dependent.

payloadloop

The received signal on this interface does not go through the device (minimum penetration) but is looped back out.

Default **noloop**

Access This parameter is read-write.

Location **ds1-profile**

Products BAN, MALC, Raptor, Sechtor 100A

protocol-emulation

Indicates whether the device is acting as a network-side device or CPE with respect to this DS1 connection.

Values **network**

cpe

Default **network**

Access This parameter is read-write.

Location **ds1-profile**

Notes Z-Edge 6200 only.

send-code

Indicates what type of code is being sent across the DS1 interface by the device.

Values **sendnocode**

Sending looped or normal data. This is the only supported option for E1 interfaces.

sendlinecode

Sending a request for a line loopback.

sendpayloadcode

Sending a request for a payload loopback. T1 only.

sendresetcode

Sending a loopback termination request. T1 only.

sendqrsspattern

Sending a Quasi-Random Signal (QRS) test pattern. T1 only.

send511pattern

Sending a 511 bit fixed test pattern. T1 only.

send3in24pattern

Sending a fixed test pattern of 3 bits set in 24. T1 only.

sendothertestpattern

Sending a test pattern other than those described by this parameter. T1 only.

send2047pattern

Sending 2047 test pattern. T1 only.

send1in2pattern

Sending alternate one, zero pattern. T1 only.

sendinbandcode

Sending inband loopback command. T1 only.

sendinbandcodeoff

Sending inband loopback off command. T1 only.

sendlinecodeoff

Sending line loopback command. T1 only.

sendpayloadcodeoff

Sending payload loopback command. T1 only.

Default sendnocode

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

signal-mode

The DS1 signaling mode.

Values None

No bits are reserved for signaling on this channel.

robbedBit

DS1 robbed bit signaling is in use.

bitOriented

E1 Channel Associated Signaling is in use.

messageOriented

Common Channel Signaling is in use either on channel 16 of an E1 link or channel 24 of a DS1.

Access This parameter is read-write.

Location ds1-profile

Products BAN, MALC, Raptor, Sechtor 100A

signal-type

The signaling type of the FXS interfaces within this DS1 connection.

- Values** **loopstart**
groundstart
- Default** **loopstart**
- Access** This parameter is read-write.
- Location** **ds1-profile**
- Notes** Z-Edge 6200 only.

transmit-clock-source

Specifies the DS1/DS3 clocking mode.

- Values** **looptiming**
 The recovered receive clock from the DS1/DS3 is used as the transmit clock.
- locltiming**
 A local (to the DS1/DS3 interface) clock source is used on the DS1/DS3 transmit signal.
- throughtiming**
 The transmit DS1/DS3 clock is derived from the recovered receive clock of another DS1/DS3 interface. Interfaces that are designated as eligible clock sources cannot be set to through timing.
- Default** **looptiming (DS3) throughtiming (DS1)**
- Location** **ds1-profile, ds3-profile**
- Products** BAN, MALC, Raptor, Sechtor 100A

DS3

channelization

Whether this DS3/E3 is channelized or unchannelized. Setting this object will cause the creation or deletion of DS2 or DS1 entries in the ifTable.

- Values** **disabled**
 This interface is unchannelized.
- enableds1**
 This is a DS3 channelized into DS1s.
- enableds2**
 This is a DS3 channelized into DS2s. Not currently supported.

Access This parameter is read-write.

Location **ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

circuit-id

The transmission vendor's circuit identification number

Values **string of up to 255 characters**

Access This parameter is read-write.

Location **ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

ds1-for-remote-loop

Which DS1/E1 on this DS3/E3 will be indicated in the remote DS1 loopback request. The type of loopback is configured in the **loopback-config** parameter.

Values **From 0 (zero) to 29, inclusive.**

A value of 0 means no DS1s will be looped. A value of 29 means all DS1/E1 will be looped.

Access This parameter is read-write.

Location **ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

far-end-equip-code

The Far End Equipment Identification code that describes the specific piece of equipment at the other end of the link. It is sent inside the Path Identification Message.

Values **A string of 0 (zero) to ten (10) characters, inclusive.**

Access This parameter is read-write.

Location **ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

far-end-fac-id-code

This code identifies a specific Far End DS3 path. It is sent inside the Path Identification Message.

Values **A string of 0 (zero) to ten (10) characters, inclusive.**

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sehtor 100A

far-end-frame-id-code

The Far End Frame Identification code that identifies where the remote equipment is located within a building at a given location. It is sent inside the Path Identification Message.

Values A string of 0 (zero) to 38 characters, inclusive.

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sehtor 100A

far-end-loc-id-code

The Far End Location Identification code that describes the location of the specific piece of equipment at the other end of the link. It is sent inside the Path Identification Message.

Values A string of 0 (zero) to eleven (11) characters, inclusive.

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sehtor 100A

far-end-unit-code

The Far End code that identifies the equipment location within a bay. It is sent inside the Path Identification Message.

Values A string of 0 (zero) to six (6) characters, inclusive.

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sehtor 100A

line-coding

This variable describes the variety of Zero Code Suppression used on this interface, which in turn affects a number of interface characteristics.

Values dsx3other

dsx3b3zs

Refers to the use of specified patterns of normal bits and bipolar violations which are used to replace sequences of zero bits of a specified length.

e3hdb3

High Density Bipolar of order 3. Refers to the use of specified patterns of normal bits and bipolar violations which are used to replace sequences of zero bits of a specified length. Used for E1 and E3.

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

line-length-meters

The length of the DS3 line in meters. This parameter provides information for line build out circuitry (if it exists) and is used to adjust the line build out.

Values From 0 to 6400 meters.

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

line-status-trap-enable

Indicates whether **line-status-trap-enable** traps should be generated for this interface.

Values **enabled**
disabled

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

line-type

The DS3 C-bit or E3 application used on this interface. The type of interface affects the interpretation of the usage and error statistics. DS3 transmits at a speed of 44.736 Mbps and E3 transmits at 34.368 Mbps.

Values **dsx3m23**
As defined in ANSI T1.107-1988 [9].

dsx3cbitparity
As defined in ANSI T1.107a-1990 [9a]

Default dsx3cbitparity

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

loopback-config

The loopback configuration of the DS3/E3 interface.

Values dsx3NoLoop

Not in the loopback state. A device that is not capable of performing a loopback on the interface will always return this value.

dsx3PayloadLoop

The received signal at this interface is looped through the device. Typically the received signal is looped back for retransmission after it has passed through the device's framing function.

dsx3LineLoop

The received signal at this interface does not go through the device (minimum penetration) but is looped back out.

dsx3InwardLoop

The sent signal at this interface is looped back through the device.

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

medium-atmframe-config

The ATM framing mode.

Values dsx3AtmFramingOther

The ATM framing format is other than PLCP or direct cell mapped.

dsx3AtmFramingPLCP

The ATM framing format is PLCP.

dsx3AtmFramingDirectCellMapped

The ATM framing format is direct cell mapped.

Default dsx3AtmFramingDirectCellMapped

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

medium-frame-config

The E3 framing mode.

Values e3FrameOther

An option other than e3FrameG832 or e3FrameG751.

e3FrameG832

E3 framing format will be G832.

e3FrameG751

E3 framing format will be G751.

Default e3FrameG832

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sehtor 100A

medium-scramble-config

Whether the DS3 scramble mode is enabled.

Values true

Scramble mode is enabled.

false

Scramble mode is disabled.

Default true

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sehtor 100A

send-code

Indicates what type of code is being sent across the DS3 interface by the device.

Values dsx3SendNoCode

Sending looped or normal data.

dsx3SendLineCode

Sending a request for a line loopback.

dsx3SendPayloadCode

Sending a request for a payload loopback. (All T1/E1s in the DS3.)

dsx3SendResetCode

Sending a loopback termination request.

dsx3SendDS1LoopCode

Sending a request to loopback a particular DS1/E1 within a DS3/E3 frame. The DS1/E1 is indicated in **ds1-for-remote-loop** parameter.

dsx3SendTestPattern

Sending a test pattern.

Default dsx3SendNoCode

Access This parameter is read-write.

Location ds3-profile

Products BAN, MALC, Raptor, Sechtor 100A

transmit-clock-source

Specifies the DS1/DS3 clocking mode.

Values **looptiming**

The recovered receive clock from the DS1/DS3 is used as the transmit clock.

localtiming

A local (to the DS1/DS3 interface) clock source is used on the DS1/DS3 transmit signal.

throughtiming

The transmit DS1/DS3 clock is derived from the recovered receive clock of another DS1/DS3 interface. Interfaces that are designated as eligible clock sources cannot be set to through timing.

Default **looptiming (DS3) throughtiming (DS1)**

Location **ds1-profile, ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

unit-mode

Specifies whether the unit is configured as a CO or CPE device.

Default **For a BAN, the default is CO. For a Z-Edge, the default is CPE.**

Access This parameter is read-write.

Location **ds3-profile**

Products BAN, MALC, Raptor, Sechtor 100A

See Also **config-line-rate, fix-bit-enabled**

DSL

config-line-rate

The SDSL line rate.

Values **line-rate-144kbps, line-rate-160kbps, line-rate-192kbps, line-rate-208kbps, line-rate-224kbps, line-rate-256kbps, line-rate-272kbps, line-rate-320kbps, line-rate-368kbps, line-rate-384kbps, line-rate-400kbps, line-rate-416kbps, line-rate-528kbps, line-rate-768kbps, line-rate-784kbps, line-rate-1040kbps, line-rate-1152kbps, line-rate-1168kbps, line-rate-1536kbps, line-rate-1552kbps, line-rate-1568kbps, line-rate-2320kbps, line-rate-176kbps, line-rate-240kbps,**

line-rate-288kbps, line-rate-304kbps, line-rate-336kbps, line-rate-352kbps, line-rate-432kbps, line-rate-464kbps, line-rate-496kbps, line-rate-560kbps, line-rate-592kbps, line-rate-624kbps, line-rate-656kbps, line-rate-688kbps, line-rate-720kbps, line-rate-752kbps, line-rate-816kbps, line-rate-848kbps, line-rate-880kbps, line-rate-912kbps, line-rate-944kbps, line-rate-976kbps, line-rate-1008kbps, line-rate-1072kbps, line-rate-1104kbps, line-rate-1136kbps, line-rate-1200kbps, line-rate-1232kbps, line-rate-1264kbps, line-rate-1296kbps, line-rate-1328kbps, line-rate-1360kbps, line-rate-1392kbps, line-rate-1424kbps, line-rate-1456kbps, line-rate-1488kbps, line-rate-1520kbps, line-rate-1584kbps, line-rate-1616kbps, line-rate-1648kbps, line-rate-1680kbps, line-rate-1712kbps, line-rate-1744kbps, line-rate-1776kbps, line-rate-1808kbps, line-rate-1840kbps, line-rate-1872kbps, line-rate-1904kbps, line-rate-1936kbps, line-rate-1968kbps, line-rate-2000kbps, line-rate-2032kbps, line-rate-2064kbps, line-rate-2096kbps, line-rate-2128kbps, line-rate-2160kbps, line-rate-2192kbps, line-rate-2224kbps, line-rate-2256kbps, line-rate-2288kbps

Default line-rate-1552kbps

Access This parameter is read-write.

Location sdsl-config

connect-mode

The connection mode compatibility.

Values **basic-2b1q-mode**

The basic operating mode.

globespan-neg-mode

The globespan mode, when the CO and the CPE can have different rates that sync on the lower rate.

copper-mtn-mode

The operating mode compatible with Copper Mountain products.

flowpoint-mode

The operating mode compatible with FlowPoint Corporation equipment.

Default flowpoint-mode

Access This parameter is read-write.

Location sdsl-config

decoder-coeffA

The 21 bit value corresponding to the decoder coefficient A.

Default The ANSI HDSL2 default

Access read-write
Location **hds12-config**

decoder-coeffB

A 21 bit value corresponding to the decoder coefficient B.

Default **The ANSI HDSL2 default**
Location **hds12-config**

fix-bit-rate

Normally, if the central office (CO) and CPE select different line rates at startup, the lower of the two rates is selected. The **fix-bit-rate** parameter enables a CO unit to override the default procedure and require startup at the rate specified in **config-line-rate**.

Values **fix-bit-disable**

This value enables automatic baud rate adaption. If the CO and CPE devices have different line rates at startup, the lower of the two rates will be selected.

fix-bit-enable

This value is used for static (set) baud rates.

Default **fix-bit-disable**
Access This parameter is read-write.
Location **sdsl-config profile**

Notes This setting applies only if the unit is configured as a CO device.

See Also **config-line-rate, unit-mode**

frame-sync-word

A 10-bit number indicating the frame sync word used.

Default **The HDSL2 standard.**
Location **hds12-config**

framer-type

Specifies the type of framer used.

Values **atm-clear-channel**

Uses direct cell mapping

atm-dllc

Uses DLCC framing specification.

atm-g991-1

Uses framing specified in G.991.1

Default atm-clear-channel

Access This parameter is read-write.

Location sdsl-config

line-status-trap-enable

Specifies whether a line status trap should be sent whenever the DSL line goes up or down. Note that this setting does not apply to line status traps sent during system bootup. During bootup, line status traps are not sent.

A DSL link down trap has a moderate severity level and a link up trap has a low severity.

Values enabled

DSL line status change traps should be generated for this interface.

disabled

DSL line status change traps will not be generated for this interface.

auto

For ADSL, a trap is generated on a line status change which is not due to a dying gasp.

Default enabled

line-type

The DSL type supported on this interface.

Values shdsl

SHDSL. Not compatible with **shdslatest** firmware.

sdsl

SDSL. Not compatible with **sdslatest** firmware.

shdslatest

Compatible with future versions of firmware code. Required for autobaud.

sdslatest

Compatible with future versions of firmware code. Required for autobaud.

Default shdslatest

Access This parameter is read-write.

Location dsl-config

Notes Refer to the release notes for your device firmware revision levels.

ntr

Network timing recovery (NTR) specifies that the system synchronizes with an external (network) clocking source.

- Values** **ntr-enable**
the system synchronizes with the network.
- ntr-disable**
the system relies on its own clocking source.
- Default** **ntr-disable**
- Location** **sdsl-config**

pointtopoint

Specifies whether the interface is point-to-point.

- Values** **true**
false
- Default** **false**
- Access** This parameter is read-write.
- Location** **ip-interface-record**
- Notes** Configure DSL interfaces as **pointtopoint**.

power-scale

Adjusts transmit power in small increments to compensate for minor differences in power between units. The formula for the adjustment is:

$$\text{Power scale} = 29952 * 10^{([\text{adjustment in dB}] / 20)}$$

The following values are recommended for different loop lengths.

- Values** **17664**
For loop lengths from 0 to 10 feet (0 to 3.05 meters). Corresponds to -3.39dB.
- 20992**
For loop lengths less than 4000 feet (1219.2 meters). Corresponds to -1.9dB.
- 29952**
For loop lengths greater than 4000 feet (1219.2 meters). Corresponds to -1.19dB.
- Default** **29952**
- Access** This parameter is read-write.
- Location** **sdsl-config**

stuff-bits

A four bit number for the stuff bits. The default is the HDSL2 standard, 1111'b.

Default The HDSL2 standard, 1111'b.

Location hdsl2-config, hdsl2-status

threshold-15min-lofs

The number of Loss of Framing seconds on a DSL interface within any given 15 minutes performance data collection period, which causes the SNMP agent to send a trap. Entering 0 will disable the trap.

Default 0

Access This parameter is read-write.

Location dsl-alarm

threshold-15min-lols

The number of Loss of link seconds on a DSL interface within any given 15 minutes performance data collection period, which causes the SNMP agent to send a trap. Entering 0 will disable the trap.

Default 0

Access This parameter is read-write.

Location dsl-alarm

threshold-15min-loss

The number of Loss of signal seconds on a DSL interface within any given 15 minutes performance data collection period, which causes the SNMP agent to send a trap. Entering 0 will disable the trap.

Default 0

Access This parameter is read-write.

Location dsl-alarm

transmit-power-back-off-mode

Whether the transmit power backoff defined in the HDSL2 standard is used.

Values **backoffdisable**
backoffenable
nochangebackoff

Default **backoffdisable**

Location **hdl2-config**

unit-mode

Specifies whether the unit is configured as a Central Office (CO) or Customer Premise Equipment (CPE) device.

Values **co**
cpe

Default **cpe**

Location **dsl-config**

up-line-rate

The upstream DSL rate in bps on the interface.

Access This parameter is read-only

Location **dsl-status-profile**

See Also **down-rate**

ELCP

audio-service

Defines a number of services for transporting audio traffic and signaling over an AAL2 CID.

Values **enabled**
disabled

Default **enabled**

Location **aal2-elcp-port**

isdn-channel-id

ISDN BRI ports.

Values **0**
D channel and POTS

1
First B channel

2
Second B channel

Location subscriber-voice-aal2-elcp

line-group-id

The line group ID for this ELCP AAL2 connection.

Location subscriber-voice-aal2-elcp

max-length-frame

Maximum length for frame mode data.

Location aal2-elcp-port

max-sdu-length

Indicates the maximum size of the SSSAR-SDU, in octets, that is allowed to be reassembled.

Location aal2-elcp-port

pcm-encoding

Voice encoding algorithm.

Values mulaw

alaw

Default alaw

Location aal2-elcp-port

port-id

Identifies a port on the IAD side for this ELCP AAL2 connection.

Location subscriber-voice-aal2-elcp

port-type

The port type for the IAD port for the current connection.

Location subscriber-voice-aal2-elcp

preferred-ap-index

Index for the preferred audio encoding format within the Audio Profile.

- Values**
- 1**
Used for G.711 encoding
 - 2**
Used for G.726 encoding
- Default** 1
- Location** aal2-elcp-port

voice-connection-type

This describes the connection type between the two voice endpoints. Where applicable the first endpoint refers to the line or premise side of the connection and the second endpoint refers to the central office side of the connection.

- Values**
- aal2togr303**
AAL2 VPI/VCI/CID to GR-303 interface group/CRV.
 - aal2tov52**
AAL2 VPI/VCI/CID to V5.2 interface/user port.
 - elcpaal2tov52**
ECLP AAL2 to V5.2.
 - potstoaal2**
POTs to AAL2.
 - isdntoaal2**
ISDN to AAL2.
 - isdntov52**
ISDN to V5.2 interface/user port
 - potstogr303**
POTS to GR-303 interface group/CRV.
 - potstov52**
POTS to V5.2 interface/user port.
 - elcpaal2tov52**
ELCP AAL2 VPI/VCI/portId/portType to V5.2.
- Location** subscriber-voice

Ethernet

adminstatus

The administrative status of the Ethernet physical and logical interface.

Values **Up**

The interface is enabled and up, and the status of the interface should become standby or operational

Down

The interface is disabled and down, and the status of the interface should become shutdown.

Location **ether**

autoNegCap

The capabilities of the Ethernet interface that are advertised by this port. Note that multiple options can be specified by adding a plus (+) sign between entries.

This parameter also controls flow control, which is used to regulate the flow of traffic between endpoints. Flow control cause the transmitter to stop sending traffic if it receives a pause message from an overwhelmed far end.

For more information on flow control refer to IEEE 802.3-2000.

Values **bOther**

Other or unknown

b100baseT4

Advertise 100BASE-T4

b100baseT2

Advertise 100BASE-T2 half duplex mode

b100baseT2FD

Advertise 100BASE-T2 full duplex mode

b10baseT

Advertise speed 10Mbps, duplex half and full

b10baseTFD

Advertise speed 10Mbps, duplex full

b100baseTX

Advertise 100BASE-TX half duplex mode

b100baseX

Advertise 100BaseX

b100baseT

Advertise speed 100Mbps, duplex half and full

b100baseTXFD

Advertise 100BASE-TX full duplex

b100baseXFD

Advertise 100BaseX full duplex

b100baseTFD

Advertise speed 100Mbps, duplex full

b1000baseX

Advertise 1000BaseX full duplex

b1000baseT

Advertise 1000Mbps, duplex full

b1000baseXFD

1000BaseX full duplex

b1000baseTFD

Advertise speed 1000Mbps, duplex full

bFdxPause

Advertise pause for full duplex links

bFdxBPause

Advertise Full (symmetric and asymmetric) flow control

bFdxAPause

Advertise Asymmetric flow control

bFdxSPause

Advertise Symmetric flow control

autonegstatus

Enables autonegotiation. When enabled, the interface will negotiate the options specified in the **autoNegCap** parameter.

Values enabled

Negotiate link attributes with remote partner. Final link rate, duplex, and flow control, are determined by the advertised capabilities on each end. The link will settle on a speed/duplex based on the hierarchy described in the IEEE 802.3-2000 document.

disabled

Do not negotiate. Link speed and duplex will be forced to the parameters indicated in the 'mauType' field. If the other end does not advertise those parameters (when in autonegotiate mode), or if the other end wants to force the link to a different speed/duplex combination, there will no link.

Default enabled**Location ether**

Notes If set to **disabled**, the interface is the same as specified in the **ifType** parameter.

clksrc

Determines which side of the link will provide clocking for the link.

If both sides are configured for automatic, both ends of the link negotiate which will be the master and which will be the slave based on the rules in IEEE 802.3-2000. If both sides are configured the same (either as master or as slave) the link will not be established.

Values **automatic**

The clock source is selected based on the rules in the IEEE 802.3-2000. This is the recommended setting.

master

The local side will attempt to provide clock for the link.

slave

The local will attempt to recover clock from the clock generated by the far end of the link.

Default **automatic**

Location **ether**

Notes Applies to Gigabit Ethernet ports only.

ifType

The type of Ethernet. Should be set to the same value as the mauType.

Values **mauOther**

Supported on UTP

mau10Baset

Supported on UTP

mau10Basethd

Supported on UTP

mau10Basetfd

Supported on UTP

mau100Basetxhd

Supported on UTP

mau100Basetxfd

Supported on UTP

mau1000basethd

Supported on UTP

mau1000basetfd

Supported on UTP

mau1000baselxhd

Supported on fiber

mau1000baselxfd
Supported on fiber

mau1000basesxhd
Not supported

mau1000basesxfd
Not supported

Location ether

mauType

Ethernet physical interface type.

Values **mauOther**
Supported on UTP

mau10Baset
Supported on UTP

mau10Basethd
Supported on UTP

mau10Basetfd
Supported on UTP

mau100Basetxhd
Supported on UTP

mau100Basetxfd
Supported on UTP

mau1000basethd
Supported on UTP

mau1000basetfd
Supported on UTP

mau1000baselxhd
Supported on fiber

mau1000baselxfd
Supported on fiber

mau1000basesxhd
Not supported

mau1000basesxfd
Not supported

Default **mau100basetxfd (for all Ethernet interfaces except Gigabit)**
mau1000baselxfd (Gigabit Ethernet)

Location ether

protection-fast-timer

The protection messages fast timer. The fast timer is used for protection protocols.

Values 1 to 20 milliseconds

Default 10 milliseconds

protection-slow-timer

This timer indicates how often the node sends out slow status messages when a protection event occurs. This value is in 50 millisecond (ms) intervals. For example, a value of 100 equals 5 seconds.

Values 1 to 200 (in 50 millisecond units)

Default 20 (1 second)

protection-wtr

The length of time in seconds, to remain in the protection state, after the cause for the switch to protection is removed. This prevents protection switch oscillations.

Values 0 to 1440 seconds

Default 10 seconds

remotefault

Indicates the state of the remote end of the Ethernet link.

Values noerror

Link is operating normally.

offline

Other end is not attempting to establish a link.

linkfailure

Failed to establish a link. This could be caused by different settings on either end of the link.

autonegerror

Failed to establish a link because a matching combination could not be found in the advertised autonegotiation capabilities.

Location ether

restart

Forces auto-negotiation to begin link renegotiation. If auto-negotiation signaling is disabled, this parameter has no effect.

Values restart

Forces auto-negotiation to begin link renegotiation. The Ethernet interface also renegotiates the link whenever the **ether** profile is saved.

norestart

This value is not supported.

Location ether

reversion-mode

The reversion mode determines if traffic resumes processing in the normal direction after a protection event is cleared.

Values true

false

wrap-config

Indicates the configured protection mode, steering or wrapping, in a MAC that supports both modes.

If the node detects another station on the ring that has a protection configuration that conflicts with its own, the station will generate a defect to higher layers.

Values true

The ring is configured for wrapping. The station will perform wrap protection during ring failures. In a wrapping configuration, the two nodes on either end of the disrupted link will “wrap” the traffic back away from the broken link.

false

The ring is configured for steering. In a steering configuration, each node of the ring is responsible for determining how to route traffic around the disrupted link. For large networks, traffic could be slower to recover if steering is used.

FXS/FXO

fxo-cfg-signal-type

The signaling type of foreign exchange office (FXO) interface.

Values fxoloopstart

Loop start.

fxogroundstart

Ground start.

fxodpt

Dial Pulse Terminating. This option allows the unit to attach to incoming one way trunks from a PBX, key system, or a telephone set.

Default **fxoloopstart**

Location **analog-fxo-cfg-profile**

if-cfg-impedence

Specifies the terminating impedance of analog voice interfaces.

Values **ohms600complex**
600 Ohms + 2.16uF

ohms900complex
900 Ohms + 2.16uF

Default **ohms900complex**

Location **analog-if-cfg-profile**

if-cfg-trunk-conditioning

Specifies whether the FXS/FXO port should send the idle pattern to the network upon declaration of a Carrier Group Alarm (CGA) on the WAN link to which the port is assigned.

Values **off**
idle
busy

Default **idle**

Location **analog-if-cfg-profile**

if-maintenance-mode

Indicates the maintenance modes of the analog voice interface.

Values **off**
ifdigitalloopback
ifanalogloopback

Default **off**

Location **analog-if-cfg-profile**

if-cfg-pcm-encoding

Line encoding.

Values	alaw For E1. mulaw For T1.
Default	mulaw
Location	analog-if-cfg-profile
Notes	This parameter can also be set with the voice add command when the voice connection is created.

if-cfg-receive-rlp

The receive TLP is the signal level TO the customer premises equipment (CPE). The receive signal range is +3 dB to -9 dB. A positive number adds gain, a negative number adds loss to the analog signal after decoding from PCM. For example, a receive TLP setting of -6 dB will generate a voice signal at -6 dB level.

Values	fxsrtlpn9db fxsrtlpn8db fxsrtlpn7db fxsrtlpn6db fxsrtlpn5db fxsrtlpn4db fxsrtlpn3db (not supported on the POTS 900 card) fxsrtlpn2db (not supported on the POTS 900 card) fxsrtlpn1db fxsrtlp0db fxsrtlp1db fxsrtlp2db fxsrtlp3db rtlpnumeric
Default	fxsrtlpn6db
Location	analog-if-cfg-profile

if-cfg-receive-tlpNum

Receive Transmission Level Point (RTLTP) settings control the amount gain or loss added to the incoming signal after it is decoded to analog. To increase the signal level set the RTLTP setting to higher values. The default is 0 dB.

Values -160 to 85 (in tenths of dB)

Default 0 dB

Location analog-if-cfg-profile

if-cfg-transmit-tlp

The transmit TLP is the signal level from the customer premises equipment (CPE). The transmit signal range is +9 dB to -3 dB. A positive number adds loss, a negative number adds gain to the analog signal before encoding to PCM. For example, a transmit TLP setting of +3 dB will set a loss of 3 dB to generate a 0 dB PCM signal.

Values fxsTtlp9db
(not supported on the POTS 900 card)

fxsTtlp8db
(not supported on the POTS 900 card)

fxsTtlp7db

fxsTtlp6db

fxsTtlp5db

fxsTtlp4db

fxsTtlp3db

fxsTtlp2db

fxsTtlp1db

fxsTtlp0db

fxsTtlpN1db

fxsTtlpN2db

fxsTtlpN3db

Default fxsttlp0db

Location analog-if-cfg-profile

if-cfg-transmit-tlpNum

Transmit Transmission Level Point (TTLTP) controls the amount of gain or loss added to a voice signal before it is encoded to digital PCM. To increase the signal level, reduce the TTLTP setting to lower value.

Values -175 to 70 (in tenths of dB)

Default 0 dB

Location analog-if-cfg-profile

ring-back

Specifies whether ring back is requested.

Values on

off

Default off

Location analog-fxs-cfg-profile

ring-frequency

The ring frequency used in the FXS interface.

Values **ringFrequency25**
Ring frequency of 25 Hz.

ringFrequency50
Ring frequency of 50 Hz.

ringFrequency20
Ring frequency of 20 Hz

ringFrequency30
Ring frequency of 30 Hz.

Default ringFrequency20

Location analog-fxs-cfg-profile

signal-type

The signaling of the FXS interface.

Values **fxsLoopStartsloop**
Loop start.

fxsGroundStart
Ground start.

fxsLoopStartFd

fxsGroundStartAutomatic
Used with equipment requiring fast response time to the Central Office (CO).

fxsGroundStartImmediate
Used with equipment requiring fast response time to the station or private branch exchange (PBX).

fxsdnLoopStart

Loop start in FXSDN mode.

fxsdnLoopStartFd**fxsdnGroundStart**

Ground start in FXSDN mode

fxsdnGroundStartImmediate

Ground start immediate in FXSDN mode

fxsdnwinkLoopStart

Loop start in fxsdnwink (Foreign Exchange Subscriber Defined Wink start). This is the same type of signaling as FXSDN. It provides 150 millisecond delay, then a 200 ms wink acknowledgement to the central office when the FXS port sees an off-hook condition from central office. The system requires a ringing generator for this option.

fxsdnwinkLoopStartFd**fxsdnwinkGroundStart**

Ground start in FXSDNWINK mode

fxsdnwinkGroundStartImmediate

Ground start immediate in FXSDNWINK mode.

fxstr08SingleParty

TR08 is Frame format signaling and data link as defined in TR-TSY-00008 Mode 1 for circuits using AT & T SLC-96 facilities. This option is for single-party service. This option connects the port to one way outgoing trunks from a PBX, CENTEREX, key system, or telephone set to an SLC channel. The SLC96 mode also must be active on the associated WAN interface.

fxstr08UniversalVoiceGrade

Toll-quality voice for SLC-96.

fxstr08UniversalVoiceGradeAutomatic

Used with some non-Bell switches for SLC-96.

Default `fxsLoopStartsloop`

Access This parameter is read-write

Location `analog-fxs-cfg-profile`

voice-pots-line-group-id

The line group identifier for the POTS line, equal to the ifIndex of the line.

Access This parameter is read-write.

Location `subscriber-voice-pots`

GR303

adminStatus

A value that is received from a remote management system (Zhone Management System) to place the unit in service or out of service.

- Values** **inService**
outOfService
- Default** **outOfService**
- Access** This parameter is read-write.
- Location** **gr303-interface-group**

channel-number

The channel number for this array.

- Values** **1 to16, inclusive**

control-channel-t303

The time that the Integrated Digital Terminal (IDT) and the Remote Digital Terminal (RDT) will wait for a reply to a SETUP message. This value depends upon the IDT.

- Values** **700, 1200, 1700, 2200, 2700, 3200, 3700, 4200, or 4700 ms.**
- Default** **700**
- Access** This parameter is read-write.
- Location** **gr303-ig-control-channel**

control-channel-t396

The time that the RDT will wait for a reply to a SETUP message after the expiration of the T303 timer.

- Values** **700, 1700, 2700, 3700, 4700, 5700, 6700, 7700, 8700, 9700, 10700, 11700, 12700, 13700, or 14700 ms.**
- Default** **14700**
- Access** This parameter is read-write.
- Location** **gr303-ig-control-channel**

ctrlChannel

The GR-303 IG control channel array. This array includes the **control-channel-t303**, **control-channel-t396**, **sapi-0-max-outstanding-frames**, **sapi-1-max-outstanding-frames**, **sapi-0-n-200**, **sapi-1-n-200**, **sapi-0-t-200**, **sapi-1-t-200**, **sapi-0-t-203**, **sapi-1-t-203**, **sapi-0-pps-mode**, and **sapi-1-pps-mode** parameters.

Location **gr303-interface-group**

ds1LM:array[1..28]

The array for T1/DS1 circuits. The maximum number of DS1 trunks allowed per IG is 28. This array includes the **dsn-lg-id**, **channel-number**, and **role** parameters.

Location **gr303-interface-group**

idt-admin-state

The administrative state of the IDT on the remote side of the GR-303 interface.

Values **inService**

The default for Call Reference Values (CRV) whose IG has **working-mode** set to **passive**.

outOfService

The default for CRVs whose IG has **working-mode** set to **active**.

Default **outOfService**

Access This parameter is read-write.

Location **gr303-ig-crv**

local-admin-state

The administrative state of the CRV on the local (RDT) side.

Values **inService**

outOfService

Default **outOfService**

Access This parameter is read-write.

Location **gr303-ig-crv**

logical-id

This is a unique number to identify each physical DS1 within an Interface Group between RDT and IDT.

Values 1 to 28, inclusive.

Access This parameter is read-write.

Location **gr303-interface-group**

Notes The DS1 Logical ID must have a value in the range of 1..28. The value 1 is reserved for the primary DS1 and cannot be used by any other DS1s.

name-id

A name assigned by the installer. It must be unique to the system. This value is a string.

rdt-admin-state

The administrative state of the RDT on the local side of the GR-303 interface.

Values **inService**

outOfService

Default **outOfService**

Access This parameter is read-write.

Location **gr303-ig-crv**

remote-admin-state

The administrative state of the CRV on the remote (IDT) side.

Values **inService**

The default for CRVs whose IG has **working-mode** set to **passive**.

outOfService

The default for CRVs whose IG has **working-mode** set to **active**.

Access This parameter is read-only.

Location **gr303-ig-crv**

role

The role the DS1 line assumes.

Values **payload**

secondary

primary

Default **payload**

Access This parameter is read-write.

Location **gr303-interface-group**

sapi-0-max-outstanding-frames

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum number of outstanding EOC information frames at layer 2. This LAPD parameter facilitates remote provisioning of the layer 2 connection.

Values 1 to 10, inclusive.

Default 7

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-0-n-200

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum number of retransmissions for a frame at layer 2. This LAPD parameter facilitates remote provisioning of the layer 2 connection.

Values 1 to 10, inclusive.

Default 3

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-0-pps-mode

The DS1 protection switching option. Facility protection switching enables traffic on a failed DS1 to be moved to one or more alternate DS1 facilities.

Values inhibit

notInhibited

notApplicable

Default notInhibited

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-0-t-200

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum layer 2 wait time for an acknowledgement of a transmitted frame in milliseconds. This LAPD parameter facilitates remote provisioning of the layer 2 connection.

Values 100, 150, 200, 250, 300, or 350.

Default 150

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-0-t-203

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum layer 2 idle time, in seconds, before connection verification is necessary. This LAPD parameter facilitates remote provisioning of the layer 2 connection.

Values 10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 110, 120, 130, 140, 150, 160, 170, 180, 190, 200, 210, 220, 230, 240, 250, 260, 270, 280, 290, or 300.

Default 30

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-1-max-outstanding-frames

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum number of outstanding TMC information frames at layer 2. This LAPD parameter facilitates remote provisioning of the layer 2 connection. (This parameter is not supported.)

Values 1 to 7, inclusive.

Default 7

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-1-n-200

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum number of retransmissions for a frame at layer 2. This LAPD parameter facilitates remote provisioning of the layer 2 connection. (This parameter is not supported)

Values 1 to 10, inclusive

Default 3

Access This parameter is read-write.

Location gr303-ig-control-channel

sapi-1-pps-mode

The DS1 protection switching option. Facility protection switching enables traffic on a failed DS1 to be moved to one or more alternate DS1 facilities.

Values **inhibit**
notInhibited
notApplicable

Default **notInhibited**

Access This parameter is read-write.

Location **gr303-ig-control-channel**

sapi-1-t-200

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum layer 2 wait time for an acknowledgement of a transmitted frame in milliseconds. This LAPD parameter facilitates remote provisioning of the layer 2 connection.

Values **100, 150, 200, 250, 300, or 350.**

Default **150**

Access This parameter is read-write.

Location **gr303-ig-control-channel**

Notes Unsupported

sapi-1-t-203

For SAPI=1 and SAPI=2, for both the active and standby data links, per IG, the maximum layer 2 idle time, in seconds, before connection verification is necessary. This LAPD parameter facilitates remote provisioning of the layer 2 connection.

Values **10, 20, 30, 40, 50, 60, 70, 80, 90, 100, 110, 120, 130, 140, 150, 160, 170, 180, 190, 200, 210, 220, 230, 240, 250, 260, 270, 280, 290, or 300.**

Default **30**

Access This parameter is read-write.

Location **gr303-ig-control-channel**

Notes Unsupported

signal-type

The signaling method used by the CRV. This value is set by the voice switch through the EOC or it is set in the **gr303-ig-crv** profile.

Values **unknown**
loopstart
groundstart
loopreversebattery
electronicbusinessset

Default **loopstart**

Access This parameter is read-write.

Location **gr303-ig-crv**

switch-type

The switch vendor for the Interface Group (IG).

Values **unknown**
lucent5Ess
nortelDms100

Default **unknown**

Access This parameter is read-write.

Location **gr303-interface-group**

working-mode

Indicates whether the Integrated Digital Terminal (IDT) can configure the Remote Digital Terminal (RDT) for Call Reference Values (CRV) using common management information service (CMIS) over the Embedded Operations Channel (EOC).

Values **active**
The IDT can configure the RDT for CRV over the EOC channel.

passive
CRVs can only be configured locally.

Default **passive**

Access This parameter is read-write.

Location **gr303-interface-group**

IfIndex

adminStatus

The default value for the upper ifIndex associated with the **upperiftype**.

Values up
down
testing

Default down

Access This parameter is read-write.

Location if-default

ifindex

The interface number of the port or port/subport that uniquely identifies the interface across the system.

Access This parameter is read-only.

Location physical-to-ifindex, if-translate

ifname

Name of the interface.

Allowable characters are:

*0123456789abcdefghijklmnopqrstuvwxyzABCDEFGHIJKLMNOPQRSTUVWXYZ
WXYZ:.- and _.*

.Do not begin if-name with a ".".

If an invalid character is used, it will be replaced with the "-" character. If the repaired if-name is not unique, the ifIndex value is appended to the if-name to make the name unique.

Access This parameter is read-only.

Location if-translate

iftype-extension

The Zhone-proprietary interface type.

Values ianaiftype_other
zhoneiftype_linegroup
zhoneiftype_none

Default zhoneiftype_none

Access This parameter is read-only.

Location if-translate

numunits

Number of units for this association. This indicates the number of ifIndexes created for this particular upper and lower interface pair on the card type. For example, 48 for the SDSL/SHDSL card.

Values 0 to 2147483647, inclusive

Access This parameter is read-only.

Location if-default

physical-flag

Indicates whether the interface is a physical layer.

Values true

The interface is a physical layer.

false

The interface is a not a physical layer.

Default false

Access This parameter is read-only.

Location if-translate

port

The port number defines the physical port number at the shelf-slot location for the line profile. Port numbers begin with 1 and are numbered sequentially.

Values 1 to 262143, inclusive

Access This parameter is read-only

Location if-translate

Notes 0 (zero) is invalid.

redundancy-param1

For physicals, this parameter is a weight value indicating which physical will be the active and which physical will be the standby for redundancy. For linegroups and pathgroups, this parameter indicates how to perform reversion.

Values -1

Do not revert the redundancy switch.

0

Revert back to the restored connection as soon as it is available.

Positive number

Number of seconds to wait after the restored connection is available until reverting back to that connection.

Access This parameter is read-write

Location **if-translate**

shelf

The physical address or number of the shelf where the desired line is located. A Zhone system is limited to a maximum of 255 shelves. The first shelf in a system is shelf 1.

Access This parameter is read-only.

Location **if-translate**

slot

The physical slot on the system.

Values **1 to 17, inclusive**

Location **if-translate**

subport

Used to identify multiple logical subports on a physical port.

Access This parameter is read-only.

Location **if-translate**

Notes A value of 0 (zero) indicates that there is no subport.

IMA

groupSymmetry

The symmetry of the Inverse Multiplexing over ATM (IMA) group. Symmetry determines whether the transmit and receive sides of the IMA link must be configured and how traffic is sent over the links.

Values **symmetricOperation**

Both transmit and receive IMA links must be configured and the system can transmit and receive traffic only if both sides of the connection are active.

asymmetricOperation

Both transmit and receive IMA links must be configured, but the system can transmit and receive traffic even if both sides of the connection are not active.

asymmetricConfiguration

Transmit and receive links do not have to be configured and the system can transmit and receive traffic even if both sides of the connection are not active.

Default **symmetricOperation**

Access This parameter is read-write.

Location **ima-group-profile**

Notes Refer to ATM Forum IMA v1.1, Section 5.2.2.7.

minNumTxLinks

Minimum number of transmit links required to be Active for the IMA group to be in the Operational state. If the number of active links falls below this value, the link drops and the redundant link (if any) takes over.

Values **1 to 32**

Access This parameter is read-write.

Location **ima-group-profile**

Notes Refer to ATM Forum IMA v1.1, Section 10.2.1.1.

Products MALC

minNumRxLinks

Minimum number of receive links required to be active for the IMA group to be in the operational state. If the number of active links falls below this value, the link drops and the redundant link (if any) takes over.

Values **1 to 32**

Access This parameter is read-write.

Location **ima-group-profile**

Notes Refer to ATM Forum IMA v1.1, Section 10.2.1.1.

txClkMode

Transmit clocking mode used by the near-end IMA group.

Values **itc**

Independent Transmit Clock. Indicates that IMA links do not all use the same transmit clock. Each IMA link derives clock from its associated T1 interface.

ctc

Common Transmit Clock. Indicates the transmit clock of all IMA links are derived from the same source. When set to **ctc**, the MALC derives the IMA clocking from the system clock.

Default `itc`
Access This parameter is read-write.
Location `ima-group-profile`
Notes Refer to ATM Forum IMA v1.1, Section 7.

txImald

The IMA ID currently in use by the near-end IMA function.

Values `0 to 255`
Access This parameter is read-write.
Location `ima-group-profile`
Notes Refer to ATM Forum IMA v1.1, Section 5.2.2.6

txFramLength

The frame length to be used by the IMA group in the transmit direction. Can only be set when the IMA group is startup.

Values `m32`
32 cells.
m64
64 cells.
m128
128 cells.
m256
256 cells.
Default `m128`
Access This parameter is read-write.
Location `ima-group-profile`
Notes Refer to ATM Forum IMA v1.1, Section 5.2.2.4.2

diffDelayMax

The maximum number of milliseconds of differential delay among the links that can be tolerated on this interface.

Values `0 to 100`
Default `25`
Access This parameter is read-write.
Location `ima-group-profile`
Notes Refer to ATM Forum IMA v1.1, Section 9.2 on page 45.

alphaValue

The number of consecutive invalid ICP cells allowed before the system changes from a Sync state to a Hunt state.

Values 1 or 2

Default 2

Access This parameter is read-write.

Location ima-group-profile

Notes Refer to ATM Forum IMA v1.1, Section 11 on page 68

betaValue

The number of consecutive ICP cells with errors allowed before the system changes from a Sync state to a Hunt state.

Values 1 to 5

Default 2

Access This parameter is read-write.

Location ima-group-profile

Notes Refer to ATM Forum IMA v1.1, Section 11.

gammaValue

The number of consecutive valid ICP cells allowed before the system changes from a PreSync state to the Sync state.

Values 1 to 5

Default 1

Access This parameter is read-write.

Location ima-group-profile

Notes Refer to ATM Forum IMA v1.1, Section 11.

testLinkIfIndex

Indicates the interface used to transmit the test pattern. The test pattern is looped back from the far end device over each active link in the IMA group. Note that this value is not the same as the txImaId value.

Values A valid interface on the system in the form shelf-slot-port-subport/type
This is the link whose link identifier (LID) value is inserted in the Tx LID field of the transmitted ICP cells.

Default 0

Access This parameter is read-write.

Location **ima-group-profile**

Notes Refer to ATM Forum IMA v1.1, Section 13.

testPattern

Specifies the transmit Test Pattern in an IMA group loopback operation. A value in the range 0 to 254 designates a specific pattern.

Values **-1 to 254**
-1 indicates that the test pattern is randomly generated.

Default **-1**

Access This parameter is read-write.

Location **ima-group-profile**

Notes Refer to ATM Forum IMA v1.1, Section 13.

testProcStatus

Enables or disables the Test Pattern Procedure.

Values **disabled**
Deactivates the test pattern procedure.
operating
Activates the test pattern procedure.

Default **disabled**

Access This parameter is read-write.

Location **ima-group-profile**

Notes Refer to ATM Forum IMA v1.1, Section 13.

txTimingRefLink

The ifIndex of the receive timing reference link to be used by near-end for IMA data cell clock recovery toward the ATM layer. A value of 0 (zero) indicates no link has been configured in the IMA group, or the receive timing reference link has not yet been detected.

Values **0**

Default **0**

Location **ima-group-profile**

Notes This parameter is not supported.

rxTimingRefLink

The ifIndex of the transmit timing reference link to be used by near-end for IMA data cell clock recovery toward the ATM layer. A value of 0 (zero) indicates no link has been configured in the IMA group, or the receive timing reference link has not yet been detected.

Values 0

Default 0

Location ima-group-profile

Notes This parameter is not supported.

IP

addr

The address of the IP interface.

Location ip-interface-record

alternateipaddress

A second IP address for this device that can be used by managers to address the device. This address may be an IP address of an existing IP interface.

Location system

Notes A manager can communicate with the device using any of the configured IP interface addresses. However, if the physical line fails or the card is inactive, communication with the manager may time-out.

bcastaddr

The IP broadcast address used for sending data grams on the (logical) interface associated with the IP interface. The broadcast address is determined by the IP address and the netmask. It should always be set to an IP address which is the network address of the interface that has all ones in the host portion of the address.

Location ip-interface-record

bcastenabled

Specifies whether broadcasts are enabled on this interface.

Values `yes`
`no`

Default `yes`

Location `ip-interface-record`

destaddr

The destination address for point-to-point IP interfaces.

Location `ip-interface-record`

Notes This parameter is ignored if the IP interface is not point-to-point.

dhcserverenable

Enables or disables DHCP server functionality.

Values `true`

`false`

Default `false`

Access This parameter is read-write.

Location `ip-interface-record`

Notes If this parameter is set to `true`, then `ipaddrdynamic` parameter has to be set to `static`. If this parameter is set to `false`, then `ipaddrdynamic` parameter can be set to `static`, `ppp`, or `dhcclient`.

See Also `ipaddressdynamic`

egressfilterid

The index of the egress filter spec provisioned for this interface.

Values `0 to 2147483647, inclusive`

A value of 0 (zero) means that there is no egress filter provisioned for this interface.

Default `0`

Access This parameter is read-write

Location `ip-interface-record`

enable

Specifies the administrative state of the static route.

Values `enabled`

The static route is used by the system to make forwarding decisions.

disabled

The static route is not used by the system to make forwarding decisions.

Default **enabled**

Location **static-route**

farendaddr

The IP address of the interface on the far end, or receiving end, of this interface. This information is used for Zhone Automatic Provisioning (ZAP).

Access This parameter is read-write

Location **ip-interface-record**

ipaddrdynamic

The mode by which the IP address is discovered by the system.

Values **static**

The IP address is static.

dhcpclient

The IP address is discovered from a DHCP server.

ppp

Use PPP to obtain an IP address.

Default **static**

Access This parameter is read-write

Location **ip-interface-record**

See Also **dhcserverenable**

ipfwdenabled

Specifies whether IP forwarding is enabled on this interface.

Values **true**

false

Default **true**

Access This parameter is read-write

Location **ip-interface-record**

ingressfilterid

The index of the ingress filter spec provisioned for this interface.

Values 0 to 2147483647, inclusive
A value of 0 (zero) means that there is no ingress filter provisioned for this interface.

Default 0
Access This parameter is read-write
Location ip-interface-record

ipUnnumberedinterface

This value specifies where to borrow the local IP address of the point-to-multipoint link.

Location ip-unnumbered-record

local-ipaddr

A local (or private) address of a host behind the Z-Edge 64, which is the real destination.

Location pat-bind

local-port

The port number on the local host where packets should be forwarded.

Location pat-bind

maxVideoStreams

The maximum number of unique multicast (video) streams to which this interface has subscribed.

Default 0
Access This parameter is read-write.
Location ip-interface-record

mcastcontrollist

List of Mcast-control-ids this IP Interface record is associated with.

Access This parameter is read-write.
Location ip-interface-record

mcastenabled

Specifies whether multicast is enabled on this interface.

Values true
false

Default true

Access This parameter is read-write.

Location ip-interface-record

mcastfwdenabled

Specifies whether multicast forwarding is enabled on this interface.

Values true
false

Default true

Access This parameter is read-write.

Location ip-interface-record

metric

Metric for the route. The meaning of this value when static routes are redistributed to other protocols is protocol-dependent, and the resulting value after redistribution is determined by the route-maps in use for that protocol. Lower numeric values for this number indicate more preferred routes.

Default 2147483647

Access This parameter is read-write.

Location static-route

mru

The size, in octets, of the largest packet which can be received on the IP interface. For interfaces used for network data grams, this is the size of the largest network datagram that can be received on the interface.

The default value depends on the type of interface and is the same as the default MTU for the interface.

Access This parameter is read-write.

Location ip-interface-record

multicastAgingPeriod

Multicast aging period (in tenths of seconds) for the specified VLAN. After the specified aging period is met, the VLAN address is deleted from the routing table.

Values 0 to 2147483647 (in tenths of seconds)
A value of 0 indicates that aging is turned off.

Access This parameter is read-create.

Location static-bridge

natenabled

Specifies whether NAT is enabled on this interface.

Values true
false

Default false

Access This parameter is read-write.

Location ip-interface-record

netmask

The subnet mask associated with the IP interface. The value of the mask is an IP address with all the network bits set to 1 and all the hosts bits set to 0.

Access This parameter is read-write.

Location dhcp-server-subnet, ip-interface-record

outgoingCOSOption

Specifies whether to overwrite the VLAN priority bits on packets bridged out this interface with the value specified in the outgoingCOSValue parameter. Values are disable and all. Disable indicates the VLAN priority bit is untouched. All overwrites all the VLAN priority bits on packets bridged out this interface with the value specified in the outgoingCOSValue parameter. The default is disable.

outgoingCOSValue

For tagged packets, specifies the value loaded into the priority field of the VLAN header. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

portType

The type of payload.

Values tcp
Transmission control protocol.

udp

User datagram protocol.

Default tcp

Location pat-bind

public-ipaddr

The IP address that will be used in the Internet. (This should be the IP address of the DSL connection.)

Location pat-bind

public-port

The port on the Internet side that the public sees.

Location pat-bind

rdindex

The routing domain to which the IP interface belongs. An IP address is unique to a routing domain.

Location ip-interface-record

reasmmaxsize

The size of the largest IP datagram that this interface can reassemble from fragmented IP datagrams this interface receives.

Values 0 (zero) to 65535, inclusive

Default 65535

Access This parameter is read-write.

Location ip-interface-record

subnetgroup

The DHCP subnet group ID. It indicates which address pool grouping may be used for the CPE subnet.

Location ip-interface-record, dhcp-server-subnet

type

Defines the video stream type.

Values normal

Join and leave when desired. Used for video.

always on

Always joined. Meant for Emergency Broadcast System (EBS) channel. Not meant for video.

periodic

Join and leave after task complete. For example, used to download the tv guide. Not meant for video.

Default normal

Access This parameter is read-write.

Location mcast-control-entry

unnumberedindex

The index of the **ip-unnumbered-record** used to obtain the local-side unnumbered address.

Location ip-interface-record

upperiftype

The value of ifType corresponding to the higher sublayer of the relationship, that is, the sublayer that runs on top of the sublayer identified by the corresponding instance of **loweriftype**.

Location if-default

upperlayer

The *shelf-slot-port-subport/type* of the upper layer in the interface stack.

Location if-stack

vlanId

The Virtual LAN Identifier for the IP Interface. If the VLAN ID specified is non-zero, all traffic destined to this interface should be configured with this VLAN ID.

Default 0

Access This parameter is read-write.

Location ip-interface-record

Products MALC

vlanIDCOS

Specifies the value loaded into the priority field of the VLAN header when an untagged packet received on this interface is tagged (VLAN ID inserted) for

bridging. Values are 0 to 7 with 0 the lowest priority and 7 the highest. The default value is 0.

ISDN

isdn-env-func-start-address

The envelope function starting address that the ISDN primary rate access is assigned to.

Values 0 to 8175, inclusive.

Access This parameter is read-write.

Location v52-interface-group

isdnds-cpath-id

If the user port is configured for ISDN, this parameter is equal to the associated C-path ID that carries Ds-type data. A value of 0 (zero) indicates that the user port is not configured to carry Ds-type data.

Values 0 to 48, inclusive.

Access This parameter is read-write.

Location v52-user-port

line-group-id

Identifies the physical line or line group (primary and redundant secondary) used for data and voice traffic. This is a unique number that is assigned when a line redundancy group is provisioned. This enables administrators to locate the physical lines (defined by the line group entry ID) used by the subscriber.

The **line-group-id** is used to associate a subscriber with data and voice subscriber profiles.

Location subscriber-voice-isdn

ulc-port-type

Identifies the ULC port provisioning. There is one entry per ULC port.

Values pots

isdn

ebs

Default isdn

Location ulc-config

Notes `isdn` is the only supported option.

Products MALC

ulc-trap-enable

Enables the sending of line-level traps from the device to SNMP managers.

Values `enabled`

`disabled`

Default `disabled`

Location `ulc-config`

Products MALC

voice-isdn-channel-id

The channel identifier for the connection.

Values `0`

Not applicable. This is the value for POTS.

`1`

D channel

`2`

B channel

`3`

B channel

Default `0 (none)`

Location `subscriber-voice-isdn`

voice-isdn-line-group-id

The line group identifier for the ISDN line, equal to the `ifIndex` of the line. Use the `linegroup` command to find the line group ID for an interface.

Location `subscriber-voice-isdn`

voice-isdn-port-type

Defines the type of ISDN channel: D channel or B channel.

Values `isdndchannel`

`isdnbchannel`

Location `subscriber-voice-isdn`

MTAC/Ring

ifIndex

Specifies the ifindex of the physical line to be tested. If no line is being tested, this value is 0.

Values A **physical interface on the system.**
In the format *shelf-slot-port-subport/type*

Default 0

Access This parameter is read-write.

Location **mtac-profile**

Notes This parameter cannot be modified while a test is in progress.

The ability of a physical line to support a metallic test may vary depending on the cards installed and the external test equipment.

Products MALC

ringSource

The ifIndex of the interface from which clock can be derived. Only OC3, DS1, and DS3 interfaces can be used for this interface.

This interface will be used to drive the 8Khz backplane signal. The interface must be set to loop or local timing in order for it to be considered as the primary clock source. It must also be administratively turned on and be in an operational state.

Only one interface in the system can be the primary clock source at any given time.

Values **externalRingSourceLabel**
internalRingSourceLabel

Default **internalRingSourceLabel**

Access This parameter is read-write.

Location **system**

test_mode

Specifies metallic test mode for a given line. The test mode can be changed only if the **ifIndex** parameter is set to a nonzero value.

Values **mtacModeBridge**
The subscriber line is metallically connected to the MTAC test access port while the subscriber is in service. To avoid service interruption, the test head must be in high impedance (bridge) mode.

mtacModeLookIn

The subscriber line is disconnected and the service port is metallicity routed to the MTAC test access port. This allows the testing of the device service port using a external test head or where the test head represents the subscriber terminal.

mtacModeLookOut

The device service port is disconnected and the subscriber line is metallicity routed to the MTAC test access port. This allows the testing of line with or without a subscriber terminal.

mtacModeNone

No MTAC test is in progress.

Default **mtacModeNone**

Access This parameter is read-write.

Location **mtac-profile**

Products MALC

Network Time Protocol

primary-ntp-server-ip-address

The IP address of the primary Network Time Protocol (NTP) server.

NTP, described in RFC 2030, synchronizes devices on the network with a timing source. When NTP is enabled, setting the system time with the **setdatetime** command is not allowed.

The device will get the time from the NTP server every hour. If the system clock has drifted more than 9 seconds from the source clock, the system time will be reset.

Values **A valid IP address**

A value of 0.0.0.0 disables NTP.

Default **0.0.0.0**

Location **ntp-client-config**

Products BAN, MALC, Raptor, Sechter 100A

secondary-ntp-server-ip-address

The IP address of the secondary NTP server. If the primary NTP server is not available, the BAN will use the secondary server.

Values **A valid IP address**

A value of 0.0.0.0 disables NTP.

Default **0.0.0.0**

Location ntp-client-config

Products BAN, MALC, Raptor, Sehtor 100A

local-timezone

The time zone the device is operating in.

Values **internationalDateLineWest**

GMT-12:00 hours

nome

GMT-11:00

hawaii

GMT-10:00

yukon

GMT-9:00

pacific

GMT-8:00

mountain

GMT-7:00

central

GMT-6:00

eastern

GMT-5:00

atlantic

GMT-4:00

newfoundland

GMT-3:30

brasilgia

GMT-3:00

azores

GMT-2:00

westAfrica

GMT-1:00

gmt

GMT/UTC

centralEuropean

GMT+1:00

easternEurope

GMT+2:00

baghdad

GMT+3:00

tehran
GMT+3:30

uae
GMT+4:00

afghanistan
GMT+4:30

islamabad
GMT+5:00

india
GMT+5:30

kathmandu
GMT+5:45

dhaka
GMT+6:00

rangoon
GMT+6:30

bangkok
GMT+7:00

chinaCoast
GMT+8:00

japan
GMT+9:00

australia
GMT+9:30

guam
GMT+10:00

magadan
GMT+11:00

newZealand
GMT+12:00

rawakiIslands
GMT+13:00

lineIslands
GMT+14:00

Default gmt

Location ntp-client-config

Products BAN, MALC, Raptor, Sechtor 100A

PON

auto-learn

Auto-learn enable flag. This sets up password-protection on the connection between OLT and ONU.

Values **oltautolearndisable**

You must set a password for the connection between OLT and ONU.

oltautolearnenable

The OLT automatically learns the password for the connection between OLT and ONU.

Default **oltautolearndisable**

Location **olt-config**

guaranteed-bw

The sum of the **guaranteed-bw** and **maximum-bw** parameter values for all the ports should be less than or equal to the upstream bit rate (155 Mb/second) of the PON OLT card.

Location **olt-traf-cont**

Notes The **guaranteed-bw** and **maximum-bw** parameter values in the **olt-traf-cont** profile must be a multiple of 63.

The **guaranteed-bw** and **maximum-bw** parameter values in the **olt-traf-cont** profile should be equal.

maximum-bw

The sum of the **guaranteed-bw** and **maximum-bw** parameter values for all the ports should be less than or equal to the upstream bit rate (155 Mb/second) of the PON OLT card.

Location **olt-traf-cont**

Notes The **guaranteed-bw** and **maximum-bw** parameter values in the **olt-traf-cont** profile must be a multiple of 63.

The **guaranteed-bw** and **maximum-bw** parameter values in the **olt-traf-cont** profile should be equal.

olt-onu-password

ONU remote-device password.

Location **olt-onu-config**

olt-onu-serial-num

ONU remote-device serial number. Usually the ZRG.

Location olt-onu-config

PPPoA

accm-enable

Enable or disable Asynchronous Control Character Map (ACCM) negotiation.

Values enabled

disabled

Default disabled

Access This parameter is read-write.

Location ppp-lcp

acfc-enable

Enable or disable Address and Control Field Compression (ACFC) negotiation.

Values enabled

disabled

Default disabled

Access This parameter is read-write.

Location ppp-lcp

callback-dial-string

The dialing string used for a callback. The format of this string is determined by callback-type.

Values 0 to 0

Default empty string

Access This parameter is read-write.

Location ppp-lcp

Notes This object only applies when callback negotiation is enabled using **callback-enable**.

callback-enable

Enable or disable callback negotiation. Provides a method for an implementation to request a dial-up peer to call back.

Values	enabled disabled
Default	disabled
Access	This parameter is read-write.
Location	ppp-lcp

callback-type

The method of determining the location to callback.

Values	byauth Location is determined by authorization information.
	bydialstr Location is determined by a dialing string.
	byidentifier Location is determined by a location ID.
	bye164 Location is determined by an E.164 number.
	byename Location is determined by a distinguished name.
Default	byauth
Access	This parameter is read-write.
Location	ppp-lcp
Notes	These objects only apply when callback negotiation is enabled using callback-enable .

call-mode

Indicates where the PPP call is initiated.

Values	nocall No call is initiated.
	incall Call is initiated remotely.
	outcall Call is initiated locally.
Default	nocall

Access This parameter is read-write.

Location **ppp-interface**

chap-enable

Enables or disables Challenge Handshake Authentication Protocol (CHAP).

Values **enabled**

disabled

Default **disabled**

Access This parameter is read-write.

Location **ppp-auth**

chap-name

The username for authenticating with the CHAP protocol.

Default **empty string**

Access This parameter is read-write.

Location **ppp-auth**

chap-secret

The password for authenticating with the CHAP protocol.

Default **empty string**

Access This parameter is read-write.

Location **ppp-aut**

comp-slot-id

Indicates whether the slot identifier field may be compressed.

Values **enabled**

The slot identifier may be compressed.

disabled

The slot identifier must not be compressed. All compressed TCP packets must set the C bit in every change mask, and must include the slot identifier.

Default **disabled**

Access This parameter is read-write.

Location **ppp-ncp**

fcs-alt-enable

Enable or disable Frame Check Sequence (FCS) alternative negotiation. The negotiated FCS values take effect only during Authentication and Network-Layer Protocol phases.

Values **enabled**
disabled

Default **disabled**

Access This parameter is read-write.

Location **ppp-lcp**

fcs-size

The size of the Frame Check Sequence (FCS) in bits, the local node will attempt to negotiate for use with the remote node.

Values **16**

Default **16**

Access This parameter is read-write.

Location **ppp-lcp**

Notes Regardless of the value of this object, the local node will comply with any FCS size negotiations initiated by the remote node, per the PPP specification.

Changing this parameter will take effect when the link is next restarted.

frame-type

Indicates which type of framing is used.

Values **atmlc**
atmvc

Default **atmlc**

Access This parameter is read-write.

Location **ppp-interface**

initial-mru

The initial Maximum Receive Unit (MRU) that the local PPP entity will advertise to the remote entity.

Values **128 to 65535**

Default **1500**

Access This parameter is read-write.

Location `ppp-lcp`

Notes If set to 0 the local PPP entity will not advertise any MRU to the remote entity and the default MRU will be assumed.

Changing this object will have effect when the link is next restarted.

ip-addr-enable

Enable or disable IP Address Negotiation.

Values `enabled`

`disabled`

Default `disabled`

Access This parameter is read-write.

Location `ppp-ncp`

ip-comp-protocol

Sets the IP compression option.

Values `none`

The local node will not attempt to negotiate any IP compression.

`vj-tcp`

The local node will attempt to negotiate Van Jacobson TCP/IP header compression.

Default `none`

Access This parameter is read-write.

Location `ppp-ncp`

Notes See RFC 1332 for more information on Van Jacobson compression.

Changing this parameter will take effect when the link is next restarted.

ip-ifindex

The index value of the **ip-interface-record** associated with this PPP authentication record.

Values `0 to 2147483647`

Default `0`

Access This parameter is read-write.

Location `ppp-auth`

Notes If this entry is to be used for incoming authentication, this object must be set to a non-zero value.

lgid

The unique identifier of the line group which uses this authentication data.

Values 0 to 2147483647

Default 0

Access This parameter is read-write.

Location ppp-auth, ppp-interface

link-type

Indicates which type of connection is used.

Values atm

isdn

asynch

virtual

Default atm

Access This parameter is read-write.

Location ppp-interface

lqr-period

The Link Quality Reporting period that the local PPP entity will attempt to negotiate with the remote entity, in units of hundredths of a second.

Values 1000 to 99999

Default 0

Access This parameter is read-write.

Location ppp-lcp

Notes Changing this parameter will take effect when the link is next restarted.

lqr-status

Enable or disable Link Quality Report (LQR) status.

Values enabled

The local node will attempt to perform LQR negotiation with the remote node.

disabled

LQR negotiation is not performed.

Default disabled

Access This parameter is read-write.

Location `ppp-lcp`

Notes Changing this parameter will take effect when the link is next restarted.
See RFC 1333 for more information on Link Quality Reporting.

pap-enable

Enables or disables Password Authentication Protocol (PAP).

Values `enabled`

`disabled`

Default `disabled`

Access This parameter is read-write.

Location `ppp-auth`

magic-number

The number used in magic number negotiation. When set to zero, a random number will be used for the magic number. This allows us to better prevent having two devices with the same magic number.

Default `0`

Access This parameter is read-write.

Location `ppp-lcp`

magic-number-enable

Enable or disable magic number negotiation.

Values `false`

Magic number negotiation is not performed.

`true`

The local node will attempt to perform magic number negotiation with the remote node.

Default `false`

Access This parameter is read-write.

Location `ppp-lcp`, `ppp-ncp`

Notes Changing this parameter will take effect when the link is next restarted.

max-config-retries

Number of Link Control Protocol (LCP) configuration retries without response before the link is brought down.

Values 1 to 999
Default 10
Access This parameter is read-write.
Location ppp-lcp

max-failure-retries

Number of times a Configuration Negative Acknowledgment is sent before a Configuration Reject is sent

Values 1 to 999
Default 10
Access This parameter is read-write.
Location ppp-ncp

max-pad

The number of padded bytes at the end of data. This is used for Self-Describing Padding, a method for placing unambiguous padding octets at the end of the PPP Information field in order to cause messages to fall on a natural boundary.

Values 1 to 255
Default 4
Access This parameter is read-write.
Location ppp-lcp
Notes See Self-Describing Padding in RFC 1570.

max-fail-retries

Number of times a Configuration Negative Acknowledgment is sent before a Configuration Reject is sent.

Values 1 to 999
Default 10
Access This parameter is read-write.
Location ppp-lcp

max-slot-id

The maximum slot ID for Van Jacobson TCP/IP header compression.

Values 3 to 16

Default 3

Access This parameter is read-write.

Location **ppp-ncp**

Notes The **ip-comp-protocol** parameter must be set to **vj-tcp** to enable Van Jacobson TCP/IP header compression. See RFC 1332 for more information on Van Jacobson compression.

max-term-retries

Number of Link Control Protocol (LCP) termination retries without response before the link is brought down.

Values 1 to 999

Default 2

Access This parameter is read-write.

Location **ppp-lcp**

max-terminate-retries

Number of IP termination retries without response before the session is brought down.

Values 1 to 999

Default 2

Access This parameter is read-write.

Location **ppp-ncp**

mru-enable

Enable or disable Maximum Receive Unit (MRU) negotiation.

Values **enabled**
disabled

Default **enabled**

Access This parameter is read-write.

Location **ppp-lcp**

num-channels

The maximum number of channels allowed on this interface.

- Values** 1
- Default** 1
- Access** This parameter is read-write.
- Location** **ppp-interface**
- Notes** Only one channel is supported.

num-mode-enable

Enable or disable Numbered Mode negotiation.

- Values** **enabled**
disabled
- Default** **disabled**
- Access** This parameter is read-write.
- Location** **ppp-lcp**
- Notes** From RFC 1663: “The Link Control Protocol (LCP) Numbered-Mode Configuration Option negotiates the use of Numbered-Mode on the link. By default or ultimate disagreement, Unnumbered-Mode is used.”

pap-password

The password used for authenticating with the PAP protocol.

- Default** **empty string**
- Access** This parameter is read-write.
- Location** **ppp-auth**
- Notes** The **pap-peer-id** and **pap-password** values must be entered as strings with single quotes. After the **ppp-auth** record is saved, the **pap-peer-id** and **pap-password** values will be converted to hexadecimal values. For example, the string ‘test’ will be returned as 74:65:73:74.

pap-peer-id

The username for authenticating with the PAP protocol.

- Default** **empty string**
- Access** This parameter is read-write.
- Location** **ppp-auth**
- Notes** The **pap-peer-id** value must be entered as a string with single quotes. After the **ppp-auth** record is saved, the **pap-peer-id** value will be converted to hexadecimal values. For example, the string ‘test’ will be returned as 74:65:73:74.

pfc-enable

Enable or disable Protocol Field Compression (PFC) negotiation.

Values **enabled**

disabled

Default **disabled**

Access This parameter is read-write.

Location **ppp-lcp**

quality-protocol

The link Quality Protocol used.

Values **lqr**

Default **lqr**

Access This parameter is read-write.

Location **ppp-lcp**

Notes The only valid quality protocol is LQR.

receive-auth-enable

Enable or disable incoming authentication.

Values **enabled**

disabled

Default **enabled**

Access This parameter is read-write.

Location **ppp-lcp**

Notes This parameter provides a method to negotiate the use of a specific protocol for authentication.

restart-timer

Number of seconds before retransmission of an Link Control Protocol (LCP) packet.

Values **1 to 999**

Default **3**

Access This parameter is read-write.

Location **ppp-lcp**

rx-acc-map

The Asynchronous Control Character (ACC) map that the local PPP entity requires for use on its receive side. In effect, this is the ACC map that is required in order to ensure that the local modem will successfully receive all characters.

Access This parameter is read-write.

Location **ppp-lcp**

Notes Changing this parameter will take effect when the link is next restarted.

sdp-enable

Enable or disable Self-Describing Padding (SDP) negotiation.

Values **enabled**
disabled

Default **disabled**

Access This parameter is read-write.

Location **ppp-lcp**

send-auth-identity

The identity (PAP peer ID or CHAP name) used with **send-auth-protocol** to look up the outgoing authentication information.

Default **empty string**

Access This parameter is read-write.

Location **ppp-lcp**

receive-auth-protocol

The preferred protocol used for incoming authentication.

Values **pap**
chap

Default **pap**

Access This parameter is read-write.

Location **ppp-lcp**

Notes If **receive-auth-enable** is enabled, the authentication protocol will be negotiated with the peer.

restart-timer

Number of seconds before retransmission of an IP packet.

Values 1 to 999

Default 3

Access This parameter is read-write.

Location ppp-ncp

send-auth-enable

Enable or disable outgoing authentication.

Values enabled

disabled

Default disabled

Access This parameter is read-write.

Location ppp-lcp

send-auth-protocol

The protocol used with **send-auth-identity** to look up the outgoing authentication information.

Values pap

chap

Default pap

Access This parameter is read-write.

Location ppp-lcp

status

Indicates whether the authentication is valid or invalid.

Values valid

invalid

Default valid

Access This parameter is read-write.

Location ppp-auth

Notes Setting this parameter to **invalid** causes the information for that record to become invalidated. Calls using the authentication information from an invalidated record will not be accepted or initiated.

tx-acc-map

The Asynchronous Control Character (ACC) map that the local PPP entity requires for use on its transmit side. In effect, this is the ACC map that is required in order to ensure that all characters can be successfully transmitted through the local modem.

Access This parameter is read-write.

Location **ppp-lcp**

Notes Changing this parameter will take effect when the link is next restarted.

vci

The Virtual Channel Identifier (VCI) value for the PPP VCL.

Values **0 to 65535**

Default **0**

Access This parameter is read-write.

Location **ppp-interface**

Notes See RFC 2515 for more information.

vpi

The Virtual Path Identifier (VPI) value for the PPP VCL.

Values **0 to 4095**

Default **0**

Access This parameter is read-write.

Location **ppp-interface**

Notes See RFC 2515 for more information.

RIP

admin-state

Operational state of Routing Information Protocol (RIP) for all routing domains on the system.

Values **disabled**
enabled

Default **enabled**

Access This parameter is read-write.

Location `rip-global-config`

Notes This parameter can also be set using the `rip enable` command.

auth-key

The RIP 2 authentication key. The key is in hexadecimal, and must be less than 16 octets (32 hex digits). If a string shorter than 16 octets is supplied, it will be left-justified and padded to 16 octets, on the right, with null characters (0x00).

Access This parameter is read-write.

Location `rip-if-config`

Notes `auth-key` is not valid if `auth-type` is set to `none`.

auth-type

The type of authentication that is used when receiving RIP packets on this interface.

Values `md5`

An MD5-encrypted string is used for the authentication as specified in RFC 1321.

`simple`

The authentication key is sent in clear text.

`none`

No authentication.

Default `none`

Access This parameter is read-write.

Location `rip-if-config`

default-metric

The metric for the default route entry in RIP updates that is transmitted from this interface. A value of 0 (zero) indicates that the system does not originate a default route. In this case, a default route from another router can be propagated. The default is set using the metric in the received update.

Access This parameter is read-write.

Location `rip-if-config`

poison

This variable specifies whether to send poison reverse updates on this interface. Poison reverse updates are used to prevent larger loops within the

network by setting the metric (cost) of neighboring routes to infinity. This will prevent two-hop loops.

Values disabled

Prevents poison reverse updates on this interface.

enabled

Allows poison updates to be sent on this interface.

Default disabled

Location rip-if-config

Notes By default, RIP uses a technique called split horizon to avoid routing loops and allow smaller update packets. Split horizon specifies that when a RIP update is sent out to a particular network interface, it should not include routing information acquired over that same interface. Poison Reverse is a variation of the split horizon technique that specifies that all routes are included in an update out a particular interface, but that the metric is set to infinity for routes acquired over that interface. One drawback is that routing update packet sizes are increased when using poison reverse.

receive-type

Which version of RIP updates the system accepts.

Values ripv1

Only RIP version 1 updates compliant with RFC 1058 are accepted.

ripv2

Only RIP version 2 updates compliant with RFC 1388 are accepted. This setting implies acceptance of multicast packets.

ripv1orripv2

Either RIP version 1 or version 2 updates are accepted. This setting implies acceptance of multicast packets.

donotreceive

No RIP updates are accepted.

Default ripv1orripv2

Access This parameter is read-write.

Location rip-if-config

See Also send-type

remotefault

Identifies any local fault indications that this media access unit (MAU) has detected and will advertise at the next auto-negotiation interaction for 1000Mbps MAUs.

Values **noerror**
offline
linkfailure
autonegerror

Location **rip-if-config**

send-type

The type of RIP updates the system sends on this interface.

Values **donotsend**
 No RIP updates are sent on the interface.

ripv1
 RFC 1058 compliant RIP updates.

ripv1compatible
 RIP-2 updates using route inclusion rules as specified in RFC 1058.

ripv2
 RIP-2 updates multicast updates.

ripv1demand
 Demand RIP on the WAN interface using RIP version 1 rules as specified in RFC 1582.

ripv2demand
 Demand RIP on the WAN interface using RIP version 2 rules as specified in RFC 1582.

Default **ripv1compatible**

Access This parameter is read-write.

Location **rip-if-config**

See Also receive-type

sent-updates

The number of triggered RIP updates actually sent on this interface. This number does not include full updates sent containing new information.

Location **rip-if-config**

src-address

The IP address that the system will use as a source address on this interface. If it is a numbered interface, this must be the interface IP address. On unnumbered interfaces, it must be the IP address for some interface on the system.

This must be the same value as ipIfAddr (from ZHONE-IP-REC-MIB).

Access This parameter is read-write.

Location **rip-if-config**

sroute-advertise

Specifies whether to advertise static routes.

Values **none**

No static routes are advertised.

low

Advertise only low preference static routes.

high

Advertise only high preference static routes.

both

Advertise both high and low preference static routes.

Default **none**

Access This parameter is read-write.

Location **rip-if-config**

update-time

The time in seconds between transmissions of RIP updates on all interfaces within a routing domain.

Default **30 seconds, which follows RFC 1058 and subsequent RIP RFCs.**

Access This parameter is read-write.

Location **rip-global-config**

version

The RIP version number in the header of the last RIP packet received from a peer.

Values **0 to 255, inclusive**

Access This parameter is read-only.

Location **rip-peer**

RS232

This section describes the RS232 parameters. These parameters are used to configure the serial craft port settings.

rs232PortInSpeed

The serial craft port input speed in bits per second (bps).

Values 9600, 19200, 38400, 57600

Access This parameter is read-write.

Location rs232-profile

Notes rs232PortInSpeed must match rs232PortOutSpeed.

Products BAN, MALC

rs232PortOutSpeed

The serial craft port output speed in bits per second (bps).

Values 9600, 19200, 38400, 57600

Access This parameter is read-write.

Location rs232-profile

Notes rs232PortOutSpeed must match rs232PortInSpeed.

Products BAN, MALC

rs232PortInFlowType

The serial craft port type of input flow control.

Values ctsRts

dsrDtr

none

Access This parameter is read-write.

Location rs232-profile

Products BAN, MALC

rs232PortOutFlowType

The serial craft port type of output flow control.

Values ctsRts

dsrDtr

none

Access This parameter is read-write.

Location rs232-profile

Products BAN, MALC

rs232AsyncPortBits

The serial craft port number of bits in a character.

Access This parameter is read-write.

Location rs232-profile

Products BAN, MALC

rs232AsyncPortStopBits

The serial craft port number of stop bits.

Values **dynamic**

one

oneAndHalf

two

Access This parameter is read-write.

Location rs232-profile

rs232AsyncPortParity

The serial craft port sense of a character parity bit.

Values **even**

mark

none

odd

space

Access This parameter is read-write.

Location rs232-profile

Products BAN, MALC

rs232AsyncPortAutobaud

Specifies whether the port automatically senses input speed.

Values **disabled**

enabled

Access This parameter is read-write.

Location rs232-profile

Notes Only **disabled** is supported.

Products BAN, MALC

SHDSL

shdsl-clock-offset

This parameter is used to help achieve a low frequency wander and jitter between network and DSL system clock. This value can only be set on devices configured as CO in the **dsl-config** profile.

Values -100 to 100 (in parts per million)

Default 0

Access This parameter is read-write.

Location shdsl-config

shdsl-config-line-rate (2-wire G.SHDSL card)

The line rate. If the **shdsl-fix-bit-rate** parameter is enabled, the line will attempt to train at this rate. Note that the DSL modem uses 8kbps for ATM framing and other ATM overhead, so that effective line rate is 8kbps less than the configured rate.

Values line-rate-72kbps, line-rate-80kbps, line-rate-136kbps, line-rate-144kbps, line-rate-200kbps, line-rate-208kbps, line-rate-264kbps, line-rate-272kbps, line-rate-328kbps, line-rate-336kbps, line-rate-392kbps, line-rate-400kbps, line-rate-456kbps, line-rate-464kbps, line-rate-520kbps, line-rate-528kbps, line-rate-584kbps, line-rate-592kbps, line-rate-648kbps, line-rate-656kbps, line-rate-712kbps, line-rate-720kbps, line-rate-776kbps, line-rate-784kbps, line-rate-840kbps, line-rate-848kbps, line-rate-904kbps, line-rate-912kbps, line-rate-968kbps, line-rate-976kbps, line-rate-1032kbps, line-rate-1040kbps, line-rate-1096kbps, line-rate-1104kbps, line-rate-1160kbps, line-rate-1168kbps, line-rate-1224kbps, line-rate-1232kbps, line-rate-1288kbps, line-rate-1296kbps, line-rate-1352kbps, line-rate-1360kbps, line-rate-1416kbps, line-rate-1424kbps, line-rate-1480kbps, line-rate-1488kbps, line-rate-1544kbps, line-rate-1552kbps, line-rate-1608kbps, line-rate-1616kbps, line-rate-1672kbps, line-rate-1680kbps, line-rate-1736kbps, line-rate-1744kbps, line-rate-1800kbps, line-rate-1808kbps, line-rate-1864kbps, line-rate-1872kbps, line-rate-1928kbps, line-rate-1936kbps, line-rate-1992kbps, line-rate-2000kbps, line-rate-2056kbps, line-rate-2064kbps, line-rate-2120kbps, line-rate-2128kbps, line-rate-2184kbps,

**line-rate-2192kbps, line-rate-2248kbps, line-rate-2256kbps,
line-rate-2312kbps, line-rate-2320kbps, line-rate-2368kbps**

Default line-rate-2320kbps

Access This parameter is read-write.

Location shdsl-config

shdsl-config-line-rate (4-wire G.SHDSL card)

The line rate. If the **shdsl-fix-bit-rate** parameter is enabled, the line will attempt to train at this rate. Note that the DSL modem uses 8kbps for ATM framing and other ATM overhead, so that effective line rate is 8kbps less than the configured rate.

Values line-rate-4w-384kbps line-rate-4w-512kbps line-rate-4w-640kbps
line-rate-4w-768kbps line-rate-4w-896kbps line-rate-4w-1024kbps
line-rate-4w-1152kbps line-rate-4w-1280kbps line-rate-4w-1408kbps
line-rate-4w-1536kbps line-rate-4w-1664kbps line-rate-4w-1792kbps
line-rate-4w-1920kbps line-rate-4w-2048kbps line-rate-4w-2176kbps
line-rate-4w-2304kbps line-rate-4w-2432kbps line-rate-4w-2560kbps
line-rate-4w-2688kbps line-rate-4w-2816kbps line-rate-4w-2944kbps
line-rate-4w-3072kbps line-rate-4w-3200kbps line-rate-4w-3328kbps
line-rate-4w-3456kbps line-rate-4w-3584kbps line-rate-4w-3712kbps
line-rate-4w-3840kbps line-rate-4w-3968kbps line-rate-4w-4096kbps
line-rate-4w-4224kbps line-rate-4w-4352kbps line-rate-4w-4480kbps
line-rate-4w-4608kbps

Default line-rate-2320kbps

Access This parameter is read-write.

Location shdsl-config

shdsl-decoder-coeffA/shdsl-decoder-coeffB

21 bit value corresponding to the decoder coefficient A or B, as defined in the G.991.2 standard. Note that the default value is bit-reversed, when compared against the recommended polynomials in the G.991.2 standard. Thus when you enter the 21-bit value, it should be written bit-reversed also.

Values 0 to 2097151

Default 366 (for shdsl-decoder-coeffA)
817 (for shdsl-decoder-coeffB)

Access This parameter is read-write.

Location shdsl-config

shdsl-dsp-version

The version of the DSP/Framer VLSI in the transceiver.

Access This parameter is read-only.

Location `shdsl-status`

shdsl-firmware-version

The firmware release number.

Access This parameter is read-only.

Location `shdsl-status`

shdsl-fix-bit-rate

Normally, if the CO side and CPE side select different line rates at startup, the lower of the two rates will be selected. By using the fix bit rate the CO side can override the default procedure and require startup at the rate specified in the `shdsl-config-line-rate`.

Values `fix-bit-disable`

This value enables automatic baud rate adaption, where the DSL modem will train at the best achievable rate. If the CO and CPE devices have different line rates at startup, the line will train up to the highest rate supported by both devices.

`fix-bit-enable`

This value is used for static (set) baud rates. With this option, the line will attempt to connect at the rate configured in the `shdsl-config-line-rate`.

Default `fix-bit-disable`

Access This parameter is read-write.

Location `shdsl-config`

Notes This parameter is applicable only if `unit-mode` is `co`.

shdsl-frame-sync

The 14 bit frame sync word (FSW).

Values `From 0 to 65535`

Default `45`

Access This parameter is read-write.

Location `shdsl-config`

Notes Not currently supported.

shdsl-ntr

Determines the clocking on the SHDSL line.

Values ntr-local-osc

The line uses the system's internal clock. Also known as local timing.

ntr-refck-8KHz

The line uses an 8KHz clock derived from a timing source such as a T1 interface.

Default ntr-local-osc

Access This parameter is read-write.

Location shdsl-config

Notes Circuit Emulation Service (CES) transports TDM circuits over ATM networks. For CES-based services: change **ntr** default setting of **ntr-local-osc** to ntr-refck-8KHz in the **shdsl-config** profile.

SHDSL lines configured with the **shdsl-ntr** parameter set to **ntr-refck-8khz** will not sync if a system clock source is not enabled in a **system-clock-profile**. To enable clocking:

```
zSH> update system-clock-profile 1-17-1-0/ds1
Please provide the following: [q]uit.
system-clock-eligibility: -> {false}: true
system-clock-weight: -----> {5}:
.....
Save changes? [s]ave, [c]hange or [q]uit: s
Record updated.
```

shdsl-power-scale

Reduces the transmit power in small increments to compensate for minor differences in power between units. The formula for the adjustment is:

$$\text{Power scale} = 26112 * 10^{(\text{adjustment in dB}/20)}$$

The following values are recommended for different loop lengths.

Values 17664

For loop lengths from 0 to 10 feet (0 to 3.05 meters). Corresponds to -3.39dB.

20992

For loop lengths less than 4000 feet (1219 meters). Corresponds to -1.9dB.

29952

For loop lengths greater than 4000 feet (1219 meters). Corresponds to -1.19dB.

Default 29298

Access This parameter is read-write.

Location shdsl-config

shdsl-repeater-id

This value identifies if the STU is being used as a repeater.

Values **noChangeRepeater**
repeaterDisable
repeaterEnable

Default **repeaterDisable**

Access This parameter is read-write.

Location **shdsl-config**

shdsl-standard

Determines the SHDSL standards.

Values **annex-a**
G.991.2 Annex A. Typically used in the United States.
annex-b
G.991.2 Annex B. Typically used outside the United States.

Default **annex-b**

Access This parameter is read-write.

Location **shdsl-config**

shdsl-startup-margin

Specifies the minimum desired target margin in dB for the local line conditions during startup. Used to negotiate the bit rate during startup.

Values **0 to 10**

Default **6**

Access This parameter is read-write.

Location **shdsl-config**

shdsl-transmit-power-back-off-mode

Indicates if transmit power backoff is used on the other end of the loop. When enabled, the transmit power is reduced in steps of 1dB from 0 to 6 dB according to the received power.

Values **backoffDisable**
backoffEnable

Default **backoffEnable**

Access This parameter is read-write.

Location shdsl-config

shdsl-wire-mode

This setting disables or enables 4-wire-framing.

Values **four-wire-disable**

Four wire framing is disabled. Use this setting for the 2 wire SHDSL card.

four-wire-enable-bit-interleave

Sends one bit on channel 1, then one bit on channel 2, as described in the ITU-T G.991.2, section E.2.

four-wire-enable-byte-interleave

sends one byte on channel 1, and then one byte on channel 2, as described in ITU-T G.991.2, section E.7

four-wire-enable-non-interleave

Sends 12 bytes on channel 1, 12 bytes on second channel 2.

Default **four-wire-disable**

Access This parameter is read-write.

Location shdsl-config

Sector 100A environmental

thermo-a-lower-threshold

The lower threshold for thermometer A in degrees Celsius. When **thermo-a-temperature** is below this value, **thermo-a-operational-status** is below the lower threshold, and a trap is generated.

Values **Valid range is -10 to 5 degrees Celsius**

Default **-5 degrees Celsius**

Access This parameter is read-write.

Location s100-environment-profile

thermo-b-lower-threshold

The lower threshold for thermometer B in degrees Celsius. When **thermo-b-temperature** is below this value, **thermo-b-operational-status** is below the lower threshold, and a trap is generated.

Values **Valid range is -10 to 5 degrees Celsius**

Default **-5 degrees Celsius**

Access This parameter is read-write.

Location s100-environment-profile

thermo-a-upper-threshold

The upper threshold for thermometer A in degrees Celsius. When **thermo-a-temperature** is above this value, **thermo-a-operational-status** is greater than the upper threshold and a trap is generated.

Values Valid range is 45 to 80 degrees Celsius

Default 65 degrees Celsius

Access This parameter is read-write.

Location s100-environment-profile

thermo-b-upper-threshold

The upper threshold for thermometer B in degrees Celsius. When **thermo-b-temperature** is above this value, **thermo-b-operational-status** is greater than the upper threshold and a trap is generated.

Values Valid range is 45 to 80 degrees Celsius.

Default 60 degrees Celsius

Access This parameter is read-write.

Location s100-environment-profile

SNMP

access-table-index

Displays the access list associated with the community name, indicating which IP addresses are allowed to use this community name.

The value 0 indicates that no address checking is performed; all SNMP requests are allowed with the access right specified by the **permissions** parameter.

Location community-access-profile, community-profile

community-name

Community name to be sent in all traps sent to this destination.

Location community-profile

ip-address

The IP address from which a management connection to the device can be established.

Location community-access-profile, malicious-caller

thresh15min-badseq

The number of sequence errors within any given 15-minute performance data collection period, which causes the SNMP agent to send an aal2PerfCellLossThreshTrap. One trap will be sent per interval per interface.

Values 0 to 900

Default 0 (will disable the trap)

Location aal2-vcl-profile

Products Sector 100A

thresh15min-congestion

The number of congestion events within any given 15-minute performance data collection period, which causes the SNMP agent to send an aal2PerfCongestionThreshTrap. One trap will be sent per interval per interface.

Values 0 to 900

Default 0 (will disable the trap)

Location aal2-vcl-profile

Products Sector 100A

trapadminstatus

Specifies whether the device reports traps to the trap destination.

Values enabled
disabled

Default enabled

Location trap-destination

trapdestination

The IP address destination for traps.

Location trap-destination

traplevel

The lowest-level severity level of the traps reported to the **trapdestination**.

Values **critical**
severe
moderate
low
Default **low**
Location **trap-destination**

traptype

The type of trap to be sent to this **trapdestination**. This parameter is currently unsupported.

Values **catAdmin**
catLine
catVoice
catIP
catRip
canRadio
Location **trap-destination**

SONET

apsChanConfigAdminStatus

Administrative status of the APS object.

Values **inService (1)**
outOfService (2)
Default **outOfService (2)**
Access This parameter is read-create.
Location **aps-channel**

apsChanConfigGroupName

The configured name of the APS group.

Access This parameter is read-write.
Location **aps-channel**

apsChanConfigNumber

A unique channel number within an APS group. The value 0 indicates the null channel. The values 1-14 define a working channel. If the SONET LTE is not part of an APS group this value is set to -1

Access This parameter is read-only.

Location aps-channel

apsChanConfigPriority

Determines whether high or low priority SD and SF codes are used in K1 requests. This field is only applicable if the channel is to be included in a group using the 1:n architecture. It is not applicable if the channel is to be included in a group using the 1+1 architecture and is ignored in that case.

Default low

Access This parameter is read-create.

Location aps-channel

apsConfigCreationTime

The value of sysUpTime at the time APS was configured.

Access This parameter is read-only.

Location aps-group

apsConfigDirection

The directional mode of the APS group.

Values **unidirectional**

The unidirectional mode provides protection in one direction.

bidirectional

The bidirectional mode provides protection in both directions.

Default **unidirectional**

Access This parameter is read-create.

Location aps-group

apsConfigExtraTraffic

Enables or disables the transfer of extra traffic on the protection channel in a 1:n architecture. This object must be set to disabled if the architecture is 1+1.

Default **disabled**

Access This parameter is read-only.

Location aps-group

apsConfigMode

The protection architecture of the APS group.

Values **onePlusOne (1)**

Access This parameter is read-only.

Location aps-group

apsConfigRevert

The revertive mode of the APS group.

Values **nonrevertive)**

After a protection switch, traffic remains on the protection line until another switch request is received.

revertive

After a protection switch, when the condition that caused a switch to the protection line is cleared the signal switches back to the working line.

Default **nonrevertive**

Access This parameter is read-create.

Location aps-group

apsConfigsdBerThreshold

The Signal Degrade Bit Error Rate. The negated value of this number is used as the exponent of 10 for computing the threshold value for the Bit Error Rate (BER). For example, a value of 5 indicates a BER threshold of 10^{-5} .

Default **6**

Access This parameter is read-create.

Location aps-group

apsConfigsfBerThreshold

The Signal Failure Bit Error Rate. The negated value of this number is used as the exponent of 10 for computing the threshold value for the Bit Error Rate (BER). For example, a value of 5 indicates a BER threshold of 10^{-5} .

Default **3**

Access This parameter is read-create.

Location aps-group

apsConfigWaitToRestore

The Wait To Restore period in seconds. After clearing a condition that necessitated an automatic switch, the wait to restore period must elapse before reverting.

Default 300

Access This parameter is read-create.

Location aps-group

clock-external-recovery

Whether internal clocking can be recovered from an external source.

Values **enabled**

disabled

Access This parameter is read-write.

Location sonet-profile

clock-transmit-source

The clocking source.

Values **external155mhz**

Transmit clock synthesized from an external 155.52 MHz source.

looptiming

Uses the recovered receive clock as the transmit clock.

localtiming

Ether uses a local clock source or an external clock is attached to the device containing the interface.

throughtiming

Uses a transmit clock derived from the recovered receive clock of another interface.

Access This parameter is read-write.

Location sonet-profile

medium-cell-scramble-config

The SONET scramble mode at the cell level.

Values **true**

Cell level scramble mode is enabled.

false

Cell level scramble mode is not enabled.

Default true
Access This parameter is read-write.
Location sonet-profile

medium-circuit-identifier

The SONET circuit identifier, determined by the system installer.

Values string of up to 260 characters
Access This parameter is read-write.
Location sonet-profile

medium-line-coding

The line coding for the SONET interface.

Values sonetMediumOther
sonetMediumB3ZS
Used for STS-1 and STS-3 electrical SONET/SDH signalling.
sonetMediumCMI
Used for STS-1 and STS-3 electrical SONET/SDH signalling.
sonetMediumNRZ
Non-Return to Zero. Used for optical SONET/SDH signals.
sonetMediumRZ
Return to Zero. Used for optical SONET/SDH signals.
Access This parameter is read-write.
Location sonet-profile

medium-line-scramble-config

The SONET scramble mode at the line level.

Values true
Line level scramble mode is enabled.
false
Line level scramble mode is not enabled.
Default true
Access This parameter is read-write.
Location sonet-profile

medium-line-type

The line type for the SONET interface.

Values **sonetShortSingleMode**
Short range single mode fiber.

sonetMultiMode
Multimode fiber.

Access This parameter is read-write.

Location **sonet-profile**

medium-loopback-config

How the SONET loopback is configured.

Values **sonetnoloop**
SONET circuit, with no loop.

sonetfacilityloop
All incoming data on the Rx interface is retransmitted out of the Tx interface. Used to check the circuit between a remote device and the Zhone device and to test the Zhone device optical module.

sonetterminalloop
All of the data transmitted on the Tx interface is also internally looped back to the Rx interface. Used to verify that the ATM and PHY layers are communicating.

sonetotherloop
All incoming data on the Rx interface is retransmitted out of the Tx interface. Used to check the circuit between the IAD and a remote unit and to verify that the optical module and the SONET PHY are working.

Access This parameter is read-write.

Location **sonet-profile**

medium-cell-scramble-config

Whether the SONET cell scramble mode is enabled.

Values **true**
Scramble mode is enabled

false
Scramble mode is not enabled.

Default **true**

Access This parameter is read-write

Location **sonet-profile**

medium-type

The type of SONET signaling.

Values **sonet**
Synchronous Optical Network (North America)

sdh
Synchronous Digital Hierarchy (Europe)

Default **sonet**

Access This parameter is read-write.

Location **sonet-profile**

path-current-width

The type of SONET/SDH path.

Values **sts1**
sts3cSTM1
sts12cSTM4

Access This parameter is read-write.

Location **sonet-profile**

Subscriber

capable-line-rate-limit

The maximum line rate that can be supported by the subscriber line. This rate is determined by several factors including the distance the subscriber is from the CO, the copper facilities to the subscriber, and the type of IAD installed. This value is determined by the service provider.

Values **0 to 2147483647, inclusive.**

Access This parameter is read-write

Location **subscriber**

iad-type

Identifies the type of IAD used by the subscriber.

Values **zedge64s**

Access This parameter is read-write.

Location **subscriber**

line-group-id

The line group identifier. Use the **lineGroup** command to find this value.

line-rate-limit

The maximum line rate (in bits per second) that the subscriber is provisioned to receive from the service provider. This value is the total line rate or bandwidth of the subscriber connection, including voice and data.

Values 0 to 2147483647, inclusive.

Access This parameter is read-write.

Location subscriber

name

Subscriber name.

Location subscriber

name-group-id

An administratively defined name used to aid operators identify subscribers in the system. The name is not used by the system, it is only for operator reference.

Access This parameter is read-write.

Location subscriber

service-provider-id

Unique service provider ID. This value is used throughout the management system to link parameters with customers or service providers.

Access This parameter is read-write.

Location subscriber

tools-access

Indicates whether the specified user has tools privileges.

Access This parameter is read-only.

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

voice-admin-status

The administrative state of this connection.

Values enabled

disabled

Default disabled

Location subscriber-voice

System

countryregion

The country or region this system is operating in. This parameter sets A-Law Mu-Law companding and sets the ring frequency for the trunk side interface of the device. These settings are in accordance with ITU-T E.180 and ITU-T E.180 Supplement 2.

Values australia, brazil, canada, chile, china, czechrepublic, egypt, etsi, finland, france, germany, hongkong, ireland, italy, japan, korea, malaysia, mexico, spain, sweden, taiwan, turkey, uk, unitedarabemirates, us

Default us

Access This parameter is read-write.

Location system

Notes Changing this parameter requires a system reboot.

enableauthtraps

Indicates whether the system is permitted to generate authenticationFailure traps. The value of this parameter overrides any configuration information and provides a means to disable all authentication Failure traps.

Access This parameter is read-write

Location system

ipaddress

The IP address of this system. Independent of the different IP interfaces configured and what is active, a manager uses this address to communicate with the system.

Access This parameter is read-write.

Location system

manuf-access

Indicates whether the specified user has manuf(acting) privileges.

Access This parameter is read-only.

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

numcards

The total number of cards in the system.

Access This parameter is read-only.

Location system

numshelves

The number of shelves in the system.

Access This parameter is read-only.

Location system

permissions

The access level associated with the community name:

Values **noAccess**

Restricts the community name any access to this device.

read

Allows read access to all parameters except administrator access parameters.

readAndWrite

Allows read and write access to all parameters except administrator access parameters.

admin

Allows read and write access to all parameters on this device.

Access This parameter is read-write.

Location community-profile

primaryclocksource

The address of the interface from which the system 8khz backplane clock can be derived. Only active DS1, DS3, and OC-3 interfaces can provide system clock.

Values Any active DS1, DS3, or OC3 interface.

Default 0/0/0/0/0

If set to the default, the system uses its internal clock.

Access This parameter is read-write.

Location system

Notes Only one interface in the system can be the primary clock source at a time.

The interface that provides the clock source must be set to loop timing or local timing (DS3 interface).

Products BAN, MALC, Raptor, Sechtor 100A

revertiveclocksource

Redundant clock sources are revertive by default. If a standby clock source becomes active after the failure of a primary clock source, the system will revert to the primary clock source after that clock source becomes active again. Note that the clock source must be active for 30 seconds before the system will revert back to the primary clock source.

Values **true**

false

Default **true**

Access read-write

Location **system**

Products BAN, MALC, Raptor, Sechtor 100A

ringsource

Ring voltage source selection (internal or external).

Values **internalRingSourceLabel**

Select internal ring generator (located within MTAC) as source for ring voltage to line cards.

externalRingSourceLabel

Select external ring generator (input connector located on MTAC) as source for ring voltage to line cards.

Default **internalRingSourceLabel**

Location **system**

setserialno

An advisory lock used to allow several cooperating SNMPv2 entities, all acting in a manager role, to coordinate their use of the SNMPv2 set operation. This parameter is used for coarse-grain coordination.

Access This parameter is read-write.

Location **system**

shelvesarray

Bit array from 0-255 (32 8-bit bytes) that are present in the system.

Access This parameter is read-only.
Location system

syscontact

The textual identification of the contact person for this managed node, together with information on how to contact this person.

Values If no contact information is known, the value is a zero-length string.
Access This parameter is read-write.
Location system

syslocation

The physical location of the device.

Values If the location is unknown, the value is a zero-length string.
Access This parameter is read-write.
Location system

sysname

An administratively-assigned name for this managed node. By convention, this is the node's fully-qualified domain name.

Values If the name is unknown, the value is the zero-length string.
Access This parameter is read-write.
Location system

system-access

Specifies user access level.

Location user-profile

V5.2

admin-status

The administrative status of the V5.2 interface group, user port or link.

Values **inservice**

outofservice

deferredoutofservice

Takes the group, port, or link out of service, but not until all calls are completed.

restart

Causes the v52 interface to shut down for a period of time, then go through the startup procedure. When restart is complete, the V5.2 interface should go back to the previously configured admin status before it was set to restart.

According to ETSI EN 300 347-1 V2.2.2, a system must be shut down for 95 seconds before it can be returned to service.

Default **outOfService**

Access This parameter is read-write.

Location **v52-user-port, v52-interface-group, v52-link**

block (V5.2 user port)

A user port can be blocked by the access network for non urgent or urgent configuration or reconfiguration. If the port is routed through a V5.2 interface to a local exchange, then the block request is granted by the local exchange through the V5 interface only, to avoid interference with call setup, calls in progress or with calls being cleared.

Values **blocked**

The user port can be unblocked by either accelerated port alignment (group unblocking) and by sequential port alignment.

shuttingDown

The user port can be unblocked by either accelerated port alignment (group unblocking) and by sequential port alignment except active ports will not be blocked until all of the calls are completed.

unblocked

The user port will be unblocked regardless of its previous port block state.

blockedNotSuitableForGroupUnblocking

The user port cannot be unblocked by accelerated port alignment unblocking, but can be unblocked by sequential blocking.

Default **blocked**

Access This parameter is read-write.

Location **v52-user-port**

block (V5.2 link)

This parameter controls the link blocking function. The Access Node (AN) requests that the link be blocked, the Local Exchange (LE) evaluates the request, releases the connection, then reestablishes semipermanent and preconnected connections.

E1 trunks are added in a blocked state and must be unblocked by the LE before they are operational, and an E1 must be administratively blocked by the LE before it can be deleted.

Values **deferredBlocked**

Wait to block the link until there are no active calls.

nonDeferredBlocked

Block the link after approval is received from the LE.

forceBlocked

The link is blocked by the AN without approval from the LE.

unblocked

Unblock the link.

Default **unblocked**

Access This parameter is read-write.

Location **v52-link**

check-id

This parameter is set to **activated** to request that the V5.2 link ID on the AN side be checked with the LE side link ID. When the **check-id** is finished, this value is **notActivated**.

A link identification check can only be started when the V5.2 link is operational, and can be initiated from either the AN or LE side. (The LE request has priority over any AN initiated requests to avoid request collision.)

Values **activated**

notActivated

Default **notActivated**

Access This parameter is read-write.

Location **v52-link**

c-path-valid-flag

When this parameter is set to valid, the C-path is active.

Values **valid**
invalid

Location **v52-interface-group**

dsn-lg-id

Describes the line group ID associated with the E1 link. Use the **lineGroup** command to find the line group ID.

Values **1 to 16, inclusive**

Location **v52-interface-group**

id (V5.2 link)

The V5.2 link identifier. Assigned by the Local Exchange (LE).

Values **0 to 255, inclusive**

Access This parameter is read-write.

Location **v52-link**

id (V5.2 path)

The ID number of the communications path.

Values **0 to 255**

Location **v52-path**

inbound-calls

The number of inbound calls completed over the V5.2 IG.

Access This parameter is read-only.

Location **v52-stats-current, v52-stats-interval, v52-stats-total**

Notes PerfCurrentCount

isdn-env-func-start-address

The start address for ISDN users. When ISDN users are added, they must have an address greater or equal to this one. This value must match the value on the switch.

Values **0 to 8175, inclusive**

Access This parameter is read-write.

Location **v52-interface-group**

isdnds-cpath-id

If the user port is configured for ISDN, this parameter is equal to the associated C-path ID that carries Ds-type data. A value of 0 (zero) indicates that the user port is not configured to carry Ds-type data.

Values 0 to 48, inclusive

Access This parameter is read-write.

Location v52-user-port

isdnf-cpath-id

If the user port is configured for ISDN, this parameter is equal to the associated C-path ID that carries f-type data. A value of 0 (zero) indicates that the user port is not configured to carry f-type data.

Values 0 to 48, inclusive.

Access This parameter is read-write.

Location v52-user-port

isdnp-cpath-id

If the user port is configured for ISDN, this parameter is equal to the associated C-path ID that carries p-type data. A value of 0 (zero) indicates that the user port is not configured to carry p-type data.

Values 0 to 48, inclusive.

Access This parameter is read-write.

Location v52-user-port

link-is-timer

Specifies the length of time that a V5.2 link must be in a framed state before the interface declares that the link is in service. This value should be less than the equivalent value that is provisioned in the LE.

Values 50 to 10000, inclusive.

Default 200

Access This parameter is read-write.

Location v52-interface-group

link-oos-timer

Specifies the length of time that a V5.2 link must be in a failed state before the interface declares that the link has failed. This value should always exceed the equivalent value that is provisioned in the LE.

Values 50..10000
Default 2500
Access This parameter is read-write.
Location v52-interface-group

link-valid-flag

Activates the E1 circuit.

Values valid
invalid
Location v52-interface-group

local-interface-id

The interface ID of the IG. Must be unique across the system. This value must match the value on the switch.

Values 1 to 16777215, inclusive.
Default 0
Access This parameter is read-write.
Location v52-interface-group

local-prov-variant

The prov(isioning) variant describes a type of provisioning. This value must match the value on the switch.

Values 0 to 127, inclusive
Default 0
Access This parameter is read-write.
Location v52-interface-group

logical-channel-id (C-path)

The logical C-channel ID that the C-path is using. This number must match the **logical-channel-id** value of the C-channel that the C-path is running over.

Values 0 to 65535, inclusive
Access This parameter is read-write.
Location v52-cpath

logical-channel-id (C-channel)

The C-channel logical channel ID. C-channels carry one or more C-paths. A V.52 interface may contain up to 44 logical C-channels and each logical C-channel on an interface is uniquely identified with a 16 bit logical C-channel identifier. C-channels that are provisioned as standby channels in a protection group do not have a logical C-channel identifier.

Values 0 to 65535, inclusive.
Access This parameter is read-write.
Location v52-cchannel

max-outstanding-frames

The maximum number of outstanding information frames at layer two.

Values 1 to 7, inclusive
Default 7
Access This parameter is read-write.
Location v52-interface-group-lapv

n200

The maximum number of retransmissions for a frame allowed at layer two.

Values 1 to 10, inclusive.
Default 3
Access This parameter is read-write
Location v52-interface-group-lapv

n201

The maximum number of octets in the information field of an I frame.

Values 0 to 256, inclusive.
Default 256
Access This parameter is read-write.
Location v52-interface-group-lapv

national-pstn-region

The regional and country-specific setting for V5.2 PSTN service. The PSTN region dictates regional signaling differences like ring cadence.

Values **australia, brazil, egypt, estonia, finland, france, germany, hongkong, ireland, italy, japan, korea, malaysia, mexico, spain, sweden, taiwan, uk, unitedarabemirates, us**

Default **unknown**

Access This parameter is read-write.

Location **v52-interface-group**

port-alignment-request

A request to block or unblock all the user ports associated with the current IG by port type.

Values **noRequest**

blockAll

Block all user ports associated with this IG.

blockIsdn

Block all of the isdnBa and isdnPra user ports associated with this IG.

blockPstn

Block all of the PSTN user ports associated with this IG.

unblockAll

Unblock all user ports associated with this IG.

unblockIsdn

Unblock all of the isdnBa and isdnPra user ports associated with this IG.

unblockPstn

Unblock all the pstn user ports associated with this IG.

Default **noRequest**

Access This parameter is read-write.

Location **v52-interface-group**

protection-group

The C-channel protection group.

Values none
 group1
 oneToOneGroup2
 mToNgroup2

Access This parameter is read-write.

Location v52-cchannel

protocol-spec

This variable specifies which variation of the v5.2 protocol is used by this V5.2 IG.

Values edition1
 The V5.2 specification defined in ETSI ETS 300 347-1 ed.1 (1994-09).
 edition2
 The V5.2 specification defined in ETSI EN 300 347-1 V2.2.2 (1999-12).

Default edition2

Access This parameter is read-write.

Location v52-interface-group

prov-variant-request

A request by the user regarding the provisioning variant.

Values noRequest
 The default value. Setting the variable to **noRequest** has no effect.

verifywithle
 A request to verify if the LE is ready for reprovisioning.

requestfromle
 A request to get the LE Variant ID and Interface ID.

switchletolocal
 A request to the LE side to change its provisioning variant to be the same as **local-prov-variant**.

Default noRequest

Access This parameter is read-write

Location v52-interface-group

pstn-layer-3-start-address

The start address for PSTN users. When PSTN users are added, they must have an address greater or equal to this one. This value must match the value on the switch.

Values 0 to 65535, inclusive
Access This parameter is read-write.
Location v52-interface-group

reg-or-lease-user

What kind of lease the user carries.

Values **regular**
permanentLease
semiPermanentLease
Default **regular**
Access This parameter is read-write.
Location v52-user-port

role

The C-channel role. This value must match the value on the switch.

Values **active**
The C-channel is in active mode.
standby
The C-channel is in standby mode.
switchToStandby
This value can be set only when the C-channel is in **active** mode. If the **role** parameter is set to **switchToStandby**, one of the standby channels in the same protection group will take over as the new active channel. When the switch has been completed, the original channel becomes a standby channel in its protection group.
Default **active**
Access This parameter is read-write.
Location v52-cchannel

shelf

The system shelf. Zero (0) is an invalid value.

Values 1 to 255, inclusive.
Access This parameter is read-only.
Location v52-interface-group-stats

startup-unblock-user-ports

Indicates whether or not user ports will be unblocked when the V5.2 interface is starting up.

Values true

false

Default true

Access This parameter is read-write.

Location v52-interface-group

startup-check-link-id

Indicates whether or not a Link ID check will be performed when the V5.2 interface is starting up.

Values true

false

Default true

Access This parameter is read-write.

Location v52-interface-group

switch-vendor

The switch vendor for this V5.2 IG.

Values unknown

lucent

nortel

alcatel

ericsson

nokia

siemens

samsung

Default unknown

Access This parameter is read-write.

Location v52-interface-group

t200

The maximum layer two wait time for an acknowledgment of a transmitted frame. Units are in milliseconds, in increments of 50.

- Values** 100 to 1000, inclusive.
Default 150
Access This parameter is read-write.
Location v52-interface-group-lapv

t203

Maximum layer two idle time before connection verification is necessary. Units are in seconds, in increments of ten.

- Values** 1 to 300, inclusive.
Default 30
Access This parameter is read-write.
Location v52-interface-group-lapv

time-slot-index

The channel that the C-channel is running over.

- Values** 15
 16
 31
Location v52-interface-group

type

The type of communications path. This tells the system how the management information is communicated.

- Values** unknown
 pstn
 POTS
 ctrl
 control protocol
 bcc
 bearer channel connection
 lctl
 link control protocol

isdnds
BRI voice data

Default unknown
Access This parameter is read-write.
Location V52_CPath

v52-c-channel:array[1..3]

This array describes up to three control channels per link (E1). There can be up to three control channels on each of the 16 links for a maximum of 48. C-channels are used to pass management information between then LE and the Zhone device system. It includes the **time-slot-index**, **logical-channel-id**, **protection-group**, **role**, and **c-channel-valid-flag** parameters.

Location v52-interface-group

v52-c-path:array[1..48]

This array describes communications paths. C-paths are used to specify the type of information running between the Zhone device and the LE. C-paths run inside C-channels. There can be up to 48 C-paths inside each C-channel. This array includes the **id**, **type**, **logical-channel-id**, and **c-path-valid-flag** parameters.

Values Use the **logical-channel-id** numbers created for the C-channels.

Location v52-interface-group

v52-ig-lapv

An array of V5.2 Lapv timer parameters. These configure retries and other functions over the management links. This array includes the parameters **max-outstanding frames**, **n200**, **n201**, **t200**, and **t203**.

Location v52-interface-group

v52-link[1..16]

This array is used to provision the E1 circuits between the LE and the Zhone device. There can be up to sixteen links. Each E1 link has 32 channels. This array includes the **dsn-lg-id**, **ds1-channel-number**, **id**, **check-id**, **check-id-status**, and **block** parameters.

Location v52-interface-group

voice-V52-interface-name

The name of the V5.2 interface group. This is the same as the **name-id** from the **v52-interface-group** profile.

Location subscriber-voice-v52

voice-V52-isdn-channel-id

The ISDN B or D channel used for the connection.

Location subscriber-voice-v52

voice-V52-user-port-id

A port ID for the V5.2 user port. This is the same as the **local-interface-id** in the **v52-interface-group** profile.

Location subscriber-voice-v52

voice-V52-user-type

The type of V5.2 user port.

Values POTS

isdndchannel

isdnbchannel

Location subscriber-voice-v52

VDSL

mode

Type of VDSL equipment.

Values vtu-r

customer premise equipment

vtu-o

central office equipment

Default vtu-o

Location vdsl-config

us-max-const

Restrict upstream quadrature amplitude modulation (QAM) constellations to use those that do not exceed this maximum.

Values	QAM-4 QAM-8 QAM-16 QAM-32 QAM-64 QAM-128 QAM-256
Default	QAM-128
Location	vdsl-config

Voice

ds0-channel-id

The DS0 assigned to this subscriber.

Access This parameter is read-write.

Location subscriber-voice-ds1

ds1-line-group

The line group Interface Index of the DS1 interface.

Access This parameter is read-write.

Location subscriber-voice-ds1

echo-cancellation-type

Which echo cancellation algorithm is used for a particular channel.

G.168 has stricter technical specs and defines how the tests are performed better than G.165. If an echo canceller meets the G.168 specification, it is G.168 and G.165 compliant.

The number following the designation describes the echo tail length in milliseconds. The echo tail length that is required depends on several factors, including the network configuration, local loop length, and line frequency response. Generally, 16ms is adequate for local loop and 32ms is a good minimum for network equipment.

Values g165EchoTL16

G.165 echo cancellation with echo tail length of 16ms (MALC only)

g168EchoTL48

G.168 echo cancellation with echo tail length of 48ms (BAN, Sechtor 100A, Z-Edge)

off

Echo cancellation is off.

- Default** **g165Echotl16 (MALC)**
g168Echotl48 (BAN, Sechtor 100A, Z-Edge)
- Location** **voice-dsp-default-profile**

echo-return-loss

The amount of loss between the transmitted signal and the reflected echo back from the hybrid where the 4-to-2 wire conversion takes place.

- Values** **0 dB, 6 dB**
MALC
- 0dB, 3dB, 6dB**
BAN, Sechtor 100A, Z-Edge
- Default** **6 (MALC)**
3 (BAN, Sechtor 100A, Z-Edge)
- Location** **voice-dsp-profile**

Notes For the BAN and Sechtor 100A changes to the echo return loss take effect on the next call.

For the MALC and Z-Edge, changes to the echo return require the CID or the VCL to be brought down and up again, or the system rebooted.

- Products** BAN, MALC, Raptor, Sechtor 100A, Z-Edge

features

Enables voice features on a per subscriber basis.

- Values** **hookflash**
hookflash detection.
- onhooksignaling**
onhook signaling.
- alwaysoffhook**
call is established as soon as incoming call initiation is made.
- +
- This allows multiple settings. For example, **hookflash+onhooksignaling**.
- Default** **hookflash+onhooksignaling**
- Access** This parameter is read-write.
- Location** **subscriber-voice**

Products MALC, ZRG

hookflash-max-timer

Specifies the maximum timer that qualifies for a hookflash. Any loopopen more than this timer will be considered as a onhook.

Access This parameter is read-write.

Location voice-system

Products MALC

hookflash-min-timer

Specifies the minimum timer that qualifies for a hookflash. Any loopopen below this time will be ignored.

Access This parameter is read-write.

Location voice-system

Products MALC

huntgroup

Determines if this connection is part of a huntgroup.

Default false

Access This parameter is read-write.

Location subscriber-voice

Products MALC

hunt-group-index

The hunt group this subscriber is part of. Each subscriber can be part of 3 hunt groups.

Access This parameter is read-write.

Location subscriber-voice-ds1, subscriber-voice-pots

Products MALC

inter-arriv-jit-threshold

The inter-arrival jitter threshold in milliseconds per channel that is used as a trigger value to generate a trap when its value is passed. If the value is 0, the threshold monitoring is disabled for inter-arrival jitter.

Values 0 to 100ms, inclusive.
Default 80ms
Access This parameter is read-write.
Location voice-dsp-default-profile

jitter-buffer-size

The voice DSP jitter buffer size in milliseconds. It refers to the amount of memory usage that can store certain milliseconds of voice.

For the BAN and Sechtor 100A, changes to the jitter buffer take effect on the next call.

For the Z-Edge, changes to the jitter buffer require the CID or the VCL to be brought down and up again, or the system rebooted.

Values 1 to 160
 Note that changes to the jitter buffer are based on 5 ms frame sizes. For example:

- 1 to 5 = 5 ms
- 6 to 10 = 10 ms
- 11 to 15 = 15 ms
- 16 to 20 = 20 ms
- 21 to 25 = 25 ms
- 26 to 30 = 30 ms
-
- 146 to 150 = 150 ms
- 151 to 155 = 155 ms
- 156 to 160 = 160 ms

Default 10 (BAN, Sechtor 100A, Z-Edge)

Location voice-dsp-default-profile

jitter-buffer-type

The voice DSP channel jitter buffer defaults. The jitter buffer accommodates the cells/packets received, so that the inter-arrival jitter of the cells/packets received don't degrade the voice quality. Without a jitter buffer, some cells as inter-arrival jitter changes would be late, which would have the same effect as lost cells. The jitter buffer also reorders the out-of-order cells/packets received.

Values static
 A static jitter buffer does not allow the jitter buffer to grow and shrink in response to changes in jitter.

Default static
Access This parameter is read-write.
Location voice-dsp-default-profile

malicious-caller-uri

Incoming call from this URI will be rejected.

Access This parameter is read-create.
Location malicious-caller

pkts-lost-threshold

How many voice DSP channel packets are lost per minute threshold. A trap is generated when this value is exceeded. If this value is 0, threshold monitoring is disabled for lost packets.

Values 0 to 10000 packets per minute.
Default 600
Access This parameter is read-write.
Location voice-dsp-default-profile

redundancy-over-subscription-type

The voice DSP redundancy oversubscription method.

A resource is called active if it is in use and is called standby if it is in reserve in case the active resource fails. The standby resources in redundant configurations can be oversubscribed. The active resource is not used when standby resources are allocated, however, if the active resources are at maximum capacity, there will be no standby resources available to take over in case of failure.

Values **high**
 Implies infinite oversubscription.
low
 Implies 1:2 oversubscription.
medium
 Implies 1:4 oversubscription.
none
 Implies 1:1 (one to one) oversubscription. When a standby is allocated, the pool of available actives is depleted by one.
Default none
Access This parameter is read-write.
Location voice-dsp-default-profile

Products BAN

reject-enabled

Indicates whether the incoming call reject is enabled.

Default true

Access This is a read-create parameter.

Location malicious-caller

Products MALC

silence-suppression-type

Which silence suppression algorithm the voice DSP should use on a channel. Silence suppression stops voice packet generation during periods of silence.

The SID (silence descriptor) frame is generated at the start of a silence period, then periodically, and is used to characterize the power level of the background noise during the silence period on the encode side of the voice path. The SID frame is passed to the decode side through a packet encoding medium (AAL2 or RTP). The decode side then generates comfort noise at an equivalent power level dictated by the SID frame values.

Values **silSupOff**
Silence suppression is off.

silSupOnSidOn
An initial SID frame is sent and then transmission every 100 ms.

Default silSupOff

Access This parameter is read-write.

Location voice-dsp-default-profile

voice-aal2-cid

The ATM Adaption Layer 2 channel identifier (AAL2 CID) for the connection.

Location subscriber-voice

voice-aal2-line-group-id

The line group ID for this AAL2 connection.

Location subscriber-voice

voice-aal2-vci

The AAL2 VCI for this connection.

Location subscriber-voice

voice-aal2-vpi

The AAL2 VPI for this connection.

Location subscriber-voice

voice-access

Indicates whether the specified user has voice privileges.

Access This parameter is read-only.

Location user-profile

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

voice-connection-description

A text string describing this voice call entry.

A common use is to define the external or public phone number for this voice line as assigned by the class 5 switch.

Default none

Access This parameter is read-write.

Location subscriber-voice

Products MALC

voice-connection-type

This describes the connection type between the two voice endpoints. Where applicable the first endpoint refers to the line or premise side of the connection and the second endpoint refers to the central office side of the connection.

Voice connections are created with the **voice add** command.

Values **aal2togr303**

AAL2 VPI/VCI/CID to GR-303 interface group/CRV.

aal2tov52

AAL2 VPI/VCI/CID to V5.2 interface/user port.

voiptogr303

VOIP to GR-303. Requires the MALC Voice Gateway card.

elcpaal2tov52

Only supported on the Sechtor 100 and the BAN.

potstoaal2

POTS to ATM AAL2.

isdntoaal2

ISDN to ATM AAL2.

isdntov52

ISDN to V5.2 interface/user port

potstogr303

POTS to GR-303.

potstov5

POTS to V5.2.

voiptods1

VOIP to DS1.

siptogr303

SIP to GR-303. Requires the MALC Voice Gateway card.

voiptov52

VOIP to V5.2. Requires the MALC Voice Gateway card.

elcpaal2tov52

ELCP to V5.2. Requires the MALC Voice Gateway card.

isdntov52

ISDN to V5.2.

ebstogr303

Electronic business system (EBS) to GR-303.

voiptopots

VOIP to POTS.

isdnsigtovoip

ISDN PRI to VOIP. Supported on the Z-Edge 6200 only.

potstods1

POTS to DS1.

potstoclass5

POTS to a class 5 switch.

Location subscriber-voice

voice-ebs-line-group-id

The line group ID for the associated connection.

Default none

Access This parameter is read-write.

Location subscriber-voice-ebs

Products 6200

voice-endpoint1-addr-index

The index into the associated address table for this end point. EndPoint1 should describe the line or premise side of the connection where applicable.

- Default** none
- Access** This parameter is read-write.
- Location** subscriber-voice
- Products** MALC

voice-endpoint2-addr-index

The index into the associated address table for this end point. EndPoint2 should describe the central office side of the connection where applicable.

- Default** none
- Access** This parameter is read-write.
- Location** subscriber-voice
- Products** MALC

voice-ext-type

The external or public phone number for this voice line as assigned by the Class 5 switch. This value is not used by the system and is provided only for operator reference.

voice-GR303-ig-crv

The crv for the associated connection.

- Default** none
- Access** This parameter is read-write.
- Location** subscriber-voice-gr303
- Products** MALC

voice-GR303-ig-name

The IG name for the associated connection.

- Default** none
- Access** This parameter is read-write.
- Location** subscriber-voice-gr303
- Products** MALC

voice-pots-line-group-id

The line group ID for the associated connection.

Location subscriber-voice-pots

User

data-access

Indicates whether the specified user has data privileges.

Access This parameter is read-only.

Location user-profile

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

database-access

Indicates whether the specified user has database privileges.

Access This parameter is read-only.

Location user-profile

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

debug access

Indicates whether the specified user has debug privileges. This parameter is read-only.

Access This parameter is read-only.

Location user-profile

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

user-admin-access

Indicates whether the specified user has user-admin privileges that enable the user to create user accounts.

Access This parameter is read-only.

Location user-profile

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

user-id

Specifies the user ID for this user.

Access This parameter is read-only.

Location **user-profile**

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

user-name

Specifies the user name.

Access This parameter is read-only.

Location **user-profile**

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

user-pass

Specifies the password for this user.

Access This parameter is read-only.

Location **user-profile**

Notes Use the **changepass** or **resetpass** commands to change user account passwords.

user-prompt

Specifies the user-prompt for this user.

Access This parameter is read-only.

Location **user-profile**

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

zhone-access

Indicates whether the specified user has Zhone privileges.

Access This parameter is read-only.

Location **user-profile**

Notes Use the **adduser** and **updateuser** commands to configure user accounts.

VOIP

destination-name

The name of the destination of the specified dial string.

Access This parameter is read-write.

Location `sip-dialplan`

dialplan-type

Indicates the type of dialplan used.

Values **normal**

Indicates normal dialing in use.

call park

Indicates dialing features such as call parking are used. Call parking places a call in a common holding or parking zone of the PBX so that any extension can retrieve the parked call.

Access This parameter is read-write.

Location `sip-dialplan`

directory-number

The directory number (phone number) assigned to this endpoint. Contains only digits.

Access This parameter is read-write.

Location `subscriber-voice-voip`

expires-invite-value

For user agent clients, this value in seconds is inserted into the Expires header. For proxy servers, if a received request contained an Expires header, then the value in the header takes precedence.

Access This parameter is read-write.

Location `sip-expires-timer-cfg`

expires-register-value

For user agent clients, this value in seconds is inserted into the Expires header. For proxy servers, if a received request contained an Expires header, then the value in the header takes precedence.

Access This parameter is read-write.

Location sip-expires-timer-cfg

expires-register-method

This convention is a bit map. Each bit represents a SIP method where the Expires header should be included. If a bit has value 1, then the requests corresponding to that SIP method must include an Expires header line. If a bit has value 0, then the Expires header line will not be added. Combinations of bits can be set when the Expires header line is required in multiple SIP methods.

Values **bit 0**
INVITE method

bit 1
REGISTER method

Access This parameter is read-write.

Location sip-expires-timer-cfg

frames-per-packet

Indicates the number of voice frames per IP packet.

Default 4

Access This parameter is read-write.

Location subscriber-voice-voip

g711-fallback

Indicates whether a subscriber may consume bandwidth by switching to g711, when a fax, modem, b-channel data session is detected.

Default true

Access This parameter is read-write.

Location subscriber-voice-voip

Products MALC

g726-byte-order

Indicates the byte order to be used when g.726 voice coding is in use. Cisco uses little endian byte order, whereas the g.726 standard calls for big endian byte order.

Default bigEndian

Access This parameter is read-write.

Location subscriber-voice-voip

Products MALC

interdigit-timeout

Indicates the duration, in seconds, that the device will wait after each digit is entered before assuming the user has finished entering digits.

Default 10

Access This parameter is read-write.

Location voip-system

Products MALC

ip-interface-index

Interface Index of the LP Interface through which the SIP signalling and RTP traffic flow.

Access This parameter is read-write.

Location subscriber-voice-voip

ip-tos

The type of service (TOS) value that is set in the IP header for voice over IP traffic.

Default 0

Location voip-system

Products MALC

keep-alive-timer

Specifies a timeout value in seconds for sending a keep alive message to MGCP servers.

Values 0 to 65535 seconds
0 disables the timer.

Default 60 seconds

Location voice-system

- Notes**
- This parameter should be set to the same value as the MGCP server's Audit Endpoint (AUEP) interval.
 - This parameter is only supported for Tekelec 6000 VoIP Application Server.

Products MALC

match-string

A dialstring against which collected digits are matched.

Access This parameter is read-write.

Location sip-dialplan

number-of-digits

The number of digits to wait for before initiating the call.

Access This parameter is read-write.

Location sip-dialplan

preferred-codec

Defines the preferred voice codec to be used for this subscriber.

Values g711a

g711mu

g723

g726

g729a

Default g711mu

Location subscriber-voice-voip

Products MALC

prefix-add

Specifies the string that is added to the beginning of the dialed digits before the call is initiated.

Access This parameter is read-write.

Location sip-dialplan

Products MALC

prefix-strip

Specifies the number of prefix digits to strip from the dialed digits.

Access This parameter is read-write.

Location sip-dialplan

Products MALC

protocol

The signalling protocol used for VOIP. Choices are SIP (Session Initiation Protocol) and MGCP (Media Gateway Control Protocol).

Default SIP

Access This parameter is read-write.

Location voip-system

Products MALC

rtcp-enabled

Indicates whether the Real-Time Control Protocol is enabled for the device.

Default false

Access This is a read-write parameter.

Location voip-system

Products MALC

rtcp-packet-interval

RTCP packet interval, in milliseconds. Range is 2500 to 10000 ms.

This object's value is only pertinent if RTCP has been enabled.

Default 5000

Access This parameter is read-write.

Location voip-system

Products MALC

send-call-proceeding-tone

Indicates whether, on call originations destined to the PSTN, the device should play a call proceeding tone while waiting for ring-back tone from the switch.

Default false

Access This parameter is read-write.

Location voip-system

Products MALC

server-max-timer

Specifies the period between RSIP retry messages. For redundant MGCP servers, this the interval between RSIP messages to each server.

Values 0 to 65535 seconds
0 disables the timer.

Default 20 seconds

Location voice-system

sip-ip-address

When a match is detected between the collected digits and the dial string in this SIP dialplan, this IP address is used for SIP negotiations to initiate the call.

Access This parameter is read-write.

Location sip-dialplan

Products MALC

system-domain-name

The Universal Resource Identifier (URI) of the system.

Default none

Access This parameter is read-write.

Location voip-system

Products MALC

voip-password

Authentication string needed for call originations through a SIP/MGCP Server.

Access This parameter is read-write.

Location subscriber-voice-voip

Products MALC

voip-plar

The subscriber PLAR (private line automatic ringdown) subscriber. If true we immediately send a INVITE instead of play dial tone.

Default false

Access This parameter is read-write.

Location subscriber-voice-voip

Notes This parameter applies to only SIP signaling.

Products MALC

voip-plar-dest-ipaddr

The destination IP address or domain name of the device to send INVITE to in case the subscriber is PLAR (private line automatic ringdown).

Access This parameter is read-write.

Location subscriber-voice-voip

Notes This parameter applies to only SIP signaling. To use this setting, the voip-plar parameter must be set to true.

Products MALC

voip-plar-dest-ipaddrtype

The type of address contained in the associated instance of VoipPlarDestIpAddr.

Default ipv4

Access This parameter is read-write.

Location subscriber-voice-voip

Products MALC

voip-server-entry-index

Specified in the SIP dialplan and when the viop-server-entry index is created, this number is used to associate dialplans and VOIP registration servers.

Access This parameter is read-write.

Location sip-dialplan

voip-udp-port

Specifies the UDP Port number for the VOIP Setup messages. 5060 is the IANA Registered SIP port.

Default 5060

Access This parameter is read-write.

Location subscriber-voice-voip

Products MALC

voip-username

A unique string that identifies the VOIP user in the system.

- Default** none
- Access** This parameter is read-write.
- Location** subscriber-voice-voip
- Products** MALC

zhoneVoipServerAddr

The address of a VOIP server this user agent will use to proxy/redirect calls.

- Default** none
- Access** This parameter is read-write.
- Location** voip-system
- Products** MALC

zhoneVoipServerAddrType

The type of address

- Default** ipv4
- Access** This parameter is read-write.
- Location** voip-system
- Products** MALC

zhoneVoipServerUdpPortNumber

Specifies the UDP Port number for the MGCP Gateway. 2427 is the IANA Registered MGCP Gateway port.

- Default** 2427
- Access** This parameter is read-write.
- Location** voip-system
- Products** MALC

ZMS

ackedseqno

Acknowledged trap sequence number. This field is set by the ZMS in order to acknowledge a trap sent by the device. There will be only one trap outstanding on the acknowledged flow at one time so this is the last sequence number sent. If not, it is ignored.

Location trap-destination

resendseqno

This is set by the ZMS in order to have the device resend saved traps because one or more were lost in transmission. The device will resend traps starting at this sequence number.

This is used only on the unacknowledged trap flow. This is the only indication of whether any traps have been acknowledged.

Location trap-destination

Notes Due to resource constraints not all traps may be available to be resent. The first trap that the device resends indicates whether or not any traps were deleted or lost.

zmsconnectionstatus

The status of the connection between this device and the Zhone Management System, if one exists. This value can either be set directly by ZMS or by the device internally when a SNMP request is processed from the ZMS. Devices not being proxied by another entity, since they are not being polled by ZMS, will set this state according to the communication channel state between this device and the connected entity.

Values active
inactive

Default inactive

Location system

zmsexists

Indicates whether or not this device is being managed by the Zhone Management System. This is can be set only by the ZMS.

Management operations depend on this setting. For example, if this device is not managed by ZMS, no configuration synchronization processing is performed on behalf of the device.

Values **true**
The device is managed by the ZMS.

false
The device is not managed by the ZMS.

Default **no**

Location **system**

zmsipaddress

The ZMS IP address for which configuration synchronization messages and any other special handling is performed. This can be set either via CLI or ZMS.

Location **system**

INDEX

Numerics

1st command 126

A

about this guide

acronyms 8

cautions 7

contacting GSS 9

intended audience 7

notes 7

ordering additional documents 9

related documents 9

style and notation conventions 7

tips 7

typographical conventions 7

warnings 7

acronyms, description of 8

adduser command 27

ADSL parameters 217

alarm command 28

alphaValue parameter 325

arpdelete command 116

arpflush command 116

arpshow command 117

ata command 28

ATM

SCR and PCR, configuring allowable values for 244

specifying VPI for auto-created profiles 208

UBR and usage-parameter-control 244

ATM parameters 229

atmping command 29

atmvclshow command 30

audience, intended 7

B

basic control commands, description of 24

betaValue parameter 325

bootstate command 33

bridge command 34

bridge-path command 43

bridging parameters 247

C

card command 45, 46, 47, 48

card parameters 251

card type, displaying 76

cautions, description of 7

ccshow command 49

cd command 53

CES parameters 259

changepass command 53

CLEI codes, displaying 76

CLI

abbreviated input 19

ADSL parameters 217

ATM parameters 229

bridging parameters 247

card parameters 251

CES parameters 259

clocking parameters 262

command completion 22

command shortcuts 21

commands 27

complete input 19

control commands 21

delete command 26

DHCP parameters 264

DNS parameters 277

DS1 parameters 280

DS3 parameters 287

DSL parameters 293

ELCP parameters 299

Ethernet parameters 302

finding a command 17

FXS/FXO parameters 307

GR303 parameters 313

help with commands 16

If-index parameters 321

ifTypes 21

IMA parameters 322

insert and change commands 25

introduction 11

IP parameters 327

- ISDN parameters 335
- logging in 12
- logical indexes 13
- modifying records 18
- movement and search commands 24
- MTAC parameters 337
- network time protocol parameters 338
- overview 13
- parameters 217
- physical addresses 13
- PON parameters 341
- PPPoA parameters 342
- profile addresses and indexes 15
- profiles and records 22
- put and undo commands 26
- record addresses and indexes 13
- RIP parameters 355
- RS232 parameters 359
- saving changes 19
- Sector 100A environmental parameters 367
- SHDSL parameters 362
- SNMP parameters 368
- SONET parameters 370
- subscriber parameters 376
- system indexes 13
- system parameters 378
- terminology 11
- user parameters 404
- V5.2 parameters 381
- VDSL parameters 394
- voice parameters 395
- ZMS parameters 414
- clkmgrshow command 54
- clocking
 - eligible and non-eligible sources 54
 - viewing system 54
- clocking parameters 262
- command shortcuts
 - basic control 24
 - delete command 26
 - insert and change commands 25
 - movement and search commands 24
 - put and undo commands 26
- commands
 - 1st 126
 - adduser 27
 - alarm 28
 - arpdelete 116
 - arpflush 116
 - arpshow 117
 - ata 28
 - atmping 29
 - atmvclshow 30
 - basic control 24
 - bootstate 33
 - bridge 34
 - bridge-path 43
 - card change 45, 46, 47, 48
 - ccshow 49
 - cd 53
 - changePASS 53
 - clkmgrshow 54
 - command completion 22
 - commit 53, 54
 - control commands 21
 - copy 56
 - create 56
 - crossconnect 56
 - datastorestats 62
 - del 62
 - delete 14, 18, 21, 26, 63
 - deleteuser 64
 - description 27
 - dir 66
 - ds1relay 67
 - ds1rps show 67, 69
 - dslstat 70
 - dump 74
 - easet 75
 - eeshow 66, 76
 - featurebitdisplay 77
 - featurebitset 78
 - fhrameping 78
 - file 79
 - filter 80
 - find 17, 82
 - find-matching-data 84
 - find-matching-subvoice 84
 - get 14, 91
 - gr303showcrv 94
 - help 95
 - help with 16
 - history 96
 - host 96
 - icmpstat 111, 114
 - ifstat 111
 - ifsum 112
 - ifxlate 100
 - image 101
 - imalink 102

- imarpshow 104
- imatppshow 106
- inetstat 112
- initiateconfigsync 55, 107
- insert and change 25
- interface 107
- ip 111, 112, 113, 114, 115, 116, 117
- ipstat 113
- linegroup 117
- list 27, 119
- load 121
- log 122
- logout 126
- mcast 127
- mkdir 128
- movement and search 24
- msg 128
- mtac-linetest 128
- new 18, 130
- ping 131
- pollzhonecpe 133
- powermon 133
- profiles and records 22
- put and undo 26
- pwd 134
- resetcliprov 134
- resetpass 135
- restore 134, 136
- rip 136
- rmdir 138
- romversion 139
- route 139
- sar8260 145
- set 153
- set2default 153, 159
- setcliprov 154
- setdatetime 154
- setline 155
- setprompt 155
- shelfctrl 156
- shelfreboot 159
- shortcuts 21
- show 159
- showactivecards 160
- showdatetime 160
- showhostname 161
- showinetstat 161
- showline 162
- showlinestatus 163
- showmem 165
- showredundancy 166
- showresolver 167
- showsonetrp 168
- showuser 169
- showzhonecpe 169
- slotreboot 170
- slots 171
- snmp 173
- sonetstatssh 175
- sonetstatusssh 177
- stack 177
- su 179
- swact 179
- swupgrade 179
- swversion 179
- syslog 180
- systemreboot 183
- systemrps 184
- telnet 184
- thermoshow 184
- timeout 185
- traceroute 185
- udpstat 115
- update 18, 20, 187
- updateuser 188
- upgrade 188
- verbose-restore-off 190
- verbose-restore-on 190
- voice 191, 202, 203, 204
- voicestat 205
- who 207
- whoami 207
- commit command 53, 54
- Config sync, initiating 55, 107
- configuration
 - specifying VPI for auto-created profiles 208
- conventions
 - style and notation 7
 - typographical 7
- copy command 56
- create command 56
- creating ip-interface profile, example of 18
- crossconnect command 56

D

- datastorestats command 62
- del command 62
- delete command 14, 18, 21, 26, 63

- deleteuser command 64
- DHCP parameters 264
- diagnostics
 - type of tests to run 149
- diffDelayMax parameter 324
- dir command 66
- DNS parameters 277
- documents, ordering additional 9
- documents, related 9
- DS1 parameters 280
- ds1relay command 67
- ds1rpshow command 67, 69
- DS3 parameters 287
- DSL parameters 293
- dslstat command 70
- dump command 74

E

- easet command 75
- eeshow command 66, 76
- ELCP parameters 299
- Ethernet parameters 302

F

- featurebitdisplay command 77
- featurebitset command 78
- fhrameping command 78
- file command 79
- filter command 80
- find command 17, 82
- finding a command 17
- find-matching-data command 84
- find-matching-subvoice command 84
- FXS/FXO parameters 307

G

- gammaValue parameter 325
- get command 14, 91
- Global Service and Support, See GSS
- GR303 parameters 313
- gr303showcrv command 94
- groupSymmetry parameter 322
- GSS, contacting 9

H

- help command 95
- help with commands
 - description 16
 - finding a command 17
 - help command 16
- history command 96
- host command 96

I

- icmpstat command 111, 114
- ifindex parameter 337
- If-index parameters 321
- ifstat command 111
- ifsum command 112
- ifTypes, list of 21
- ifxlate command 100
- IMA
 - alphaValue 325
 - betaValue 325
 - diffDelayMax 324
 - displaying group status 104
 - displaying test pattern procedure status 106
 - gammaValue 325
 - groupSymmetry 322
 - imaGroupDiffDelayMaxObs 324
 - imaGroupFeTxClkMode 323
 - imaGroupLeastDelayLink 324
 - imaGroupRxFrameLength 324
 - imaGroupTxTimingRefLink 323
 - minNumRxLinks 323
 - minNumTxLinks 322
 - parameters 322
 - testLinkIfindex 325
 - txClkMode 323
- image command 101
- imaGroupDiffDelayMaxObs 324
- imaGroupFeTxTimingRefLink parameter 323
- imaGroupLeastDelayLink parameter 324
- imaGroupRxFrameLength parameter 324
- imalink command 102
- imarps show command 104
- imatppshow command 106
- inetstat command 112
- initiateconfigsync command 55, 107
- insert and change commands 25
- interface command 107

introduction to CLI 11
Inverse Multiplexing over ATM, See IMA
IP
 statistics 161
ip commands 111, 112, 113, 114, 115, 116, 117
IP parameters 327
ip-interface profile, creation 18
ip-interface-record, updating 20
ipstat command 113
ISDN parameters 335

L

line group
 displaying 117
linegroup command 117
list command 119
load command 121
log command 122
logging
 enabling/disabling for session 122, 180
 enabling/disabling over the serial craft port
 122, 180
logging into CLI 12
logical indexes, description of 13
logout command 126

M

mcast command 127
minNumRxLinks parameter 323
minNumTxLinks parameter 322
mkdir command 128
modifying records
 delete command 18, 21
 new command 18
 update command 18, 20
movement and search commands 24
msg command 128
MTAC card
 ifindex 337
 parameters 337
 test_mode 337
mtac-linetest command 128

N

network time protocol parameters 338
new command 18, 130

notes, description of 7

O

overview of the CLI 13

P

parameters
 ADSL 217
 alphabetical list 217
 alphaValue 325
 ATM 229
 betaValue 325
 bridging 247
 card 251
 CES 259
 clocking 262
 DHCP 264
 diffDelayMax 324
 displaying valid values 19
 DNS 277
 DS1 280
 DS3 287
 DSL 293
 ELCP 299
 Ethernet 302
 FXS/FXO 307
 gammaValue 325
 GR303 313
 If-index 321
 IMA 322
 imaGroupDiffDelayMaxObs 324
 imaGroupLeastDelayLink 324
 imaGroupRxFrameLength 324
 IP 327
 ISDN 335
 MTAC card 337
 network time protocol 338
 PON 341
 PPPoA 342
 RIP 355
 RS232 359
 Sector 100A environmental 367
 SHDSL 362
 SNMP 368
 SONET 370
 subscriber 376
 system 378

- testLinkIfindex 325
 - user 404
 - V5.2 381
 - VDSL 394
 - voice 395
 - ZMS 414
 - physical addresses, description of 13
 - ping command 131
 - pollzhonecpe command 133
 - PON parameters 341
 - powermon command 133
 - PPPoA parameters 342
 - profile addresses and indexes 15
 - profiles and records
 - addresses and indexes 15
 - commands 22
 - delete command 14, 21
 - get command 14
 - modifying 18
 - update command 20
 - viewing 16
 - put and undo commands 26
 - pwd command 134
- ## R
- record addresses and indexes
 - logical indexes 13
 - physical indexes 13
 - system indexes 13
 - types of records 13
 - records, modifying 18
 - resetcliprov command 134
 - resetpass command 135
 - restore command 134, 136
 - rip command 136
 - RIP parameters 355
 - rmdir command 138
 - romversion command 139
 - route command 139
 - RS232 parameters 359
- ## S
- sar8260 command 145
 - Sechtor 100A environmental parameters 367
 - serial number, displaying 76
 - set command 153
 - set2default command 153, 159
 - setcliprov command 154
 - setdatetime command 154
 - setline command 155
 - setprompt command 155
 - SHDSL parameters 362
 - shelfctrl command 156
 - shelfreboot command 159
 - show command 159
 - showactivecards command 160
 - showdatetime command 160
 - showhostname command 161
 - showinetstat command 161
 - showline command 162
 - showlinestatus command 163
 - showmem command 165
 - showredundancy command 166
 - showresolver command 167
 - showsonetrp command 168
 - showuser command 169
 - showzhonecpe command 169
 - slotreboot command 170
 - slots command 171
 - snmp command 173
 - SNMP parameters 368
 - SONET parameters 370
 - sonetstatssh command 175
 - sonetstatusshow command 177
 - stack command 177
 - statistics
 - displaying IP 161
 - su command 179
 - subscriber parameters 376
 - swact command 179
 - swupgrade command 179
 - swversion command 179
 - syslog command 180
 - system
 - displaying temperature 156
 - system indexes, description of 13
 - system parameters 378
 - systemreboot command 183
 - systemrpshow command 184
- ## T
- telnet command 184
 - temperature, displaying 156
 - terminology used in document 11
 - test_mode parameter 337

- testLinkIfindex parameter 325
- thermoshow command 184
- timeout command 185
- tips, description of 7
- traceroute command 185
- txClkMode parameter 323

U

- UBR
 - modem train rates and 244
- udpstat command 115
- update command 18, 20, 187
- updateuser command 188
- updating ip-interface-record, example of 20
- upgrade command 188
- user parameters 404
- users
 - updating accounts 188

V

- V5.2 parameters 381
- values
 - displaying valid 19
- VDSL parameters 394
- verbose-restore-off command 190
- verbose-restore-on command 190
- viewing profiles and records 16
- voice command 191, 202, 203, 204
- voice parameters 395
- voicestat command 205

W

- warnings, description of 7
- who command 207
- whoami command 207

Z

- ZMS
 - synchronizing with device 55, 107
- ZMS parameters 414